

---

**Nortel Communication Server 1000**

Nortel Communication Server 1000 Release 4.5

---

# **Communication Server 1000M and Meridian 1**

## **Large System Upgrade Procedures (Book 3 of 3)**

Document Number: 553-3021-258

Document Release: Standard 6.00

Date: July 2006

---

Copyright © 2006 Nortel Networks. All rights reserved.  
Produced in Canada

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

Nortel, Nortel (Logo), the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks.

---



## Revision history

---

### July 2006

Standard 6.00. This document is up-issued with corrections from CR Q001354732.

### May 2006

Standard 5.00. This document is up-issued with corrections from CRs Q01215486 and Q01347637.

### January 2006

Standard 4.00. This document is up-issued with corrections from CR Q01231173.

### August 2005

Standard 3.00. This document is up-issued to support CP PIV and Communication Server 1000 Release 4.5.

### September 2004

Standard 2.00. This document is up-issued for Communication Server 1000 Release 4.0.

### October 2003

Standard 1.00. This document is a new NTP for Succession 3.0. It was created to support a restructuring of the Documentation Library. This document contains information previously contained in the following legacy document, now retired: *Upgraded Systems Installation: Upgrade to Options 51C, 61C, 81C* (553-3001-258).



---

# Contents

---

<b>List of Procedures .....</b>	<b>11</b>
<b>Finding the latest updates on the Nortel web site .....</b>	<b>37</b>
<b>How to get help .....</b>	<b>39</b>
<b>About this document .....</b>	<b>41</b>
Subject .....	41
Applicable systems .....	42
Intended audience .....	43
Conventions .....	43
NTP feedback .....	44
Related information .....	44
<b>Using the Keycode Retrieval Utility .....</b>	<b>47</b>
Contents .....	47
Introduction .....	47
Register for the KRS web site .....	47
Access the KRS web site .....	48
<b>Replace NT4N46 CP PII Core/Net with NT4N40 ..</b>	<b>55</b>
Contents .....	55
Prepare for upgrade .....	56
Equipment requirements .....	71

Check personnel requirements . . . . .	73
Install Core 1 hardware . . . . .	73
Disable and remove equipment from Core 1 . . . . .	74
Cable Core 1 . . . . .	90
Power up Core 1 . . . . .	96
Complete the CP PII replacement . . . . .	102

## **Adding a Network Group (NT4N40) . . . . . 107**

Contents . . . . .	107
Add a Core Network Group to Option 81C CP PII with FNF . . . . .	108
Prepare for upgrade . . . . .	110
Perform the upgrade . . . . .	120
Add an NT8D35 Network Group to Option 81C CP PII with FNF . . . . .	153
Prepare for upgrade . . . . .	155
Perform the upgrade . . . . .	166
Add a Core Network Group to Option 81C/IGS CP PII . . . . .	200
Prepare for upgrade . . . . .	200
Perform the upgrade . . . . .	210
Add an NT8D35 Network Group to Option 81C/IGS CP PII . . . . .	234
Prepare for upgrade . . . . .	234
Perform the upgrade . . . . .	244
Post-conversion procedure . . . . .	270

## **Adding a Network Group (NT4N46) . . . . . 279**

Contents . . . . .	279
Add a Core Network Group to Option 81C/FNF CP PII . . . . .	280
Prepare for upgrade . . . . .	283
Perform the upgrade . . . . .	293
Add an NT8D35 Network Group to Option 81C/FNF CP PII . . . . .	328
Prepare for upgrade . . . . .	329

---

Perform the upgrade . . . . .	339
Add a Core Network Group to Option 81C/IGS CP PII . . . . .	375
Prepare for upgrade . . . . .	375
Perform the upgrade . . . . .	385
Add an NT8D35 Network Group to Option 81C/IGS CP PII . . . . .	413
Prepare for upgrade . . . . .	413
Perform the upgrade . . . . .	421
Post-conversion procedure . . . . .	451
 <b>Adding an NT8D35 Network Group to Option 81 (NT5D60) . . . . .</b>	 <b>461</b>
Contents . . . . .	461
Add an NT8D35 Network Group to Option 81 with FNF . . . . .	462
Prepare for upgrade . . . . .	463
Perform the upgrade . . . . .	473
Add an NT8D35 Network Group to Option 81/IGS . . . . .	510
Prepare for upgrade . . . . .	510
Perform the upgrade . . . . .	519
Post-conversion procedure . . . . .	549
 <b>Adding a Network Group to Option 81C CP3, CP4 (NT5D21) . . . . .</b>	 <b>559</b>
Contents . . . . .	559
Add a Core Network Group to Option 81C CP3, CP4 with FNF . . . . .	560
Prepare for upgrade . . . . .	561
Perform the upgrade . . . . .	570
Add an NT8D35 Network Group to Option 81C CP3, CP4 with FNF . . . . .	604

Prepare for upgrade .....	605
Perform the upgrade .....	614
Add a Core Network Group to Option 81C/IGS CP3, CP4 .....	652
Prepare for upgrade .....	652
Perform the upgrade .....	661
Add an NT8D35 Network Group to Option 81C/IGS CP3, CP4 .....	687
Prepare for upgrade .....	687
Perform the upgrade .....	696
Post-conversion procedure .....	723

## **Installing IODU/C cards, CP cards, CP memory ..... 733**

Contents .....	733
Installing memory on Meridian 1 Options 61C CP PII, 81C CP PII .....	734
Installing memory on Meridian 1 Option 51C .....	805
Installing memory on Meridian 1 Options 61C, 81, 81C .....	839
Installing a Call Processor card on Options 61C CP PII, 81C CP PII .....	900
Installing an IODU/C on Meridian 1 Options 61C, 81, 81C .....	958
Installing a Call Processor card on Option 51C .....	1004
Installing IODU/C on Meridian 1 Option 51C .....	1021
Installing a Call Processor on Options 61C, 81, 81C .....	1051
Upgrade to an NTRB53 Clock Controller .....	1098
Upgrades on the web .....	1103

## **Using the Distributor Keycode Application ..... 1105**

Contents .....	1105
Introduction .....	1105
Hardware and Software Requirements .....	1106



---

Install DKA .....	1106
Adding the KDS network client in Dial-up Networking .....	1112
Downloading from KDS .....	1116
Reading from a File .....	1123
Manually enter a keycode .....	1124
<b>Terminal and modem connections .....</b>	<b>1127</b>
Contents .....	1127
Introduction .....	1127
Existing modems on upgraded systems .....	1142
Available modem for an upgraded system .....	1142
<b>Troubleshooting the upgrade .....</b>	<b>1155</b>
Contents .....	1155
Introduction .....	1155
Troubleshooting procedures .....	1155
<b>Appendix A: Upgrade checklists .....</b>	<b>1159</b>
Contents .....	1159
Introduction .....	1159
Site details .....	1160
Upgrade details .....	1160
Pre-upgrade checklists .....	1161
Pre-conversion steps .....	1164
Post-conversion checks .....	1166
Quick reference .....	1166
Software generic by machine type .....	1170
<b>Appendix B: Technical Assistance service ....</b>	<b>1171</b>
Contents .....	1171
Nortel Technical Assistance Centers .....	1171
Services available .....	1174

Requesting assistance ..... 1177

**Appendix C: Software Installation Tool ..... 1179**

**Index ..... 1205**

---

# List of Procedures

---

Procedure 1	
Registering for the KRS web site .....	48
Procedure 2	
Accessing the Keycode Retrieval System .....	48
Procedure 3	
Connecting a terminal .....	59
Procedure 4	
Checking the Core ID switches .....	60
Procedure 5	
Performing a data dump .....	67
Procedure 6	
Performing an ABKO (save the database to floppies) .....	68
Procedure 7	
Converting to 2 MByte database media .....	69
Procedure 8	
Checking main Core card installation .....	73
Procedure 9	
Checking that Core 0 is active and split the cores .....	74
Procedure 10	
Software disabling cards in network slots of Core/Net 1 .....	77
Procedure 11	
Removing the system monitors from Core 1 .....	79
Procedure 12	
Removing Core 1 cables and card cage .....	80

Procedure 13	
Installing the CP PII card cage in Core 1 .....	84
Procedure 14	
Relocating Core and Network cards to CoreNet 1 .....	90
Procedure 15	
Installing intermodule cables .....	90
Procedure 16	
Preparing for power up .....	96
Procedure 17	
Powering up Core 1 .....	98
Procedure 18	
Software enabling cards in network slots of Core/Net 1 .....	99
Procedure 19	
Software enabling Ring 1 .....	101
Procedure 20	
Making the system redundant .....	102
Procedure 21	
Switching call processing .....	105
Procedure 22	
Connecting a terminal .....	113
Procedure 23	
Performing a data dump .....	119
Procedure 24	
Label and route the shelf 0 fiber-optic cables (ascending) .....	124
Procedure 25	
Label and route the shelf 1 fiber optic cables (descending) .....	126
Procedure 26	
Interconnecting the Core/Net modules .....	129
Procedure 27	
Adding CNI cards .....	131
Procedure 28	
Installing the QPC441F 3PE cards. ....	135

---

Procedure 29	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	137
Procedure 30	
Disabling and inserting the FIJI cards .....	137
Procedure 31	
Disabling and inserting the NT8D17 Conf/TDS cards .....	137
Procedure 32	
Installing new CNI cards if required .....	137
Procedure 33	
Splitting the Cores .....	139
Procedure 34	
Adding new group .....	140
Procedure 35	
Checking that Ring 0 is active in Core 0 .....	141
Procedure 36	
Testing Core/Net 1 .....	147
Procedure 37	
Testing Core/Net 0 .....	150
Procedure 38	
Connecting a terminal .....	158
Procedure 39	
Performing a data dump .....	164
Procedure 40	
Labeling and routing the shelf 0 fiber optic cables (ascending) ..	170
Procedure 41	
Labeling and routing the shelf 1 fiber optic cables (descending) .	172
Procedure 42	
Interconnecting the network modules .....	175
Procedure 43	
Adding CNI cards if necessary .....	177
Procedure 44	
Connecting the 3PE to CNI cables .....	178

Procedure 45	
Installing and enabling the QPC441 3PE cards .....	182
Procedure 46	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	184
Procedure 47	
Disabling and inserting the FIJI cards .....	184
Procedure 48	
Disabling and inserting the NT8D17 Conf/TDS cards .....	184
Procedure 49	
Checking that Core 0 is active .....	185
Procedure 50	
Checking that Clock Controller 0 is active .....	185
Procedure 51	
Adding the CNI cards or ports .....	186
Procedure 52	
Checking that Ring 0 is active in Core 0 .....	188
Procedure 53	
Testing Core/Net 1 .....	193
Procedure 54	
Switching call processing .....	196
Procedure 55	
Testing Core/Net 0 .....	196
Procedure 56	
Connecting a terminal .....	203
Procedure 57	
Performing a data dump .....	209
Procedure 58	
Connecting the 3PE to CNI cables .....	214
Procedure 59	
Installing and enable the QPC441 3PE cards .....	217
Procedure 60	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	219

---

Procedure 61	
Disabling and inserting the NT8D17 Conf/TDS cards .....	219
Procedure 62	
Checking that Core 0 is active .....	220
Procedure 63	
Checking that Clock Controller 0 is active .....	220
Procedure 64	
Adding the CNI cards or ports .....	221
Procedure 65	
Seating the remaining cards .....	223
Procedure 66	
Testing Core/Net 1 .....	228
Procedure 67	
Switching call processing .....	230
Procedure 68	
Testing Core/Net 0 .....	231
Procedure 69	
Connecting a terminal .....	237
Procedure 70	
Performing a data dump .....	243
Procedure 71	
Interconnecting the network modules .....	248
Procedure 72	
Connecting the 3PE to CNI cables .....	250
Procedure 73	
Installing and enabling the QPC441 3PE cards .....	254
Procedure 74	
Installing and enabling the Peripheral Signaling (Per Sig) cards ..	256
Procedure 75	
Disabling and inserting NT5D30 DIGS cards .....	256
Procedure 76	
Disabling and inserting the NT8D17 Conf/TDS cards .....	256

Procedure 77	
Checking that Core 0 is active .....	257
Procedure 78	
Checking that Clock Controller 0 is active .....	257
Procedure 79	
Adding the CNI cards or ports .....	258
Procedure 80	
Seating remaining cards .....	260
Procedure 81	
Testing Core/Net 1 .....	264
Procedure 82	
Switching call processing .....	266
Procedure 83	
Testing Core/Net 0 .....	267
Procedure 84	
Performing the post-conversion procedure .....	271
Procedure 85	
Connecting a terminal .....	286
Procedure 86	
Performing a data dump .....	292
Procedure 87	
Placing a Group other than Group 0 in the core .....	297
Procedure 88	
Labeling and routing the shelf 0 fiber-optic cables (ascending) ..	299
Procedure 89	
Labeling and routing the shelf 1 fiber-optic cables (descending) .	301
Procedure 90	
Interconnecting the network modules .....	304
Procedure 91	
Adding CNI cards .....	305
Procedure 92	
Connecting the 3PE to CNI cables .....	306



---

Procedure 93	
Installing and enable the QPC441 3PE cards .....	309
Procedure 94	
Installing and enable the Peripheral Signaling (Per Sig) cards ...	311
Procedure 95	
Disabling and inserting the FIJI cards .....	311
Procedure 96	
Disabling and inserting the Conf/TDS cards .....	311
Procedure 97	
Checking that Core 0 is active .....	312
Procedure 98	
Checking that Clock Controller 0 is active .....	313
Procedure 99	
Adding the CNI cards or ports .....	313
Procedure 100	
Checking that Ring 0 is active in Core 0 .....	316
Procedure 101	
Testing Core/Net 1 .....	321
Procedure 102	
Switching call processing .....	324
Procedure 103	
Testing Core/Net 0 .....	324
Procedure 104	
Connecting a terminal .....	332
Procedure 105	
Performing a data dump .....	338
Procedure 106	
Labeling and routing the shelf 0 fiber-optic cables (ascending) ..	344
Procedure 107	
Labeling and routing the shelf 1 fiber-optic cables (descending) .	347
Procedure 108	
Interconnecting the network modules .....	350

Procedure 109	
Adding CNI cards .....	352
Procedure 110	
Connecting the 3PE to CNI cables .....	353
Procedure 111	
Installing and enabling the 3PE cards .....	356
Procedure 112	
Installing and enabling the QPC43R Peripheral Signaling cards ..	358
Procedure 113	
Disabling and inserting the NTRB33AC FIJI cards .....	358
Procedure 114	
Disabling and inserting the NT8D17 Conf/TDS cards .....	358
Procedure 115	
Checking that Core 0 is active .....	359
Procedure 116	
Checking that Clock Controller 0 is active .....	360
Procedure 117	
Adding the CNI cards or ports .....	360
Procedure 118	
Checking that Ring 0 is active in Core 0 .....	363
Procedure 119	
Testing Core/Net 1 .....	368
Procedure 120	
Switching call processing .....	371
Procedure 121	
Testing Core/Net 0 .....	371
Procedure 122	
Connecting a terminal .....	379
Procedure 123	
Performing a data dump .....	384
Procedure 124	
Placing a Group other than Group 0 in the core .....	388

<b>Procedure 125</b>	
<b>Interconnecting the network modules .....</b>	<b>390</b>
<b>Procedure 126</b>	
<b>Adding CNI cards .....</b>	<b>391</b>
<b>Procedure 127</b>	
<b>Connecting the 3PE to CNI cables .....</b>	<b>392</b>
<b>Procedure 128</b>	
<b>Installing and enabling the 3PE cards .....</b>	<b>395</b>
<b>Procedure 129</b>	
<b>Installing and enabling the QPC43R Peripheral Signaling cards ..</b>	<b>397</b>
<b>Procedure 130</b>	
<b>Disabling and inserting the NT5D30 DIGS cards .....</b>	<b>397</b>
<b>Procedure 131</b>	
<b>Disabling and inserting the NT8D17 Conf/TDS cards .....</b>	<b>397</b>
<b>Procedure 132</b>	
<b>Checking that Core 0 is active .....</b>	<b>398</b>
<b>Procedure 133</b>	
<b>Checking that Clock Controller 0 is active .....</b>	<b>398</b>
<b>Procedure 134</b>	
<b>Adding the CNI cards or ports .....</b>	<b>399</b>
<b>Procedure 135</b>	
<b>Seating remaining cards .....</b>	<b>401</b>
<b>Procedure 136</b>	
<b>Testing Core/Net 1 .....</b>	<b>406</b>
<b>Procedure 137</b>	
<b>Switching call processing .....</b>	<b>409</b>
<b>Procedure 138</b>	
<b>Testing Core/Net 0 .....</b>	<b>409</b>
<b>Procedure 139</b>	
<b>Connecting a terminal .....</b>	<b>415</b>
<b>Procedure 140</b>	
<b>Performing a data dump .....</b>	<b>420</b>

Procedure 141	
Interconnecting the network modules .....	427
Procedure 142	
Adding CNI cards .....	429
Procedure 143	
Installing and enable the QPC441 3PE cards .....	430
Procedure 144	
Connecting the 3PE to CNI cables .....	432
Procedure 145	
Installing and enabling the QPC43R Peripheral Signaling cards ..	436
Procedure 146	
Disabling and inserting the Conf/TDS cards .....	437
Procedure 147	
Checking that Core 0 is active .....	437
Procedure 148	
Checking that Clock Controller 0 is active .....	438
Procedure 149	
Adding the CNI cards or ports .....	438
Procedure 150	
Seating remaining cards .....	440
Procedure 151	
Testing Core/Net 1 .....	444
Procedure 152	
Switching call processing .....	447
Procedure 153	
Testing Core/Net 0 .....	447
Procedure 154	
Performing the post-conversion procedure .....	452
Procedure 155	
Connecting a terminal .....	466
Procedure 156	
Performing a data dump .....	471

<b>Procedure 157</b>	
<b>Label and route the shelf 0 fiber-optic cables (ascending) . . . . .</b>	<b>477</b>
<b>Procedure 158</b>	
<b>Label and route the shelf 1 fiber-optic cables (descending) . . . . .</b>	<b>481</b>
<b>Procedure 159</b>	
<b>Interconnect the network modules . . . . .</b>	<b>484</b>
<b>Procedure 160</b>	
<b>Connecting the 3PE to CNI cables . . . . .</b>	<b>487</b>
<b>Procedure 161</b>	
<b>Installing and enable the QPC441 3PE cards . . . . .</b>	<b>491</b>
<b>Procedure 162</b>	
<b>Installing and enabling the Peripheral Signaling (Per Sig) cards .</b>	<b>493</b>
<b>Procedure 163</b>	
<b>Disabling and inserting the FIJI cards . . . . .</b>	<b>493</b>
<b>Procedure 164</b>	
<b>Disabling and inserting the Conf/TDS cards . . . . .</b>	<b>493</b>
<b>Procedure 165</b>	
<b>Checking that Core 0 is active . . . . .</b>	<b>494</b>
<b>Procedure 166</b>	
<b>Checking that Clock Controller 0 is active . . . . .</b>	<b>495</b>
<b>Procedure 167</b>	
<b>Place CP 1 into parallel mode . . . . .</b>	<b>495</b>
<b>Procedure 168</b>	
<b>Defining the XCT and extenders to the added group . . . . .</b>	<b>495</b>
<b>Procedure 169</b>	
<b>Checking that Ring 0 is active in Core 0 . . . . .</b>	<b>498</b>
<b>Procedure 170</b>	
<b>Testing Core/Net 1 . . . . .</b>	<b>503</b>
<b>Procedure 171</b>	
<b>Switching call processing . . . . .</b>	<b>506</b>
<b>Procedure 172</b>	
<b>Testing Core/Net 0 . . . . .</b>	<b>506</b>

Procedure 173	
Connecting a terminal .....	513
Procedure 174	
Performing a data dump .....	518
Procedure 175	
Interconnecting the network modules .....	523
Procedure 176	
Installing and enabling the QPC441 3PE cards .....	530
Procedure 177	
Installing and enabling the Peripheral Signaling (Per Sig) cards ..	532
Procedure 178	
Disabling and inserting DIGS cards .....	532
Procedure 179	
Disabling and inserting the Conf/TDS cards .....	533
Procedure 180	
Checking that Core 0 is active .....	534
Procedure 181	
Checking that Clock Controller 0 is active .....	535
Procedure 182	
Place CP 1 into parallel mode .....	535
Procedure 183	
Defining the XCT and extenders to the added group .....	535
Procedure 184	
Seating the remaining cards .....	537
Procedure 185	
Switching call processing to Core 1 .....	539
Procedure 186	
Testing Core/Net 1 .....	543
Procedure 187	
Switching call processing .....	546
Procedure 188	
Testing Core/Net 0 .....	546

---

Procedure 189	
Performing the post-conversion procedure .....	550
Procedure 190	
Connecting a terminal .....	564
Procedure 191	
Performing a data dump .....	569
Procedure 192	
Labeling and routing the shelf 0 fiber-optic cables (ascending) ..	576
Procedure 193	
Labeling and routing the shelf 1 fiber-optic cables (descending) .	579
Procedure 194	
Installing and enable the QPC441 3PE cards .....	583
Procedure 195	
Interconnecting the network modules .....	585
Procedure 196	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	586
Procedure 197	
Disabling and inserting the NTRB33AC/AD FIJI cards .....	587
Procedure 198	
Disabling and inserting the NT8D17 Conf/TDS cards .....	587
Procedure 199	
Checking that Core 0 is active .....	588
Procedure 200	
Checking that Clock Controller 0 is active .....	588
Procedure 201	
Place CP 1 into parallel mode .....	588
Procedure 202	
Defining the XCT and extenders to the added group .....	589
Procedure 203	
Checking that Ring 0 is active in Core 0 .....	592
Procedure 204	
Testing Core/Net 1 .....	597

Procedure 205	
Switching call processing .....	600
Procedure 206	
Testing Core/Net 0 .....	600
Procedure 207	
Connecting a terminal .....	608
Procedure 208	
Performing a data dump .....	613
Procedure 209	
Labeling and routing the shelf 0 fiber-optic cables (ascending) ..	620
Procedure 210	
Labeling and routing the shelf 1 fiber-optic cables (descending) .	623
Procedure 211	
Interconnecting the network modules .....	625
Procedure 212	
Connecting the 3PE to CNI cables .....	629
Procedure 213	
Installing and enable the QPC441 3PE cards .....	632
Procedure 214	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	635
Procedure 215	
Disabling and inserting the NTRB33AC FIJI cards .....	635
Procedure 216	
Disabling and inserting the NT8D17 Conf/TDS cards .....	635
Procedure 217	
Checking that Core 0 is active .....	636
Procedure 218	
Checking that Clock Controller 0 is active .....	637
Procedure 219	
Place CP 1 into parallel mode .....	637
Procedure 220	
Defining the XCT and extenders to the added group .....	637



<b>Procedure 221</b>	
Checking that Ring 0 is active in Core 0 .....	640
<b>Procedure 222</b>	
Testing Core/Net 1 .....	646
<b>Procedure 223</b>	
Switching call processing .....	648
<b>Procedure 224</b>	
Testing Core/Net 0 .....	649
<b>Procedure 225</b>	
Connecting a terminal .....	655
<b>Procedure 226</b>	
Performing a data dump .....	660
<b>Procedure 227</b>	
Interconnecting the network modules .....	665
<b>Procedure 228</b>	
Adding CNI cards .....	666
<b>Procedure 229</b>	
Installing and enable the QPC441 3PE cards. ....	667
<b>Procedure 230</b>	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	670
<b>Procedure 231</b>	
Disabling and inserting the NT8D17 Conf/TDS cards .....	670
<b>Procedure 232</b>	
Disabling and insert the NT5D30 DIGS cards .....	670
<b>Procedure 233</b>	
Checking that Core 0 is active .....	671
<b>Procedure 234</b>	
Checking that Clock Controller 0 is active .....	671
<b>Procedure 235</b>	
Placing CP 1 into parallel mode .....	672
<b>Procedure 236</b>	
Defining the XCT and extenders to the added group .....	672

Procedure 237	
Seating the remaining cards .....	675
Procedure 238	
Testing Core/Net 1 .....	680
Procedure 239	
Switching call processing .....	683
Procedure 240	
Testing Core/Net 0 .....	683
Procedure 241	
Connecting a terminal .....	690
Procedure 242	
Performing a data dump .....	695
Procedure 243	
Interconnecting the network modules .....	701
Procedure 244	
Adding an NTRB34 CNI cards .....	703
Procedure 245	
Connecting the 3PE to CNI cables .....	704
Procedure 246	
Installing and enable the QPC441 3PE cards. ....	706
Procedure 247	
Installing and enabling the Peripheral Signaling (Per Sig) cards .	706
Procedure 248	
Disabling and inserting the NT8D17 Conf/TDS cards .....	707
Procedure 249	
Disabling and inserting the NT5D30 DIGS cards .....	707
Procedure 250	
Checking that Core 0 is active .....	709
Procedure 251	
Checking that Clock Controller 0 is active .....	710
Procedure 252	
Place CP 1 into parallel mode .....	710

Procedure 253	
Defining the XCT and extenders to the added group .....	710
Procedure 254	
Seating the remaining cards .....	713
Procedure 255	
Switching call processing to Core 1 .....	714
Procedure 256	
Testing Core/Net 1 .....	717
Procedure 257	
Switching call processing .....	720
Procedure 258	
Testing Core/Net 0 .....	721
Procedure 259	
Performing the post-conversion procedure .....	724
Procedure 260	
Connecting a terminal .....	737
Procedure 261	
Performing a data dump .....	742
Procedure 262	
Performing an ABKO (save the database to floppies) .....	743
Procedure 263	
Converting to 2 MByte database media .....	744
Procedure 264	
Backing up the current data .....	746
Procedure 265	
Determining hardware status .....	748
Procedure 266	
Upgrade memory .....	749
Procedure 267	
Installing the software on Core/Net 1 .....	756
Procedure 268	
Transferring call processing from Core/Net 0 to Core/Net 1 .....	775

Procedure 269	
Testing call processing on Core/Net 1 .....	776
Procedure 270	
Upgrade memory .....	776
Procedure 271	
Installing the software and converting the database .....	783
Procedure 272	
Enabling system redundancy .....	801
Procedure 273	
Testing Core/Net 1 and Core/Net 0 .....	802
Procedure 274	
Performing a data dump .....	804
Procedure 275	
Connecting a terminal .....	808
Procedure 276	
Performing a data dump .....	813
Procedure 277	
Performing an ABKO (save the database to floppies) .....	814
Procedure 278	
Converting to 2 MByte database media .....	815
Procedure 279	
Performing a data dump on the Meridian 1 Option 51C .....	819
Procedure 280	
Determining the hardware status on the Meridian 1 Option 51C ..	821
Procedure 281	
Remove CP card from Core/Net 1 .....	821
Procedure 282	
Installing the DRAM SIMMs .....	822
Procedure 283	
Installing the Flash memory .....	825
Procedure 284	
Installing the software and converting the database .....	826

---

Procedure 285	
Completing the upgrade .....	838
Procedure 286	
Connecting a terminal .....	842
Procedure 287	
Performing a data dump .....	847
Procedure 288	
Performing an ABKO (save the database to floppies) .....	848
Procedure 289	
Converting to 2 MByte database media .....	849
Procedure 290	
Performing a data dump .....	850
Procedure 291	
Obtaining hardware status .....	851
Procedure 292	
Splitting the Core processors .....	853
Procedure 293	
Installing the DRAM SIMMs .....	856
Procedure 294	
Installing the Flash memory .....	860
Procedure 295	
Installing the system software on Core/Net 1 .....	861
Procedure 296	
Checking peripheral software versions .....	873
Procedure 297	
Switching call processing from Core/Net 0 to Core/Net 1 .....	874
Procedure 298	
Testing Core/Net 1 .....	875
Procedure 299	
Removing CP card from Core/Net 0 .....	876
Procedure 300	
Installing the DRAM SIMMs .....	878

Procedure 301	
Installing the Flash memory .....	882
Procedure 302	
Installing the software and converting the database .....	883
Procedure 303	
Exiting the split mode .....	894
Procedure 304	
Testing Core/Net 0 and Core/Net 1 .....	895
Procedure 305	
Switching the Clocks .....	896
Procedure 306	
Stat the rings .....	897
Procedure 307	
Synchronizing the hard disks .....	898
Procedure 308	
Performing a data dump .....	899
Procedure 309	
Connecting a terminal .....	903
Procedure 310	
Performing a data dump .....	908
Procedure 311	
Performing an ABKO (save the database to floppies) .....	909
Procedure 312	
Backing up the current data .....	912
Procedure 313	
Determining hardware status .....	914
Procedure 314	
Upgrading Core/Net 1 hardware .....	915
Procedure 315	
Installing the software on Core/Net 1 .....	915
Procedure 316	
Transferring call processing from Core/Net 0 to Core/Net 1 .....	935

Procedure 317	
Testing call processing on Core/Net 1 .....	935
Procedure 318	
Upgrading Core/Net 0 hardware .....	936
Procedure 319	
Installing the software and converting the database .....	936
Procedure 320	
Enabling system redundancy .....	954
Procedure 321	
Testing Core/Net 1 and Core/Net 0 .....	955
Procedure 322	
Performing a data dump .....	957
Procedure 323	
Connecting a terminal .....	961
Procedure 324	
Performing a data dump .....	966
Procedure 325	
Performing an ABKO (save the database to floppies) .....	967
Procedure 326	
Obtaining hardware status .....	970
Procedure 327	
Splitting the Core processors .....	971
Procedure 328	
Upgrading hardware .....	972
Procedure 329	
Installing the system software on Core/Net 1 .....	972
Procedure 330	
Checking peripheral software versions .....	984
Procedure 331	
Switching call processing from Core/Net 0 to Core/Net 1 .....	985
Procedure 332	
Testing Core/Net 1 .....	986

Procedure 333	
Upgrading Core/Net 0 hardware .....	986
Procedure 334	
Installing the software and converting the database .....	987
Procedure 335	
Exiting the split mode .....	998
Procedure 336	
Testing Core/Net 0 and Core/Net 1 .....	999
Procedure 337	
Switching the Clocks .....	1000
Procedure 338	
Stat the rings .....	1001
Procedure 339	
Synchronizing the hard disks .....	1002
Procedure 340	
Performing a data dump .....	1003
Procedure 341	
Connecting a terminal .....	1007
Procedure 342	
Performing a data dump .....	1012
Procedure 343	
Performing an ABKO (save the database to floppies) .....	1013
Procedure 344	
Converting to 2 MByte database media .....	1014
Procedure 345	
Installing the CP card and CS 1000 Release 4.5 software .....	1015
Procedure 346	
Completing the upgrade .....	1019
Procedure 347	
Connecting a terminal .....	1024
Procedure 348	
Performing a data dump .....	1029



---

Procedure 349	
Performing an ABKO (save the database to floppies) .....	1030
Procedure 350	
Determining the hardware status on the Meridian 1 Option 51C ..	1035
Procedure 351	
Using the Database Transfer Utility .....	1035
Procedure 352	
Upgrading Core/Net 1 hardware .....	1036
Procedure 353	
Installing the software and converting the database .....	1038
Procedure 354	
Completing the upgrade .....	1050
Procedure 355	
Connecting a terminal .....	1054
Procedure 356	
Performing a data dump .....	1060
Procedure 357	
Performing an ABKO (save the database to floppies) .....	1060
Procedure 358	
Obtaining hardware status .....	1064
Procedure 359	
Splitting the Core processors .....	1065
Procedure 360	
Upgrading Core/Net 1 hardware .....	1066
Procedure 361	
Installing the system software on Core/Net 1 .....	1066
Procedure 362	
Checking peripheral software versions .....	1079
Procedure 363	
Switching call processing from Core/Net 0 to Core/Net 1 .....	1080
Procedure 364	
Testing Core/Net 1 .....	1081

Procedure 365	
Upgrading Core/Net 0 hardware .....	1081
Procedure 366	
Installing the software and converting the database .....	1082
Procedure 367	
Exiting split mode .....	1093
Procedure 368	
Testing Core/Net 0 and Core/Net 1 .....	1094
Procedure 369	
Switching the Clocks .....	1095
Procedure 370	
Stat the rings .....	1096
Procedure 371	
Synchronizing the hard disks .....	1097
Procedure 372	
Performing a data dump .....	1098
Procedure 373	
Upgrading to an NTRB53 Clock Controller .....	1099
Procedure 374	
Installing new equipment .....	1100
Procedure 375	
Installing the DKA program .....	1107
Procedure 376	
Creating a shortcut .....	1111
Procedure 377	
Configuring Dial-up Networking .....	1112
Procedure 378	
Configuring the Type of Dial-Up Server .....	1115
Procedure 379	
Establishing the PPP connection to the KDS server via Dial-up Networking .....	1117
Procedure 380	
Reading from a File .....	1123

<b>Procedure 381</b>	
<b>Manually entering a keycode .....</b>	<b>1124</b>
<b>Procedure 382</b>	
<b>Configuring the system .....</b>	<b>1129</b>
<b>Procedure 383</b>	
<b>Connecting a terminal to a CPSI port .....</b>	<b>1136</b>
<b>Procedure 384</b>	
<b>Connecting a switch box and terminal to CPSI ports .....</b>	<b>1137</b>
<b>Procedure 385</b>	
<b>Connecting a switch box and terminal to the SDI and CPSI ports .</b>	<b>1138</b>
<b>Procedure 386</b>	
<b>Configuring the US Robotics 33.5 Data/Fax modem .....</b>	<b>1142</b>
<b>Procedure 387</b>	
<b>Installing the modem .....</b>	<b>1144</b>
<b>Procedure 388</b>	
<b>Configuring an A0381391 UDS FastTalk modem .....</b>	<b>1147</b>
<b>Procedure 389</b>	
<b>Connecting a modem to an SDI port .....</b>	<b>1149</b>
<b>Procedure 390</b>	
<b>Connecting a modem to a switch box and CPSI and SDI ports ...</b>	<b>1151</b>
<b>Procedure 391</b>	
<b>If the IOP/CMDU, IODU/C, or MMDU card fails the self-test .....</b>	<b>1155</b>
<b>Procedure 392</b>	
<b>If the CP/CP PII Card or card fails the self-test .....</b>	<b>1156</b>
<b>Procedure 393</b>	
<b>If “IOP Out of Service” appears on the Call Processor card LCD .</b>	<b>1156</b>
<b>Procedure 394</b>	
<b>If the system points to file corruption while loading software ....</b>	<b>1157</b>



---

## Finding the latest updates on the Nortel web site

---

The content of this documentation was current at the time the product was released. To check for updates to the latest documentation and software for CS 1000 Release 4.5, click one of the links below.

<a href="#">Latest Software</a>	Takes you directly to the Nortel page for CS 1000 Release 4.5 software.
<a href="#">Latest Documentation</a>	Takes you directly to the Nortel page for CS 1000 Release 4.5 documentation.



# How to get help

---

This section explains how to get help for Nortel products and services.

## Getting help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

[www.nortel.com/support](http://www.nortel.com/support)

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

## Getting help over the telephone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

[www.nortel.com/callus](http://www.nortel.com/callus)

## **Getting help from a specialist by using an Express Routing Code**

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

[www.nortel.com/erc](http://www.nortel.com/erc)

## **Getting help through a Nortel distributor or reseller**

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.



---

## About this document

---

This document is a global document. Contact your system supplier or your Nortel representative to verify that the hardware and software described is supported in your area.

### Subject

Use this document to perform upgrades on Meridian 1 Large Systems. This document also contains information on database transfers, Call Processor card upgrades, and network group upgrades.

This document also contains information on converting Release 19.0x or later software to CS 1000 Release 4.5 or later on Meridian 1 Options 51C, 61C, 81, 81C, CS 1000M SG and CS 1000M MG systems. For software conversion procedures prior to Release 19.xx, refer to the *Software conversion procedures* (553-2001-320) NTP for software Release 24.



#### IMPORTANT!

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT, and XT must be completed by Nortel's Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

#### Note on legacy products and releases

This NTP contains information about systems, components, and features that are compatible with Nortel Communication Server 1000 Release 4.5 software. For more information on legacy products and releases, click the **Technical Documentation** link under **Support** on the Nortel home page:

[www.nortel.com/](http://www.nortel.com/)

## Applicable systems

This document applies to the following systems:

- Communication Server 1000M Half Group (CS 1000M HG)
- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Meridian 1 PBX 51C
- Meridian 1 PBX 61C
- Meridian 1 PBX 81
- Meridian 1 PBX 81C

*Note:* When upgrading software, memory upgrades may be required on the Signaling Server, the Call Server, or both.

### System migration

When particular Meridian 1 systems are upgraded to run CS 1000 Release 4.5 software and configured to include a Signaling Server, they become CS 1000M systems. Table 1 lists each Meridian 1 system that supports an upgrade path to a CS 1000M system.

**Table 1**  
**Meridian 1 systems to CS 1000M systems**

This Meridian 1 system...	Maps to this CS 1000M system
Meridian 1 PBX 51C	CS 1000M Half Group
Meridian 1 PBX 61C	CS 1000M Single Group
Meridian 1 PBX 81	CS 1000M Multi Group
Meridian 1 PBX 81C	CS 1000M Multi Group

## Upgrade paths

This document contains information on the following Large System upgrades:

- Meridian 1 Options 51, 61, 71, 51C, 61C, 81C, CS 1000M SG, and CS 1000M MG
- upgrades to FNF
- software upgrades
- network additions

The upgrades documented in this NTP are structured as source platform to target platform upgrades.

## Intended audience

This document is intended for individuals responsible for upgrading Large Systems.

This document is intended for individuals responsible for software conversion and memory upgrades.

## Conventions

### Terminology

The following systems are referred to generically as “Large System”:

- Communication Server 1000M Half Group (CS 1000M HG)
- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Meridian 1 PBX 51C
- Meridian 1 PBX 61C
- Meridian 1 PBX 81
- Meridian 1 PBX 81C

## NTP feedback

Nortel strives to provide accurate documentation for our customers. However, if you feel there are errors or omissions in this document, your feedback is welcome.

Send comments via email to [gntsdoc@nortel.com](mailto:gntsdoc@nortel.com) or open a problem report via the normal procedures.

Please provide as much information as possible including the NTP number, standard version and date of the document, as well as the page, problem description, and any supporting documentation and capture files.

## Related information



### CAUTION — Data Loss

Only personnel who are familiar with the system and with conversion procedures should perform the conversion.

Read the applicable procedures carefully before beginning any the conversion.

**Note:** Converting software on single CPU systems disrupts call processing and allows service only to those telephones connected to Power Failure Transfer Units (PFTU).



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected antistatic wrist strap when working on system equipment.

Follow pre-conversion and post-conversion procedures for every system conversion.

Throughout this document the term *media* refers to tape, disk, CD-ROM or Compact Flash (CF), whichever applies to the system.

The term **source** refers to the hardware and software that is currently running. The term **target** refers to the new hardware and software to which the system is converting.

**CAUTION — Data Loss**

Read “General software conversion information” in Book 1 before performing any operations.

It contains information vital to the conversion process.

## NTPs

The following NTPs are referenced in this document:

- *Product Compatibility* (553-3001-156)
- *Converging the Data Network with VoIP* (553-3001-160)
- *Circuit Card: Description and Installation* (553-3001-211)
- *Signaling Server: Installation and Configuration* (553-3001-212)
- *IP Peer Networking: Installation and Configuration* (553-3001-213)
- *Features and Services* (553-3001-306)
- *Software Input/Output: Administration* (553-3001-311)
- *Element Manager: System Administration* (553-3001-332)
- *IP Trunk: Description, Installation, and Operation* (553-3001-363)
- *IP Line: Description, Installation, and Operation* (553-3001-365)
- *ISDN Basic Rate Interface: Features* (553-3001-380)
- *Software Input/Output: Maintenance* (553-3001-511)
- *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)
- *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210)
- *Communication Server 1000M and Meridian 1: Large System Maintenance* (553-3021-500)

- *Communication Server 1000S: Overview (553-3031-010)*
- *Communication Server 1000S: Installation and Configuration (553-3031-210)*
- *Communication Server 1000S: Upgrade Procedures (553-3031-258)*

## Online

To access Nortel documentation online, click the **Technical Documentation** link under **Support** on the Nortel home page:

[www.nortel.com](http://www.nortel.com)

## CD-ROM

To obtain Nortel documentation on CD-ROM, contact your Nortel customer representative.

## Technical support

For technical support contact information, see “Technical Assistance service” on [page 1171](#).

---

# Using the Keycode Retrieval Utility

---

## Contents

This section contains information on the following topics:

<a href="#">Introduction . . . . .</a>	<a href="#">47</a>
<a href="#">Register for the KRS web site . . . . .</a>	<a href="#">47</a>
<a href="#">Access the KRS web site . . . . .</a>	<a href="#">48</a>

## Introduction

The Keycode Retrieval Utility is a Nortel Customer Support service feature available to registered customers. The Keycode Retrieval Utility provides a full suite of online tools, services, resources and interactive capabilities.

The Keycode Retrieval Utility provides a tool for distributors to browse and retrieve keycodes. A distributor is considered to “own” a keycode once it has been manufactured and its associated order invoiced.

If you cannot access the Keycode Retrieval System (KRS) web site, you must register for access and wait approximately 5 business days for the account to be activated before accessing the “Downloading keycodes” procedure.

## Register for the KRS web site

If you cannot access the KRS web site, use the following procedure to register.

**Procedure 1**  
**Registering for the KRS web site**

- 1 Open your web browser software.
- 2 Enter the URL **www.nortel.com** in the Address or Net Site bar and press **Return** or **Enter**.
- 3 Under Support, click on the Keycode Retrieval link. You are now on the Keycode Retrieval page. See Figure 2 on [page 50](#).
- 4 Click on the Online Registration link, then follow the instructions provided.

---

**End of Procedure**

---

## **Access the KRS web site**


Follow the steps in this procedure only after completing the registration procedure above.

**Procedure 2**  
**Accessing the Keycode Retrieval System**


- 1 Open your web browser.
- 2 Enter the URL "**http://www.nortel.com**" in the Address or Net Site bar and press **Return** or **Enter**.
- 3 Under Support, click on the Keycode Retrieval link. See Figure 1 on [page 49](#). You are now on the Keycode Retrieval page. See Figure 2 on [page 50](#).
- 4 In Step 1, select a login location. See Figure 3 on [page 51](#).
- 5 In Step 2, select the product family for the keycode access.
- 6 Click **Go**. The Keycode Retrieval System window opens. See Figure 5 on [page 53](#).




**Figure 1**  
**Nortel home page.**




**Figure 2**  
**Keycode Retrieval page**



**Figure 3**  
**Login location selection(step 1)**



**Figure 4**  
**Product family selection (step 2)**



**Figure 5**  
**Keycode Retrieval System**

File Edit View Favorites Tools Help

Back Forward Stop Home Search Favorites Media Print Mail

Address [http://qtcf5Dnj.ca.nortel.com/nortelnetworks/eservice/eld/jsps/retrieve\\_keycode.jsp?WebLogicSession=QIVY](http://qtcf5Dnj.ca.nortel.com/nortelnetworks/eservice/eld/jsps/retrieve_keycode.jsp?WebLogicSession=QIVY) Go

Links [CCKOL Home Page](#) [Customize Links](#) [Desktop Technology & Management](#) [DT&M Dell Leasing Page](#) »

**NORTEL NETWORKS**  Go

Your Location: [Home](#) / [Customer Support](#) / [Keycode Retrieval](#) / [Meridian 1](#) / [Retrieve Keycode](#)

**Keycode Retrieval System**

• **Retrieve Keycode**

In this section you can search for and retrieve keycodes.

USER: Guest User TYPE: User

GROUP: All Customer Groups

**Step 1:** Query available sites by entering text, in any combination of the 3 query fields and then pressing the "Search" button. Matching sites will be displayed in the "Site List". Select one to view or download its keycode(s). Note that the site list will show only the first 50 sites that satisfy the query so you may need to further refine your query.

System ID/Product ID:

Nortel Order #:

Customer PO #:

**Customer Support** • [Register](#)

**Product Control** • [Retrieve Keycode](#) • [Retrieve History](#) • [Download KMT](#) • [Download SW Forms](#)

**Help** •

**Terms & Conditions** •

You can contact us at:

North America  
 1-800-4 NORTEL  
 1-800-466-7835

[International Contacts](#)

Done Internet

## Meridian 1 Keycode Retrieval System

Use the Keycode Retrieval System window to access the keycode application for the Meridian product line.

***Note:*** A registered user has access to all keycode applications for the various product lines displayed.

The following is a list of the Quick Links on the left of the Keycode Retrieval System window screen:

- **Retrieve by Site.** To specify a site ID and retrieve all keycodes for products associated with the entered site ID.
- **Retrieve by Product.** To view Site I.D.'s sorted by product type.
- **Retrieve by Date.** To retrieve all historic (previously produced) keycodes for a particular site ID.
- **Retrieve by Custom Set.** To retrieve previously "grouped" keycodes by a custom label created by the customer.
- **Edit Custom Set.** To edit (add or delete) the contents of a custom set of keycodes.
- **Compare.** To compare two keycodes of the same product type.
- **Terms and Conditions.** Legal disclaimers
- **Download KMT.** Links to a site where the latest version of the KMT can be downloaded to a PC desktop to manage keycodes. This client side application is only necessary for viewing downloaded keycodes when not connected to the web site.
- **Support.** Provides the phone numbers or e-mail address for support.
- **Related Links.** Links to additional Nortel keycode related sites.
- **Feedback.** Pops up an e-mail reply to provide comments and suggestions back to the business owners of the KRS web site.
- **FAQ and What's New.**

---

# Replace NT4N46 CP PII Core/Net with NT4N40

---

## Contents

This section contains information on the following topics:

Prepare for upgrade . . . . .	56
Equipment requirements . . . . .	71
Check personnel requirements . . . . .	73
Install Core 1 hardware . . . . .	73
Disable and remove equipment from Core 1 . . . . .	74
Cable Core 1 . . . . .	90
Power up Core 1 . . . . .	96
Complete the CP PII replacement . . . . .	102

## Prepare for upgrade

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 2.

**Table 2**  
**Prepare for upgrade steps**

Procedure Step	Page
Plan upgrade	<a href="#">57</a>
Upgrade Checklists	<a href="#">57</a>
Prepare	<a href="#">57</a>
Identifying the proper procedure	<a href="#">58</a>
Connect a terminal	<a href="#">59</a>
Check the Core ID switches	<a href="#">60</a>
Print site data	<a href="#">63</a>
Perform a template audit	<a href="#">65</a>
Back up the database (data dump and ABKO)	<a href="#">67</a>
Identify two unique IP addresses	<a href="#">70</a>
Check requirements for cCNI to 3PE cables (NTND14)	<a href="#">71</a>



## Plan upgrade

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Prepare

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.

- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### Procedure 3

#### Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2 The settings for the terminal are:
  - a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 3 If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

---


**End of Procedure**

---

## Check the Core ID switches

**Procedure 4**  
**Checking the Core ID switches**

Each CP PII NT4N40 Core/Net card cage or module is identified as “Core 0” or “Core 1”. This setting is made by a set of option switches on the System Utility card. The Core ID switches are set in the factory. Confirm that these settings match the identification labels for the module into which they will be installed.



**CAUTION — Service Interruption**

**System Failure**

The CP PII Core/Net card cages **MUST** be installed in the correct Core 0 or Core 1 module.


- 1 Pull the System Utility card (NT4N48) far enough out of its slot so you can see the ID switch settings.
- 2 Check and confirm the switch settings according to Table 3.
- 3 Reinstall the System Utility card.
  - a. Gently slide the card into the slot until it makes contact with the backplane. Never force a card into the slot.
  - b. Push in the top and bottom latches on the card to lock it in place.

————— **End of Procedure** —————


**Table 3**  
**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core 0	On	On
Core 1	Off	On

**Figure 6**  
Core card placement in the NT4N40 Core/Net card cage (front)



**Figure 7**  
**Core Module ID switch**



## Print site data

Print site data to preserve a record of the system configuration (Table 4).  
Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 4**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 4**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>



**Table 4**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 5

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

## Procedure 6

### Performing an ABKO (save the database to floppies)

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**                      Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**                      Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5 Once the backup is complete, type:

\*\*\*\*                      Exit program

---

**End of Procedure**

---

### Procedure 7

#### Converting to 2 MByte database media



#### IMPORTANT!

Database conversion for Meridian 1 Options STE, NT, XT, 21E, 51, 61, 71, must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility.

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

Before the system is upgraded to CP PII, you must convert the database to 2 MByte media. Systems with an IODU/C drive already have 2 MByte media and can skip this procedure.

If the database is on a 4 Mbyte database media (the system has an IOP/ CMDU), the 4 Mbyte customer database must be transferred to 2 Mbyte media.

- 1 Split the Cores and transfer call processing to Core 0.
- 2 Install the Database Transfer Utility diskette into the floppy drive on the IOP or CMDU in Core 1.

- 3 Press the reset button (MAN RST) on the Call Processor card in Core 1 to reboot the system. Start the Database Transfer Utility Tool.



**CAUTION — Service Interruption**

**System Failure**

Select only options:

- <t> Tools Menu from the Install menu, and
- <s> To archive existing database from the Tools menu.

DO NOT select any other options. Other options can result in operating system corruption.

- 4 From the installation menu select:

- |          |  |
|----------|--|
| <t>      | Go to the Tools menu.  |
| <s>      | Archive existing database.   |
| <cr> <a> | Continue with archive (insert blank 2MB diskette from the software kit into the floppy drive in Core 1). |
| <cr> <a> | Diskette is now in floppy drive in Core 1.   |

- 5 The message displays “Database backup complete!” and the Tool menu appears again after the backup completes correctly.
- 6 Remove the 2 Mbyte diskette with the customer database from the floppy drive of the IOP or CMDU. Keep the diskette for use after you convert Core 1 to NT4N40 Core/Net 1. Do not reboot the system at this point.

---

**End of Procedure**

---

## Identify two unique IP addresses

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this

configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Check requirements for cCNI to 3PE cables (NTND14)

Existing NTND14 CNI to 3PE cables on Meridian 1 81 and 81C platforms using NT5D21 and/or NTND60 shelves can be reused if they meet the following conditions:



### IMPORTANT!

When configuring NTND14 cables, observe the following rules:


- The shortest NTND14 Cable should always be used.
- A network group requires 4 NTND14 cables, 2 to each half group. Both cables to each half group must be the same length.
- A check should be made on the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50' cables are manufacture discontinued.

## Equipment requirements

This section describes the minimum equipment required to replace the CPP II Core/Net module. Some cards and cables are shipped in separate packages to prevent damage to the equipment. The required hardware must be ordered by piece and not by assemble. For order codes, see Table 5 on [page 72](#).

Before you begin to replace equipment, check that the equipment listed on the order form is also listed on the packing slip. If any items are missing, contact your supplier for replacements before you begin the replacement.



**WARNING**

If any required equipment is missing, DO NOT proceed with equipment replacement. Instead, contact your supplier for replacements.

Table 5 describes the minimum hardware required to replace an NT4N46 CoreNet shelf with an NT4N40 Core/Net shelf.

**Table 5**  
**Required hardware**

Order number	Description	Quantity per Core/Net Shelf
NT4N40AA	CP PII Core/Network Card Cage AC/DC	1*
NT4N48	CP PII System Utility Card	1*
NTND14	cCNI to 3PE cables	2**
MMDU NT4N43CA		1***
CPU NT4N64		1***
cCNI NT4N65AB		1-4***
<p><b>Note 1:</b> *Assumes customer is replacing ONE Core/Network Card cage but not both.</p> <p><b>Note 2:</b> ** Two NTND14 cables are required for each Network shelf to connect to NT4N40AA card cage. If more than 2 groups are configured, more NTND14 cables are required.</p> <p><b>Note 3:</b> ***Reuse from existing NT4N46 shelf.</p>		



## Check personnel requirements

Nortel recommends that no fewer than two people perform a card cage replacement.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Install Core 1 hardware

In this section, the customer is assumed to be replacing a Core/Net 1 NT4N46 card cage. If you are replacing a Core/Net 0, care should be taken to change Core/Net 0 to Core/Net 1. For information on customer supplied hardware in the NT4N46 Core/Net shelf, see Table 5 on [page 72](#).

### **Procedure 8**

#### **Checking main Core card installation**

- 1 If not already installed, install a P0605337 CP PII Card Slot Filler Panel in each slot. (Slots c13 and c14 are left empty.)
- 2 Check side ID switch settings for SU card in Core/Net 1 according to Table 6 below. (NT4N48 System Utility card is located in slot c15.)

**Table 6**

**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core 0	On	On
Core 1	Off	On

————— **End of Procedure** —————

## Check factory-installed cables

Table 7 lists factory-installed cables.

**Table 7**  
**Factory-installed cables**

Order Number	Description	Quantity per Core/Net shelf
NT4N4405	Shelf Power Cable	1
NT4N89AA	System Monitor cable	1
NT4N29AA	CNI to 3PE cable	2

## Disable and remove equipment from Core 1

See Table 5 on [page 72](#) for minimum equipment requirements to replace the CPP II Core/Net module.

### Procedure 9

#### Checking that Core 0 is active and split the cores

- 1 Verify that Core 0 is the active side performing call processing.

**LD 135**      Load program

**STAT CPU**    Get the status of the CPUs

- 2 If Core 1 is active, make Core 0 active.

**SCPU**      Switch to Core 0

**\*\*\*\***      Exit program

- 3 Split the cores.

**LD 135**      Load program

**SPLIT CPU**   Split call processing from Core 0 to Core 1

**\*\*\*\***      Exit program

Result: The system is now in split mode, with call processing on Core 0.

---

**End of Procedure**

---

## Check that Clock Controller 0 is active

- 1 Check the status of the Clock Controllers:

**LD 60** Load program

**SSCK 0** Get the status of Clock Controller 0

**SSCK 1** Get the status of Clock Controller 1

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK** If necessary, switch to Clock Controller 0

**DIS CC 1** Disable Clock Controller 1

**\*\*\*\*** Exit program

- 3 Faceplate disable Clock Controller 1.

---

**End of Procedure**

---

## Check that Ring 0 is active

- 1 Check the status of Ring 0.

**LD 39** Load program

**STAT RING 0** Get the status of Ring 0  
(Ring state should be HALF/HALF)

- 2 Disable Ring auto recovery.

**LD 39** Load program

**ARCV ON/OFF** Set or reset auto-recovery operation for ring

**3**    Swap to Ring 0.

**LD 39**            Load program

**SWRG 0**        Switch call processing to ring 0

**4**    Disable Ring 1.

**LD 39**            Load program

**DIS RING 1**    Disables all FIJI cards on side 1

---

**End of Procedure**

---

## Software disable Network cards in Core/Net 1



### **CAUTION — Service Interruption**

#### **Service Interruption**

At this point, the upgrade interrupts service.

### **Procedure 10**

#### **Software disabling cards in network slots of Core/Net 1**

- 1** In Core/Net 1 only, software disable all network and I/O cards, such as XNET, TTY, Conf/TDS and ISDN cards:

- a.** In Core/Net 1 only, disable XNET.

**LD 32** Load program

**DISL sl** Disable XNET, where sl = the superloop number of the XNET card

**\*\*\*\*** Exit program

- b.** In Core/Net 1 only, disable ENET.

**LD 32** Load program

**DISL X** Disable ENET, where X = loop number of ENET card

**\*\*\*\*** Exit program

- c.** In Core/Net 1 only, software disable each port on the SDI cards:

**LD 37** Load program

**DIS TTY x** Disable port on SDI card, where x = the number of the interface device attached to a port

**\*\*\*\*** Exit program

d. In Core/Net 1 only, disable DTI cards.

<b>LD 60</b>	Load program
<b>DISL x</b>	Disable the DTI card, where x = the loop number of the DTI port
<b>****</b>	Exit program

e. In Core/Net 1 only, disable DCH and PRI cards.

<b>LD 96</b>	Load program
<b>DIS DCH x</b>	Disable DCH, where x = associated D-Channel
<b>****</b>	Exit program
<b>LD 60</b>	Load program
<b>DISL x</b>	Disable PRI card, where x = the loop number PRI port
<b>****</b>	Exit program

f. In Core/Net 1 only, disable MSDL cards.

<b>LD 48</b>	Load program
<b>DIS MSDL x</b>	Disable the MSDL card, where x = the MSDL card number. System will respond with group 0
<b>****</b>	Exit program

g. In Core/Net 1 only, disable XCT cards.

<b>LD 34</b>	Load program
<b>DISX x</b>	Disable the XCT card, where x = the superloop number of the XCT card
<b>****</b>	Exit program

- 2 In Core/Net 1 only, software disable the QPC43 Peripheral Signaling Card:
  - LD 32** Load program
  - DSPS x** Disable the QPC43 card. See Table 8 for Peripheral Signaling Card numbers
  - \*\*\*\*** Exit program

**Table 8**  
**Peripheral Signaling Card numbers**

Group/ shelf	Peripheral Signaling Card	Loops disabled/enabled
0 / 0	0	0–15
0 / 1	1	16–31

- 3 In Core/Net 1 only, faceplate disable the fiji, 3PE, PS and all network cards.

---

**End of Procedure**

---

**Procedure 11**  
**Removing the system monitors from Core 1**

**Note:** This procedure applies to both AC and DC systems.

- 1 In Core 1, software disable the master system monitor (NT8D22).
  - LD 37** Load program
  - DIS TTY #** Disable the master system monitor TTY interface
- 2 Remove J3 and J4 cables on Core 1 system monitors.
 

**Note:** Do *not* turn off the blower units in the front of the pedestals.

- 3    Remove the system monitor from the rear of the pedestal on Core 1.



**CAUTION — Service Interruption**

**Service Interruption**

The system can shut down if the system monitors are not removed. Remove the monitors and keep the cooling fans ON.



**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

---

**End of Procedure**

---

## Power down Core/Net 1



**CAUTION — Service Interruption**

**Service Interruption**

Call processing is interrupted for approximately 60 minutes while the procedures are completed.

In AC-powered systems, set the MPDU circuit breaker located at the left end of the module to OFF (top position).

In DC-powered systems, set the breaker for the Core 1 module in the back of the column pedestal to OFF (down position).

### Procedure 12

#### Removing Core 1 cables and card cage

- 1    Label and disconnect all cables from the front of the module.
- 2    Tape over the contacts to avoid grounding.



- 3 Tie all cables to the sides so the working area in front of the card cage is totally clear.
- 4 Remove the I/O safety panel by turning the screws on each side. Set the I/O safety panel aside.
- 5 Tag and disconnect all cables from the backplane to the interior of the I/O assembly.
- 6 Tag and disconnect all plugs, wires, and cables to the backplane.

**Note 1:** Leave the network cards in the card cage. You will relocate them to the CP PII card cage later in the upgrade procedure.

**Note 2:** Two people are needed to remove the Core card cage because of the weight of the card cage and its contents.

- 7 Use a 1/4" nut driver to remove the two mounting screws at the bottom rear of the card cage. The screws secure the card cage to the module casting. Keep the screws to use with the CP PII card cage.




#### **CAUTION — Service Interruption**

Do not drop the mounting screws into the pedestal. Doing so can cause serious damage.


- 8 Remove the front trim panels on both sides of the card cage.
- 9 Remove the three mounting screws that secure the front of the card cage to the bottom of the module. Keep the screws for use with the CP PII card cage.
- 10 Pull the card cage forward until it is halfway out of the module.
- 11 Disconnect cables, plugs, and wires from the rear of the module to the backplane.
- 12 Remove the logic return (LTRN) (orange) wire from the backplane bolt. Be careful; do not drop the nut or lock washer into the pedestal. See Figure 8 below for DC power connectors; Figure 9 on [page 83](#) for AC power connectors.
- 13 Remove the frame ground (FGND) (green) wire from the frame ground bolt on the module.

**Figure 8**  
**DC power connectors on the Core module backplane**



- 14** Label and disconnect the module power connectors. These are small orange connectors plugged into the module power distribution unit (MPDU) in an AC-powered system, or connected to each other in a DC-powered system.
- 15** Label and disconnect the system monitor ribbon cables to J1 and J2.
- 16** Remove the Core card cage from the module.

**Figure 9**  
**AC power connectors on the Core module backplane**



- 17 Remove the power harness and reserve it for reinstallation when you install the new NT4N40 card cage. The power harness is located at the right rear lower corner and plugs into the rear of the power supply.
  - For AC systems, relocate power harness NT8D80AM.
  - For DC systems, relocate power harness NT7D11.
- 18 Reposition the EMI shield (it looks like a brass grill) in the base of the module. Tape over the front mounting tabs to hold the shield in position. You will remove the tape later.



**WARNING**

If you do not tape the EMI shield in position, you cannot install the card cage correctly.

- 19 In AC-power systems only, plug the module power cable (the short harness attached to the module power connector) into connector J3 on the MPDU. The MPDU is attached to the side of the card cage.

---

**End of Procedure**

---



**CAUTION — Service Interruption**

**Damage to Equipment**

Remove any debris (such as screws) that fell into the base of the UEM module.

## Install the CP PII card cage in Core 1


### Procedure 13

#### Installing the CP PII card cage in Core 1

- 1 Check that the card cage is configured as Core 1. See “Check the Core ID switches” on [page 60](#) for instructions.
- 2 For AC-powered systems only, after the card cage is out of the module, do the following:

- a. Remove the MPDU.
- b. Reinstall the MPDU on the CP PII card cage.
- c. Attach the new MPDU (part of the CP PII Upgrade kit) to the side of the NT4N40 card cage. The screws that secure the MPDU are accessible from the power supply slot, as shown in Figure 10 on [page 85](#).
- d. Pre-thread two bottom mounting screws at the back of the Core/Net shelf.

**Figure 10**  
**Location of the screws for the MPDU**



- 3 Check that the power harness at the right rear corner of the card cage has been transferred from the old card cage to the CP PII card cage.
- 4 Slide the CP PII card cage halfway into the module.
- 5 Hold the card cage firmly and make the following connections at the rear of the module.
  - a. In AC-powered systems, connect the remaining module power connectors to J2 on the MPDU. Then plug the module power cable

(the short harness attached to the module power connector) into connector J3 on the MPDU (attached to the side of the card cage).



**CAUTION — Service Interruption**

**Damage to Equipment**

Check for and remove any debris (such as screws) that may have fallen into the base of the UEM module.

- b. In DC-powered systems, connect the module power connectors to each other. Then attach the system monitor ribbon cables. Connect the ribbon cable that goes down the column to connector J1 on the backplane. Connect the ribbon cable that goes up the column to J2 on the backplane.
- c. Use a 11/32" socket wrench is used to attach the green ground wire to the frame ground bolt on the module. Remove the nut and the lock washer at the top of the bolt. Put the frame ground wire terminal over the bolt. Reinstall the top lock washer and the nut and then tighten down the nut.

**Note:** For all of the wire terminals to fit on the bolt, remove one of the lock washers. Leave one lock washer at the bottom of the bolt, leave a second lock washer at the top of the bolt, and a third lock washer between the second and third, or third and fourth, wire terminals.

- d. Attach the orange logic return wire. Remove one nut and the lock washer from the LRTN bolt at the rear of the card cage. Put the wire terminal over the bolt, reinstall the lock washer and nut, then tighten down the nut. (You need a 1/4" socket wrench.)

- 6 Slide the card cage completely into the module.
- 7 Check the position of the EMI shield. If the EMI shield has shifted, reposition it. Remove the tape holding the EMI shield.
- 8 Pre-route cables NT4N88AA, NT4N88BA and NT4N90BA before you secure the card cage. (See Figure 12 on [page 91](#).)
  - a. Route cable NT4N88AA from COM1 on the CP PII faceplate to J25 on the I/O panel. (NT4N88AA is used to connect a terminal.)
  - b. Route cable NT4N88BA from COM2 on the CP PII faceplate to J21 on the I/O panel. (NT4N88BA is used to connect a modem.)

- 9** Route cable NT4N90BA from LAN 1 on the CP PII faceplate to J31 (top) of the I/O panel.
- 10** Connect NTRC17BA crossover Cat5 Ethernet cable.

---

**End of Procedure**

---

## Install the Security Device

The Security Device fits into the System Utility card (see Figure 11 on [page 89](#)). To install the Security Device, do the following.

- 1    Remove the original Security dongle from the Security Device holder on the System Utility Transition Card.
- 2    Insert the Security Device into the Security Device holder on the System Utility card with the "Nortel" side facing up. Do not bend the clip more than necessary.
- 3    Check that the Security Device is securely in place.


---

**End of Procedure**

---



Figure 11  
Security Device



## Relocate Core and Network cards to CoreNet 1

### Procedure 14

#### Relocating Core and Network cards to CoreNet 1

- 1    Move all Core cards from the NT4N46 card cage to the NT4N40 card cage.
- 2    Move all remaining Network cards from the NT4N46AA card cage to the NT4N40 card cage.
- 3    Connect the tagged cables to the relocated cards.

---

**End of Procedure**

---

## Cable Core 1

### In Core 1, inspect factory installed cables

New NT4N29 cables must be installed for existing Network group 0. If the system has XSDI cards, reinstall the cards and attach the cables. Then inspect the system monitor cables (NT4N89).

### Installing intermodule cables

#### Procedure 15

#### Installing intermodule cables


- 1    Connect the NT8D99AD and NT8D80BZ cables.
- 2    Install NT8D99AD cables between the D connectors on the backplane of each Core/Net module. Install another NT8D99AD cable between the E connectors on the backplane of each Core/Net module (see Figure 13 on [page 92](#)).
- 3    Install an NT8D80BZ cable between the J3 connector on the 3PE card in Core/Net 0 and the J3 connector on the 3PE card in Core/Net 1. Install another cable between the J4 connectors on the 3PE cards (see Figure 14 on [page 93](#)).

---

**End of Procedure**

---

**Figure 12**  
**COM and LAN connections to the Core/Net I/O panel**



**Figure 13**  
**Fanout Panel connections on the CP PII Core/Net backplane**






Figure 14  
3PE card connections



**Figure 15**  
**Connectors for CNI-3PE cables to the Fanout panel**



## In Core 1, route and connect the cCNI to 3PE (NTND14) cables

Each (NT8D35)Network shelf requires 2 NTND14 cables (for cCNI to 3PE connection) to a Core/Net Card cage. Cables are routed to a module beside the Core/Net module to allow for equipment removal. Once the NT4N46 card cage has been replaced with a new NT4N40 card cage, you can install the cables in the new Core/Net card cage.

- 1 Remove the existing NT8D76 cCNI to 3PE cables.
- 2 Label each cable at both ends with:
  - Network group number
  - Shelf 1 of the Network group
  - J3 or J4 (of the 3PE card)
- 3 Route the NT4N14 cCNI to 3PE cables from the Side 1 3PE cards to a module above or adjacent to Core/Net 1.

**Table 9**  
**Fanout Panel to 3PE card connectors (Part 1 of 2)**

Group Number	Fanout Panel connector	3PE card connector
0	9-0, J3	A
0	9-0, J4	B
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
<b>Note:</b> Group 0/shelf 1 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1.(see Figure 15 on <a href="#">page 94</a> . Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1 (see Figure 16 on <a href="#">page 97</a> ).		

**Table 9**  
**Fanout Panel to 3PE card connectors (Part 2 of 2)**

Group Number	Fanout Panel connector	3PE card connector
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4
<b>Note:</b> Group 0/shelf 1 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1.(see Figure 15 on <a href="#">page 94</a> . Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1 (see Figure 16 on <a href="#">page 97</a> ).		

---

**End of Procedure**

---

## Power up Core 1

### Procedure 16


#### Preparing for power up

- 1 Check that a terminal is connected to the J25 I/O panel connector on Core/Net 1.

**Note:** A maintenance terminal is required to access the Core/Net modules during the upgrade.



**Figure 16**  
**3PE Fanout Panel connections**



- 2    Connect a terminal to the J25 port on the I/O panel in Core 1.
- 3    Check the terminal settings as follows:
  - a.   9600 Baud
  - b.   8 data
  - c.   parity none
  - d.   1 stop bit
  - e.   full duplex
  - f.   XOFF

**Note:** If only one terminal is used for both Cores, that terminal must be switched from side to side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

- 4    Faceplate *enable* the cCNI cards in Core 1.

---

**End of Procedure**

---

**Procedure 17**  
**Powering up Core 1**

- 1    Power up the Core/Net Module.
- 2    Wait for the system to load/initialize.
- 3    Check that the Network and I/O cards have working power.

Result: CoreNet 1 should now come up with CoreNet 0 as Active Call processor.

---

**End of Procedure**

---

## **Re-enable all network cards in CoreNet 1 from CoreNet 0**

Re-enable all network cards in CoreNet 1 from CoreNet 0 so full call processing can resume.

### Procedure 18

#### Software enabling cards in network slots of Core/Net 1

- 1 In Core/Net 1 only, faceplate enable fiji, 3PE, PS and all network cards.
- 2 In Core/Net 1 only, software enable the QPC43 Peripheral Signaling Card:

**LD 32**                      Load program

**ENPS x**                    Enable the QPC43 card. See Table 10 below for Peripheral Signaling Card numbers

**\*\*\*\***                        Exit program

**Table 10**

**Peripheral Signaling Card numbers**

Group/ shelf	Peripheral Signaling Card	Loops disabled/enabled		
0 / 0	0	0	–	15
0 / 1	1	16	–	31

- 3 In Core/Net 1 only, software enable all network and I/O cards such as XNET, TTY, Conf/TDS and ISDN cards:

- a. In Core/Net 1 only, enable XNET.

**LD 32**                      Load program

**ENLL sl**                    Enable XNET, where sl = the superloop number of the XNET card

**\*\*\*\***                        Exit program

- b. In Core/Net 1 only, enable ENET.

**LD 37**                      Load program

**ENLL x**                    Enable ENET, where x = the loop number

**\*\*\*\***                        Exit program

c. In Core/Net 1 only, software enable each port on the SDI cards:

<b>LD 37</b>	Load program
<b>ENL TTY x</b>	Enable each SDI port, where x = number of the interface devices attached to a port
<b>****</b>	Exit program

d. In Core/Net 1 only, enable DTI cards.

<b>LD 60</b>	Load program
<b>ENLL x</b>	Enable DTI card, where x = loop number
<b>****</b>	Exit program

e. In Core/Net 1 only, enable PRI cards.

<b>LD 60</b>	Load program
<b>ENLL x</b>	Enable PRI card, where x = loop number
<b>****</b>	Exit program

f. In Core/Net 1 only, enable MSDL cards.

<b>LD 48</b>	Load program
<b>ENL MSDL x</b>	Enable MSDL card, where x = MSDL card number. System will respond with group X
<b>****</b>	Exit program

g. In Core/Net 1 only, enable XCT cards.

<b>LD 34</b>	Load program
<b>ENLX x</b>	Enable XCT card, where x = the loop number of the XCT card
<b>****</b>	Exit program

---

**End of Procedure**

---

## Enable Ring 1

### Procedure 19 Software enabling Ring 1

#### 1 Software enable ring 1:

<b>LD 39</b>	Load program
<b>ENL RING 1</b>	Enable all FIJI cards on ring (x = 0 or 1)
<b>STAT RING x</b>	Get status of ring on side x (x = 0 or 1)
<b>RSET</b>	Reset threshold for switchover functionality
<b>RSTR</b>	Restore ring
<b>ARCV ON</b>	Enable auto-recovery operation for ring

#### 2 Confirm ring is enabled and in Half/Half state:

<b>LD 39</b>	Load the program
<b>STAT RING x</b>	Get status of ring on side x (x = 0 or 1)
<b>STAT ALRM x y FULL</b>	Query status of all alarms (active and inactive) for FIJI card in group x, side y
<b>****</b>	Exit

#### 3 Verify status of system clocks:

<b>LD 60</b>	Load the program
<b>SSCK x</b>	Get status of system clock (x = 0 or 1)
<b>****</b>	Exit

---

**End of Procedure**

---

## Make the system redundant

### Procedure 20 Making the system redundant

- |               |  |
|---------------|--|
| <b>LD 135</b> | Load program                                 |
| <b>JOIN</b>   | Join the 2 CPUs together to become redundant |

Core/Net 1 will INI and become the inactive call processor.

---

**End of Procedure**

---

## Complete the CP PII replacement

### Test Core/Net 1

From Core/Net 1, perform the following tests.

- 1 Perform a redundancy sanity test:

- |                 |                              |
|-----------------|------------------------------|
| <b>LD 135</b>   | Load program                 |
| <b>STAT CPU</b> | Get status of CPU and memory |
| <b>TEST CPU</b> | Test the CPU                 |

- 2 Check the LCD states.

- a. Perform a visual check of the LCDs.

- b. Test LCDs:

- |                  |              |
|------------------|--------------|
| <b>LD 135</b>    | Load program |
| <b>TEST LCDs</b> | Test LCDs    |
| <b>DSPL ALL</b>  | Display all  |

- c. Check that the LCD display matches the software check.

**3** Test the System Utility cards and the cCNI cards:

- LD 135**            Load program
- STAT SUTL**      Get the status of the System Utility (main and Transition) cards
- TEST SUTL**      Test the System Utility (main and Transition) cards
- STAT CNI c s**    Get status of cCNI cards (core, slot)
- TEST CNI c s**    Test cCNI (core, slot)

**4** Test system redundancy:

- LD 137**            Load program
- TEST RDUN**      Test redundancy
- DATA RDUN**
- TEST CMDU**      Test the MMDU card

**5** Install the two system monitors. Test that the system monitors are working.

- LD 37**            Load program
- ENL TTY x**        Enable the TTY, where x= system XMS
- STAT XSM**        Check the system monitors
- \*\*\*\***            Exit program

**6** Clear the display and minor alarms on both Cores.

- LD 135**            Load program
- CDSP**            Clear the displays on the cores
- CMAJ**            Clear major alarms
- CMIN ALL**        Clear minor alarms

7    Test the clocks.

- a.    Verify that the clock controller is assigned to the *active* Core.

**LD 60**                    Load program

**SSCK *x***                To get the status of the clock controllers (*x* is “0” or “1” for Clock 0 or Clock 1

**SWCK**                    Switch the Clock if necessary

**\*\*\*\***                    Exit program

- b.    Verify that the Clock Controllers are switching correctly.

**SWCK**                    Switch the Clock

**SWCK**                    Switch the Clock again

8    Test the Fiber Rings

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.    Check that the Fiber Rings operate correctly.

**LD 39**                    Load program

**STAT RING 0**          Check the status of Ring 0 (HALF/HALF)

**STAT RING 1**          Check the status of Ring 1 (HALF/HALF)

- b.    If necessary, restore the Rings to Normal State.

**RSTR**                    Restore both Rings to HALF state

- c.    Check that the Rings operate correctly:

**STAT RING 0**          Check the status of Ring 0 (HALF/HALF)

**STAT RING 1**          Check the status of Ring 1 (HALF/HALF)



**9** Check the status of the FIJI alarms

**STAT ALRM**      Query the alarm condition for all FIJI cards in all Network Groups

\*\*\*\*                      Exit program

---

**End of Procedure**

---

## Switch call processing

**Procedure 21**  
**Switching call processing**

**LD 135**                      Load program

**SCPU**                      Switch call processing from CoreNet 0 to CoreNet 1

Core/Net 0 will INI and Core/Net 1 will become the active call processor.

---

**End of Procedure**

---

This concludes replacement of the NT4N46 Card Cage for Core/Net 1.

Verify that all system applications are active and functional (such as CallPilot and Symposium).

If the Core/Net 0 shelf is being replaced, repeat the procedures in this chapter for Core/Net 0.



---

# Adding a Network Group (NT4N40)

---

## Contents

This section contains information on the following topics:

Add a Core Network Group to Option 81C CP PII with FNF .....	108
Prepare for upgrade .....	110
Perform the upgrade .....	120
Add an NT8D35 Network Group to Option 81C CP PII with FNF ...	153
Prepare for upgrade .....	155
Perform the upgrade .....	166
Add a Core Network Group to Option 81C/IGS CP PII .....	200
Prepare for upgrade .....	200
Perform the upgrade .....	210
Add an NT8D35 Network Group to Option 81C/IGS CP PII .....	234
Prepare for upgrade .....	234
Perform the upgrade .....	244
Post-conversion procedure .....	270

## Add a Core Network Group to Option 81C CP PII with FNF

### Introduction

Complete the following procedures to add a Network Group to the Core/Net module of a Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf.

The NT4N40 Core/Net shelf is factory configured with Network group 0 in the Core. Upgrades from Meridian Option 71 or Meridian Option 81 to Meridian Option 81C CP PII do not require Group 0 to be moved to the Core.

The Meridian 1 Option 81C CP PII CNI port to group number cannot be changed in software configuration. The NT4N29 cables must be connected to the proper group.

The Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- NTRB53AA Clock Controller is required.
- The shortest fiber cable should always be used.

- The cables from group 0-1 must be the same length.
- The difference between the lengths of each fiber ring from group 0 to group 1 must not exceed 50 ft.

**IMPORTANT!**

Always use the shortest NTRC48 fiber cable.

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.

To add a Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf:

- Clock Controller cards must be NTRB53AA.
- NTRB33 Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.
- NT4N65AC CNI card.



### IMPORTANT!

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform, and maintenance window required to perform the upgrade.

Each chapter features checkboxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and to limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel must complete the steps in Table 11.

**Table 11**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">111</a>
Upgrade checklists	<a href="#">112</a>
Prepare	<a href="#">112</a>
Identify the proper procedure	<a href="#">113</a>
Connect a terminal	<a href="#">113</a>
Print site data	<a href="#">114</a>
Perform a template audit	<a href="#">117</a>
Back up the database (data dump)	<a href="#">119</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.

- Determine if software can be converted on site or must be sent to Nortel Networks.
- Prepare a contingency plan if you abort the upgrade.



#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, power to the entire column *must* be shut down throughout the procedures.

## **Upgrade checklists**

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers can print this section for reference during the upgrade.

## **Prepare**

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.



- Secure the source software and keycode.
- Print site data.

## Identify the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes can cause longer service interruptions.



### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

### **Procedure 22**

#### **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF

- 2
- If only one terminal is used for both Core or Core/Net modules, connect the terminal from side to side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

End of Procedure

Print site data

Print site data to preserve a record of the system configuration (see Table 12). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

Table 12  
Print site data (Part 1 of 3)

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>

**Table 12**  
**Print site data (Part 2 of 3)**

Site data	Print command	
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop

**Table 12**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ TYPE LOOP APPL PH	PRT MISP loop number (0-158) <cr> <cr>
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on Large Systems. Run the audit during a low traffic period.



### **CAUTION — Service Interruption**

#### **Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data can be corrupted.

**LD 01**
The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT**
**CHECKSUM**  
**LOW**
**OK**

**TEMPLATE 0002 USER COUNT**
**CHECKSUM**  
**HIGH**
**OK**

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT OK**
**CHECKSUM**  
**OK**

- 
- 

**TEMPLATE 0120 USER COUNT OK**
**CHECKSUM**  
**OK**

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 23

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When "EDD000" appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\* Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---





## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- The NT4N65AC CNI card.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

### Check required hardware

Table 13 describes the *minimum* equipment required to add a Core Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N40 shelf. Additional equipment for increased Network capacity must be ordered separately.

**Table 13**  
**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT4N40 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT4N65AC	CNI card	(see Note)
NTRC48	FIJI fiber cable	4
NTRC47	FIJI to FIJI cable	1
<b>Note:</b> The quantity of CNI cards required is dependent on the system configuration.		

## Tools

Table 14 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 14**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group. See Figure 18 on [page 127](#).

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.

**Note:** Do not disconnect the existing Fiber cables.

**Procedure 24**

**Label and route the shelf 0 fiber-optic cables (ascending)**

Route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order (Figure 18 on [page 127](#)).



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 15 on [page 125](#).
- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4 If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5 Continue to route NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6 To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 15**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

————— End of Procedure —————

**Procedure 25**

**Label and route the shelf 1 fiber optic cables (descending)**

Route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 18 on [page 127](#)).



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note 1:** Do not disconnect FIJI cable.

**Note 2:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1 Start with Group 0, shelf 1.
- 2 Label each cable on both sides with the appropriate connection information from Table 16 on [page 128](#).
- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4 Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5 Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6 Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 18**  
**Shelf 1 descending fiber-optic Ring (example)**



**Table 16**  
**FIJI Ring 1 connections**

<b>Groups 0 - X are cabled in descending order</b>		
<b>Group/shelf</b>	<b>NTRC48 fiber cable connector</b>	<b>FIJI card connector</b>
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2



## **Interconnect the Core/Net modules**

### **Procedure 26**

#### **Interconnecting the Core/Net modules**

On the back of each Core/Net module backplanes are two connectors labeled D and E.


- 1** Connect the NT8D99AD cable from the D connector in shelf 0, to the D connector in shelf 1 of the NT4N40 Core/Net Module.
- 2** Connect the NT8D99AD cable from the E connector in shelf 0, to the E connector in shelf 1 of the NT4N40 Core/Net Module.

---

**End of Procedure**

---

**Figure 19**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



## Add CNI cards if necessary


### Procedure 27 Adding CNI cards

If additional CNI cards are required, add to each Core Module as required (see Figure 20 on [page 131](#)).

- 1 Faceplate disable CNI card.
- 2 Insert the card into Core/Net module, but do not seat the card into backplane at this time.

**End of Procedure**

**Figure 20**  
**NT4N40 Core/Net card cage**



## Connect the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

If Network Group 0 will not be in the Core/Net module, reconfiguring of the processor module is required.

The NT4N40 shelf is factory installed with NT4N29 cables and is configured as group 0. If the Network portion of the Core/Net shelf is used as a higher Network Group, use the extraction tool to disconnect the NT4N29 cables from the Core backplane. Once the cables are disconnected, connect the cables to the appropriate group. For connector replacement, see Figure 21 on [page 134](#) and Table 17 on [page 133](#).


**Table 17**  
**Fanout Panel to 3PE card connectors**

Group Number	Fanout Panel connector	3PE card connector
0	9-0, J3	A
0	9-0, J4	B
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4

**Note 1:** Group 0 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1.(see Figure 21 on [page 134](#)).

**Note 2:** Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1 (see Figure 21 on [page 134](#) ).

**Figure 21**  
**3PE Fanout Panel (Core/Net module)**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### Install and enable the QPC441 3PE cards

#### **Procedure 28**

#### **Installing the QPC441F 3PE cards.**

**1** Verify the 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 18 on [page 136](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

**2** Install a 3PE card in slot 11 of each added Network module.

**3** Seat the 3PE card and ensure it is faceplate disabled.

**4** Attach the NT8D80BZ cables to the 3PE faceplates:

- a.** Attach the NT8D80BZ cable to the QPC441 3PE card J2 connector in shelf 0 to the QPC441 card J2 connector in shelf 1.
- b.** Attach the NT8D80BZ cable to the QPC441 3PE card J3 connector in shelf 0 to the QPC441 card J3 connector in shelf 1.

**Table 18**  
**QPC441 3PE Card installed in the NT4N40 Module**

<b>Jumper settings.</b> Set Jumper RN27 at E35 to “A”.									
Switch Settings									
Module		D20 switch position							
NT4N40 (Option 81C CP PII)		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
	Group 1	off	on	on	off	on	on	off	on
	Group 2	off	on	on	off	on	off	on	on
	Group 3	off	on	on	off	on	off	off	on
	Group 4	off	on	on	off	off	on	on	on
	Group 5	off	on	on	off	off	on	off	on
	Group 6	off	on	on	off	off	off	on	on
	Group 7	off	on	on	off	off	off	off	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off
	Group 1	off	on	on	off	on	on	off	off
	Group 2	off	on	on	off	on	off	on	off
	Group 3	off	on	on	off	on	off	off	off
	Group 4	off	on	on	off	off	on	on	off
	Group 5	off	on	on	off	off	on	off	off
	Group 6	off	on	on	off	off	off	on	off
	Group 7	off	on	on	off	off	off	off	off

**Note:** Settings for the 3PE can be found in *Circuit card installation and testing* (553-3001-211).

---

**End of Procedure**

---



**Procedure 29****Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC43R Per Sig card into slot 10 of each Core/Net module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 30****Disabling and inserting the FIJI cards**

- 1 Faceplate *disable* the NTRB33AC/AD FIJI cards.
- 2 Insert the NTRB33AC/AD FIJI cards into slots 8 and 9 of each added Network module.

Do not plug the card into the backplane.

---

**End of Procedure**

---

**Procedure 31****Disabling and inserting the NT8D17 Conf/TDS cards**

If the NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.
- 3 Seat the card and faceplate enable.

**Note:** The NT8D17 Conference/TDS card is typically installed in slot 0 of the Core/Net module.

---

**End of Procedure**

---

**Procedure 32****Installing new CNI cards if required**

- 1 Faceplate *disable* new NT4N65AC CNI cards.
- 2 Insert a NT4N65AC CNI card on both cores.

Do not plug the card into the backplane.

---

**End of Procedure**

---

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.



Core 0 is active, clock 0 is active, FIJI is half/half.

Follow these procedures to activate the added CNI ports.

Verifying Core/Net 0 is active.

- 1     Get the status of the CPUs. Verify that all common equipment is enabled.

**LD 135**             Load program.

**STAT CPU**        Get the status of both Core/Nets.

- 2     Ensure Core/Net 0 is active.

If Core/Net 1 is active, switch Core/Nets.

**STAT CPU**        Get the status of the Core/Nets.

**SCPU**             Switch to Core/Net 0.

**\*\*\*\***             Exit program.

**3** Ensure Clock Controller 0 is active and tracking.

<b>LD 60</b>	Load program.
<b>SSCK 0</b>	Get the status of Clock 0.
<b>SSCK 1</b>	Get the status of Clock 1.
<b>SWCK</b>	Switch to Clock 0 (if necessary).



CP 0 is active, clock 0 is active, FIJI is half/half.

---

**End of Procedure**

---

## Split the Cores

### Procedure 33 Splitting the Cores

From Core 0 side, split the Cores.

<b>LD 135</b>	Load the program.
<b>SPLIT</b>	Split the Cores.
<b>****</b>	Exit the program.

Add new group in software on the inactive core

**Procedure 34**  
**Adding new group**

1 In Core 1, define the XCT and extenders in the added group.

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	Exit the program.
<b>LD 43</b>	Load the program.
<b>EDD</b>	Invoke the data dump program.
<b>****</b>	Exit the program.

Table 19 on [page 141](#) specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 19**  
**CNI Network group designations**

<b>CNI card slot</b>	<b>CNI card port</b>	<b>3PE Fanout Panel label</b>	<b>Connected to Network group</b>
c9	0	Port 9-0	0
c9	1	Port 9-1	1
c10	0	Port 10-0	2
c10	1	Port 10-1	3
c11	0	Port 11-0	4
c11	1	Port 11-1	5
c12	0	Port 12-0	6
c12	1	Port 12-1	7

---

**End of Procedure**

---

**Procedure 35**  
**Checking that Ring 0 is active in Core 0**

- 1 Check the status of Ring 0.

**LD 39** Load program.

**STAT RING 0** Get the status of Ring 0  
(Ring state should be half/half).

- 2 Disable Ring auto recovery.

**LD 39** Load program.

**ARCV OFF** Set or reset auto-recovery operation for ring.

**3** Swap to Ring 0.

**LD 39** Load program.

**SWRG 0** Swing traffic to ring 0.

**4** Disable Ring 1.

**LD 39** Load program.

**DIS RING 1** Disable all FIJI cards on side 1.



**WARNING**

Cable Ring 1 to new network shelf only.

**5** Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

**6** Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).

**7** Break Ring 1 and cable the added FIJI cards. Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.

**8** In **Core 1 only**, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, Call Pilot, and Symposium.



### CAUTION

#### Service Interruption

Call processing is interrupted for approximately 10 minutes while the INI is completed.

**9** In LD 135 switch Cores.

**LD 135** Load the program.

**CUTOVR** Switch Cores.



### WARNING

All call processing may be interrupted.



### IMPORTANT!

Power up all applications such as Meridian Mail, Call Pilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.

**Note 1:** On FNF based systems after the INI, a FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

**10** Switch the clock controllers, if necessary:

<b>LD 60</b>	Load the program.
<b>SSCK n</b>	Get status of clock n where: n = 0 for clock controller 0 1 for clock controller 1
<b>SWCK</b>	Switch system clock from active to standby.  <b>Note:</b> Make clock controller 1 the active clock.
<b>****</b>	Exit the program.

**11** Disable Ring 0.

<b>LD 39</b>	Load the program.
<b>DIS RING 0</b>	Disables all FIJI cards on side 0.
<b>****</b>	Exit the program.

**12** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.



**13** In LD 39, enable and stat Ring 0.

<b>LD 39</b>	Load the program.
<b>ENL Ring 0</b>	Enable Ring 0.
<b>Stat Ring 0</b>	Status of Ring x.
<b>****</b>	Exit the program.



The system is in split mode with Core 1 active, Clock 1 active, and FIJI half and half.

**14** In **Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 19 on [page 141](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)

**<cr>** Continue to the last prompt.

**\*\*\*\*** Exit the program.

**15** Data dump the software changes.

**LD 43** Load the program.

**EDD** Invoke the data dump program.

**\*\*\*\*** Exit the program.

**16** Seat the CNI card in Core 0 and faceplate enable it.

**17** In Core 1, Stat the CNIs.

**LD 135** Load the program.

**STAT CNI** Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN** Synchronize the memory and drives.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 36

#### Testing Core/Net 1

From Core/Net 1, perform these tests.

- 1 Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

- 2 Check the LCD states.

a. Perform a visual check of the LCDs.

b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL**

- 3 Test the System Utility cards and the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

- 4 Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

- 5 Install the two system monitors. Test that the system monitors are working.

<b>LD 37</b>	Load the program.
<b>ENL TTY x</b>	Enable the XMS, where x = system XMS.
<b>STAT XSM</b>	Check the system monitors.
<b>****</b>	Exit the program.

- 6 Clear the display and minor alarms on both Cores.

<b>LD 135</b>	Load the program.
<b>CDSP</b>	Clear the displays on the cores.
<b>CMAJ</b>	Clear major alarms.
<b>CMIN ALL</b>	Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core:

<b>LD 60</b>	Load the program.
<b>SSCK x</b>	Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1).
<b>SWCK</b>	Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

<b>SWCK</b>	Switch the Clock.
<b>SWCK</b>	Switch the Clock again.

**8 Test the Fiber Rings.**

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

**a. Check that the Fiber Rings operate correctly.**

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

**b. If necessary, restore the Rings to Normal State.**

**RSTR** Restore both Rings to HALF state.

**c. Check that the Rings operate correctly.**

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

**9 Check the status of the FIJI alarms.**

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\*** Exit program.

**10 Check applications such as CallPilot, Symposium, and Meridian Mail.****11 Check for dial tone.**

---

**End of Procedure**

---

**Switch call processing****1 Seat new CNI cards, faceplate enable.****2 Check that all new cards are seated and faceplate enabled (CNI, FIJI, PS and XCT).**

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

**Procedure 37**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1 Perform a redundancy sanity test.

<b>LD 135</b>	Load the program.
<b>STAT CPU</b>	Get the status of CPU and memory.
<b>TEST CPU</b>	Test the CPU.

- 2 Check the LCD states.

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

<b>LD 135</b>	Load the program.
<b>TEST LCDs</b>	Test LCDs.
<b>DSPL ALL</b>	Display all.

- 3 Test the System Utility cards and the CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI c s</b>	Get status of CNI cards (core, slot).
<b>TEST CNI c s</b>	Test CNI (core, slot).

- 4 Test system redundancy.

<b>LD 137</b>	Load the program.
<b>TEST RDUN</b>	Test redundancy.
<b>DATA RDUN</b>	
<b>TEST CMDU</b>	Test the MMDU card.

- 5 Test that the system monitors are working.

<b>LD 37</b>	Load the program.
--------------	-------------------

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6** Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8** Test the Fiber Rings.

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- 9 Check the status of the FIJI alarms.

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\* Exit program.

- 10 Check applications such as CallPilot and Symposium.

- 11 Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 270](#).



## Add an NT8D35 Network Group to Option 81C CP PII with FNF

### Introduction

Complete the following procedure to add an NT8D35 Network Group to the Core/Net module of a Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf.

The NT4N40 Core/Net shelf is factory configured with Network group 0 in the Core. Upgrades from Meridian Option 71 or Meridian Option 81 to Meridian Option 81C CP PII do not require Group 0 to be moved to the Core.

The Meridian 1 Option 81C CP PII CNI port to group number cannot be changed in software configuration. The NT4N29 cables must be connected to the proper group.

The Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- NTRB53AA Clock Controller is required.
- The shortest fiber cable should always be used.

- The cables from group 0-1 must be the same length.
- The difference between the lengths of each fiber ring from group 0 to group 1 must not exceed 50 ft.



**IMPORTANT!**

The shortest fiber cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.

To add a Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N40 Core/Net shelf:

- The Clock Controller cards must be NTRB53AA.
- The NTRB33 Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.
- NT4N65AC CNI card.

**IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- The shortest NTND14 Cable should always be used.
- A network group requires 4 NTND14 cables, 2 to each half group. Both cables to each half group must be the same length.
- A check should be made on the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade, field personnel must complete the steps in Table 20.

**Table 20**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">156</a>
Upgrade checklists	<a href="#">157</a>
Prepare	<a href="#">157</a>
Identifying the proper procedure	<a href="#">158</a>
Connect a terminal	<a href="#">158</a>
Print site data	<a href="#">159</a>
Perform a template audit	<a href="#">161</a>
Back up the database (data dump)	<a href="#">164</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers can print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan, and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.

## Connect a terminal

### Procedure 38 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side to side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (see Table 21). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 21**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 21**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>



**Table 21**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on Large Systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 39

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\* Exit the program.

---

**End of Procedure**

---



**IMPORTANT!**

Preserve database backup information for a minimum of five days.


## Perform the upgrade

## Introduction

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/FNF equipped with an NT4N40 shelf.

Figure 22 shows a Meridian 1 Option 81C/FNF (NT4N40).

**Figure 22**  
**CP PII NT4N40 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- NT4N65AC CNI card Vintage AC.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

### Check required hardware

Table 22 describes the *minimum* equipment required to add a Core Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N40 shelf. Additional equipment for increased Network capacity must be ordered separately.

**Table 22**  
**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT4N40 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	2
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC48	FIJI fiber cable	4
NTRC47	FIJI to FIJI Cable	1
NT8D35	Network Module	5
NTND14	CNI to 3PE cable	4
NT4N65AC	CNI card	(see Note)
<b>Note:</b> The quantity of CNI cards required is dependent on the system configuration.		



## Tools

Table 23 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 23**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group. See Figure 22 on [page 166](#).

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.

**Note:** Do not disconnect the existing Fiber cables.

**Procedure 40**

**Labeling and routing the shelf 0 fiber optic cables (ascending)**

Route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order (Figure 23 on [page 173](#)).



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 24 on [page 171](#).
- 3 Route an NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4 If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5 Continue to route the NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6** To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 24**  
**FIJI Ring 0 connections**

<b>Groups X - 0 are cabled in ascending order</b>		
<b>Group/shelf</b>	<b>NTRC48 fiber cable connector</b>	<b>FIJI card connector</b>
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

**End of Procedure**

**Procedure 41**

**Labeling and routing the shelf 1 fiber optic cables (descending)**

Route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 23 on [page 173](#)).



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1 Start with Group 0, shelf 1.
- 2 Label each cable on both sides with the appropriate connection information from Table 25 on [page 174](#).
- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4 Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5 Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6 Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 23**  
**Shelf 1 descending fiber-optic Ring (example)**



**Table 25**  
**FIJI Ring 1 connections**

Groups 0 - X are cabled in descending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2

**Procedure 42****Interconnecting the network modules**

**Note:** The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 24 on [page 176](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group. To add modules to a system, see *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

- 1** Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2** Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3** Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4** Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5** Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6** Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0).


**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**

---

**Figure 24**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**





## Add CNI cards if necessary


### Procedure 43

#### Adding CNI cards if necessary

- 1 Faceplate *disable* the CNI card.
- 2 Place the card in the slot location but do not seat the cards.

If additional CNI cards are required, add to each Core Module as required (see Figure 25).

**Figure 25**  
**NT4N40 Core/Net card cage**



#### Procedure 44

##### Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 26, Figure 26 on [page 180](#), and Figure 27 on [page 181](#) for NT4N14 cable connections.

- 1 Connect the NTND14 cables to J3 and J4 of the 3PE cards.
- 2 Connect the NTND14 cables to the Fanout Panel in the Core/Net.

**Table 26**  
**Fanout Panel to 3PE card connectors**

Group Number	Fanout Panel connector	3PE card connector
0	9-0, J3	A
0	9-0, J4	B
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4

**Note 1:** Group 0 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1. See Figure 21 on [page 134](#).

**Note 2:** Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1. See Figure 21 on [page 134](#).

**IMPORTANT!**

When configuring the NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.


**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

---


**End of Procedure**

---

**Figure 26**  
**3PE faceplate to 3PE Fanout Panel connection**



**Figure 27**  
**3PE Fanout Panel (Core/Net module)**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### Procedure 45

#### Installing and enabling the QPC441 3PE cards

- 1 Verify the QPC 441F 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 27 on [page 183](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2 Install a QPC 441F 3PE card in slot 1 of each added Network module.

- 3 Faceplate disable the QPC 441F 3PE cards and seat them in the proper network shelf location.

**Table 27**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

End of Procedure

**Procedure 46**

**Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC43R Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 47**

**Disabling and inserting the FIJI cards**

- 1 Faceplate *disable* the NTRB33AC/AD FIJI cards.
- 2 Insert the NTRB33AC/AD FIJI cards into slots 2 and 3 of each added Network module.

---

**End of Procedure**

---

**Procedure 48**

**Disabling and inserting the NT8D17 Conf/TDS cards**

If the NT8D17 Conf/TDS cards are used in the system, complete the following steps.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.

Do not plug the card into the backplane.

---

**End of Procedure**

---

## **Enable the Network Group**

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.



**Procedure 49**  
**Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135** Load program.

**STAT CPU** Get the status of the CPUs.

- 2 If Core 1 is active, make Core 0 active.

**SCPU** Switch to Core 0 (if necessary).

**\*\*\*\*** Exit program.

---

**End of Procedure**

---

**Procedure 50**  
**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers.

**LD 60** Load program.

**SSCK 0** Get the status of Clock Controller 0.

**SSCK 1** Get the status of Clock Controller 1.

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK** Switch to Clock Controller 0 (if necessary).

**DIS CC 1** Disable Clock Controller 1.

**\*\*\*\*** Exit program.

---

**End of Procedure**

---

## Add the CNI cards or ports

### Procedure 51 Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

1 In LD 135 split the Cores.

LD 135            Load the program.  
SPLIT            Split the Cores.  
\*\*\*\*            Exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1.

2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 27 on [page 183](#).

LD 17            Load the program.  
REQ            CHG  
TYPE            CEQU  
XCT X            X = the extended conference/TDS/MFS  
EXT0 3PE  
CNI s p g        Core to Network Interface card location  
                  where:  
                  s = slot (9 to 12)  
                  p = port number (0 to 1)  
                  g = group number (0 to 7)  
EXT1 3PE  
CNI s p g        Core to Network Interface card location  
                  where:  
                  s = slot (9 to 12)  
                  p = port number (0 to 1)  
                  g = group number (0 to 7)

**<cr>** Continue to the last prompt.

**\*\*\*\*** Exit the program.

Table 28 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 28**  
**CNI Network group designations**

<b>CNI card slot</b>	<b>CNI card port</b>	<b>3PE Fanout Panel label</b>	<b>Connected to Network group</b>
c9	0	Port 9-0	0
c9	1	Port 9-1	1
c10	0	Port 10-0	2
c10	1	Port 10-1	3
c11	0	Port 11-0	4
c11	1	Port 11-1	5
c12	0	Port 12-0	6
c12	1	Port 12-1	7

**3** Perform a data dump.

**LD 43** Load the program.

**EDD** Invoke the data dump program.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

**Procedure 52**

**Checking that Ring 0 is active in Core 0**

- 1    Check the status of Ring 0.

**LD 39**                    Load program.

**STAT RING 0**        Get the status of Ring 0  
                              (Ring state should be HALF/HALF).

- 2    Disable Ring auto recovery.

**LD 39**                    Load program.

**ARCV OFF**            Set or reset auto-recovery operation for ring.

- 3    Swap to Ring 0.

**LD 39**                    Load program.

**SWRG 0**                Swing Traffic to Ring x.

- 4    Disable Ring 1.

**LD 39**                    Load program.

**DIS RING 1**          Disable all FIJI cards on side 1.



**WARNING**

Cable Ring 1 to new network shelf only.

- 5    Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).

- 7 Break Ring 1 and cable the added FIJI cards. See Figure 18 on [page 127](#). Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.

**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.

**CAUTION****Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 9 In LD 135 switch Cores.

**LD 135**

Load the program.

**CUTOVR**

Switch Cores.

**WARNING**

All call processing may be interrupted.

**IMPORTANT!**

Power up all applications such as Meridian Mail, Call Pilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.



**CAUTION**

**Service Interruption**

Allow the system to recover from all downloads after the INI completes.

**Note 1:** On FNF based systems after the INI, a FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

**10** Switch the clock controllers, if necessary:

- |               |  |
|---------------|--|
| <b>LD 60</b>  | Load the program.  |
| <b>SSCK n</b> | Get the status of clock n where:<br>n = 0 for clock controller 0<br>1 for clock controller 1 |

**SWCK** Switch system clock from active to standby.

**Note:** Make clock controller 1 the active clock.

\*\*\*\* Exit the program.

**11** Disable Ring 0:

**LD 39** Load the program.

**DIS RING 0** Disable Ring 0.

\*\*\*\* Exit the program.

**12** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.

**13** In LD 39, enable and stat Ring 0:

**LD 39** Load the program.

ENL Ring 0 Enable Ring 0.

Stat Ring 0 Status of Ring x.

\*\*\*\* Exit the program.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

**14** In Core 0 only, define the XCT and Extenders to the added group.

**Note:** See Table 28 on [page 187](#):

**LD 17** Load the program.

**REQ** CHG

**TYPE** CEQU

**XCT X**                      X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                              Continue to the last prompt.

**\*\*\*\***                                Exit the program.

**15**   Data dump the software changes.

**LD 43**                              Load the program.

**EDD**                                Invoke the data dump program.

**\*\*\*\***                                Exit the program.

**16**   Seat the CNI card in Core 0 and faceplate enable it.



**17** In Core 1, Stat the CNIs:

**LD 135** Load the program.

**STAT CNI** Get the status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN** Synchronize the memory and drives.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 53

#### Testing Core/Net 1

**From Core/Net 1**, perform these tests.

**1** Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get the status of CPU and memory.

**TEST CPU** Test the CPU.

**2** Check the LCD states.

**a.** Perform a visual check of the LCDs.

**b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL**

- 3 Test the System Utility cards and the CNI cards.
  - LD 135** Load the program.
  - STAT CNI c s** Get the status of CNI cards (core, slot).
  - TEST CNI c s** Test CNI (core, slot).
- 4 Test system redundancy.
  - LD 137** Load the program.
  - TEST RDUN** Test redundancy.
  - DATA RDUN**
  - TEST CMDU** Test the MMDU card.
- 5 Install the two system monitors. Test that the system monitors are working.
  - LD 37** Load the program.
  - ENL TTY x** Enable the XMS, where x = system XMS.
  - STAT XSM** Check the system monitors.
  - \*\*\*\*** Exit the program.
- 6 Clear the display and minor alarms on both Cores.
  - LD 135** Load the program.
  - CDSP** Clear the displays on the cores.
  - CMAJ** Clear major alarms.
  - CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.**
- Verify that the clock controller is assigned to the
- active*
- Core:

<b>LD 60</b>	Load the program.
<b>SSCK x</b>	Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.
<b>SWCK</b>	Switch the Clock if necessary.

- b.**
- Verify that the Clock Controllers are switching correctly.

<b>SWCK</b>	Switch the Clock.
<b>SWCK</b>	Switch the Clock again.

**8** Test the Fiber Rings.

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.**
- Check that the Fiber Rings operate correctly.

<b>LD 39</b>	Load the program.
<b>STAT RING 0</b>	Check the status of Ring 0 (HALF/HALF).
<b>STAT RING 1</b>	Check the status of Ring 1 (HALF/HALF).

- b.**
- If necessary, restore the Rings to Normal State.

<b>RSTR</b>	Restore both Rings to HALF state.
-------------	-----------------------------------

- c.**
- Check that the Rings operate correctly.

<b>STAT RING 0</b>	Check the status of Ring 0 (HALF/HALF).
<b>STAT RING 1</b>	Check the status of Ring 1 (HALF/HALF).

**9** Check the status of the FIJI alarms.

<b>STAT ALRM</b>	Query the alarm condition for all FIJI cards in all Network Groups.
<b>****</b>	Exit program.

- 10 Check applications such as CallPilot, Symposium, and Meridian Mail.
- 11 Check for dial tone.

---

**End of Procedure**

---

**Procedure 54**  
**Switching call processing**

- LD 135**            Load the program.
- SCPU**            Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 55**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1 Perform a redundancy sanity test.
  - LD 135**            Load the program.
  - STAT CPU**        Get the status of CPU and memory.
  - TEST CPU**        Test the CPU.
- 2 Check the LCD states.
  - a. Perform a visual check of the LCDs.
  - b. Test LCDs.
    - LD 135**            Load the program.
    - TEST LCDs**        Test LCDs.
    - DSPL ALL**        Display all.

**3** Test the System Utility cards and the CNI cards.**LD 135** Load the program.**STAT CNI c s** Get the status of CNI cards (core, slot).**TEST CNI c s** Test CNI (core, slot).**4** Test system redundancy.**LD 137** Load the program.**TEST RDUN** Test redundancy.**DATA RDUN****TEST CMDU** Test the MMDU card.**5** Test that the system monitors are working.**LD 37** Load the program.**STAT XSM** Check the system monitors.**\*\*\*\*** Exit the program.**6** Clear the display and minor alarms on both Cores.**LD 135****CDSP** Clear the displays on the cores.**CMAJ** Clear major alarms.**CMIN ALL** Clear minor alarms.

7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

8 Test the Fiber Rings.

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

9 Check the status of the FIJI alarms.

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\*

Exit program.

**10** Check applications such as CallPilot and Symposium.

**11** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 270](#).

## Add a Core Network Group to Option 81C/IGS CP PII

### Introduction

Complete the following procedures to add a Network Group to the Core/Net module of a Meridian 1 Option 81C/IGS equipped with an NT4N40 Core/Net shelf.

The NT4N40 Core/Net shelf is factory configured with Network group 0 in the Core. Upgrades from Meridian Option 71 or Meridian Option 81 to Meridian Option 81C CP PII do not require Group 0 to be moved to the Core.

The Meridian 1 Option 81C CP PII CNI port-to-group number cannot be changed in software configuration. The NT4N29 cables must be connected to the proper group.



#### IMPORTANT!

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

### Introduction

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.



Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should complete the steps in Table 29.

**Table 29**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">201</a>
Upgrade checklists	<a href="#">202</a>
Prepare	<a href="#">202</a>
Identifying the proper procedure	<a href="#">203</a>
Connect a terminal	<a href="#">203</a>
Print site data	<a href="#">204</a>
Perform a template audit	<a href="#">207</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.

- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.



#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## **Upgrade checklists**

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers can print this section for reference during the upgrade.

## **Prepare**

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Determine and communicate the required maintenance window, contingency plan, and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

### **Procedure 56**

#### **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF

- 2
- If only one terminal is used for both Core or Core/Net modules, connect the terminal from side to side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

End of Procedure

Print site data

Print site data to preserve a record of the system configuration (see Table 30). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

Table 30  
Print site data (Part 1 of 3)

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>

**Table 30**  
**Print site data (Part 2 of 3)**

Site data	Print command	
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop

**Table 30**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ TYPE LOOP APPL PH	PRT MISP loop number (0-158) <cr> <cr>
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on Large Systems. Run the audit during a low traffic period.



### **CAUTION — Service Interruption**

#### **Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT      CHECKSUM**  
**LOW                                      OK**

**TEMPLATE 0002 USER COUNT      CHECKSUM**  
**HIGH                                    OK**

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT OK      CHECKSUM**  
**OK**

- 
- 

**TEMPLATE 0120 USER COUNT OK      CHECKSUM**  
**OK**

**TEMPLATE AUDIT COMPLETE**



## Back up the database (data dump)

### Procedure 57

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.



#### CAUTION — Service Interruption

##### Loss of Data

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.




#### IMPORTANT!

Preserve database backup information for a minimum of five days.

————— **End of Procedure** —————

Perform the upgrade

Introduction




**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/IGS (NT4N40).

**Figure 28**  
**CP PII NT4N40 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with IGS. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- NT4N65AC CNI card.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 31 describes the *minimum* equipment required to add a Network Group to Meridian 1 Option 81C/IGS CP PII (NT4N40). Additional equipment for increased Network capacity must be ordered separately.

**Table 31**  
**Minimum equipment required to add a Core Network Group to an Option 81C/IGS equipped with an NT4N40 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT5D30AA	Dual IGS	2
NT8D76	IGS to IGM Cable 6'	4
NT4N64AC	CNI card	(see Note)
<b>Note:</b> The quantity of CNI cards required is dependent on the system configuration.		

## Tools

Table 32 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 32**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Add CNI cards if necessary

If additional CNI cards are required, add to each Core Module as required (see Figure 29 on [page 214](#)).



**Table 33**  
**Fanout Panel to 3PE card connectors**

Group Number	Fanout Panel connector	3PE card connector
0	9-0, J3	A
0	9-0, J4	B
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4

**Note 1:** Group 0 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1.(see Figure 21 on [page 134](#)).


**Note 2:** Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1 (see Figure 21 on [page 134](#) ).

---

**End of Procedure**

---

**Figure 30**  
**3PE Fanout Panel (Core/Net module)**





## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### **Procedure 59**

#### **Installing and enable the QPC441 3PE cards**

- 1 Verify the QPC 441F 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 34 on [page 218](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2 Install a QPC 441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

- 3 Attach the NT8D80BZ cables to the QPC 441F 3PE faceplates.
  - a. Connect 1 NT8D80BZ cable from QPC441F J3 of Core/Net 0 to QPC441F J3 of Core/Net 1.
  - b. Connect 1 NT8D80BZ cable from QPC441F J4 of Core/Net 0 to QPC 441F J4 of Core/Net 1.

**Table 34**  
**QPC441 3PE Card installed in the NT4N40 Module**

<b>Jumper settings.</b> Set Jumper RN27 at E35 to “A”.									
Switch Settings									
Module		D20 switch position							
NT4N40 (Option 81C CP PII)		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
	Group 1	off	on	on	off	on	on	off	on
	Group 2	off	on	on	off	on	off	on	on
	Group 3	off	on	on	off	on	off	off	on
	Group 4	off	on	on	off	off	on	on	on
	Group 5	off	on	on	off	off	on	off	on
	Group 6	off	on	on	off	off	off	on	on
	Group 7	off	on	on	off	off	off	off	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off
	Group 1	off	on	on	off	on	on	off	off
	Group 2	off	on	on	off	on	off	on	off
	Group 3	off	on	on	off	on	off	off	off
	Group 4	off	on	on	off	off	on	on	off
	Group 5	off	on	on	off	off	on	off	off
	Group 6	off	on	on	off	off	off	on	off
	Group 7	off	on	on	off	off	off	off	off

————— End of Procedure —————

**Procedure 60****Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC43R Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 61****Disabling and inserting the NT8D17 Conf/TDS cards**

If the NT8D17 Conf/TDS cards are used in the system, complete the following steps.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.
- 3 Seat and Faceplate Enable cards.

---

**End of Procedure**

---

## Enable the Network Group

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

**Procedure 62**  
**Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1    Verify that Core 0 is active:

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2    If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 63**  
**Checking that Clock Controller 0 is active**

- 1    Check the status of the Clock Controllers.

**LD 60**            Load program.

**SSCK 0**           Get the status of Clock Controller 0.

**SSCK 1**           Get the status of Clock Controller 1.

- 2    If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK**            Switch to Clock Controller 0 (if necessary).

**DIS CC 1**        Disable Clock Controller 1.

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

## Add the CNI cards or ports

### Procedure 64

#### Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

- 1 In LD 135 split the Cores.

**LD 135** Load the program.

**SPLIT** Split the Cores.

**\*\*\*\*** Exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1.

- 2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 34 on [page 218](#).

**LD 17** Load the program.

**REQ** CHG

**TYPE** CEQU

**XCT X** X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g** Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g** Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                      Continue to the last prompt.

**\*\*\*\***                      Exit the program.

**3**     Perform a data dump.

**LD 43**                      Load the program.

**EDD**                      Invoke the data dump program.

**\*\*\*\***                      Exit the program.

Table 35 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 35**  
**CNI Network group designations**

<b>CNI card slot</b>	<b>CNI card port</b>	<b>3PE Fanout Panel label</b>	<b>Connected to Network group</b>
c9	0	Port 9-0	0
c9	1	Port 9-1	1
c10	0	Port 10-0	2
c10	1	Port 10-1	3
c11	0	Port 11-0	4
c11	1	Port 11-1	5
c12	0	Port 12-0	6
c12	1	Port 12-1	7

---

**End of Procedure**

---

**Procedure 65****Seating the remaining cards**

- 1 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules. See Table 36 on [page 223](#) and Figure 31 on [page 224](#).

**Note:** Cards must be faceplate *disabled* before seating.

- 2 Faceplate *enable* all cards in both network modules (3PE, PER SIG, XCT and DIGS).
- 3 Cable the added NT5D30 DIGS cards.

**Table 36****IGS to InterGroup cable assignment — use NT8D76 cables (Part 1 of 2)**


From				To
Network Group	Network Shelf	Slot	IGS Connector J1	InterGroup Connector
0	0 (Core/Net 0)	8	0	J1
0	0 (Core/Net 0)	9	1	J6
0	1 (Core/Net 1)	9	1	J17
0	1 (Core/Net 1)	8	0	J22
1	0	3	0	J2
1	0	2	1	J7
1	1	2	1	J16
1	1	3	0	J21
2	0	3	0	J3
2	0	2	1	J8
2	1	2	1	J15
2	1	3	0	J20
3	0	3	0	J4
3	0	2	1	J9
3	1	2	1	J14
3	1	3	0	J19

**Table 36**  
IGS to InterGroup cable assignment — use NT8D76 cables (Part 2 of 2)


From				To
Network Group	Network Shelf	Slot	IGS Connector J1	InterGroup Connector
4	0	3	0	J5
4	0	2	1	J10
4	1	2	1	J13
4	1	3	0	J18

**Note:** The NT5D30 DIGS card is located in slot 9 of the Core/Net and slot 2 of the NT8D35 Network shelf.

**Figure 31**  
NT8D36 Inter-group module connections for IGS cards



4    In Core 1 only, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION****Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 5 In LD 135 switch Cores.

**LD 135** Load the program.

**CUTOVR** Switch Cores.

**WARNING**

All call processing may be interrupted.

**IMPORTANT!**

Power up all applications such as Meridian Mail, Call Pilot, and Symposium.



Core 1 is active, Clock 0 is active.

- 6 Switch the clock controllers, if necessary.

**LD 60** Load the program.

**SSCK n** Get status of clock n where:  
n = 0 for clock controller 0  
1 for clock controller 1

**SWCK**                      Switch system clock from active to standby.

**Note:** Make clock controller 1 the active clock.

\*\*\*\*                      Exit the program.



The system is in split mode with Core 1 active. Clock 1 is active.

**7 In Core 0 only,** define the XCT and extenders to the added group.

**Note:** See Table 35 on [page 222](#).

**LD 17**                      Load the program.

**REQ**                      CHG

**TYPE**                      CEQU

**XCT X**                      X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                      Continue to the last prompt.

\*\*\*\*                      Exit the program.

**8** Data dump the software changes:

**LD 43** Load the program.

**EDD** Invoke the data dump program.

**\*\*\*\*** Exit the program.

**9** Seat the CNI card in Core 0 and faceplate enable it.

**10** In Core 1, Stat the CNIs.

**LD 135** Load the program.

**STAT CNI** Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN** Synchronize the memory and drives.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 66

#### Testing Core/Net 1

From **Core/Net 1**, perform these tests.

- 1 Perform a redundancy sanity test:

<b>LD 135</b>	Load the program.
<b>STAT CPU</b>	Get status of CPU and memory.
<b>TEST CPU</b>	Test the CPU.

- 2 Check the LCD states.

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

<b>LD 135</b>	Load the program.
<b>TEST LCDs</b>	Test LCDs.
<b>DSPL ALL</b>	

- 3 Test the System Utility cards and the CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI c s</b>	Get status of CNI cards (core, slot).
<b>TEST CNI c s</b>	Test CNI (core, slot).

- 4 Test system redundancy.

<b>LD 137</b>	Load the program.
<b>TEST RDUN</b>	Test redundancy.
<b>DATA RDUN</b>	
<b>TEST CMDU</b>	Test the MMDU card.

- 5 Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x = system XMS.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number.) See Table 37.

**\*\*\*\*** Exit program.

**Table 37**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot, Symposium, and Meridian Mail.

**10** Check for dial tone.

---

**End of Procedure**

---

## Switch call processing

### Procedure 67 Switching call processing

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

**Procedure 68**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1** Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

- 2** Check the LCD states.

- a.** Perform a visual check of the LCDs.

- b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

- 3** Test the System Utility cards and the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

- 4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

- 5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core:

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 38).

**\*\*\*\*** Exit program.



**Table 38**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot and Symposium.

**10** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 270](#).

## Add an NT8D35 Network Group to Option 81C/IGS CP PII

### Prepare for upgrade

#### Introduction

Complete this procedures to add an NT8D35 Network group to an Option 81C/IGS CP PII system equipped with an NT4N40 Core/Net shelf.

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action. Each section is written to maintain dial tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel must complete the steps in Table 39.

**Table 39**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">235</a>
Upgrade checklists	<a href="#">235</a>
Prepare	<a href="#">235</a>
Identifying the proper procedure	<a href="#">236</a>
Connect a terminal	<a href="#">237</a>
Print site data	<a href="#">237</a>
Perform a template audit	<a href="#">240</a>
Back up the database (data dump)	<a href="#">243</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.

- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

### Procedure 69 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side to side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (see Table 40 on [page 238](#)). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 40**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN

**Table 40**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 40**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.



**Note:** The template audit may take an extended period of time on Large Systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**
The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT**
**CHECKSUM**  
**LOW**
**OK**

**TEMPLATE 0002 USER COUNT**
**CHECKSUM**  
**HIGH**
**OK**

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

**TEMPLATE 0001 USER COUNT OK**
**CHECKSUM**  
**OK**

- 
- 

**TEMPLATE 0120 USER COUNT OK**
**CHECKSUM**  
**OK**

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 70

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.




#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

Perform the upgrade

Introduction




**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add an NT8D35 Network Group to the Meridian 1 Option 81C/IGS (NT4N40).

**Figure 32**  
**CP PII NT4N40 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### CAUTION — Service Interruption

##### Service Interruption

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- The NT4N65AC CNI card.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### CAUTION — Service Interruption

##### Service Interruption

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 41 describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81C/IGS (NT4N40). Table 41 and Table 42 on [page 247](#) and Table 43 on [page 247](#) list the DC and AC power equipment requirements. Additional equipment for increased Network capacity must be ordered separately.

**Table 41**  
**Minimum equipment required to add an NT8D35 Network Group to an Option 81C/IGS equipped with an NT4N40 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	5
NT8D35	Network Module AC/DC	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	XCT/CONF/TDS/MFS	2
NT8D76	Intergroup Switch to Intergroup Module cables	4
NT4N65AC	CNI cards	(see Note)
NTND14	3PE CNI cables	4
NT5D30	Dual IGS card	2
<b>Note:</b> The quantity of CNI cards required is dependent on the system configuration.		

## Check required power equipment

**Table 42**

**DC power requirements for Meridian 1 Option 81C CP PII/IGS upgrades**

Order number	Description	Quantity per system
NT6D41	Common Equipment	2

**Table 43**

**AC power requirements for Meridian 1 Option 81C CP PII/IGS upgrades**

Order number	Description	Quantity per system
NT8D29	Common Equipment	2

## Tools

Table 44 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 44**

**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Check personnel requirements

Nortel recommends that a minimum of two people perform the upgrade.

### Procedure 71

#### Interconnecting the network modules

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 33 on [page 249](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group.

- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3 Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4 Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5 Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6 Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0).

**Note:** All connections are made with an NT8D99AB cable.


---

**End of Procedure**

---



**Figure 33**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**




## Connect the network to the Core/Net module

### Add CNI cards if necessary

If additional CNI cards are required, see Figure 34 on [page 250](#), add to each Core Module as required.

**Figure 34**  
**Core/Net card cage**



**Procedure 72**  
**Connecting the 3PE to CNI cables**

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 45 on [page 251](#), Figure 35 on [page 252](#), and Figure 36 on [page 253](#) for NTND14 cable connections.

- 1 Connect the NTND14 cables to J3 and J4 of the 3PE cards.
- 2 Connect the new NTND14 cables to the Fanout Panel in the Core/Net.

**End of Procedure**


**Table 45**  
**Fanout Panel to 3PE card connectors**

Group Number	Fanout Panel connector	3PE card connector
0	9-0, J3	A
0	9-0, J4	B
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4


**Note 1:** Group 0 cables (NT4N29) connect from the Fanout panel directly to the backplane of Core/Net 1. See Figure 21 on [page 134](#).

**Note 2:** Group 1 cables (NTND14) connect from the Fanout panel to the faceplate of the 3PE cards of Group 1. See Figure 21 on [page 134](#).

**Figure 35**  
**Example of 3PE faceplate to 3PE Fanout Panel connection**



**Figure 36**  
**3PE Fanout Panel (Core/Net module)**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### Procedure 73

#### Installing and enabling the QPC441 3PE cards

Three steps are required to install the QPC441F 3PE cards.

**1** Verify the QPC 441F 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 46 on [page 255](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

**2** Install a QPC 441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

**3** Attach the NT8D80BZ cables to the QPC 441F 3PE faceplates.

- a.** Connect 1 NT8D80BZ cable from QPC441F J3 of Core/Net 0 to QPC441F J3 of Core/Net 1.
- b.** Connect 1 NT8D80BZ cable from QPC441F J4 of Core/Net 0 to QPC441F J4 of Core/Net 1.

**Table 46**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

————— **End of Procedure** —————

**Procedure 74**

**Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC 43R Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 75**

**Disabling and inserting NT5D30 DIGS cards**

- 1 Faceplate *disable* IGS.
- 2 Insert the NT5D30 DIGS card into slot x.

---

**End of Procedure**

---

**Procedure 76**

**Disabling and inserting the NT8D17 Conf/TDS cards**

**Note:** If the NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.

---

**End of Procedure**

---

## **Enable the Network Group**

**Note:** To add more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.



**Procedure 77****Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135** Load program.

**STAT CPU** Get status of the CPUs.

- 2 If Core 1 is active, make Core 0 active:

**SCPU** Switch to Core 0 (if necessary).

**\*\*\*\*** Exit program.

---

**End of Procedure**

---

**Procedure 78****Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers.

**LD 60** Load program.

**SSCK 0** Get the status of Clock Controller 0.

**SSCK 1** Get the status of Clock Controller 1.

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK** Switch to Clock Controller 0 (if necessary).

**DIS CC 1** Disable Clock Controller 1.

**\*\*\*\*** Exit program.

---

**End of Procedure**

---

## Add the CNI cards or ports

### Procedure 79 Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

1 In LD 135 split the Cores.

<b>LD 135</b>	Load the program.
<b>SPLIT</b>	Split the Cores.
<b>****</b>	Exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1.

2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 46 on [page 255](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)

**<cr>** Continue to the last prompt.

**\*\*\*\*** Exit the program.

**3** Perform a data dump.

**LD 43** Load the program.

**EDD** Invoke the data dump program.

**\*\*\*\*** Exit the program.

Table 47 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 47**  
**CNI Network group designations**

<b>CNI card slot</b>	<b>CNI card port</b>	<b>3PE Fanout Panel label</b>	<b>Connected to Network group</b>
c9	0	Port 9-0	0
c9	1	Port 9-1	1
c10	0	Port 10-0	2
c10	1	Port 10-1	3
c11	0	Port 11-0	4
c11	1	Port 11-1	5
c12	0	Port 12-0	6
c12	1	Port 12-1	7

---

**End of Procedure**

---

**Procedure 80**  
**Seating remaining cards**

- 1    Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.  

**Note:** Cards must be faceplate disabled before seating.
- 2    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and DIGS).
- 3    Cable the NT5D30 DIGS cards.

**Table 48**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 4 In Core 1 only, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION**

**Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 5 In LD 135 switch Cores.

**LD 135** Load the program.

**CUTOVR** Switch Cores.



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

- 6    Switch the clock controllers, if necessary:
- |               |   |
|---------------|---|
| <b>LD 60</b>  | Load the program.   |
| <b>SSCK n</b> | Get status of clock n, where<br>n = 0 for clock controller 0<br>1 for clock controller 1                  |
| <b>SWCK</b>   | Switch system clock from active to standby.<br><br><b>Note:</b> Make clock controller 1 the active clock. |
| <b>****</b>   | Exit the program.   |



The system is in split mode with Core 1 active. Clock 1 is active.

- 7    In Core 0 only, define the XCT and extenders to the added group.

**Note:** See Table 48 on [page 260](#).

- |                  |  |
|------------------|--|
| <b>LD 17</b>     | Load the program.  |
| <b>REQ</b>       | CHG  |
| <b>TYPE</b>      | CEQU   |
| <b>XCT X</b>     | X = the extended conference/TDS/MFS  |
| <b>EXT0 3PE</b>  |  |
| <b>CNI s p g</b> | Core to Network Interface card location<br>where:<br>s = slot (9 to 12)<br>p = port number (0 to 1)<br>g = group number (0 to 7) |

**EXT1 3PE**

**CNI s p g**      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**      Continue to the last prompt.

**\*\*\*\***      Exit the program.

**8**    Data dump the software changes.

**LD 43**      Load the program.

**EDD**      Invoke the data dump program.

**\*\*\*\***      Exit the program.

**9**    Seat the CNI card in Core 0 and faceplate enable it.

**10**   In Core 1, Stat the CNIs.

**LD 135**      Load the program.

**STAT CNI**      Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN**      Synchronize the memory and drives.

**\*\*\*\***      Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 81

#### Testing Core/Net 1

From **Core/Net 1**, perform these tests.

- 1    Perform a redundancy sanity test.

**LD 135**            Load the program.

**STAT CPU**        Get status of CPU and memory.

**TEST CPU**        Test the CPU.

- 2    Check the LCD states.

**a.**    Perform a visual check of the LCDs.

**b.**    Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**        Test LCDs.

**DSPL ALL**

- 3    Test the System Utility cards and the CNI cards.

**LD 135**            Load the program.

**STAT CNI c s**    Get status of CNI cards (core, slot).

**TEST CNI c s**    Test CNI (core, slot).

- 4    Test system redundancy.

**LD 137**            Load the program.

**TEST RDUN**        Test redundancy.

**DATA RDUN**

**TEST CMDU**        Test the MMDU card.



- 5 Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x = system XMS.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1).

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 49).

**\*\*\*\*** Exit program.

**Table 49**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot, Symposium, and Meridian Mail.

**10** Check for dial tone.

---

**End of Procedure**

---

**Procedure 82**  
**Switching call processing**

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 83**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1** Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get the status of CPU and memory.

**TEST CPU** Test the CPU.

- 2** Check the LCD states.

**a.** Perform a visual check of the LCDs.

**b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

- 3** Test the System Utility cards and the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

- 4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

- 5    Test that the system monitors are working.
- LD 37**                    Load the program.
- STAT XSM**            Check the system monitors.
- \*\*\*\*                    Exit the program.
- 6    Clear the display and minor alarms on both Cores.
- LD 135**
- CDSP**                    Clear the displays on the cores.
- CMAJ**                    Clear major alarms.
- CMIN ALL**            Clear minor alarms.
- 7    Test the clocks.
- a.    Verify that the clock controller is assigned to the *active* Core:
- LD 60**                    Load the program.
- SSCK x**                Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.
- SWCK**                    Switch the Clock if necessary.
- b.    Verify that the Clock Controllers are switching correctly.
- SWCK**                    Switch the Clock.
- SWCK**                    Switch the Clock again.
- 8    Check the IGS status.
- LD 39**                    Load the program.
- STAT IGS X**            Check the status of IGS (X = IGS/DIGS card number.) See Table 50.
- \*\*\*\*                    Exit program.

**Table 50**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot and Symposium.

**10** Check for dial tone.

---

**End of Procedure**

---

## Post-conversion procedure

### Introduction

This procedure verifies that the conversion process was successful, and system data converted completely. This is the last part of the total conversion procedure. Perform these steps **after** completing all other procedures for the system.

The site data should be printed before and after conversion. See Table 52 on page 276. If the data has changed, make the necessary updates on the **Target** release, and datadump to the new system media. Print out the items marked with an asterisk (\*) to be sure everything converted properly. All other items on Table 52 on page 276 are provided to be printed if desired.

Check the General Release Bulletin (GRB), and the Conversion notes (earlier in this document) to verify any database updates that need to be made as a result of conversion. Be sure to verify all SYSxxx messages that might appear during the conversion process. These messages might indicate some database updates are required.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Test call processing thoroughly. This can include more testing than is described in this procedure, depending on system configuration. This procedure is intended to show some of the basic tests performed to complete the conversion process.

**Note:** When parallel reload is complete, the attendant consoles will be in Night mode. If performing these procedures during the day, contact the attendant. If these procedures are taking place during the evening, it might not be desirable to perform these call processing steps.

## Post-conversion steps

Follow the steps in Procedure 84 to perform the post-conversion procedure.

### Procedure 84

#### Performing the post-conversion procedure

- 1 Print system data listed in Table 52 on [page 276](#). Verify that all information matches the printouts created before conversions. Make changes if necessary.
- 2 From any unrestricted telephone, dial the access code for an outside line (usually 9), and dial the listed Directory Number (DN) for the customer. Verify that the correct Incoming Call Indicator (ICI) lights at the attendant console.
- 3 If the customer is equipped with more than one console, transfer the call to another console.
- 4 Extend the call to a telephone, and release the call from the console.
- 5 From the called telephone, transfer the call back to the attendant.
- 6 Answer and release the call.
- 7 From any telephone dial the DN for the attendant. Verify that the correct ICI lights at the console, then release the call.
- 8 Busy-out one trunk group using a Trunk Group Busy (TGB) key on the console.
- 9 From any telephone with TGAR 0-7, dial the access code of the busied-out trunk group, to verify that the call is intercepted to the console and receives either overflow tone or a recorded announcement.
- 10 Restore the trunk group to the in-service state using the Trunk Group Busy (TGB) key on the console.
- 11 During the conversion procedure the Central Office might have busied-out the DID trunks. If DID trunks are equipped, from any unrestricted telephone, dial the access code for an outside line, and dial a DID number into the system.
- 12 If a private network is used, from any unrestricted telephone, dial the network access code and place a CDP, ESN, BARS/NARS, or ISDN call as applicable to the system.

- 13 If not done previously, set the time and date. If Call Detail Recording (CDR) is used, system message ERR225 will appear. This is normal.

**LD 02**

**STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

*Note:* Test all applications and call handling.

- 14 If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.
- 15 Keep one copy of the **Source** software, as it was backed up in the pre-conversion procedure, in case it becomes necessary to reconvert. After the **Target** software has been running well for a few weeks, return the original software to Nortel through the usual distribution channel.
- 16 Load LD 135 to test and switch CPUs. (Omit this step for Option 51C.)

<b>LD 135</b>	Load the program.
<b>TEST CPU</b>	Test CPU.
<b>SCPU</b>	Switch CPUs.
****	Exit LD.

- 17 Load LD 137 to get the status of the CMDUs and IOPs.

<b>LD 137</b>	Load the program.
<b>STAT</b>	Get the status of both CMDUs and IOPs.
****	Exit LD.

*Note:* Check MMDU in CP PII machines.



- 18** Load LD 43 to back up the other set of B1 disks. Insert the B1 disk in the active CMDU.

**LD 43** Load the program.

**BKO** Back up to the backup disks and the active CMDU.

**Note:** Back up additional 2 MByte floppy disks.

- 19** If not done previously, set the time and date. If Call Detail Recording (CDR) is used, the system message ERR225 will appear. This is normal.

**LD 02**

**STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

\*\*\*\* Exit LD.

**Note:** If equipped with FNF, perform steps 21-24. If equipped with IGS, perform step 20.

- 20** Test the IGS

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number.) See Table 51.

\*\*\*\* Exit program.

**Table 51**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
0	0	IGS/DIGS 0 & 2
1	0	IGS/DIGS 4 & 6
2	0	IGS/DIGS 8 & 10
3	0	IGS/DIGS 12 & 14
4	0	IGS/DIGS 16 & 18
0	1	IGS/DIGS 1 & 3
1	1	IGS/DIGS 5 & 7
2	1	IGS/DIGS 9 & 11
3	1	IGS/DIGS 13 & 15
4	1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**21** Check that Fiber Ring 1 operates correctly.

**LD 39** Load the program  
**STAT RING 1** to check the status of Ring 1

**22** Reset the Rings.

**RSET** to reset the Rings and prepare them for redundancy  
**RSTR** to restore both Rings to HALF state

**23** Check that the Rings operate correctly.

**STAT RING 0** to check the status of Ring 0 (HALF/HALF)  
**STAT RING 1** to check the status of Ring 1 (HALF/HALF)

- 24 If any Ring problems occur, correct them now.

**STAT ALRM <X> <Y>** to check the alarm status of individual FIJI cards or all FIJI cards. See *Software Input/Output: Administration* (553-3001-311) for more information.

- 25 Verify that call processing operates correctly. This includes, but is not limited to the following:

- Check for dial tone.
- Make internal, external, and network calls.
- Check attendant console activity.
- Check DID trunks.
- Check any auxiliary processors.

- 26 If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.

- 27 Keep one copy of the **Source** software, as it was backed up in the pre-conversion procedure, in case it becomes necessary to reconvert. After the **Target** software has been running well for a few weeks, return the original software to Nortel through the usual distribution channel.

Items marked with asterisks (\*) are required printout for conversion. Other items are recommended for a total system status.

**Table 52**  
**Print site data (Part 1 of 3)**

Site data	Print command
Terminal Blocks for all TNs	LD 20 REQ PRT TYPE TNB CUST <cr>
Directory Numbers	LD 20 REQ PRT TYPE DNB CUST <cr>
Attendant Console data block for all customers	LD 20 REQ PRT TYPE ATT, 2250 CUST <cr>
*Customer Data Block for all customers	LD 21 REQ PRT TYPE CDB CUST <cr>
Route Data Block for all customers	LD 21 REQ PRT TYPE RDB CUST Customer number ROUT <cr> ACOD <cr>

**Table 52**  
**Print site data (Part 2 of 3)**

Site data	Print command
*Configuration Record	LD 22 REQ PRT TYPE CFN
*Software Packages	LD 22 REQ PRT TYPE PKG
*Software Issues, Patches, ROM and Tape ID	LD 22 REQ ISSP REQ ROM REQ TID
* Peripheral software versions	LD 22 REQ PRT TYPE PSWV
ACD data block for all customers	LD 23 REQ PRT TYPE ACD CUST Customer Number ACDN ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32 . IDC loop

**Table 52**  
**Print site data (Part 3 of 3)**

Site data	Print command
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27  REQ     PRT  TYPE     MISP  LOOP     loop number (0–158)  APPL     <cr>  PH     <cr>
DTI/PRI data block for all customers	LD 73  REQ     PRT  TYPE     DDB
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

**28** Obtain status of CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI</b>	Get the status of CNI cards.
<b>****</b>	Exit the program.

---

**End of Procedure**

---

---

# Adding a Network Group (NT4N46)

---

## Contents

This section contains information on the following topics:

Add a Core Network Group to Option 81C/FNF CP PII .....	280
Prepare for upgrade .....	283
Perform the upgrade .....	293
Add an NT8D35 Network Group to Option 81C/FNF CP PII .....	328
Prepare for upgrade .....	329
Perform the upgrade .....	339
Add a Core Network Group to Option 81C/IGS CP PII .....	375
Prepare for upgrade .....	375
Perform the upgrade .....	385
Add an NT8D35 Network Group to Option 81C/IGS CP PII .....	413
Prepare for upgrade .....	413
Perform the upgrade .....	421
Post-conversion procedure .....	451

## Add a Core Network Group to Option 81C/FNF CP PII

### Introduction

Complete the following procedure to add a Network Group to the Core/Net Module of a Meridian 1 Option 81C with FNF equipped with an NT4N46 Core/Net shelf.

The NT4N46 Core/Net shelf is factory configured with Network Group 0 in the Core. Upgrades from Meridian Option 71 or Meridian Option 81 to Meridian Option 81C CP PII do not require Group 0 to be moved to the Core.

The Meridian 1 Option 81C CP PII CNI port to group number cannot be changed in software configuration. In order to configure a group other than group 0, an NT4N72 kit must be ordered and installed.

The Meridian 1 Option 81C with FNF equipped with an NT4N46 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- PB requires NTRB53AA Clock Controller.
- Shortest fiber cable should be used.
- Cables from group 0 - 1 must be same length.
- Distance between each ring from group 0 - group 1 must not exceed 50 ft.



#### IMPORTANT!

The shortest fiber cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The distance between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.



To add a Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N46 Core/Net shelf:

- Clock Controller cards must be NTRB53AA.
- NTRB33 Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.

**IMPORTANT!**

When configuring NT8D76 cables, observe the following rules:

- The shortest NT8D76 Cable should always be used.
- A network group requires four NT8D76 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NT8D76 cables. Replace any cables that do not meet the above requirement.

In a Meridian 1 Option 81C CP PII, the Core/Net shelf is factory configured to house Network Group 0. For new installations, this is satisfactory, as it promotes a standard layout for Meridian 1 Option 81C installations and eases maintenance.

However, when upgrading a system with earlier processors, this configuration is not always ideal. In particular, Meridian 1 Option 71, Meridian 1 Option 81 systems, or Meridian 1 Option 81C systems that have previously been upgraded from these earlier Options frequently have Network Group 0 configured in regular Network modules.

Due to the amount of customer data and hardware reconfiguration required, customers with these configurations do not want to place group 0 in the Core/Net. Instead, the Core/Net is used to house a higher numbered group (e.g. Network group 4).

The layout of the CP PII NT4N46 Core/Net shelf does not currently lend itself to easily doing this. It is also not possible to reconfigure the CNI to Network map in software as with CP3 and CP4 processors.

This has led to non-standard cabling arrangements behind the CP PII Core, and to cases where the Network portion of the Core/Net has had to be left empty.

Nortel recommends modifying the NT4N46 shelf. These modifications can be retrofitted to existing CP PII systems equipped with the NT4N46 shelf.

Two new pieces of hardware are being introduced:

- P0942500 3PE Termination Panel, 8 group
- NT4N72AA A0860193 CNI to Core/Net Cable (19 inch.)

### 3PE Termination Panel

**Note:** Check the current termination panel to determine if it is currently a P0942599 3PE termination panel. If the panel is the older 7 group version (P0908658), it must be changed.

The 3PE Termination Panel is mounted behind the CP PII Core shelf, and is used to mount the connectors from the CNI Transition Cards. The previous panel (P0908658) has sufficient cutouts to mount the connectors for 7 groups, those corresponding to groups 1 to 7. The connectors from CNI in slot 9, port 0 typically pass through a slot in the panel and are directly connected to the

Network portion of the Core/Net backplane. Thus this panel has 14 connector cutouts. This is supplied as part of the CP PII processor complex, and does not need to be ordered separately or installed on site.

The new 3PE termination panel P0942500 differs in that it has cutouts for 16 connectors, thus allowing CNI terminations for all 8 groups to be terminated. In new systems and hardware upgrades as supplied from the factory, only 14 connectors (those corresponding to groups 1 – 7) are terminated, with the two remaining cutouts left empty.

The CNI cables corresponding to Network group 0 still pass through a slot in this panel to terminate directly on the Network backplane, and this is how new systems continue to be delivered. However, it is possible to disconnect these Group 0 connectors from the Network backplane and mount them into the panel, which facilitates connecting 3PE cables connected to a remote Network group 0.

These new panels are included as standard on all CP PII NT4N46 shelf systems manufactured after February 18th 2002. The panels are also included with hardware upgrades, beginning approximately with the introduction of X11/25.40 software in early 2002. The panels are also available as merchandise to retrofit into any CP PII system installed prior to then.

### **NT4N72AA cable**

This short (19 inch – 48 cm.) cable is designed to interconnect the connectors mounted in the 3PE Termination Panel discussed above to the 3PE Network connectors on the Network portion of the Core/Net backplane. Any Network group CNI cards are easily connected to the Network backplane, allowing any Network group to be placed in the Core/Net.

Two cables are required in each CP PII module, and 4 are required in a complete Meridian 1 Option 81C CP PII system. These cables are not required when Network group 0 is installed in the Core/Net shelf, since the CNI Transition Card cables for group 0 pass directly through the 3PE Termination Panel and terminate on the Network backplane (the standard factory configuration). These cables are delivered as part of any marketing packages, and have to be ordered as merchandise when needed.

***Note:*** It is still required that the two Core/Net shelves only contain a single Network group. For example, it is not possible to place one half of Group 1 in a Core/Net shelf and the other half in a Network shelf, and then proceed to split up Group 2 in the same way using the other Core/Net shelf.

## **Prepare for upgrade**

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions. Each section assumes any NT8D35 Network module

installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade, field personnel should follow the steps in Table 53.

**Table 53**  
**Prepare for upgrade steps**

Procedure Step	Page
Plan the upgrade	<a href="#">284</a>
Upgrade checklists	<a href="#">285</a>
Prepare	<a href="#">285</a>
Identifying the proper procedure	<a href="#">286</a>
Connect a terminal	<a href="#">286</a>
Print site data	<a href="#">287</a>
Perform a template audit	<a href="#">289</a>
Back up the database (data dump)	<a href="#">292</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.

- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Network Alerts that impact the site.
- Determine a contingency plan for backing out of the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Install Current patch or Dep lists at the source platform.
- Install Current patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.

- Perform an inventory on required software and hardware.
- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.

## Connect a terminal

### **Procedure 85** **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2 The settings for the terminal are:
  - a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 3 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (see Table 54). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 54**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 54**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>



**Table 54**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on Large Systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)



### IMPORTANT!

Preserve database backup information for a minimum of 5 days.

To backup existing data, perform the following procedure:

### Procedure 86

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When "EDD000" appears on the terminal, enter:

**EDD** Begin the data dump.



### CAUTION — Service Interruption

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\* Exit the program.

---

**End of Procedure**

---


## Perform the upgrade

### Introduction

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/FNF equipped with an NT4N46 shelf.

Figure 37 shows a Meridian 1 Option 81C/FNF (NT4N46).

**Figure 37**  
**Meridian 1 Option 81C/FNF (NT4N46)**




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/FNF (NT4N46).

Figure 38 shows the NT4N46 Core/Net shelf.

**Figure 38**  
**NT4N46 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### CAUTION — Service Interruption

DO NOT proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- NTRB53AA Clock Controller
- NTRB33 AC or AD FIJI

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### CAUTION — Service Interruption

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

### Check required hardware

Table 55 describes the *minimum* equipment required to add a Core Network Group to a Meridian 1 Option 81C/FNF equipped with an NT4N46 shelf. Additional equipment for increased Network capacity must be ordered separately.

**Table 55**  
**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT4N46 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC47	FIJI to FIJI Cable	1
NT4N72	CNI to Core/Net Cable	4
PO942500	16-connector cutout 3PE Termination Panel	2
NTRC48	fiber-optic cables	2



## Tools

Table 56 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 56**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Placing a Group other than Group 0 in the core

### Procedure 87

#### Placing a Group other than Group 0 in the core

If it is desired to modify a system that is already installed, or is currently being installed, so that a group other than Group 0 is in the Core/Net, some reconfiguration of the factory arrangement will be required.

Complete the following steps on **both** Core/Net modules.

- 1 Power down the Core/Net shelf (after transferring call processing to the other Core if required).
- 2 Ensure that the 16-connector cutout 3PE Termination Panel P0942500 is equipped. This can be retrofitted into systems initially equipped with the 14-connector cutout Panel P0908658 by removing all the cable connectors and then the 4 screws that attach the panel to its frame.

- 3 Remove the connections from the Network backplane connectors that originate from CNI card 9, port 0. This may involve removing the screws that hold in the panel, so that the connectors can be moved through the slot.
- 4 Connect all eight pairs of cables from the CNI Transition Cards to this panel.
- 5 Using two cables NT4N72AA, connect the appropriate pair of connectors on the 3PE Termination Panel corresponding to the desired Group to the two connectors on the Network backplane.
- 6 Use standard NT8D76 cables to connect all other groups, including Group 0, to the 3PE cards in the respective Network modules.
- 7 Restore power to the Core/Net shelf, transfer call processing if required, and proceed to upgrade the other Core/Net shelf.

---

**End of Procedure**

---

## **Route FIJI to FIJI cables**

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group.

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.

**Note:** Do not disconnect the existing Fiber cables.

**Procedure 88****Labeling and routing the shelf 0 fiber-optic cables (ascending)**

Route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order.

**CAUTION****Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 57 on [page 300](#).
- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4 If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5 Continue to route the NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

**IMPORTANT!**

The shortest Fiber Cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0

The distance between the lengths of each fiber ring from group 0 to any other group must not exceed 50'. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional network group, fiber cables must be changed to adhere to the rules above.

- 6 To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 57**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

————— End of Procedure —————

**Procedure 89****Labeling and routing the shelf 1 fiber-optic cables (descending)**

Route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 39 on [page 302](#)).

**CAUTION****Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note 1:** Do not disconnect existing Fiber cables

**Note 2:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1 Start with Group 0, shelf 1.
- 2 Label each cable on both sides with the appropriate connection information from Table 58 on [page 303](#).
- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4 Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5 Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths *between* shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6 Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 39**  
**Shelf 1 descending fiber-optic Ring (example)**



**Table 58**  
**FIJI Ring 1 connections**

Groups 0 - X are cabled in descending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2

## Interconnect the network modules


On the back of each Core/Net module backplanes are two connectors labeled D and E.

### Procedure 90 Interconnecting the network modules

- 1 Connect the NT8D99AD cable from the D connector in shelf 0 to the D connector in shelf 1 of the NT4N46 Core/Net Module.
- 2 Connect the NT8D99AD cable from the E connector in shelf 0 to the E connector in shelf 1 of the NT4N46 Core/Net Module.

End of Procedure

**Figure 40**  
Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)





## Add CNI cards if necessary


If additional CNI cards are required, add to each Core Module as required. See Figure 41.

### Procedure 91 Adding CNI cards

- 1 Face plate disable CNI card.
- 2 Insert card into Core/Net module, but do not seat card into backplane at this time.

**End of Procedure**

**Figure 41**  
**Core/Net card cage**



### Procedure 92

#### Connecting the 3PE to CNI cables

Using two NT4N72AA cables, connect the appropriate pair of connectors on the 3PE Termination Panel corresponding to the desired Group to the two connectors on the Network backplane.

The CNI slot and port connections are labeled on the 3PE Fanout Panel. See Table 59, and Figure 42 on [page 308](#) for NT8D72 cable connections.

- 1 Connect the NT4N72 cables to Core/Net backplane of the 3PE cards.
- 2 Connect the new NT4N72 cables to the Fanout Panel in the Core/Net.

**Table 59**  
**Fanout Panel to 3PE card connectors**

Group Number	Connects from the Fanout Panel connector	To the 3PE card connector
0	9-0, J3	J3
0	9-0, J4	J4
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4

**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 **or** to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.


- 3** Connect NT8D80BZ cable from J3 of the 3PE card in Core 0 to the J3 of 3PE card in Core 1.
- 4** Connect NT8D80BZ cable from J4 of the 3PE card in Core 0 to the J4 of 3PE card in Core 1.

---

**End of Procedure**

---

**Figure 42**  
**3PE Termination Panel (Core/Net module)**



## **Install cards in the network modules**

Network cards must be installed in the Core/Net modules as described below. Each card must be installed and enabled or disabled as indicated.

## **Install and enable the QPC441 3PE cards**

### **Procedure 93**

#### **Installing and enable the QPC441 3PE cards**

Three steps are required to install the QPC441 3PE cards.

- 1** Verify the QPC441 3PE card settings.

The group and shelf number of each Network module is determined by the switch settings on the QPC441 3PE card. Use the information in Table 60 on [page 310](#) to verify that the QPC441 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2** Install a QPC441 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

3     Attach the cables to the QPC441 3PE faceplates.

**Table 60**  
**QPC441 3PE Card installed in the NT4N46 Module**

<b>Jumper settings.</b> Set Jumper RN27 at E35 to “A”.									
Switch Settings									
Module		D20 switch position							
NT4N46 (Option 81C CP PII)		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
	Group 1	off	on	on	off	on	on	off	on
	Group 2	off	on	on	off	on	off	on	on
	Group 3	off	on	on	off	on	off	off	on
	Group 4	off	on	on	off	off	on	on	on
	Group 5	off	on	on	off	off	on	off	on
	Group 6	off	on	on	off	off	off	on	on
	Group 7	off	on	on	off	off	off	off	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off
	Group 1	off	on	on	off	on	on	off	off
	Group 2	off	on	on	off	on	off	on	off
	Group 3	off	on	on	off	on	off	off	off
	Group 4	off	on	on	off	off	on	on	off
	Group 5	off	on	on	off	off	on	off	off
	Group 6	off	on	on	off	off	off	on	off
	Group 7	off	on	on	off	off	off	off	off

————— **End of Procedure** —————

## Install and enable the QPC43R Peripheral Signaling (Per Sig) cards

### Procedure 94

#### Installing and enable the Peripheral Signaling (Per Sig) cards

- 1 Install a Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

End of Procedure

---

## Disable and insert the NTRB33AC FIJI cards

### Procedure 95

#### Disabling and inserting the FIJI cards

- 1 Faceplate *disable* the FIJI cards.
- 2 Insert the FIJI cards into slots 2 and 3 of each added Network module.
- 3 Do not plug the card into the backplane.

---

End of Procedure

---

## Disable and insert the NT8D17 Conf/TDS cards

### Procedure 96

#### Disabling and inserting the Conf/TDS cards

If Conf/TDS cards are used in the system, complete the steps below.

- 1 Faceplate *disable* the Conf/TDS cards.
- 2 Insert a Conf/TDS card into each added Network module.
- 3 Do not plug the card into the backplane.

---

End of Procedure

---

## Enable the Network Group

*Note:* If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

### Procedure 97

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135** Load program

**STAT CPU** Get status of the CPUs

- 2 If Core 1 is active, make Core 0 active:

**SCPU** Switch to Core 0 (if necessary)

**\*\*\*\*** Exit program

---

**End of Procedure**

---



**Procedure 98****Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

<b>LD 60</b>	Load program
<b>SSCK 0</b>	Get the status of Clock Controller 0
<b>SSCK 1</b>	Get the status of Clock Controller 1

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

<b>SWCK</b>	Switch to Clock Controller 0 (if necessary)
<b>DIS CC 1</b>	Disable Clock Controller 1
<b>****</b>	Exit program

---

**End of Procedure**

---

**Add the CNI cards or ports****Procedure 99****Adding the CNI cards or ports**

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

- 1 In OVL 135 split the Cores.

<b>LD 135</b>	To load the program.
<b>SPLIT</b>	Split the Cores.
<b>****</b>	To exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1:

- 2    On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 69 on [page 357](#).

<b>LD 17</b>	To load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	To exit the program.

- 3    Perform a data dump

<b>LD 43</b>	To load the program.
<b>EDD</b>	Invoke data dump program.
<b>****</b>	To exit the program.

Table 61 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 61**  
**Fanout Panel to 3PE card connectors**

Group Number	Connects from the Fanout Panel connector	To the 3PE card connector
0	9-0, J3	J3
0	9-0, J4	J4
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4

**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 **or** to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.

End of Procedure

**Procedure 100**  
**Checking that Ring 0 is active in Core 0**

- 1    Check the status of Ring 0.

**LD 39**                    Load program

**STAT RING 0**    Get the status of Ring 0  
                                  (Ring state should be HALF/HALF)

- 2    Disable Ring auto recovery.

**LD 39**                    Load program

**ARCV OFF**        Set or reset auto-recovery operation for ring

- 3    Swap to Ring 0.

**LD 39**                    Load program

**SWRG 0**            Swing Traffic to Ring x.

- 4    Disable Ring 1.

**LD 39**                    Load program

**DIS RING 1**        Disable all FIJI cards on side 1



**WARNING**

Cable Ring 1 to new network shelf only.

- 5    Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).

- 7 Break Ring 1 and cable the added FIJI cards. Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.



### IMPORTANT!

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



### CAUTION

#### Service Interruption

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 9 In LD 135 switch Cores.

**LD 135**

To load the program.

**CUTOVR**

Switch Cores.



### WARNING

All call processing may be interrupted.



### IMPORTANT!

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.

**Note 1:** On FNF based systems after the INI:  
A FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

**10** Switch the clock controllers, if necessary:

- LD 60**                      To load the program.
- SSCK n**                    Get status of clock n where  
n = 0 for clock controller 0  
1 for clock controller 1
- SWCK**                      Switch system clock from active to standby.
- Note:** Make clock controller 1 the active clock.
- \*\*\*\***                        To exit the program.

**11** Disable Ring 0.

- LD 39**                      To load the program.

**DIS RING 0**                      Disables all FIJI cards on side 0.

\*\*\*\*                                  To exit the program.

- 12** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

- 13** In LD 39, enable and stat Ring 0:

**LD 39**                                  To load the program.

ENL Ring 0                          Enable Ring 0.

Stat Ring 0                          Status of Ring x.

\*\*\*\*                                  To exit the program.

- 14** In **Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 69 on [page 357](#):

**LD 17**                                  To load the program.

**REQ**                                    CHG

**TYPE**                                CEQU

**XCT X**                                X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                          Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                    Continue to the last prompt.

**\*\*\*\***                    To exit the program.

**15** Data dump the software changes.

**LD 43**                    To load the program.

**EDD**                    Invoke data dump program.

**\*\*\*\***                    To exit the program.

**16** Seat the CNI card in Core 0 and faceplate enable it.

**17** In Core 1, Stat the CNIs:

**LD 135**                    Load the program.

**STAT CNI**                Get status of CNI card.

**Note:** If any CNIs are disabled they must  
be enabled.

**JOIN**                    Synchronize the memory and drives.

**\*\*\*\***                    To exit the program.

---

**End of Procedure**

---



## Test the Cores

### Procedure 101

#### Testing Core/Net 1

From Core/Net 1, perform these tests.

- 1 Perform a redundancy sanity test:

<b>LD 135</b>	Load the program.
<b>STAT CPU</b>	Get status of CPU and memory.
<b>TEST CPU</b>	Test the CPU.

- 2 Check the LCD states:

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

<b>LD 135</b>	Load the program.
<b>TEST LCDs</b>	Test LCDs.
<b>DSPL ALL</b>	

- 3 Test the System Utility cards and the CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT SUTL</b>	Get the status of the System Utility (main and Transition) cards.
<b>TEST SUTL</b>	Test the System Utility (main and Transition) cards.
<b>STAT CNI c s</b>	Get status of CNI cards (core, slot).
<b>TEST CNI c s</b>	Test CNI (core, slot).

- 4 Test system redundancy.

<b>LD 137</b>	Load the program.
<b>TEST RDUN</b>	Test redundancy.

**DATA RDUN**

**TEST CMDU**      Test the MMDU card.

- 5 Install the two system monitors. Test that the system monitors are working.

**LD 37**              Load the program.

**ENL TTY x**        Enable the XMS, where x= system XMS.

**STAT XSM**        Check the system monitors.

**\*\*\*\***              Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135**            Load the program.

**CDSP**             Clear the displays on the cores.

**CMAJ**             Clear major alarms.

**CMIN ALL**        Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60**             Load the program.

**SSCK x**            To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**             Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK**             Switch the Clock.

**SWCK**             Switch the Clock again.

**8 Test the Fiber Rings**

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.** Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- b.** If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c.** Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

**9 Check the status of the FIJI alarms.**

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\*** Exit program.

**10 Check applications such as CallPilot, Symposium, and Meridian Mail..****11 Check for dial tone.**

---

**End of Procedure**

---

**Procedure 102**  
**Switching call processing**

- |               |   |
|---------------|---|
| <b>LD 135</b> | Load the program.                                     |
| <b>SCPU</b>   | Switch call processing from Core/Net 1 to Core/Net 0. |

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 103**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1    Perform a redundancy sanity test:

- |                 |                               |
|-----------------|-------------------------------|
| <b>LD 135</b>   | Load the program.             |
| <b>STAT CPU</b> | Get status of CPU and memory. |
| <b>TEST CPU</b> | Test the CPU.                 |

- 2    Check the LCD states

- a.   Perform a visual check of the LCDs.
  - b.   Test LCDs.

- |                  |                   |
|------------------|-------------------|
| <b>LD 135</b>    | Load the program. |
| <b>TEST LCDs</b> | Test LCDs.        |
| <b>DSPL ALL</b>  | Display all.      |

- 3    Test the System Utility cards and the CNI cards.

- |                  |   |
|------------------|---|
| <b>LD 135</b>    | Load the program.   |
| <b>STAT SUTL</b> | Get the status of the System Utility (main and Transition) cards. |
| <b>TEST SUTL</b> | Test the System Utility (main and Transition) cards.              |

**STAT CNI c s**      Get status of CNI cards (core, slot).

**TEST CNI c s**      Test CNI (core, slot).

**4**    Test system redundancy.

**LD 137**              Load the program.

**TEST RDUN**        Test redundancy.

**DATA RDUN**

**TEST CMDU**        Test the MMDU card.

**5**    Test that the system monitors are working.

**LD 37**              Load the program.

**STAT XSM**        Check the system monitors.

**\*\*\*\***                Exit the program.

**6**    Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP**              Clear the displays on the cores.

**CMAJ**              Clear major alarms.

**CMIN ALL**        Clear minor alarms.

7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

8 Test the Fiber Rings

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- 9** Check the status of the FIJI alarms.

**STAT ALRM**

Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\*

Exit program.

- 10** Check applications (such as CallPilot and Symposium).

- 11** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 451](#).

## Add an NT8D35 Network Group to Option 81C/FNF CP PII

### Introduction

The target platform, the Meridian 1 Option 81C/FNF (NT4N46) must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- PB requires NTRB53AA Clock Controller.
- shortest fiber cable should be used.
- cables from group 0 - 1 must be same length.
- Distance between each ring from group 0 - group 1 must not exceed 50 ft.



#### IMPORTANT!

The shortest Fiber Cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0

The distance between the lengths of each fiber ring from group 0 to any other group must not exceed 50'. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.

To add an NT8D35 Network Group to a Meridian 1 Option 81C/FNF (NT4N46) system:

- Clock Controller cards must be NTRB53AA.



NTRB33 AC/AD Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.

**IMPORTANT!**

When configuring NT8D76 cables, observe the following rules:

- The shortest NT8D76 Cable should always be used.
- A network group requires 4 NT8D76 cables, 2 to each half group. Both cables to each half group must be the same length.
- A check should be made on the existing NT8D76 cables. Replace any cables that do not meet the above requirement.

## Prepare for upgrade

### Introduction

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel should complete the steps in Table 62.

**Table 62**  
**Prepare for upgrade steps**

Procedure Step	Page
Plan the upgrade	<a href="#">330</a>
Upgrade checklists	<a href="#">331</a>
Prepare	<a href="#">331</a>
Identifying the proper procedure	<a href="#">332</a>
Connect a terminal	<a href="#">332</a>
Print site data	<a href="#">333</a>
Perform a template audit	<a href="#">335</a>
Back up the database (data dump)	<a href="#">338</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- A contingency plan for backing out of the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Current patch or Dep lists installed at the source platform.
- Required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Preserve database backup information for a minimum of 5 days.

## Connect a terminal

### Procedure 104 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2 The settings for the terminal are:
  - a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 3 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (see Table 63). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 63**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 63**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

**Table 63**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.



**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 105

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43**                      Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\*                      Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of 5 days.

---

**End of Procedure**


---

## Perform the upgrade

### Introduction

Figure 43 shows a Meridian 1 Option 81C/FNF (NT4N46).

**Figure 43**  
**Meridian 1 Option 81C/FNF (NT4N46)**




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add an NT8D35 Network Group to the Meridian 1 Option 81C/FNF (NT4N46).

**Figure 44**  
**NT4N46 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### CAUTION — Service Interruption

##### Service Interruption

DO NOT proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- NTRB53AA Clock Controller
- NTRB33AC/AD FIJI

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### CAUTION — Service Interruption

##### Service Interruption

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

### Check required hardware

Table 64 describes the *minimum* equipment required to upgrade a system. Additional equipment for increased Network capacity must be ordered separately. Check required power equipment

**Table 64**  
**Minimum equipment required to add an NT8D35 Network Group to an Option 81C/FNF equipped with an NT4N46 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 6 ft.	5
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC47	FIJI to FIJI Cable	1
NT8D76	CNI to 3PE Cables	4
NT8D35	Network Shelves	2
NTRC48	Fiber-Optic cables	2

## Tools

Table 65 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 65**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Check personnel requirements

Nortel recommends that a minimum of two people perform the upgrade.


## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group. See Figure 45 on [page 344](#).

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.


**Note:** Do not disconnect the existing Fiber cables.

**Figure 45**  
**FIJI to FIJI cables (Option 81C example)**



**Procedure 106**  
**Labeling and routing the shelf 0 fiber-optic cables (ascending)**

Route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order (Table 57 on [page 300](#)):



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 66 on [page 346](#).



- 3 Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4 If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5 Continue to route NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6     To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 66**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

————— End of Procedure —————

**Procedure 107****Labeling and routing the shelf 1 fiber-optic cables (descending)**

Route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 46 on [page 348](#)).

**CAUTION****Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1 Start with Group 0, shelf 1.
- 2 Label each cable on both sides with the appropriate connection information from Table 67 on [page 349](#).
- 3 Route an NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4 Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5 Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6 Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 46**  
**Shelf 1 descending fiber-optic Ring (example**



)

**Table 67**  
**FIJI Ring 1 connections**

Groups 0 - X are cabled in descending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2

### Procedure 108

#### Interconnecting the network modules

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 47 on [page 351](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group.

- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3 Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4 Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5 Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6 Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0).


**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**

---

**Figure 47**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



### Add CNI cards if necessary

If additional CNI cards are required, add to each Core Module as required.  
 See Figure 48.


## Procedure 109

### Adding CNI cards

- 1 Faceplate disable CNI card.
- 2 Insert card into Core/Net module, but do not seat card into backplane at this time.

## End of Procedure

**Figure 48**  
**NT4N46 Core/Net card cage**





**Procedure 110****Connecting the 3PE to CNI cables**

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 68, Figure 49 on [page 354](#), and Figure 50 on [page 355](#) for NT8D76 cable connections.

- 1 Connect the NT8D76 cables to J3 and J4 of the 3PE cards.
- 2 Connect the new NT8D76 cables to the Fanout Panel in the Core/Net.


**Table 68**  
**Fanout Panel to 3PE card connectors**

Group Number	Connects from the Fanout Panel connector	To the 3PE card connector
0	9-0, J3	J3
0	9-0, J4	J4
1	9-1, J3	J3
1	9-1, J4	J4
2	10-0, J3	J3
2	10-0, J4	J4
3	10-1, J3	J3
3	10-1, J4	J4
4	11-0, J3	J3
4	11-0, J4	J4
5	11-1, J3	J3
5	11-1, J4	J4
6	12-0, J3	J3
6	12-0, J4	J4
7	12-1, J3	J3
7	12-1, J4	J4


**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 **OR** to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.

————— End of Procedure —————

**Figure 49**  
**Example of 3PE faceplate to 3PE Fanout Panel connection**



**Figure 50**  
**3PE Fanout Panel (Core/Net module)**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### Procedure 111

#### Installing and enabling the 3PE cards

- 1 Verify the 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 69 on [page 357](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2 Install a 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

**3** Attach the cables to the 3PE faceplates.**Table 69**  
**3PE card settings for the NT8D35 Module**

<b>Jumper Settings</b>								
Set Jumper RN27 at E35 to "A".								
<b>Switch Settings</b>								
D20 switch position:		<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>			
81, 81C (Note)		off	on	on	on			
Shelf	Group	<b>D20 switch position:</b>				<b>5</b>	<b>6</b>	<b>7</b>
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on
	1					on	on	off
	2					on	off	on
	3					on	off	off
	4					off	on	on
	5					off	on	off
	6					off	off	on
	7					off	off	off
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on
	1					on	on	off
	2					on	off	on
	3					on	off	off
	4					off	on	on
	5					off	on	off
	6					off	off	on
	7					off	off	off

**End of Procedure**

**Procedure 112**

**Installing and enabling the QPC43R Peripheral Signaling cards**

- 1 Install a Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 113**

**Disabling and inserting the NTRB33AC FIJI cards**

- 1 Faceplate *disable* the FIJI cards.
- 2 Insert the FIJI cards into slots 2 and 3 of each added Network module.
- 3 Do not plug the card into the backplane.

---

**End of Procedure**

---

**Procedure 114**

**Disabling and inserting the NT8D17 Conf/TDS cards**

If Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the Conf/TDS cards.
- 2 Insert a Conf/TDS card into each added Network module.
- 3 Do not plug the card into the backplane.

---

**End of Procedure**

---

## Enable the Network Group

*Note:* If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

### Procedure 115

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135**            Load program

**STAT CPU**        Get status of the CPUs

- 2 If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary)

**\*\*\*\***            Exit program

---

**End of Procedure**

---

**Procedure 116**

**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

<b>LD 60</b>	Load program
<b>SSCK 0</b>	Get the status of Clock Controller 0
<b>SSCK 1</b>	Get the status of Clock Controller 1

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

<b>SWCK</b>	Switch to Clock Controller 0 (if necessary)
<b>DIS CC 1</b>	Disable Clock Controller 1
<b>****</b>	Exit program

---

**End of Procedure**

---

## **Add the CNI cards or ports**

**Procedure 117**

**Adding the CNI cards or ports**

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

- 1 In OVL 135 split the Cores.

<b>LD 135</b>	To load the program.
<b>SPLIT</b>	Split the Cores.
<b>****</b>	To exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1:



- 2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 69 on [page 357](#):

<b>LD 17</b>	To load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	To exit the program.

Table 70 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

Table 70  
 Fanout Panel to 3PE card connectors

Group Number	connects from	Fanout Panel connector	to	3PE card connector
0		9-0, J3		J3
0		9-0, J4		J4
1		9-1, J3		J3
1		9-1, J4		J4
2		10-0, J3		J3
2		10-0, J4		J4
3		10-1, J3		J3
3		10-1, J4		J4
4		11-0, J3		J3
4		11-0, J4		J4
5		11-1, J3		J3
5		11-1, J4		J4
6		12-0, J3		J3
6		12-0, J4		J4
7		12-1, J3		J3
7		12-1, J4		J4

**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 **or** to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.

- 3
Perform a data dump:
- LD 43

To load the program.
- EDD

Invoke data dump program.
- \*\*\*\*

To exit the program.

End of Procedure

**Procedure 118**  
**Checking that Ring 0 is active in Core 0**

- 1 Check the status of Ring 0.

**LD 39** Load program

**STAT RING 0** Get the status of Ring 0  
(Ring state should be HALF/HALF)

- 2 Disable Ring auto recovery.

**LD 39** Load program

**ARCV OFF** Set or reset auto-recovery operation for ring

- 3 Swap to Ring 0.

**LD 39** Load program

**SWRG 0** Swing Traffic to Ring x.

- 4 Disable Ring 1.

**LD 39** Load program

**DIS RING 1** Disable all FIJI cards on side 1

**WARNING**

Cable Ring 1 to new network shelf only.

- 5 Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6 Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).

- 7 Break Ring 1 and cable the added FIJI cards. See Figure 39 on [page 302](#). Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION**

**Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 9 In LD 135 switch Cores.

**LD 135**

To load the program.

**CUTOVR**

Switch Cores



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.



### CAUTION

#### Service Interruption

Allow the system to recover from all downloads after the INI completes.

**Note 1:** On FNF based systems after the INI:

A FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

#### 10 Switch the clock controllers, if necessary:

<b>LD 60</b>	To load the program.
<b>SSCK n</b>	Get status of clock n where n = 0 for clock controller 0 1 for clock controller 1

SWCK

Switch system clock from active to standby.

**Note:** Make clock controller 1 the active clock.

\*\*\*\*

To exit the program.

11 Disable Ring 0.

LD 39

To load the program.


DIS RING 0

Disable Ring 0.

\*\*\*\*

To exit the program.

12 Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

13 In LD 39, enable and stat Ring 0:.

LD 39

To load the program.

ENL Ring 0

Enable Ring 0.

Stat Ring 0

Status of Ring x.

\*\*\*\*

To exit the program.

14 In Core 0 only, define the XCT and Extenders to the added group.

**Note:** See Table 69 on [page 357](#):

LD 17

To load the program.

REQ

CHG

TYPE

CEQU

**XCT X** X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g** Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g** Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>** Continue to the last prompt.

**\*\*\*\*** To exit the program.

**15** Data dump the software changes.

**LD 43** To load the program.

**EDD** Invoke data dump program.

**\*\*\*\*** To exit the program.

**16** Seat the CNI card in Core 0 and faceplate enable it.

17   In Core 1, Stat the CNIs:

**LD 135**            Load the program.

**STAT CNI**        Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN**            Synchronize the memory and drives.

**\*\*\*\***            To exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 119

#### Testing Core/Net 1

From Core/Net 1, perform these tests.

1    Perform a redundancy sanity test:

**LD 135**            Load the program.

**STAT CPU**        Get status of CPU and memory.

**TEST CPU**        Test the CPU.

2    Check the LCD states

a.   Perform a visual check of the LCDs.

b.   Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**        Test LCDs.

**DSPL ALL**



**3** Test the System Utility cards and the CNI cards.

- LD 135** Load the program.
- STAT SUTL** Get the status of the System Utility (main and Transition) cards.
- TEST SUTL** Test the System Utility (main and Transition) cards.
- STAT CNI c s** Get status of CNI cards (core, slot).
- TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

- LD 137** Load the program.
- TEST RDUN** Test redundancy.
- DATA RDUN**
- TEST CMDU** Test the MMDU card.

**5** Install the two system monitors. Test that the system monitors are working.

- LD 37** Load the program.
- ENL TTY x** Enable the XMS, where x= system XMS.
- STAT XSM** Check the system monitors.
- \*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

- LD 135** Load the program.
- CDSP** Clear the displays on the cores.
- CMAJ** Clear major alarms.
- CMIN ALL** Clear minor alarms.

7    Test the clocks.

- a.    Verify that the clock controller is assigned to the *active* Core.

**LD 60**                    Load the program.

**SSCK x**                To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**                Switch the Clock if necessary.

- b.    Verify that the Clock Controllers are switching correctly.

**SWCK**                Switch the Clock.

**SWCK**                Switch the Clock again.

8    Test the Fiber Rings

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.    Check that the Fiber Rings operate correctly.

**LD 39**                    Load the program.

**STAT RING 0**        Check the status of Ring 0 (HALF/HALF).

**STAT RING 1**        Check the status of Ring 1 (HALF/HALF).

- b.    If necessary, restore the Rings to Normal State.

**RSTR**                Restore both Rings to HALF state.

- c.    Check that the Rings operate correctly.

**STAT RING 0**        Check the status of Ring 0 (HALF/HALF).

**STAT RING 1**        Check the status of Ring 1 (HALF/HALF).

9    Check the status of the FIJI alarms.

**STAT ALRM**        Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\***                Exit program.

- 10** Check applications such as CallPilot, Symposium, and Meridian Mail..
- 11** Check for dial tone.

---

**End of Procedure**

---

**Procedure 120**  
**Switching call processing**

- |               |   |
|---------------|---|
| <b>LD 135</b> | Load the program.                                     |
| <b>SCPU</b>   | Switch call processing from Core/Net 1 to Core/Net 0. |

Core/Net 1 will initialize and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 121**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1** Perform a redundancy sanity test:

<b>LD 135</b>	Load the program.
<b>STAT CPU</b>	Get status of CPU and memory.
<b>TEST CPU</b>	Test the CPU.
- 2** Check the LCD states
  - a.** Perform a visual check of the LCDs.
  - b.** Test LCDs.

<b>LD 135</b>	Load the program.
<b>TEST LCDs</b>	Test LCDs.
<b>DSPL ALL</b>	Display all.

- 3    Test the System Utility cards and the CNI cards.
- LD 135**            Load the program.
- STAT SUTL**        Get the status of the System Utility (main and Transition) cards.
- TEST SUTL**        Test the System Utility (main and Transition) cards.
- STAT CNI c s**      Get status of CNI cards (core, slot).
- TEST CNI c s**      Test CNI (core, slot).
- 4    Test system redundancy.
- LD 137**            Load the program.
- TEST RDUN**        Test redundancy.
- DATA RDUN**
- TEST CMDU**        Test the MMDU card.
- 5    Test that the system monitors are working.
- LD 37**            Load the program.
- STAT XSM**        Check the system monitors
- \*\*\*\*              Exit the program.
- 6    Clear the display and minor alarms on both Cores.
- LD 135**
- CDSP**            Clear the displays on the cores.
- CMAJ**            Clear major alarms.
- CMIN ALL**        Clear minor alarms.
- 7    Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Test the Fiber Rings

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

**9** Check the status of the FIJI alarms.

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\* Exit program.

- 10** Check applications (such as CallPilot and Symposium).
- 11** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 451](#).

## Add a Core Network Group to Option 81C/IGS CP PII

### Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

### 3PE Termination Panel

**Note:** Check the current termination panel to determine if it is currently a P0942599 3PE termination panel. If the panel is the older 7 group version (P0908658), it must be changed.

The 3PE Termination Panel is mounted behind the CP PII Core shelf, and is used to mount the connectors from the CNI Transition Cards. The previous panel (P0908658) has sufficient cutouts to mount the connectors for 7 groups, those corresponding to groups 1 to 7. The connectors from CNI in slot 9, port 0 typically pass through a slot in the panel and are directly connected to the

Network portion of the Core/Net backplane. Thus this panel has 14 connector cutouts. This is supplied as part of the CP PII processor complex, and does not need to be ordered separately or installed on site.

The new 3PE termination panel P0942500 differs in that it has cutouts for 16 connectors, thus allowing CNI terminations for all 8 groups to be terminated. In new systems and hardware upgrades as supplied from the factory, only 14 connectors (those corresponding to groups 1 – 7) are terminated, with the two remaining cutouts left empty.

The CNI cables corresponding to Network group 0 still pass through a slot in this panel to terminate directly on the Network backplane, and this is how new systems continue to be delivered. However, it is possible to disconnect these Group 0 connectors from the Network backplane and mount them into the panel, which facilitates connecting 3PE cables connected to a remote Network group 0.

These new panels are included as standard on all CP PII NT4N46 shelf systems manufactured after February 18th 2002. The panels are also included with hardware upgrades, beginning approximately with the introduction of X11/25.40 software in early 2002. The panels are also available as merchandise to retrofit into any CP PII system installed prior to then.

## NT4N72AA cable

This short (19 inch – 48 cm.) cable is designed to interconnect the connectors mounted in the 3PE Termination Panel discussed above to the 3PE Network connectors on the Network portion of the Core/Net backplane. Any Network group CNI cards are easily connected to the Network backplane, allowing any Network group to be placed in the Core/Net.

Two cables are required in each CP PII module, and 4 are required in a complete Meridian 1 Option 81C CP PII system. These cables are not required when Network group 0 is installed in the Core/Net shelf, since the CNI Transition Card cables for group 0 pass directly through the 3PE Termination Panel and terminate on the Network backplane (the standard factory configuration). These cables are delivered as part of any marketing packages, and have to be ordered as merchandise when needed.

**Note:** It is still required that the two Core/Net shelves only contain a single Network group. For example, it is not possible to place one half of Group 1 in a Core/Net shelf and the other half in a Network shelf, and then proceed to split up Group 2 in the same way using the other Core/Net shelf.



Before attempting any software or hardware upgrade field personnel should follow the steps in Table 71.

**Table 71**  
**Prepare for upgrade steps**

<b>Procedure Step</b>	<b>Page</b>
Plan the upgrade	<a href="#">377</a>
Upgrade checklists	<a href="#">378</a>
Prepare	<a href="#">378</a>
Identifying the proper procedure	<a href="#">379</a>
Connect a terminal	<a href="#">379</a>
Print site data	<a href="#">379</a>
Perform a template audit	<a href="#">382</a>
Back up the database (data dump)	<a href="#">384</a>

## **Plan the upgrade**

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- A contingency plan for backing out of the upgrade.



#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## **Upgrade checklists**

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## **Prepare**

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Current patch or Dep lists installed at the source platform.
- Required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.

## Connect a terminal

### Procedure 122

#### Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- The settings for the terminal are:
  - a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF

If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (see Table 63). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 72**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN

**Table 72**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 72**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



### **CAUTION — Service Interruption**

#### **Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

### **TEMPLATE AUDIT**

#### **STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

#### **STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 123

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43**                      Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\*                      Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of 5 days.

---

**End of Procedure**

---



# Perform the upgrade

## Introduction




### DANGER OF ELECTRIC SHOCK

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/IGS (NT4N46).

Figure 51 shows the NT4N46 Core/Net shelf.

**Figure 51**  
**CP PII NT4N46 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII with IGS. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

DO NOT proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 73 describes the *minimum* equipment required to add a Network Group to Meridian 1 Option 81C/IGS CP PII (NT4N46). Additional equipment for increased Network capacity must be ordered separately.

**Table 73**  
**Minimum equipment required to add a Core Network Group to an Option 81C/IGS equipped with an NT4N46 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT8D76	IGS to IGM DIGS cards cable	4
NT4N72	CNI Core/Net Cable	4
PO942500	16-connector cutout 3PE Termination Panel	2
NT5D30	Dual IGS card	2
NT4N65AC	CNI card	4

Tools

Table 56 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 74**  
**List of recommended tools**


Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

Placing a Group other than Group 0 in the core

**Procedure 124**  
**Placing a Group other than Group 0 in the core**

If it is desired to modify a system that is already installed, or is currently being installed, so that a group other than Group 0 is in the Core/Net, some reconfiguration of the factory arrangement will be required.

**Figure 52**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



Complete the following steps on **both** Core/Net modules.

- 1 Power down the Core/Net shelf (after transferring call processing to the other Core if required).
- 2 Ensure that the 16-conductor cutout 3PE Termination Panel P0942500 is equipped. This can be retrofitted into systems initially equipped with the 14-conductor cutout Panel P0908658 by removing all the cable connectors and then the 4 screws that attach the panel to its frame.

- 3 Remove the connections from the Network backplane connectors that originate from CNI card 9, port 0. This may involve removing the screws that hold in the panel, so that the connectors can be moved through the slot.
- 4 Connect all eight pairs of cables from the CNI Transition Cards to this panel.
- 5 Using two cables NT4N72AA, connect the appropriate pair of connectors on the 3PE Termination Panel corresponding to the desired Group to the two connectors on the Network backplane.
- 6 Use standard NT8D76 cables to connect all other groups, including Group 0, to the 3PE cards in the respective Network modules.
- 7 Restore power to the Core/Net shelf, transfer call processing if required, and proceed to upgrade the other Core/Net shelf.

---

**End of Procedure**

---

## **Interconnect the network modules**

On the back of each Core/Net module backplanes are 2 connectors labeled D and E.

### **Procedure 125**

#### **Interconnecting the network modules**

- 1 Connect the NT8d99AD cable from the D connector in shelf 0 to the D connector in shelf 1 of the NT4N40 Core/Net Module.
- 2 Connect the NT8d99AD cable from the E connector in shelf 0 to the E connector in shelf 1 of the NT4N40 Core/Net Module.

## **Add CNI cards if necessary**


If additional CNI cards are required, add to each Core Module as required. See Figure 41.

### Procedure 126 Adding CNI cards

- 1 Face plate disable CNI card.
- 2 Insert card into Core/Net module, but do not seat card into backplane at this time.

**End of Procedure**

**Figure 53**  
**NT4N46 Core/Net card cage**



553-9123a

## Connect the 3PE to CNI cables

### Procedure 127

#### Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel.

See Table 75 on [page 394](#) and Figure 54 on [page 393](#) for NT4N72 cable connections.

- 1 Connect NT4N72 cable from the Fanout Panel J3 to the Backplane Connector marked "A".
- 2 Connect NT4N72 cable from the Fanout Panel J4 to the Backplane Connector marked "B"
- 3 Connect NT8D80BZ cable from J3 of the 3PE card in Core 0 to the J3 of 3PE card in Core 1.
- 4 Connect NT8D80BZ cable from J4 of the 3PE card in Core 0 to the J4 of 3PE card in Core 1.



**Figure 54**  
**3PE Fanout Panel (Core/Net module)**




Table 75

Termination Panel to 3PE card connectors

Group Number	connects from	Fanout Panel connector	to	3PE card connector
0		9-0, J3		J3
0		9-0, J4		J4
1		9-1, J3		J3
1		9-1, J4		J4
2		10-0, J3		J3
2		10-0, J4		J4
3		10-1, J3		J3
3		10-1, J4		J4
4		11-0, J3		J3
4		11-0, J4		J4
5		11-1, J3		J3
5		11-1, J4		J4
6		12-0, J3		J3
6		12-0, J4		J4
7		12-1, J3		J3
7		12-1, J4		J4
<p><b>Note:</b> Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 <b>OR</b> to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.</p>				

## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### **Procedure 128**

#### **Installing and enabling the 3PE cards**

- 1 Verify the 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 76 and Table 77 on [page 396](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2 Install a 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

3     Attach the cables to the 3PE faceplates.

**Table 76**  
**Settings for switch D20 on QPC441 3PE card in Option 81C network shelf 1 modules**

Group	Switch position							
	1	2	3	4	5	6	7	8
0	off	on	on	off	on	on	on	off
1	off	on	on	off	on	on	off	off
2	off	on	on	off	on	off	on	off
3	off	on	on	off	on	off	off	off
4	off	on	on	off	off	on	on	off
<b>Note:</b> Jumper RN27 at location E35: set to A								

**Table 77**  
**Settings for switch D20 on QPC441 3PE card in Option 81C network shelf 0 modules**

Group	Switch position							
	1	2	3	4	5	6	7	8
0	off	on	on	off	on	on	on	on
1	off	on	on	off	on	on	off	on
2	off	on	on	off	on	off	on	on
3	off	on	on	off	on	off	off	on
4	off	on	on	off	off	on	on	on
<b>Note:</b> Jumper RN27 at location E35: set to A								

————— End of Procedure —————

**Procedure 129****Installing and enabling the QPC43R Peripheral Signaling cards**

- 1 Install a Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 130****Disabling and inserting the NT5D30 DIGS cards**

- 1 Faceplate *disable* the DIGS cards.
- 2 Insert DIGS card into slot 9 of each Core/Net Module.

Do not plug the cards into the backplane.

---

**End of Procedure**

---

**Procedure 131****Disabling and inserting the NT8D17 Conf/TDS cards**

If Conf/TDS cards are used in the system, complete the following steps.

- 1 Faceplate *disable* the Conf/TDS cards.
- 2 Insert a Conf/TDS card into each added Network module.

Do not plug the card into the backplane.

---

**End of Procedure**

---

## **Enable the Network Group**

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

**Procedure 132**  
**Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1    Verify that Core 0 is active.

**LD 135**            Load program

**STAT CPU**        Get status of the CPUs

- 2    If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary)

**\*\*\*\***            Exit program

---

**End of Procedure**

---

**Procedure 133**  
**Checking that Clock Controller 0 is active**

- 1    Check the status of the Clock Controllers:

**LD 60**            Load program

**SSCK 0**            Get the status of Clock Controller 0

**SSCK 1**            Get the status of Clock Controller 1

- 2    If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK**            Switch to Clock Controller 0 (if necessary)

**DIS CC 1**        Disable Clock Controller 1

**\*\*\*\***            Exit program

---

**End of Procedure**

---

## Add the CNI cards or ports

### Procedure 134

#### Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

- 1 In OVL 135 split the Cores.

**LD 135** To load the program.

**SPLIT** Split the Cores.

**\*\*\*\*** To exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1:

- 2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 75 on [page 394](#):

**LD 17** To load the program.

**REQ** CHG

**TYPE** CEQU

**XCT X** X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g** Core to Network Interface card location  
where:

s = slot (9 to 12)

p = port number (0 to 1)

g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g** Core to Network Interface card location  
where:

s = slot (9 to 12)

p = port number (0 to 1)

g = group number (0 to 7)

**<cr>** Continue to the last prompt.

**\*\*\*\*** To exit the program.

**3** Perform a data dump

**LD 43** To load the program.

**EDD** Invoke data dump program.

**\*\*\*\*** To exit the program.



Table 78 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software

**Table 78**  
**Fanout Panel to 3PE card connectors**

Group Number	connects from	Fanout Panel connector	to	3PE card connector
0		9-0, J3		J3
0		9-0, J4		J4
1		9-1, J3		J3
1		9-1, J4		J4
2		10-0, J3		J3
2		10-0, J4		J4
3		10-1, J3		J3
3		10-1, J4		J4
4		11-0, J3		J3
4		11-0, J4		J4
5		11-1, J3		J3
5		11-1, J4		J4
6		12-0, J3		J3
6		12-0, J4		J4
7		12-1, J3		J3
7		12-1, J4		J4

**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 or to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.

---

### End of Procedure

---

#### Procedure 135

##### Seating remaining cards

- 1 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.


**Note:** Cards must be faceplate disabled before seating.

- 2 Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and DIGS).
- 3 Cable the added DIGS cards. See Table 79 and Figure 55 on [page 403](#).

**Table 79**  
**IGS to InterGroup cable assignment—use NT8D76 cables**

From				To
Network Group	Network Shelf	Slot	IGS Connector J1	InterGroup Connector
0	0 (Core/Net 0)	8	0	J1
0	0 (Core/Net 0)	9	1	J6
0	1 (Core/Net 1)	9	1	J17
0	1 (Core/Net 1)	8	0	J22
1	0	3	0	J2
1	0	2	1	J7
1	1	2	1	J16
1	1	3	0	J21
2	0	3	0	J3
2	0	2	1	J8
2	1	2	1	J15
2	1	3	0	J20
3	0	3	0	J4
3	0	2	1	J9
3	1	2	1	J14
3	1	3	0	J19
4	0	3	0	J5
4	0	2	1	J10
4	1	2	1	J13
4	1	3	0	J18
<b>Note:</b> The NT5D30 DIGS card is located in slot 9 of the Core/Net and slot 2 of the NT8D35 Network shelf.				

**Figure 55**  
**NT8D36 Inter-group module connections for IGS cards**



**4 In Core 1 only**, seat the new CNI card and faceplate enable.



### IMPORTANT!

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



### CAUTION

#### Service Interruption

Call processing is interrupted for approximately 10 minutes while the INI is completed.

**5 In LD 135 switch Cores.**

**LD 135**

To load the program.

**CUTOVR**

Switch Cores



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

**6**    Switch the clock controllers, if necessary:

**LD 60**

To load the program.

**SSCK n**

Get status of clock n where  
n = 0 for clock controller 0  
1 for clock controller 1

**SWCK**

Switch system clock from active to standby.

**Note:** Make clock controller 1 the active clock.

**\*\*\*\***

To exit the program.



The system is in split mode with Core 1 active. Clock 1 is active.

**7 In Core 0 only, define the XCT and extenders to the added group.****Note:** See Table 69 on [page 357](#):

<b>LD 17</b>	To load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	To exit the program.

**8 Data dump the software changes.**

<b>LD 43</b>	To load the program.
<b>EDD</b>	Invoke data dump program.
<b>****</b>	To exit the program.

**9 Seat the CNI card in Core 0 and faceplate enable it.**

10   In Core 1, Stat the CNIs:

**LD 135**            Load the program.

**STAT CNI**        Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**JOIN**             Synchronize the memory and drives.

**\*\*\*\***              To exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 136

#### Testing Core/Net 1

From Core/Net 1, perform these tests.

1    Perform a redundancy sanity test:

**LD 135**            Load the program.

**STAT CPU**        Get status of CPU and memory.

**TEST CPU**        Test the CPU.

2    Check the LCD states

a.   Perform a visual check of the LCDs.

b.   Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**       Test LCDs.

**DSPL ALL**

**3** Test the System Utility cards and the CNI cards.

- LD 135** Load the program.
- STAT SUTL** Get the status of the System Utility (main and Transition) cards.
- TEST SUTL** Test the System Utility (main and Transition) cards.
- STAT CNI c s** Get status of CNI cards (core, slot).
- TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

- LD 137** Load the program.
- TEST RDUN** Test redundancy.
- DATA RDUN**
- TEST CMDU** Test the MMDU card.

**5** Install the two system monitors. Test that the system monitors are working.

- LD 37** Load the program.
- ENL TTY x** Enable the XMS, where x= system XMS.
- STAT XSM** Check the system monitors.
- \*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

- LD 135** Load the program.
- CDSP** Clear the displays on the cores.
- CMAJ** Clear major alarms.
- CMIN ALL** Clear minor alarms.

- 7    Test the clocks.
  - a.    Verify that the clock controller is assigned to the *active* Core.

**LD 60**                      Load the program.

**SSCK x**                  To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**                      Switch the Clock if necessary.
  - b.    Verify that the Clock Controllers are switching correctly.

**SWCK**                      Switch the Clock.

**SWCK**                      Switch the Clock again.
- 8    Check the IGS status.

**LD 39**                      Load the program.

**STAT IGS X**              Check the status of IGS (X = IGS/DIGS card number. See Table 80).

**\*\*\*\***                        Exit program.

**Table 80**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11



**Table 80**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot, Symposium, and Meridian Mail..

**10** Check for dial tone.

---

**End of Procedure**

---

**Procedure 137**  
**Switching call processing**

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 138**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

**1** Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

**2** Check the LCD states

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

**3** Test the System Utility cards and the CNI cards.

**LD 135** Load the program.

**STAT SUTL** Get the status of the System Utility (main and Transition) cards.

**TEST SUTL** Test the System Utility (main and Transition) cards.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

**5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 81).

**\*\*\*\*** Exit program.

**Table 81**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3

**Table 81**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 1	Shelf 1	IGS/DIGS 5& 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 9    Check applications (such as CallPilot and Symposium).
- 10   Check for dial tone.

————— **End of Procedure** —————

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 451](#).

## Add an NT8D35 Network Group to Option 81C/IGS CP PII

### Prepare for upgrade

#### Introduction

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions. Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 82:

**Table 82**  
**Prepare for upgrade steps (Part 1 of 2)**

Procedure Step	Page
Plan the upgrade	<a href="#">414</a>
Upgrade checklists	<a href="#">414</a>
Prepare	<a href="#">415</a>
Identifying the proper procedure	<a href="#">415</a>
Connect a terminal	<a href="#">415</a>
Print site data	<a href="#">416</a>


**Table 82**  
**Prepare for upgrade steps (Part 2 of 2)**

Procedure Step	Page
Perform a template audit	<a href="#">419</a>
Back up the database (data dump)	<a href="#">420</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.



**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Current patch or Dep lists installed at the source platform.
- Required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and keycode.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.

## Connect a terminal

### Procedure 139

#### Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- The settings for the terminal are:

- a. 9600 Baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF

If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

End of Procedure

Print site data

Print site data to preserve a record of the system configuration (Table 83). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

Table 83  
Print site data (Part 1 of 4)

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>



**Table 83**  
**Print site data (Part 2 of 4)**

Site data	Print command	
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV

**Table 83**  
**Print site data (Part 3 of 4)**

Site data	Print command	
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)

**Table 83**  
**Print site data (Part 4 of 4)**

Site data	Print command
Superloops and XPEs	LD 97
	REQ
	CHG
	TYPE
	SUPL
	Vxxx
	V stands for a virtual superloop and xxx is the number of the virtual superloop.
	xxx = 0-252 in multiples of four for MG 1000E
	xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



### CAUTION — Service Interruption

#### Loss of Data

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT LOW</b>	<b>CHECKSUM OK</b>
---	------------------------

<b>TEMPLATE 0002 USER COUNT HIGH</b>	<b>CHECKSUM OK</b>
--	------------------------

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM OK</b>
------------------------------------	------------------------

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM OK</b>
------------------------------------	------------------------

**TEMPLATE AUDIT COMPLETE**

## **Back up the database (data dump)**

### **Procedure 140**

#### **Performing a data dump**

- 1**     On the Meridian 1 Option 81C, log in to the system.
- 2**     Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43**             Load the program.

**3** When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump.



**CAUTION — Service Interruption**

**Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

**\*\*\*\***                      Exit the program.



**IMPORTANT!**


Preserve database backup information for a minimum of 5 days.

## Perform the upgrade

### Introduction


Complete the procedure in this section to add an NT8D35 Network Group to the Meridian 1 Option 81C/IGS (NT4N46).

Figure 56  
NT8D35 Network Shelf



**Note:** An IGS QPC-412 card uses slots 2 & 3. An NT5D30 DIGS card uses slot 2.

**Figure 57**  
**CP PII NT4N46 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP PII. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

DO NOT proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.



## Check required hardware

Table 84 describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81C/IGS (NT4N46). Table 85 on [page 426](#) and Table 86 on [page 426](#) list the DC and AC power equipment requirements. Additional equipment for increased Network capacity must be ordered separately.

**Table 84**  
**Minimum equipment required to add an NT8D35 Network Group to an Option 81C/IGS equipped with an NT4N46 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	5
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT8D76	IGS to IGM DIGS cards cable <b>Note:</b> There are a total of 8 cables required for installation; 4 for IGS to IGM, and 4 for 3PE to CNI.	8
NT5D30	Dual IGS card	2
NT8D35	Network Shelf	2
NT4N65AC	CNI card	4

## Check required power equipment

Table 85 lists the equipment required for AC-powered systems. Table 86 lists the equipment required for DC-powered systems.

**Table 85**  
**Ac power requirements for Meridian 1 Option 81C CP PII/IGS upgrades**

Order number	Description	Quantity per system
Peripheral Equipment Power Supply AC	NT8D06AA	1
Common Equipment Power Supply AC	NT8D29AB	2

**Table 86**  
**Dc power requirements for Meridian 1 Option 81C CP PII/IGS upgrades**

Order number	Description	Quantity per system
Peripheral Equipment Power Supply DC	NT6D40AB	1
Common Equipment Power Supply DC	NT6D41AB	2

## Tools

Table 56 lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 87**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Check personnel requirements

Nortel recommends that a minimum of two people perform the upgrade.

### **Procedure 141** **Interconnecting the network modules**

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 58 on [page 428](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group.


- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3 Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4 Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5 Connect the E connector in shelf 0 to the E connector in shelf 1.

- 6     Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0).

**Note:** All connections are made with an NT8D99AB cable.

————— End of Procedure —————

**Figure 58**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



## Add CNI cards if necessary

If additional CNI cards are required, add to each Core Module as required.  
See Figure 59 on [page 429](#).


## Procedure 142

### Adding CNI cards

- 1 Face plate disable CNI card.
- 2 Insert card into Core/Net module, but do not seat card into backplane at this time.

## End of Procedure

**Figure 59**  
**NT4N46 Core/Net card cage**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

## Install and enable the QPC441 3PE cards

### Procedure 143

#### Installing and enable the QPC441 3PE cards

Three steps are required to install the QPC441 3PE cards.

- 1 Verify the QPC441 3PE card settings.

The group and shelf number of each Network module is determined by the switch settings on the QPC441 3PE card. Use the information in Table 88 on [page 431](#) to verify that the QPC441 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2 Install a QPC441 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

### 3 Attach the cables to the QPC441 3PE faceplates.

**Table 88**  
**QPC441 3PE Card installed in the NT4N46 Module**

<b>Jumper settings.</b> Set Jumper RN27 at E35 to "A".									
Switch Settings									
Module		D20 switch position							
NT4N46 (Option 81C CP PII)		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
	Group 1	off	on	on	off	on	on	off	on
	Group 2	off	on	on	off	on	off	on	on
	Group 3	off	on	on	off	on	off	off	on
	Group 4	off	on	on	off	off	on	on	on
	Group 5	off	on	on	off	off	on	off	on
	Group 6	off	on	on	off	off	off	on	on
	Group 7	off	on	on	off	off	off	off	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off
	Group 1	off	on	on	off	on	on	off	off
	Group 2	off	on	on	off	on	off	on	off
	Group 3	off	on	on	off	on	off	off	off
	Group 4	off	on	on	off	off	on	on	off
	Group 5	off	on	on	off	off	on	off	off
	Group 6	off	on	on	off	off	off	on	off
	Group 7	off	on	on	off	off	off	off	off

**End of Procedure**

Procedure 144

Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 89, Figure 60 on [page 433](#), and Figure 61 on [page 434](#) for NT8D76 cable connections.

- 1
- Connect the NT8D76 cables to J3 and J4 of the 3PE cards.
- 2
- Connect the new NT8D76 cables to the Fanout Panel in the Core/Net.

Table 89

Fanout Panel to 3PE card connectors


Group Number	connects from	Fanout Panel connector	to	3PE card connector
0		9-0, J3		J3
0		9-0, J4		J4
1		9-1, J3		J3
1		9-1, J4		J4
2		10-0, J3		J3
2		10-0, J4		J4
3		10-1, J3		J3
3		10-1, J4		J4
4		11-0, J3		J3
4		11-0, J4		J4
5		11-1, J3		J3
5		11-1, J4		J4
6		12-0, J3		J3
6		12-0, J4		J4
7		12-1, J3		J3
7		12-1, J4		J4

**Note:** Group 0 cables connect from the CNI Transition card directly to the backplane of Core/Net 0 or to the NT8D76 cable (depending on your CNI group configuration). If the Core/Net module contains a Network Group other than group 0, use NT4N72AA cables to connect the Fanout panel to the network portion of the Core/Net backplane.


End of Procedure



**Figure 60**  
**Example of 3PE faceplate to 3PE Fanout Panel connection**



**Figure 61**  
**3PE Fanout Panel (Core/Net module)**



**Table 90**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

**Procedure 145**  
**Installing and enabling the QPC43R Peripheral Signaling cards**

- 1     Install a Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2     Faceplate *enable* the cards.
- 3     Insert NT5D30 card into slot 2 of each added Network group
- 4     Cable DIGS cards with NT8D76 IGS to IGM cable.

**Table 91**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

————— **End of Procedure** —————

## Disable and insert the NT8D17 Conf/TDS cards

### Procedure 146

#### Disabling and inserting the Conf/TDS cards

If Conf/TDS cards are used in the system, complete the following steps.

- 1 Faceplate disable the Conf/TDS cards.
- 2 Insert a Conf/TDS card into each added Network module.
- 3 Seat the Con/TDS card and faceplate Enable.

---

**End of Procedure**

---

## Enable the Network Group

*Note:* If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

### Procedure 147

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135**            Load program

**STAT CPU**        Get status of the CPUs

- 2 If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary)

**\*\*\*\***            Exit program

---

**End of Procedure**

---

**Procedure 148**

**Checking that Clock Controller 0 is active**

- 1    Check the status of the Clock Controllers:

**LD 60**                      Load program

**SSCK 0**                    Get the status of Clock Controller 0

**SSCK 1**                    Get the status of Clock Controller 1

- 2    If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK**                      Switch to Clock Controller 0 (if necessary)

**DIS CC 1**                  Disable Clock Controller 1

**\*\*\*\***                        Exit program

---

**End of Procedure**

---

## **Add the CNI cards or ports**

**Procedure 149**

**Adding the CNI cards or ports**

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

- 1    In OVL 135 split the Cores.

**LD 135**                                      To load the program.

**SPLIT**                                        Split the Cores.

**\*\*\*\***                                        To exit the program.

Follow these steps to activate the added CNI ports. Wait until the INI is complete on Core 1:

- 2 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 89 on [page 432](#):

<b>LD 17</b>	To load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	To exit the program.

- 3 Perform a data dump

<b>LD 43</b>	To load the program.
<b>EDD</b>	Invoke data dump program.
<b>****</b>	To exit the program.

Table 92 specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 92**  
**CNI Network group designations**

CNI card slot	CNI card port	3PE Fanout Panel label	Connected to Network group
c9	0	Port 9-0	0
c9	1	Port 9-1	1
c10	0	Port 10-0	2
c10	1	Port 10-1	3
c11	0	Port 11-0	4
c11	1	Port 11-1	5
c12	0	Port 12-0	6
c12	1	Port 12-1	7

---

End of Procedure

---

**Procedure 150**  
**Seating remaining cards**

- 1    Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate disabled before seating.



- 2 Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and DIGS).

**Table 93**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 3 In Core 1 only, seat the new CNI card and faceplate enable.



#### **IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



#### **CAUTION**


##### **Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

- 4
- In LD 135 switch Cores.
- LD 135


To load the program.
- CUTOVR

Switch cores.




WARNING

All call processing may be interrupted.



IMPORTANT!

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

- 5
- Switch the clock controllers, if necessary:
- LD 60

To load the program.
- SSCK n

Get status of clock n where  
n = 0 for clock controller 0  
1 for clock controller 1
- SWCK

Switch system clock from active to standby.
- Note:

Make clock controller 1 the active clock.
- \*\*\*\*

To exit the program.



The system is in split mode with Core 1 active. Clock 1 is active.

**6 In Core 0 only, define the XCT and extenders to the added group.**

**Note:** See Table 89 on [page 432](#):

<b>LD 17</b>	To load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	To exit the program.

**7 Data dump the software changes.**

<b>LD 43</b>	To load the program.
<b>EDD</b>	Invoke data dump program.
<b>****</b>	To exit the program.

- 8    Seat the CNI card in Core 0 and faceplate enable it.
- 9    In Core 1, Stat the CNIs:
  - LD 135**            Load the program.
  - STAT CNI**        Get status of CNI card.  
  
**Note:** If any CNIs are disabled they must be enabled.
  - JOIN**             Synchronize the memory and drives.
  - \*\*\*\***              To exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 151 Testing Core/Net 1

**From Core/Net 1**, perform these tests.

- 1    Perform a redundancy sanity test:
  - LD 135**            Load the program.
  - STAT CPU**        Get status of CPU and memory.
  - TEST CPU**        Test the CPU.
- 2    Check the LCD states
  - a.   Perform a visual check of the LCDs.
  - b.   Test LCDs.
    - LD 135**            Load the program.
    - TEST LCDs**        Test LCDs.
    - DSPL ALL**

**3** Test the System Utility cards and the CNI cards.

- LD 135** Load the program.
- STAT SUTL** Get the status of the System Utility (main and Transition) cards.
- TEST SUTL** Test the System Utility (main and Transition) cards.
- STAT CNI c s** Get status of CNI cards (core, slot).
- TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

- LD 137** Load the program.
- TEST RDUN** Test redundancy.
- DATA RDUN**
- TEST CMDU** Test the MMDU card.

**5** Install the two system monitors. Test that the system monitors are working.

- LD 37** Load the program.
- ENL TTY x** Enable the XMS, where x= system XMS.
- STAT XSM** Check the system monitors
- \*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

- LD 135** Load the program.
- CDSP** Clear the displays on the cores.
- CMAJ** Clear major alarms.
- CMIN ALL** Clear minor alarms.

- 7    Test the clocks.
  - a.    Verify that the clock controller is assigned to the *active* Core.
 

**LD 60**                      Load the program.

**SSCK x**                  To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**                      Switch the Clock if necessary.
  - b.    Verify that the Clock Controllers are switching correctly.
 

**SWCK**                      Switch the Clock.

**SWCK**                      Switch the Clock again.
- 8    Check the IGS status.
 

**LD 39**                      Load the program.

**STAT IGS X**              Check the status of IGS (X = IGS/DIGS card number. See Table 94).

**\*\*\*\***                        Exit program.

**Table 94**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11

**Table 94**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot, Symposium, and Meridian Mail..

**10** Check for dial tone.

---

**End of Procedure**

---

**Procedure 152**  
**Switching call processing**

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 153**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

**1** Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

**2** Check the LCD states

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

**3** Test the System Utility cards and the CNI cards.

**LD 135** Load the program.

**STAT SUTL** Get the status of the System Utility (main and Transition) cards.

**TEST SUTL** Test the System Utility (main and Transition) cards.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

**5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors

**\*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.



**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 95).

**\*\*\*\*** Exit program.

**Table 95**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3

**Table 95**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 1	Shelf 1	IGS/DIGS 5& 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 9    Check applications (such as CallPilot and Symposium).
- 10   Check for dial tone.

————— **End of Procedure** —————

## Post-conversion procedure

### Introduction

This procedure verifies that the conversion process was successful, and system data converted completely. This is the last part of the total conversion procedure. Perform these steps **after** completing all other procedures for the system.

The site data should be printed before and after conversion. See Table 97 on [page 456](#). If the data has changed, make the necessary updates on the **Target** release, and datadump to the new system media. Print out the items marked with an asterisk (\*) to be sure everything converted properly. All other items on Table 97 on [page 456](#) are provided to be printed if desired.

Check the General Release Bulletin (GRB), and the Conversion notes (earlier in this document) to verify any database updates that need to be made as a result of conversion. Be sure to verify all SYSxxx messages that might appear during the conversion process. These messages might indicate some database updates are required.



#### CAUTION — Service Interruption

##### Service Interruption

Test call processing thoroughly. This can include more testing than is described in this procedure, depending on system configuration. This procedure is intended to show some of the basic tests performed to complete the conversion process.

**Note:** When parallel reload is complete, the attendant consoles will be in Night mode. If performing these procedures during the day, contact the attendant. If these procedures are taking place during the evening, it might not be desirable to perform these call processing steps.

### Post-conversion steps

Follow the steps in Procedure 154 to perform the post-conversion procedure.

### **Procedure 154**

#### **Performing the post-conversion procedure**

- 1** Print system data. Verify that all information matches the printouts created before conversions. Make changes if necessary.
- 2** From any unrestricted telephone, dial the access code for an outside line (usually 9), and dial the listed Directory Number (DN) for the customer. Verify that the correct Incoming Call Indicator (ICI) lights at the attendant console.
- 3** If the customer is equipped with more than one console, transfer the call to another console.
- 4** Extend the call to a telephone, and release the call from the console.
- 5** From the called telephone, transfer the call back to the attendant.
- 6** Answer and release the call.
- 7** From any telephone dial the DN for the attendant. Verify that the correct ICI lights at the console, then release the call.
- 8** Busy-out one trunk group using a Trunk Group Busy (TGB) key on the console.
- 9** From any telephone with TGAR 0-7, dial the access code of the busied-out trunk group, to verify that the call is intercepted to the console and receives either overflow tone or a recorded announcement.
- 10** Restore the trunk group to the in-service state using the Trunk Group Busy (TGB) key on the console.
- 11** During the conversion procedure the Central Office might have busied-out the DID trunks. If DID trunks are equipped, from any unrestricted telephone, dial the access code for an outside line, and dial a DID number into the system.
- 12** If a private network is used, from any unrestricted telephone, dial the network access code and place a CDP, ESN, BARS/NARS, or ISDN call as applicable to the system.
- 13** If not done previously, set the time and date. If Call Detail Recording (CDR) is used, system message ERR225 will appear. This is normal.

### **LD 02**

#### **STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)  
yyyy = year (last 2 or all four digits, for example, 92 or 1992)  
hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)  
mm = minute (for example, 25)  
ss = seconds (for example, 00)

**Note:** Test all applications and call handling

- 14 If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.
- 15 Keep one copy of the **Source** software, as it was backed up in the pre-conversion procedure, in case it becomes necessary to reconvert. After the **Target** software has been running well for a few weeks, return the original software to Nortel through the usual distribution channel.
- 16 Load LD 135 to test and switch CPUs. (Omit this step for Option 51C.)

<b>LD 135</b>	Load the program.
<b>TEST CPU</b>	Test CPU.
<b>SCPU</b>	Switch CPUs.
<b>****</b>	Exit LD.

- 17 Load LD 137 to get the status of the CMDUs and IOPs.

<b>LD 137</b>	Load the program.
<b>STAT</b>	Get the status of both CMDUs and IOPs.
<b>****</b>	Exit LD.

**Note:** Check MMDU in CP PII machines.

- 18 Load LD 43 to back up the other set of B1 disks. Insert the B1 disk in the active CMDU.

<b>LD 43</b>	Load the program.
<b>BKO</b>	Back up to the backup disks and the active CMDU.

**Note:** Back up additional 2 MByte floppy disks.

- 19 If not done previously, set the time and date. If Call Detail Recording (CDR) is used, the system message ERR225 will appear. This is normal.

### LD 02

#### STAD dd mm yyyy hh mm ss

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

\*\*\*\* Exit LD.

**Note:** If equipped with FNF, perform steps 21-24. If equipped with IGS, perform step 20.

### 20 Test the IGS

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 96).

\*\*\*\* Exit program.

**Table 96**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18

**Table 96**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**21** Check that Fiber Ring 1 operates correctly.

**LD 39** to load the program

**STAT RING 1** to check the status of Ring 1

**22** Reset the Rings:

**RSET** to reset the Rings and prepare them for redundancy

**RSTR** to restore both Rings to HALF state

**23** Check that the Rings operate correctly.

**STAT RING 0** to check the status of Ring 0 (HALF/HALF)

**STAT RING 1** to check the status of Ring 1 (HALF/HALF)

24 If any Ring problems occur, correct them now.

**STAT ALRM <X> <Y>** to check the alarm status of individual FIJI cards or all FIJI cards. See *Software Input/Output: Administration* (553-3001-311) for more information.

**Note:** if equipped with IGS, you must STAT IGS.

25 Verify that call processing operates correctly. this includes, but is not limited to the following:

- Check for dial tone.
- Make internal, external, and network calls.
- Check attendant console activity.
- Check DID trunks.
- Check any auxiliary processors.

26 If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.

27 Keep one copy of the **Source** software, as it was backed up in the pre-conversion procedure, in case it becomes necessary to reconvert. After the **Target** software has been running well for a few weeks, return the original software to Nortel through the usual distribution channel.

Items marked with asterisks (\*) are required printout for conversion. Other items are recommended for a total system status.

**Table 97**  
**Print site data (Part 1 of 4)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>



**Table 97**  
**Print site data (Part 2 of 4)**

Site data	Print command	
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID

**Table 97**  
**Print site data (Part 3 of 4)**

Site data	Print command	
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)

**Table 97**  
**Print site data (Part 4 of 4)**

Site data	Print command
Superloops and XPEs	LD 97
	REQ
	TYPE
	SUPL
	CHG
	SUPL
	Vxxx
	V stands for a virtual superloop and xxx is the number of the virtual superloop.
	xxx = 0-252 in multiples of four for MG 1000E
	xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

**28** Obtain status of CNI cards.

**LD 135** To load the program.

**STAT CNI** Get the status of CNI cards.

**\*\*\*\*** To exit the program.

---

**End of Procedure**

---



---

# Adding an NT8D35 Network Group to Option 81 (NT5D60)

---

## Contents

This section contains information on the following topics::

Add an NT8D35 Network Group to Option 81 with FNF .....	462
Prepare for upgrade .....	463
Perform the upgrade .....	473
Add an NT8D35 Network Group to Option 81/IGS .....	510
Prepare for upgrade .....	510
Perform the upgrade .....	519
Post-conversion procedure .....	549

## Add an NT8D35 Network Group to Option 81 with FNF

### Introduction

Complete the following procedure to add an NT8D35 Network Group to the Meridian 1 Option 81/FNF equipped with an NT5D60 Core/Net shelf.

The Meridian 1 Option 81/FNF equipped with an NT5D60 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- PB requires NTRB53AA Clock Controller.
- shortest fiber cable should be used.
- cables from group 0 - 1 must be same length.
- Distance between each ring from group 0 - group 1 must not exceed 50 ft.



#### IMPORTANT!

The shortest Fiber Cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0

The distance between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.

To add a Network Group to a Meridian 1 Option 81/FNF equipped with an NT5D60 Core/Net shelf:

- Clock Controller cards must be NTRB53AA.
- NTRB33AC/AD Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.

**IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 98 below:

**Table 98**  
**Prepare for upgrade steps**

Procedure Step	Page
Plan the upgrade	<a href="#">464</a>
Upgrade checklists	<a href="#">465</a>
Prepare	<a href="#">465</a>
Identifying the proper procedure	<a href="#">466</a>
Connect a terminal	<a href="#">466</a>
Print site data	<a href="#">467</a>
Perform a template audit	<a href="#">470</a>
Back up the database (data dump)	<a href="#">471</a>

## Plan the upgrade

To plan for an upgrade, complete the following tasks:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.



- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Preserve database backup information for a minimum of five days.

## Connect a terminal

### Procedure 155 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF

- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (Table 99). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 99**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>

**Table 99**  
**Print site data (Part 2 of 3)**

Site data	Print command	
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop


**Table 99**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
-

**TEMPLATE 0120 USER COUNT OK      CHECKSUM  
OK**

**TEMPLATE AUDIT COMPLETE**

## **Back up the database (data dump)**

To backup existing data, perform the following procedure:

### **Procedure 156 Performing a data dump**

- 1 On the Meridian 1 Option 81, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43**              Load the program.

- 3 When "EDD000" appears on the terminal, enter:

**EDD**              Begin the data dump.



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\*

Exit the program.



**IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---




# Perform the upgrade

## Introduction

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81/FNF equipped with an NT5D60 shelf.

Figure 62 shows a Meridian 1 Option 81/FNF (NT5D60).

**Figure 62**  
**NT5D60 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81 with FNF. Additional equipment

can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements:

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- NTRB33 AC/AD
- NTRB54AA Global Clock Controller



#### **IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

If equipment does not meet the requirements, replace it before you begin the upgrade.



### **CAUTION — Service Interruption**

#### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## **Check required hardware**

Table 100 below describes the *minimum* equipment required to add a Core Network Group to a Meridian 1 Option 81/FNF equipped with an NT5D60 shelf. Additional equipment for increased Network capacity must be ordered separately.

**Table 100**

**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT5D21 shelf (Part 1 of 2)**

<b>Order Number</b>	<b>Description</b>	<b>Quantity per system</b>
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC47	Cable FIJI to FIJI	1
NTRC48	Cable FIJI to FIJI	1

**Table 100**  
**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT5D21 shelf (Part 2 of 2)**

Order Number	Description	Quantity per system
NTRB34	3 port CNI  <b>Note:</b> A vacant CNI port must available, otherwise 2 new 3-port CNIs must be added.	4
NTND14	CNI to 3PE cable	4
NT9D89	Faceplate CNI to 3PE cable	4
<b>Note:</b> The type of cabling is determined by available port assignment (4). Two for each Core of the same type is required.		

## Tools

Table 101 below lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 101**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group.

**Note:** Do not disconnect existing cables at this time.

### Procedure 157

#### Label and route the shelf 0 fiber-optic cables (ascending)

Pre-route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order.



#### CAUTION

##### Damage to Equipment

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Figure 63 on [page 479](#).
- 3 Route an NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4 If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5 Continue to route NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6     To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 102**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

---

**End of Procedure**

---

**Figure 63**  
**Shelf 0 ascending fiber-optic Ring**





Figure 64  
FIJI to FIJI cables





**Procedure 158****Label and route the shelf 1 fiber-optic cables (descending)**

Route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 65 on [page 482](#)).

**Note:** Do not disconnect existing cables at this time.

**CAUTION****Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1** Start with Group 0, shelf 1.
- 2** Label each cable on both sides with the appropriate connection information from Figure 65 on [page 482](#).
- 3** Route an NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4** Route an NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5** Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6** Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 65**  
**Shelf 1 descending fiber-optic Ring**



**Table 103**  
**FIJI Ring 1 connections (Part 1 of 2)**

Groups 0 - X are cabled in descending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2

**Table 103**  
**FIJI Ring 1 connections (Part 2 of 2)**

<b>Groups 0 - X are cabled in descending order</b>		
<b>Group/shelf</b>	<b>NTRC48 fiber cable connector</b>	<b>FIJI card connector</b>
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2

## Interconnect the network modules

### Procedure 159

#### Interconnect the network modules

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 66 on [page 485](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector. To add modules to a system, see *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).


- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3 Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4 Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5 Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6 Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0).

**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**


---

**Figure 66****Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**

### Add CNI cards if necessary

If additional CNI cards are required, add to each Core Module as required.  
See Figure 67 on [page 486](#).

Figure 67  
NT5D60 Core/Net shelf



## Connect the 3PE to CNI cables

### Procedure 160

#### Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 104 on [page 488](#), Figure 68 on [page 490](#) and Figure 69 on [page 491](#) for NT4N14 cable connections.

- 1 Connect the NTND14 cables to J3 and J4 of the 3PE cards.

2
Connect the NTND14 cables to the Fanout Panel in the Core/Net.

Table 104  
CNI to 3PE connections

Group Number	connects from	CNI to 3PE connector	to	3PE card connector
0		8D		J3
0		8F		J4
1		9A		J3
1		9C		J4
2		9D		J3
2		9F		J4
3		10A		J3
3		10C		J4
4		10D		J3
4		10F		J4
5		8, J1		J3
5		8, J2		J4
6		9, J1		J3
6		9, J4		J4
7		10, J1		J3
7		10, J4		J4
<p><b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available network group. This table reflects the default factory settings.</p> <p><b>Note 2:</b> Groups 5, 6 and 7 require NTRB34 3-port CNI cards and NT9D89 CNI to 3-port cables.</p> <p><b>Note 3:</b> Groups 5, 6 and 7 are only available on systems equipped with FNF.</p>				





**IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.


**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

---


**End of Procedure**

---

**Figure 68**  
**3PE faceplate to 3PE Termination connection**



**Figure 69**  
**3PE Termination Panel (Core/Net module)**



## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

## Install and enable the QPC441 3PE cards

### Procedure 161

#### Installing and enable the QPC441 3PE cards

- 1 Verify the QPC441F 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 105 on [page 492](#), to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2     Install a QPC441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.
- 3     Attach the cables to the QPC441F 3PE faceplates.

**Table 105**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81 (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81 systems, QPC441 vintage F or later must be used in all modules.									

————— End of Procedure —————

## Install and enable the Peripheral Signaling (Per Sig) cards

### Procedure 162

#### Installing and enabling the Peripheral Signaling (Per Sig) cards

- 1 Install a QPC43R Per Sig card into slot 4 of each added Network module.  
Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

End of Procedure

---

## Disable and insert the FIJI cards

### Procedure 163

#### Disabling and inserting the FIJI cards

- 1 Faceplate *disable* the NTRB33AC FIJI cards.
- 2 Insert the NTRB33AC FIJI cards into slots 2 and 3 of each added Network module.

Do not plug the card into the backplane.

---

End of Procedure

---

## Disable and insert the Conf/TDS cards

### Procedure 164

#### Disabling and inserting the Conf/TDS cards

If the NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.

Do not plug the card into the backplane.

---

End of Procedure

---

## Enable the Network Group

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

### Procedure 165

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1    Verify that Core 0 is active.

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2    If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 166**
**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

<b>LD 60</b>	Load program.
<b>SSCK 0</b>	Get the status of Clock Controller 0.
<b>SSCK 1</b>	Get the status of Clock Controller 1.



Core 0 is active, Clock 0 is active and FIJI is in half/half mode.

---

**End of Procedure**


---

**Procedure 167**
**Place CP 1 into parallel mode**

- 1 Set the CP card in Core 0 into maintenance.
- 2 Set the CNI cards in Core 1 to disable.
- 3 Place the CP card in Core 1 into maintenance.
- 4 Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**


---

**Procedure 168**
**Defining the XCT and extenders to the added group**

- 1 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 105 on [page 492](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU

**XCT X**                      X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                          Continue to the last prompt.

**\*\*\*\***                          To exit the program.

**2**     Perform a data dump.

**LD 43**                          Load the program.

**EDD**                          Invoke the data dump program.

**\*\*\*\***                          To exit the program.



Table 106 on [page 497](#) below specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 106**  
**CNI to 3PE connections**

Group Number	connects from	CNI to 3PE connector	to	3PE card connector
0		8D		J3
0		8F		J4
1		9A		J3
1		9C		J4
2		9D		J3
2		9F		J4
3		10A		J3
3		10C		J4
4		10D		J3
4		10F		J4
5		8, J1		J3
5		8, J2		J4
6		9, J1		J3
6		9, J4		J4
7		10, J1		J3
7		10, J4		J4

**Note 1:** The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available network group. This table reflects the default factory settings.

**Note 2:** Groups 5, 6 and 7 require NTRB34 3-port CNI cards and NT9D89 CNI to 3-port cables.

**Note 3:** Groups 5, 6 and 7 are only available on systems equipped with FNF.

**End of Procedure**

**Procedure 169**

**Checking that Ring 0 is active in Core 0**

- 1    Check the status of Ring 0.

**LD 39**            Load program.

**STAT RING 0**    Get the status of Ring 0  
                      (Ring state should be HALF/HALF).

- 2    Disable Ring auto recovery.

**LD 39**            Load program.

**ARCV OFF**       Set or reset auto-recovery operation for ring.

- 3    Swap to Ring 0.

**LD 39**            Load program.

**SWRG 0**          Switch Traffic to Ring x.

- 4    Disable Ring 1.

**LD 39**            Load program.

**DIS RING 1**      Disable all FIJI cards on side 1.



**WARNING**

Cable Ring 1 to new network shelf only.

- 5    Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).

- 7 Break Ring 1 and cable the added FIJI cards. Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.



### IMPORTANT!

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



### CAUTION

#### Service Interruption

Call processing is interrupted for approximately 10 minutes while the INI is completed.

In LD 135, switch call processing to Core 1:

- 9 In Core/Net 0, disable the CNI cards by setting the ENL/DIS faceplate switches to DIS.
- 10 In Core/Net 0, set the DIS/ENL faceplate switch on the IODU/C card to DIS and unseat it.
- 11 In Core/Net 1, enable the CNI cards by setting the ENL/DIS faceplate to ENL.
- 12 In Core/Net 1, press the MAN INT button.



### WARNING

All call processing may be interrupted.



### IMPORTANT!

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.

**Note 1:** On FNF based systems after the INI, a FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

13 Switch the clock controllers, if necessary.

- LD 60Load the program.
- SSCK nGet the status of clock n where:  
n = 0 for clock controller 0  
1 for clock controller 1
- SWCKSwitch system clock from active to standby.
- Note:** Make clock controller 1 the active clock.
- \*\*\*\*To exit the program.

14 Disable Ring 0.

- LD 39Load the program.

**DIS RING 0**                      Disables all FIJI cards on side 0.

\*\*\*\*                                  To exit the program.

- 15** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.

- 16** In LD 39, enable and stat Ring 0:

**LD 39**                              Load the program.

ENL Ring 0                      Enable Ring 0.

Stat Ring 0                      Status of Ring x.

\*\*\*\*                                  To exit the program.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

- 17 In Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 106 on [page 497](#).

**LD 17**                              Load the program.

**REQ**                                CHG

**TYPE**                              CEQU

**XCT X**                            X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                Continue to the last prompt.

**\*\*\*\***                To exit the program.

**18** Data dump the software changes.

**LD 43**                Load the program.

**EDD**                Invoke data dump program.

**\*\*\*\***                To exit the program.

**19** Seat the CNI card in Core 0 and faceplate enable it.

**20** In Core 1, Stat the CNIs:

**LD 135**            Load the program.

**STAT CNI**            Get the status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***                To exit the program.

**21** Enable the CNI cards by setting the ENL/DIS faceplate switch to ENL in Core/Net 0.

**22** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

**RUNNING ROM OS**

**ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**23** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**24** Synchronize the hard drives:

**LD 137**                      Load the program.

**SYNC**                      Synchronize the hard drives.

**\*\*\*\***                      Exit the program.

---

**End of Procedure**

---

## **Test the Cores**

**Procedure 170**

**Testing Core/Net 1**

**From Core/Net 1**, perform these tests.

**1** Perform a redundancy sanity test:

**LD 135**                      Load the program.

**STAT CPU**                      Get the status of CPU and memory.

**TEST CPU**                      Test the CPU.

**2** Check the LCD states.

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**        Test LCDs.

**DSPL ALL**

**3** Test the CNI cards.

**LD 135**            Load the program.

**STAT CNI c s**      Get the status of CNI cards (core, slot).

**TEST CNI c s**      Test CNI (core, slot).

**4** Test system redundancy.

**LD 137**            Load the program.

**TEST RDUN**        Test redundancy.

**DATA RDUN**

**TEST CMDU**        Test the MMDU card.

**5** Install the two system monitors. Test that the system monitors are working.

**LD 37**            Load the program.

**ENL TTY x**        Enable the XMS, where x = system XMS.

**STAT XSM**        Check the system monitors.

**\*\*\*\***            Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135**            Load the program.

**CDSP**            Clear the displays on the cores.



**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Test the Fiber Rings

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.** Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- b.** If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c.** Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- 9 Check the status of the FIJI alarms..

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\*** Exit the program.

- 10 Check applications such as CallPilot, Symposium, and Meridian Mail..

- 11 Check for dial tone.

---

**End of Procedure**

---

#### Procedure 171

##### Switching call processing

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

---

**End of Procedure**

---

#### Procedure 172

##### Testing Core/Net 0

From Core/Net 0, perform these tests.

- 1 Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

- 2 Check the LCD states.

a. Perform a visual check of the LCDs.

b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs**      Test LCDs.

**DSPL ALL**      Display all.

**3**    Test the CNI cards.

**LD 135**            Load the program.

**STAT CNI c s**    Get status of CNI cards (core, slot).

**TEST CNI c s**    Test CNI (core, slot).

**4**    Test system redundancy.

**LD 137**            Load the program.

**TEST RDUN**      Test redundancy.

**DATA RDUN**

**TEST CMDU**      Test the MMDU card.

**5**    Test that the system monitors are working.

**LD 37**            Load the program.

**STAT XSM**        Check the system monitors.

**\*\*\*\***              Exit the program.

**6**    Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP**            Clear the displays on the cores.

**CMAJ**            Clear major alarms.

**CMIN ALL**        Clear minor alarms.

**7**    Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60**                      Load the program.

**SSCK x**                    Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**                    Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK**                    Switch the Clock.

**SWCK**                    Switch the Clock again.

**8** Test the Fiber Rings.

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39**                    Load the program.

**STAT RING 0**            Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1**            Check the status of Ring 1. (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR**                    Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0**            Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1**            Check the status of Ring 1. (HALF/HALF).

**9** Check the status of the FIJI alarms.

**STAT ALRM**            Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\***                      Exit program.

- 10** Check applications (such as CallPilot and Symposium).
- 11** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See the “Post-conversion procedure” on [page 549](#).

## Add an NT8D35 Network Group to Option 81/IGS

### Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before you begin any software or hardware upgrade, field personnel must complete the steps in Table 10.

**Table 107**  
**Prepare for upgrade steps (Part 1 of 2)**

Procedure Step	Page
Plan the upgrade	511
Upgrade checklists	511
Prepare	512
Identifying the proper procedure	512
Connect a terminal	513
Print site data	513

**Table 107**  
**Prepare for upgrade steps (Part 2 of 2)**

Procedure Step	Page
Perform a template audit	<a href="#">516</a>
Back up the database (data dump)	<a href="#">518</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade*

*Procedures (553-3021-258).* Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures (553-3021-258)*.
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and keycode.
- Verify the new keycode using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing



the procedure or ignoring the warning boxes could cause longer service interruptions.

**IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

**Procedure 173****Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (Table 108). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 108**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN

**Table 108**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 108**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 174

#### Performing a data dump

- 1 On the Meridian 1 Option 81, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---

## Perform the upgrade

### Introduction




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add an NT8D35 Network Group to the Meridian 1 Option 81/IGS (NT5D60).

**Figure 70**  
**NT5D60 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements:

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.





### IMPORTANT!

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

If equipment does not meet the requirements, replace it before you begin the upgrade.



### CAUTION — Service Interruption

#### Service Interruption

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 109 on [page 522](#) describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81/IGS (NT5D60).

Additional equipment for increased Network capacity must be ordered separately.

**Table 109**  
**Minimum equipment required to add an NT8D35 Network Group to an Option 81/IGS equipped with an NT5D60 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	5
NT8D35	Module, Network AC/DC	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT8D76	Intergroup Switch to Intergroup Module cables	4
NTRB34	3 Port CNI  <b>Note:</b> A vacant CNI port must available, otherwise 2 new 3-port CNIs must be added.	
NTND14	CNI to 3PE cable	4

## Tools

Table 110 below lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 110**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Check personnel requirements

Nortel recommends that a minimum of two people perform the upgrade.

## Interconnect the network modules

### **Procedure 175** **Interconnecting the network modules**

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 71 on [page 525](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group.

- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3 Connect the C connector in shelf 0 to the C connector in shelf 1.


- 4**    Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5**    Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6**    Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0)

**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**


---

**Figure 71****Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**

### Add CNI cards if necessary

If additional CNI cards are required, add to each Core Module as required.  
See Figure 72 on [page 526](#). below.

**Figure 72**  
**NT5D60 Core/Net shelf**



## Connect the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.



### IMPORTANT!

When configuring NTND14 cables, observe the following rules:

- The shortest NTND14 Cable should always be used.
- A network group requires 4 NTND14 cables, 2 to each half group. Both cables to each half group must be the same length.
- A check should be made on the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50' cables are manufacture discontinued.

**Note:** See for b, Figure 73 on [page 529](#) and Figure 74 on [page 530](#) for NTND14 cable connections.

Connect the NTND14 cables to J3 and J4 of the 3PE cards.

**Table 111**  
**CNI backplane connector positions—NTND14 cables**

Backplane Connection	Group
8D	0
8F	0
9A	1
9C	1
9D	2
9F	2
10A	3
10C	3
10D	4
10F	4
<b>Note:</b> Backplane shroud designations are 18 through 8 from left to right and A through F from top to bottom.	



**Figure 73**  
**Example of 3PE faceplate to 3PE Termination Panel**





Figure 74  
3PE Termination Panel (Core/Net module)



Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

Install and enable the QPC441 3PE cards

Procedure 176  
Installing and enabling the QPC441 3PE cards

- 1
- Verify the QPC441F 3PE card settings.
- Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 112 on [page 531](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.
- The FIJI card displays group and shelf setting.

- 2 Install a QPC441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.
- 3 Attach the cables to the QPC441F 3PE faceplates.

**Table 112**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81 (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81 systems, QPC441 vintage F or later must be used in all modules.									

**End of Procedure**

## Install and enable the Peripheral Signaling (Per Sig) cards

### Procedure 177

#### Installing and enabling the Peripheral Signaling (Per Sig) cards

- 1 Install a QPC43R Per Sig card into slot 4 of each added Network module.  
Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

End of Procedure

---

## Disable and insert DIGS cards

### Procedure 178

#### Disabling and inserting DIGS cards

- 1 Faceplate *disable* NT5D30 IGS.
- 2 Insert DIGS card into slot 2.

**3** Add NT8D76 IGS cables.**Table 113**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

---

**End of Procedure**

---

**Disable and insert the Conf/TDS cards****Procedure 179****Disabling and inserting the Conf/TDS cards**

If the NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.

- 3     Faceplate *enable* the NT8D17 Conf/TDS cards.

---

**End of Procedure**

---

## Enable the Network Group

**Note:** If you are adding more than one Network Group, add one group at a time in software. Complete the remaining procedures in this chapter to enable one group before enabling another group.

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

Follow these procedures to activate the added CNI ports:

### Procedure 180

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1     Verify that Core 0 is active.

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2     If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 181**
**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

<b>LD 60</b>	Load program.
<b>SSCK 0</b>	Get the status of Clock Controller 0.
<b>SSCK 1</b>	Get the status of Clock Controller 1.



Core 0 is active, Clock 0 is active and FIJI is in half/half mode.

**Procedure 182**
**Place CP 1 into parallel mode**

- 1 Set the CP card in Core 0 into maintenance.
- 2 Set the CNI cards in Core 1 to disable.
- 3 Place the CP card in Core 1 into maintenance.
- 4 Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**


---

**Procedure 183**
**Defining the XCT and extenders to the added group**

- 1 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 113 on [page 533](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	

- |                   |  |
|-------------------|--|
| <b>CNI s p g</b>  | Core to Network Interface card location<br>where:<br>s = slot (9 to 12)<br>p = port number (0 to 1)<br>g = group number (0 to 7) |
| <b>EXT1 3PE</b>   |  |
| <b>CNI s p g</b>  | Core to Network Interface card location<br>where:<br>s = slot (9 to 12)<br>p = port number (0 to 1)<br>g = group number (0 to 7) |
| <b>&lt;cr&gt;</b> | Continue to the last prompt.   |
| <b>****</b>       | To exit the program.   |
- 2**    Perform a data dump
- |              |                               |
|--------------|-------------------------------|
| <b>LD 43</b> | Load the program.             |
| <b>EDD</b>   | Invoke the data dump program. |
| <b>****</b>  | To exit the program.          |



Table 114. below specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 114**  
**CNI backplane connector positions—NTND14 cables**

Backplane Connection	Group
8D	0
8F	0
9A	1
9C	1
9D	2
9F	2
10A	3
10C	3
10D	4
10F	4
<b>Note:</b> Backplane shroud designations are 18 through 8 from left to right and A through F from top to bottom.	

---

**End of Procedure**

---

**Procedure 184**  
**Seating the remaining cards**

- 1 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 2 Faceplate enable all cards in both network modules (3PE, PER SIG, XCT, DIGS).

- 3 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

**Table 115**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 4 In Core 1 only**, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION**

**Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

---

**End of Procedure**

---

## **Switch call processing to Core 1**

### **Procedure 185**

#### **Switching call processing to Core 1**

- 1** In Core/Net 0, disable the CNI cards by setting the ENL/DIS faceplate switches to DIS.
- 2** In Core/Net 0, set the DIS/ENL faceplate switch on the IODU/C card to DIS and unseat it.
- 3** In Core/Net 1, enable the CNI cards by setting the ENL/DIS faceplate to ENL.
- 4** In Core/Net 1, press the MAN INT button.



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

- 5    Switch the clock controllers, if necessary.

<b>LD 60</b>	Load the program.
<b>SSCK n</b>	Get status of clock n where n = 0 for clock controller 0 1 for clock controller 1
<b>SWCK</b>	Switch system clock from active to standby.  <b>Note:</b> Make clock controller 1 the active clock.
<b>****</b>	To exit the program.

- 6    In **Core 0** only, define the XCT and Extenders to the added group.

**Note:** See Table 115 on [page 538](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	

**CNI s p g**      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**      Continue to the last prompt.

**\*\*\*\***      To exit the program.

**7**    Data dump the software changes.

**LD 43**      Load the program.

**EDD**      Invoke data dump program.

**\*\*\*\***      To exit the program.

**8**    Seat the CNI card in Core 0 and faceplate enable it.

**9**    In Core 1, Stat the CNIs:

**LD 135**      Load the program.

**STAT CNI**    Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***      To exit the program.

**10**   Enable the CNI cards by setting the ENL/DIS faceplate switch to ENL in Core/Net 0.

**11** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

**RUNNING ROM OS**

**ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**12** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**13** Synchronize the hard drives:

**LD 137**                      Load the program.

**SYNC**                      Synchronize the hard drives.

**\*\*\*\***                      Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 186

#### Testing Core/Net 1

**From Core/Net 1**, perform these tests.

- 1 Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get the status of CPU and memory.

**TEST CPU** Test the CPU.

- 2 Check the LCD states

**a.** Perform a visual check of the LCDs.

**b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display LCDs

- 3 Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

- 4 Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

- 5 Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x= system XMS.

**STAT XSM** Check the system monitors

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** To get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

**\*\*\*\*** Exit program.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Check the IGS status.

**LD 39** Load the program.



**STAT IGS X**

Check the status of IGS (X = IGS/DIGS card number. See Table 116 below).

\*\*\*\*

Exit program.

**Table 116**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications such as CallPilot, Symposium, and Meridian Mail..

**10** Check for dial tone.

---

**End of Procedure**

---

**Procedure 187**  
**Switching call processing**

- |               |   |
|---------------|---|
| <b>LD 135</b> | Load the program.                                     |
| <b>SCPU</b>   | Switch call processing from Core/Net 1 to Core/Net 0. |

---

**End of Procedure**

---

**Procedure 188**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1** Perform a redundancy sanity test:

- |                 |                               |
|-----------------|-------------------------------|
| <b>LD 135</b>   | Load the program.             |
| <b>STAT CPU</b> | Get status of CPU and memory. |
| <b>TEST CPU</b> | Test the CPU.                 |

- 2** Check the LCD states

- a.** Perform a visual check of the LCDs.
- b.** Test LCDs.

- |                  |                   |
|------------------|-------------------|
| <b>LD 135</b>    | Load the program. |
| <b>TEST LCDs</b> | Test LCDs.        |
| <b>DSPL ALL</b>  | Display all.      |

- 3** Test the CNI cards.

- |                     |                                       |
|---------------------|---------------------------------------|
| <b>LD 135</b>       | Load the program.                     |
| <b>STAT CNI c s</b> | Get status of CNI cards (core, slot). |
| <b>TEST CNI c s</b> | Test CNI (core, slot).                |

**4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

**5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors

**\*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

**a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

**\*\*\*\*** Exit the program.

**b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8    Check the IGS status.
  - LD 39**                      Load the program.
  - STAT IGS X**              Check the status of IGS (X = IGS/DIGS card number. See Table 117 below).
  - \*\*\*\***                      Exit program.

**Table 117**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 9    Check applications (such as CallPilot and Symposium).
- 10   Check for dial tone.

\_\_\_\_\_ **End of Procedure** \_\_\_\_\_

## Post-conversion procedure

### Introduction

This procedure verifies that the conversion process was successful, and system data converted completely. This is the last part of the total conversion procedure. Perform these steps **after** completing all other procedures for the system.

The site data should be printed before and after conversion. See Table 119 on [page 554](#). If the data has changed, make the necessary updates on the **Target** release, and datadump to the new system media. Print out the items marked with an asterisk (\*) to be sure everything converted properly. All other items in g are provided to be printed if desired.

Check the General Release Bulletin (GRB), and the Conversion notes (earlier in this document) to verify any database updates that need to be made as a result of conversion. Be sure to verify all SYSxxx messages that might appear during the conversion process. These messages might indicate some database updates are required.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Test call processing thoroughly. This can include more testing than is described in this procedure, depending on system configuration. This procedure is intended to show some of the basic tests performed to complete the conversion process.

**Note:** When parallel reload is complete, the attendant consoles will be in Night mode. If performing these procedures during the day, contact the attendant. If these procedures are taking place during the evening, it might not be desirable to perform these call processing steps.

### Post-conversion steps

Follow the steps in Procedure 189 on [page 550](#). to perform the post-conversion procedure.

### **Procedure 189**

#### **Performing the post-conversion procedure**

- 1 Print system data listed in Table 119 on [page 554](#). Verify that all information matches the printouts created before conversions. Make changes if necessary.
- 2 From any unrestricted telephone, dial the access code for an outside line (usually 9), and dial the listed Directory Number (DN) for the customer. Verify that the correct Incoming Call Indicator (ICI) lights at the attendant console.
- 3 If the customer is equipped with more than one console, transfer the call to another console.
- 4 Extend the call to a telephone, and release the call from the console.
- 5 From the called telephone, transfer the call back to the attendant.
- 6 Answer and release the call.
- 7 From any telephone dial the DN for the attendant. Verify that the correct ICI lights at the console, then release the call.
- 8 Busy-out one trunk group using a Trunk Group Busy (TGB) key on the console.
- 9 From any telephone with TGAR 0-7, dial the access code of the busied-out trunk group, to verify that the call is intercepted to the console and receives either overflow tone or a recorded announcement.
- 10 Restore the trunk group to the in-service state using the Trunk Group Busy (TGB) key on the console.
- 11 During the conversion procedure the Central Office might have busied-out the DID trunks. If DID trunks are equipped, from any unrestricted telephone, dial the access code for an outside line, and dial a DID number into the system.
- 12 If a private network is used, from any unrestricted telephone, dial the network access code and place a CDP, ESN, BARS/NARS, or ISDN call as applicable to the system.

- 13** If not done previously, set the time and date. If Call Detail Recording (CDR) is used, system message ERR225 will appear. This is normal.

**LD 02**

**STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

**Note:** Test all applications and call handling

- 14** If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.
- 15** Keep one copy of the **Source** software, (it was backed up in the pre-conversion procedure), in case you must reconvert. After the **Target** software runs well for a few weeks, return the original software to Nortel through the usual distribution channel.
- 16** Load LD 135 to test and switch CPUs.

<b>LD 135</b>	Load the program.
<b>TEST CPU</b>	Test CPU.
<b>SCPU</b>	Switch CPUs.
<b>****</b>	Exit LD.

- 17** Load LD 137 to get the status of the CMDUs and IOPs.

<b>LD 137</b>	Load the program.
<b>STAT</b>	Get the status of both CMDUs and IOPs.
<b>****</b>	Exit LD.

**Note:** Check MMDU in CP PII machines.

- 18** Load LD 43 to back up the other set of B1 disks. Insert the B1 disk in the active CMDU.

**LD 43** Load the program.

**BKO** Back up to the backup disks and the active CMDU.

**Note:** Back up additional 2 MByte floppy disks.

- 19** If not done previously, set the time and date. If Call Detail Recording (CDR) is used, the system message ERR225 will appear. This is normal.

**LD 02**

**STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

\*\*\*\* Exit LD.

**Note:** If equipped with FNF, perform steps 21-24. If equipped with IGS, perform step 20 below.

- 20** Test the IGS

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 118 on [page 553](#) below).

\*\*\*\* Exit program.



**Table 118**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**21** Check that Fiber Ring 1 operates correctly.

**LD 39** Load the program.

**STAT RING 1** Check the status of Ring 1.

**22** Reset the Rings:

**RSET** Reset the Rings and prepare them for redundancy.

**RSTR** Restore both Rings to HALF state .

**23** Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1 (HALF/HALF).

**24** If any Ring problems occur, correct them now.

STAT ALRM <X> <Y> To check the alarm status of individual FIJI cards or all FIJI cards. See *Software Input/Output: Administration* (553-3001-311) for more information.

**Note:** If equipped with IGS, you must STAT IGS.

**25** Verify that call processing operates correctly. this includes, but is not limited to the following:

- Check for dial tone.
- Make internal, external, and network calls.
- Check attendant console activity.
- Check DID trunks.
- Check any auxiliary processors.

**26** If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.

**27** Keep one copy of the **Source** software, (it was backed up in the pre-conversion procedure), in case you must reconvert. After the **Target** software runs well for a few weeks, return the original software to Nortel through the usual distribution channel.

Items marked with asterisks (\*) are required printout for conversion. Other items are recommended for a total system status.

**Table 119**  
**Print site data (Part 1 of 4)**

Site data	Print command
Terminal Blocks for all TNs	LD 20  REQ PRT  TYPE TNB  CUST <cr>

**Table 119**  
**Print site data (Part 2 of 4)**

<b>Site data</b>	<b>Print command</b>
Directory Numbers	LD 20 REQ PRT TYPE DNB CUST <cr>
Attendant Console data block for all customers	LD 20 REQ PRT TYPE ATT, 2250 CUST <cr>
*Customer Data Block for all customers	LD 21 REQ PRT TYPE CDB CUST <cr>
Route Data Block for all customers	LD 21 REQ PRT TYPE RDB CUST Customer number ROUT <cr> ACOD <cr>
*Configuration Record	LD 22 REQ PRT TYPE CFN

**Table 119**  
**Print site data (Part 3 of 4)**

Site data	Print command
*Software Packages	LD 22  REQ     PRT  TYPE    PKG
*Software Issues, Patches, ROM and Tape ID	LD 22  REQ     ISSP REQ     ROM REQ     TID
* Peripheral software versions	LD 22  REQ     PRT  TYPE    PSWV
ACD data block for all customers	LD 23  REQ     PRT  TYPE    ACD  CUST    Customer Number ACDN    ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32  .        IDC loop

**Table 119**  
**Print site data (Part 4 of 4)**

Site data	Print command
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27  REQ      PRT  TYPE     MISP  LOOP     loop number (0–158)  APPL     <cr>  PH        <cr>
DTI/PRI data block for all customers	LD 73  REQ      PRT  TYPE     DDB
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

**28** Obtain status of CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI</b>	Get the status of CNI cards.
<b>****</b>	To exit the program.

---

**End of Procedure**

---



---

# Adding a Network Group to Option 81C CP3, CP4 (NT5D21)

---

## Contents

This section contains information on the following topics:

Add a Core Network Group to Option 81C CP3, CP4 with FNF . . . . .	560
Prepare for upgrade . . . . .	561
Perform the upgrade . . . . .	570
Add an NT8D35 Network Group to Option 81C CP3, CP4 with FNF. . . . .	604
Prepare for upgrade . . . . .	605
Perform the upgrade . . . . .	614
Add a Core Network Group to Option 81C/IGS CP3, CP4 . . . . .	652
Prepare for upgrade . . . . .	652
Perform the upgrade . . . . .	661
Add an NT8D35 Network Group to Option 81C/IGS CP3, CP4 . . . . .	687
Prepare for upgrade . . . . .	687
Perform the upgrade . . . . .	696
Post-conversion procedure . . . . .	723

## Add a Core Network Group to Option 81C CP3, CP4 with FNF

### Introduction

Complete the following procedure to add a Network Group to the Core/Net module of a Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf.

Upgrades from Meridian Option 71 or Meridian Option 81 to Meridian Option 81C CP3, CP4 do not require Group 0 to be moved to the Core.

The Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- NTRB53AA Clock Controller required.
- The shortest fiber cable should always be used.
- The cables from group 0-1 must be the same length.
- The difference between the lengths of each fiber ring from group 0 to group 1 must not exceed 50 ft.



#### IMPORTANT!

The shortest Fiber Cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.



To add a Network Group to a Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf:

- Clock Controller cards must be NTRB53AA.
- NTRB33AC Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.

**IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each section features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Each section is written to maintain dial tone where possible and limit service interruptions.

Before field personnel attempt any software or hardware upgrade, they must complete the steps listed in Table 1.

**Table 120**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">562</a>
Upgrade checklists	<a href="#">563</a>
Prepare	<a href="#">563</a>
Identifying the proper procedure	<a href="#">564</a>
Connect a terminal	<a href="#">564</a>
Print site data	<a href="#">565</a>
Perform a template audit	<a href="#">567</a>
Back up the database (data dump)	<a href="#">569</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- Prepare a contingency plan if you abort the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers can print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.

## Connect a terminal

### Procedure 190 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (Table 121). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 121**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 121**
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

**Table 121**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**



## Back up the database (data dump)

### Procedure 191

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---

## Perform the upgrade

### Introduction

Figure 75 on page 571 shows a Meridian 1 Option 81C CP3, CP4 with FNF (NT5D21).




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C CP3, CP4 with FNF (NT5D21).

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

**Figure 75**  
**NT5D21 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for the NT5D21 with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP3, CP4.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- The NTRB33AC/AD Fiber Junctor Interface (FIJI) card.
- The NTRB53AA Clock Controller.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 122 below describes the *minimum* equipment required to add a Core Network Group to a Meridian 1 Option 81C CP3, CP4 with FNF (NT5D21). Additional equipment for increased Network capacity must be ordered separately.

**Table 122**

**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT5D21 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC47	Cable FIJI to FIJI	1
NTRC48	Cable FIJI to FIJI	1
NTRB34	3 port CNI <b>Note:</b> A vacant CNI port must be available, otherwise two new 3-port CNIs must be added.	
NTND14	CNI to 3PE cable	
NT9D89	Faceplate CNI to 3PE cable	
<b>Note:</b> The type of cabling is determined by available port assignment (4). Two for each Core of the same type is required.		

## Tools

Table 123 below lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 123**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group. See Figure 76 on [page 576](#).

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.

**Note:** Do not disconnect the existing Fiber cables.



**IMPORTANT!**


The shortest fiber cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional network group, fiber cables must be changed to adhere to the rules above.

Figure 76  
FIJI to FIJI cables (Option 81C example)



**Procedure 192**  
**Labeling and routing the shelf 0 fiber-optic cables (ascending)**

Route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order (Figure 77 on [page 580](#)).

**CAUTION**  
**Damage to Equipment**  
Do not excessively bend or cinch the fiber ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the fiber ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 124 on [page 578](#).



- 3** Pre-route a NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4** If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5** Continue to route NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6    To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 124**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

————— End of Procedure —————

**Procedure 193****Labeling and routing the shelf 1 fiber-optic cables (descending)**

Pre-route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 77 on [page 580](#)).

**CAUTION****Damage to Equipment**


Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note 1:** Do not disconnect FIJI cables.

**Note 2:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.

- 1** Start with Group 0, shelf 1.
- 2** Label each cable on both sides with the appropriate connection information from Table 125 on [page 580](#).
- 3** Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4** Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5** Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6** Route a final cable to the current highest Network Group, shelf 1.

**Figure 77**  
**Shelf 1 descending fiber-optic Ring (example)**




**Table 125**  
**FIJI Ring 1 connections (Part 1 of 2)**

Groups 0 - X are cabled in descending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/1	P1	Tx - J1
7/1	P2	Rx - J2
7/1	P1	Tx - J1
6/1	P2	Rx - J2

**Table 125**  
**FIJI Ring 1 connections (Part 2 of 2)**

<b>Groups 0 - X are cabled in descending order</b>		
<b>Group/shelf</b>	<b>NTRC48 fiber cable connector</b>	<b>FIJI card connector</b>
6/1	P1	Tx - J1
5/1	P2	Rx - J2
5/1	P1	Tx - J1
4/1	P2	Rx - J2
4/1	P1	Tx - J1
3/1	P2	Rx - J2
3/1	P1	Tx - J1
2/1	P2	Rx - J2
2/1	P1	Tx - J1
1/1	P2	Rx - J2
1/1	P1	Tx - J1
0/1	P2	Rx - J2

**Figure 78**  
**NT5D21 Core/Net card cage**



**Note 3:** CNI 8 port 0 is hardwired through the Core/Net backplane. No cable is required.

## End of Procedure

## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

## **Install and enable the QPC441 3PE cards**

### **Procedure 194**

#### **Installing and enable the QPC441 3PE cards**

- 1** Verify the 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 126 on [page 584](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2** Install a 3PE card in slot 11 of each added Network module.
- 3** Attach the cables to the 3PE faceplates.
- 4** Seat the cards.
- 5** Run 1 NT8D80BZ cable from the faceplate jack J4 of the QPC441 in Core 0 to the face plate jack of the QPC441 J4 connector.

- 6 Run 1 NT8D80BZ cable from the faceplate jack J3 of the QPC441 in Core 0 to the faceplate jack J3 of the QPC441 in Core 1.

**Table 126**  
**3PE card settings for the NT5D21 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	off				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

**Note:** Settings for the 3PE installed in the NT5D21 Module can be found in *Circuit card installation and testing* (553-3001-211).

**End of Procedure**



## **Interconnect the network modules**

On the back of each Core/Net module backplanes are 2 connectors labeled D and E.

### **Procedure 195**

#### **Interconnecting the network modules**


- 1** Connect the NT8D99AD cable from the D connector in shelf 0 to the D connector in shelf 1 of the NT5D21 Core/Net Module.
- 2** Connect the NT8D99AD cable from the E connector in shelf 0 to the E connector in shelf 1 of the NT5D21 Core/Net Module.

---

**End of Procedure**

---

**Figure 79**  
**NT5D21 Core/Network Module (rear view)—location of D and E connectors**



## Install and enable the QPC43R Peripheral Signaling (Per Sig) cards

### Procedure 196

#### Installing and enabling the Peripheral Signaling (Per Sig) cards

- 1 Install a QPC43R Per Sig card into slot 10 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

————— End of Procedure —————

## Disable and insert the NTRB33AC/AD FIJI cards

### Procedure 197

#### Disabling and inserting the NTRB33AC/AD FIJI cards

- 1 Faceplate *disable* the NTRB33AC FIJI cards.
- 2 Insert the NTRB33AC FIJI cards into slots 8 and 9 of each added Network module.
- 3 Seat the card and faceplate *enable* it.  
Do not cable the card at this time.

---

**End of Procedure**

---

## Disable and insert the NT8D17 Conf/TDS cards

### Procedure 198

#### Disabling and inserting the NT8D17 Conf/TDS cards

If NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.  
Do not plug the card into the backplane.

---

**End of Procedure**

---

## Enable the Network Group

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

Follow these procedures to activate the added CNI ports:

**Procedure 199**  
**Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1    Verify that Core 0 is active.

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2    If Core 1 is active, make Core 0 active.

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 200**  
**Checking that Clock Controller 0 is active**

- 1    Check the status of the Clock Controllers.

**LD 60**            Load program.

**SSCK 0**           Get the status of Clock Controller 0.

**SSCK 1**           Get the status of Clock Controller 1.



Core 0 is active, Clock 0 is active and FIJI is in half/half mode.

**Procedure 201**  
**Place CP 1 into parallel mode**

- 1    Set the CP card in Core 0 into maintenance.
- 2    Set the CNI cards in Core 1 to disable.
- 3    Place the CP card in Core 1 into maintenance.

- 4 Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**

---

**Procedure 202**

**Defining the XCT and extenders to the added group**

- 1 **On Core 1 only**, define the XCT and extenders to the added group.

**Note:** See Table 126 on [page 584](#):

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>&lt;cr&gt;</b>	Continue to the last prompt.
<b>****</b>	Exit the program.

- 2 Perform a data dump.

<b>LD 43</b>	Load the program.
--------------	-------------------

**EDD**                    Invoke data dump program.

**\*\*\*\***                    Exit the program.

Table 127 below specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 127**  
**Default CNI group assignments**

Group	CNI Slot Connections	3PE Faceplate Connection	Cable
<b>0</b>	Group 0 is hard-wired through the Core/Net module backplane: no cable is required.		
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>2</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>3</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>5*</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>5*</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<b>6*</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>6*</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>7*</b>	14 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>7*</b>	14 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<p><b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available Network group. This table reflects the default factory settings.</p> <p><b>Note 2:</b> *Fiber Network systems only.</p>			

**End of Procedure**

**Procedure 203**

**Checking that Ring 0 is active in Core 0**

- 1    Check the status of Ring 0.

**LD 39**                    Load program.

**STAT RING 0**        Get the status of Ring 0  
                              (Ring state should be HALF/HALF).

- 2    Disable Ring auto recovery.

**LD 39**                    Load program.

**ARCV OFF**            Set or reset auto-recovery operation for ring.

- 3    Swap to Ring 0.

**LD 39**                    Load program.

**SWRG 0**                Switch traffic to Ring x.

- 4    Disable Ring 1.

**LD 39**                    Load program.

**DIS RING 1**          Disable all FIJI cards on side 1.



**WARNING**

Cable Ring 1 to new network shelf only.

- 5    Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).



- 7 Break Ring 1 and cable the added FIJI cards. Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.



### IMPORTANT!

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



### CAUTION

#### Service Interruption

Call processing is interrupted for approximately 10 minutes while the INI is completed.

In LD 135, switch call processing to Core 1:

- 9 In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 10 In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 11 In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 12 In Core/Net 1, press the MAN INT button.



### WARNING

All call processing may be interrupted.



### IMPORTANT!

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.

**Note 1:** On FNF based systems after the INI, a FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding.

```
New State Ring 0 None
                Ring 1 Full
```

**13** Switch the clock controllers, if necessary.

- LD 60**                      Load the program.
- SSCK n**                    Get the status of clock n where:  
                                   n = 0 for clock controller 0  
                                   1 for clock controller 1
- SWCK**                      Switch system clock from active to standby.
- Note:** Make clock controller 1 the active clock.
- \*\*\*\***                        Exit the program.

**14** Disable Ring 0.

- LD 39**                      Load the program.

**DIS RING 0**                      Disables all FIJI cards on side 0.

\*\*\*\*                                  Exit the program.

- 15** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.

- 16** In LD 39, enable and stat Ring 0:

**LD 39**                              Load the program.

ENL Ring 0                      Enable Ring 0.

Stat Ring 0                      Status of Ring x.

\*\*\*\*                                  Exit the program.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

- 17 In Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 127 on [page 591](#).

**LD 17**                              Load the program.

**REQ**                                CHG

**TYPE**                            CEQU

**XCT X**                            X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                Continue to the last prompt.

**\*\*\*\***                Exit the program.

**18** Data dump the software changes.

**LD 43**                Load the program.

**EDD**                Invoke data dump program.

**\*\*\*\***                Exit the program.

**19** Seat the CNI card in Core 0 and faceplate enable it.

**20** In Core 1, Stat the CNIs:

**LD 135**              Load the program.

**STAT CNI**            Get status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***                Exit the program.

**21** Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.

**22** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

**RUNNING ROM OS**

**ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**23** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**24** Synchronize the hard drives:

**LD 137**                      Load the program.

**SYNC**                      Synchronize the hard drives.

**\*\*\*\***                      Exit the program.

---

**End of Procedure**

---

## **Test the Cores**

**Procedure 204**

**Testing Core/Net 1**

**From Core/Net 1**, perform these tests.

**1** Perform a redundancy sanity test:

**LD 135**                      Load the program.

**STAT CPU**                      Get status of CPU and memory.

**TEST CPU**                      Test the CPU.

**2** Check the LCD states

a. Perform a visual check of the LCDs.

b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL**

3 Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

4 Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

5 Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x = system XMS.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

6 Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Test the Fiber Rings

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.** Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- b.** If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c.** Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- 9    Check the status of the FIJI alarms.

**STAT ALRM**            Query the alarm condition for all FIJI cards in  
all Network Groups.

**\*\*\*\***                    Exit program.

- 10   Check applications such as CallPilot, Symposium, and Meridian Mail..

- 11   Check for dial tone.

---

**End of Procedure**

---

**Procedure 205**

**Switching call processing**

- 1    In LD 135, enter the SCPU command:

**LD 135**                Load the program.

**SCPU**                 Switch call processing from Core/Net 1 to Core/Net 0.

Core/Net 1 will INI and Core/Net 0 will become the active call processor.

---

**End of Procedure**

---

**Procedure 206**

**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1    Perform a redundancy sanity test:

**LD 135**                Load the program.

**STAT CPU**            Get the status of CPU and memory.

**TEST CPU**            Test the CPU.

- 2    Check the LCD states



- a. Perform a visual check of the LCDs.
- b. Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**      Test LCDs.

**DSPL ALL**        Display all.

**3** Test the CNI cards.

**LD 135**            Load the program.

**STAT CNI c s**    Get status of CNI cards (core, slot).

**TEST CNI c s**    Test CNI (core, slot).

**4** Test system redundancy.

**LD 137**            Load the program.

**TEST RDUN**      Test redundancy.

**DATA RDUN**

**TEST CMDU**      Test the MMDU card.

**5** Test that the system monitors are working.

**LD 37**            Load the program.

**STAT XSM**        Check the system monitors.

**\*\*\*\***              Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP**            Clear the displays on the cores.

**CMAJ**            Clear major alarms.

**CMIN ALL**        Clear minor alarms.

7    Test the clocks.

- a.    Verify that the clock controller is assigned to the *active* Core.

**LD 60**                    Load the program.

**SSCK x**                Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK**                Switch the Clock if necessary.

- b.    Verify that the Clock Controllers are switching correctly.

**SWCK**                Switch the Clock.

**SWCK**                Switch the Clock again.

8    Test the Fiber Rings.

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a.    Check that the Fiber Rings operate correctly.

**LD 39**                    Load the program.

**STAT RING 0**        Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1**        Check the status of Ring 1. (HALF/HALF).

- b.    If necessary, restore the Rings to Normal State.

**RSTR**                Restore both Rings to HALF state.

- c.    Check that the Rings operate correctly.

**STAT RING 0**        Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1**        Check the status of Ring 1. (HALF/HALF).

9    Check the status of the FIJI alarms.

**STAT ALRM**        Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\*

Exit program.

**10** Check applications (such as CallPilot and Symposium).

**11** Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See “Post-conversion procedure” on [page 723](#).

## Add an NT8D35 Network Group to Option 81C CP3, CP4 with FNF

### Introduction

Complete the following procedure to add an NT8D35 Group to a Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf.

The Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf must meet the requirements of Product Bulletins P-2002-1658-NA and PAA-2003-0199-NA for firmware 19. Highlights of the bulletins include:

- NTRB53AA Clock Controller required.
- The shortest fiber cable must always be used.
- The cables from group 0-1 must be the same length.
- The difference between the lengths of each fiber ring from group 0 to group 1 must not exceed 50 ft.



#### IMPORTANT!

The shortest fiber cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.

**Note:** When adding an additional Network Group, fiber cables must be changed to adhere to the rules above.

To add an NT8D35 Network Group to a Meridian 1 Option 81C/FNF equipped with an NT5D21 Core/Net shelf:

- Clock Controller cards must be NTRB53AA.
- NTRB33AC Fiber Junctor Interface (FIJI) card and the NTRE39 Optical Cable Management Card (OCMC) are added for FNF.

**IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 128 below.

**Table 128**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	606
Upgrade checklists	607
Prepare	607
Identifying the proper procedure	608
Connect a terminal	608
Print site data	609
Perform a template audit	612
Back up the database (data dump)	613

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- A contingency plan for backing out of the upgrade.

**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.

- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Preserve database backup information for a minimum of five days.

## Connect a terminal

### Procedure 207 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF



- 2** If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (Table 129). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 129**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>

**Table 129**  
**Print site data (Part 2 of 3)**

Site data	Print command
Route data block for all customers	LD 21
	REQ PRT
	TYPE RDB
	CUST Customer number
	ROUT <cr>
	ACOD <cr>
*Configuration Record	LD 22
	REQ PRT
	TYPE CFN
*Software packages	LD 22
	REQ PRT
	TYPE PKG
*Software issue and tape ID	LD 22
	REQ ISS
	REQ TID
* Peripheral software versions	LD 22
	REQ PRT
	TYPE PSWV
ACD data block for all customers	LD 23
	REQ PRT
	TYPE ACD
	CUST Customer Number
	ACDN ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32
	IDC loop


**Table 129**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
-

**TEMPLATE 0120 USER COUNT OK      CHECKSUM  
OK**

**TEMPLATE AUDIT COMPLETE**

## **Back up the database (data dump)**

### **Procedure 208 Performing a data dump**

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43**                      Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump.



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.



### IMPORTANT!

Preserve database backup information for a minimum of five days.

---

End of Procedure

---

## Perform the upgrade

### Introduction

Figure 80 on [page 615](#) shows a Meridian 1 Option 81C CP3, CP4 (NT5D21) with FNF.




### DANGER OF ELECTRIC SHOCK

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a NT8D35 Network Group to the Meridian 1 Option 81C CP3, CP4 (NT5D21) with FNF.

**Figure 80**  
**NT5D21 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP3, CP4 with FNF. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP PII.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.
- The NTRB33AC/AD Fiber Junctor Interface (FIJI) card.
- The NTRB53AA Clock Controller.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.



## Check required hardware

Table 130 describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81C CP3, CP4 (NT5D21) with FNF. Additional equipment for increased Network capacity must be ordered separately.

**Table 130**

**Minimum equipment required to add an NT8D35 Network Group to an Option 81C/FNF equipped with an NT5D21 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	5
NTRB33AC/AD	Card, Fibre Junctor Interface (FIJI)	2
NTND14	CNI to 3PE cables	4
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NTRC47	Cable FIJI to FIJI	1
NT8D35	Module, Network AC/DC	2
NTRC48	Cable FIJI to FIJI	4
NTRB34	3 port CNI <b>Note:</b> A vacant CNI port must available, otherwise 2 new 3-port CNIs must be added.	
NT9D89	Faceplate CNI to 3PE cable	
<b>Note:</b> The type of cabling is determined by available port assignment (4). Two for each Core of the same type is required.		

## Tools

Table 131 below lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 131**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Route FIJI to FIJI cables

Pre-route an NTRC47AA cable between the FIJI cards in shelf 0 and shelf 1 of each added Network Group. See Figure 81 on [page 620](#).

To minimize system downtime during the upgrade, all FIJI cables must be in place before the Network Groups are installed.

**Note:** Do not disconnect existing cables.



**IMPORTANT!**


The shortest fiber cable must always be used (NTRC48).

The cables from group 0 to group 1 must always be the same length as the cables from the last group back to group 0.

The difference between the lengths of each fiber ring from group 0 to any other group must not exceed 50 ft. Rings are directional. Ring 0 is ascending and ring 1 is descending.


**Note:** When adding an additional network group, fiber cables must be changed to adhere to the rules above.

**Figure 81**  
**FIJI to FIJI cables (Option 81C example)**



**Procedure 209**  
**Labeling and routing the shelf 0 fiber-optic cables (ascending)**

Pre-route the NTRC48 cables between the FIJI cards in each added Network shelf 0 in *ascending* order (Figure 83 on [page 627](#)).



**CAUTION**

**Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

- 1 Start with shelf 0 in the current highest Network Group.
- 2 Label each cable on both sides with the appropriate connection information from Table 132 on [page 622](#).

- 3** Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from the FIJI card in shelf 0 of the current highest Network Group, to the FIJI card in shelf 0 of the added Network Group.
- 4** If more than one Network Group is to be added, route a second NTRC48 cable of the appropriate length to shelf 0 of the second added group.
- 5** Continue to route NTRC48 cable of the appropriate length in *ascending* order between shelf 0 of each added Network Group.

- 6 To complete the Ring, route a final cable from the highest number group back to Group 0, shelf 0.

**Table 132**  
**FIJI Ring 0 connections**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

————— End of Procedure —————

**Procedure 210****Labeling and routing the shelf 1 fiber-optic cables (descending)**

Pre-route the NTRC48 cables between the FIJI cards in each Network shelf 1 in *descending* order (Figure 82 on [page 624](#)).

**CAUTION****Damage to Equipment**

Do not excessively bend or cinch the Fiber Ring cables. These cables are easily damaged. Use the Optical Cable Management Card (OCMC) to manage and protect the Fiber Ring cables.

**Note:** Each end of the NTRC48 cable is labeled “Tx” or Rx” in the factory.


- 1** Start with Group 0, shelf 1.
- 2** Label each cable on both sides with the appropriate connection information from Table 133 on [page 624](#).
- 3** Route a NTRC48 FIJI Fiber Ring cable of the appropriate length from shelf 1 of the FIJI card in Group 0, to the FIJI card in the added highest Network Group, shelf 1.
- 4** Route a NTRC48 cable from the FIJI card in the added highest Network Group, shelf 1 to the FIJI card in the second highest Network Group, shelf 1.
- 5** Continue to route NTRC48 FIJI Fiber Ring cables of the appropriate lengths between shelf 1 of each added Network Group. Route these cables in *descending* order of Network Groups.
- 6** Route a final cable to the current highest Network Group, shelf 1.

---

**End of Procedure**

---

**Figure 82**  
**Shelf 1 descending fiber-optic Ring (example)**



**Table 133**  
**FIJI Ring 0 connections (Part 1 of 2)**

Groups X - 0 are cabled in ascending order		
Group/shelf	NTRC48 fiber cable connector	FIJI card connector
0/0	P1	Tx - J1
1/0	P2	Rx - J2
1/0	P1	Tx - J1
2/0	P2	Rx - J2



**Table 133**  
**FIJI Ring 0 connections (Part 2 of 2)**

<b>Groups X - 0 are cabled in ascending order</b>		
<b>Group/shelf</b>	<b>NTRC48 fiber cable connector</b>	<b>FIJI card connector</b>
2/0	P1	Tx - J1
3/0	P2	Rx - J2
3/0	P1	Tx - J1
4/0	P2	Rx - J2
4/0	P1	Tx - J1
5/0	P2	Rx - J2
5/0	P1	Tx - J1
6/0	P2	Rx - J2
6/0	P1	Tx - J1
7/0	P2	Rx - J2
7/0	P1	Tx - J1
0/0	P2	Rx - J2

## Interconnect the network modules

### Procedure 211 Interconnecting the network modules

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 83 on [page 627](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.

- 1 Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2 Connect the B connector in shelf 0 to the B connector in shelf 1.


- 3**    Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4**    Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5**    Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6**    Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0)

**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**


---

**Figure 83****Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**

### Add CNI cards if necessary

If additional CNI cards are required, see Figure 84 on [page 628](#), add to each Core Module as required.

**Figure 84**  
**NT5D21 Core/Net card cage**



## Connect the 3PE to CNI cables

### Procedure 212

#### Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE Fanout Panel. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE Fanout Panel.

**Note:** See Table 134 on [page 630](#), Figure 85 on [page 631](#), and Figure 86 on [page 632](#) for NT8D76 cable connections.

- 1 Connect the NTND14 or NT9D89 cables to J3 and J4 of the 3PE cards.
- 2 Connect the new NTND14 or NT9D89 cables to the Fanout Panel in the Core/Net.

---


**End of Procedure**

---

**Table 134**  
**Default CNI group assignments**


Group	CNI Slot Connections	3PE Faceplate Connection	Cable
<b>0</b>	<b>Note:</b> Group 0 is hard-wired through the Core/Net module backplane: no cable is required.		
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>2</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>3</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>5*</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>5*</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<b>6*</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>6*</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>7*</b>	14 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>7*</b>	14 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<p><b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 (LD 17) if necessary. Any CNI port can support any available Network group. This table reflects the default factory settings.</p> <p><b>Note 2:</b> *Fiber Network systems only.</p>			

**Figure 85**  
**3PE backplane termination**



553-9492D

Figure 86  
3PE backplane termination



Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

Install and enable the QPC441 3PE cards

Procedure 213  
Installing and enable the QPC441 3PE cards

- 1
- Verify the QPC441F 3PE card settings.
- Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 135 on [page 634](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.



The FIJI card displays group and shelf setting.

- 2** Install a QPC441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.

3 Attach the cables to the QPC441F 3PE faceplates.

**Table 135**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

End of Procedure

**Procedure 214****Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC43R Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

**Procedure 215****Disabling and inserting the NTRB33AC FIJI cards**

- 1 Faceplate *disable* the NTRB33AC FIJI cards.
- 2 Insert the NTRB33AC FIJI cards into slots 2 and 3 of each added Network module.

Do not plug the card into the backplane.

---

**End of Procedure**

---

**Procedure 216****Disabling and inserting the NT8D17 Conf/TDS cards**

If NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert an NT8D17 Conf/TDS card into each added Network module.

Do not plug the card into the backplane.

---

**End of Procedure**

---

## **Enable the Network Group**

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

Follow these procedures to activate the added CNI ports:

### Procedure 217

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1    Verify that Core 0 is active.

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2    If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 218**
**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

<b>LD 60</b>	Load program.
<b>SSCK 0</b>	Get the status of Clock Controller 0.
<b>SSCK 1</b>	Get the status of Clock Controller 1.



Core 0 is active, Clock 0 is active and FIJI is in half/half mode.

---

**End of Procedure**


---

**Procedure 219**
**Place CP 1 into parallel mode**

- 1 Set the CP card in Core 0 into maintenance.
- 2 Set the CNI cards in Core 1 to disable.
- 3 Place the CP card in Core 1 into maintenance.
- 4 Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**


---

**Procedure 220**
**Defining the XCT and extenders to the added group**

- 1 On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 135 on [page 634](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU

**XCT X**                      X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                          Continue to the last prompt.

**\*\*\*\***                          Exit the program.

**2**    Perform a data dump.

**LD 43**                          Load the program.

**EDD**                          Invoke the data dump program.

**\*\*\*\***                          Exit the program.

**Note:** Table 136 on [page 639](#) specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software

---

**End of Procedure**

---

**Table 136**  
**Option 81C CNI group assignments**

Group	CNI Slot Connections	3PE Faceplate Connection	Cable
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	12 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>2</b>	12 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>3</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>5</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>5</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>6</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>6</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>7</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>7</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<p><b>Note 1:</b> Group 0 is hard-wired through the Core/Net module backplane; no cable is required.</p> <p><b>Note 2:</b> The default assignments in this table can be reconfigured with LD 17 (LD 17) if necessary.</p>			

**Procedure 221**

**Checking that Ring 0 is active in Core 0**

- 1    Check the status of Ring 0.

**LD 39**                    Load program.

**STAT RING 0**        Get the status of Ring 0  
                              (Ring state should be HALF/HALF).

- 2    Disable Ring auto recovery.

**LD 39**                    Load program.

**ARCV OFF**            Set or reset auto-recovery operation for ring.

- 3    Swap to Ring 0.

**LD 39**                    Load program.

**SWRG 0**                Switch traffic to Ring x.

- 4    Disable Ring 1.

**LD 39**                    Load program.

**DIS RING 1**          Disable all FIJI cards on side 1.



**WARNING**

Cable Ring 1 to new network shelf only.

- 5    Seat the remaining cards (3PE, PER SIG, XCT, FIJI) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 6    Faceplate enable all cards in both network modules (3PE, PER SIG, XCT and FIJI).



- 7 Break Ring 1 and cable the added FIJI cards. Ring 1 is descending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.
- 8 **In Core 1 only**, seat the new CNI card and faceplate enable.



### **IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



### **CAUTION**

#### **Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

In LD 135, switch call processing to Core 1:

- 9 In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 10 In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 11 In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 12 In Core/Net 1, press the MAN INT button.



### **WARNING**

All call processing may be interrupted.



### **IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active, FIJI ring 1 is full, FIJI ring 0 is none.

**Note 1:** On FNF based systems after the INI, a FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring; downloading up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all FIJI's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process does not affect service. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**Note 2:** Wait for new ring state change message to appear before proceeding:

```
New State Ring 0 None
                Ring 1 Full
```

**13** Switch the clock controllers, if necessary.

- LD 60**                      Load the program.
- SSCK n**                    Get the status of clock n where:  
                                   n = 0 for clock controller 0  
                                   1 for clock controller 1
- SWCK**                      Switch system clock from active to standby.
- Note:** Make clock controller 1 the active clock.
- \*\*\*\***                        Exit the program.

**14** Disable Ring 0.

- LD 39**                      Load the program.

**DIS RING 0**                      Disables all FIJI cards on side 0.

\*\*\*\*                                  Exit the program.

- 15** Break Ring 0 and cable the added FIJI cards. Ring 0 is ascending. Transmit from the lower Group FIJI card to Receive of next higher Group FIJI card. Transmit of the highest Group FIJI card cables to the Receive of Group FIJI card.

- 16** In LD 39, enable and stat Ring 0:

**LD 39**                              Load the program.

ENL Ring 0                      Enable Ring 0.

Stat Ring 0                      Status of Ring x.

\*\*\*\*                                  Exit the program.



The system is in split mode with Core 1 active. Clock 1 active and FIJI half and half.

- 17 In Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 136 on [page 639](#).

**LD 17**                              Load the program.

**REQ**                                CHG

**TYPE**                            CEQU

**XCT X**                          X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**                      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                Continue to the last prompt.

**\*\*\*\***                Exit the program.

**18** Data dump the software changes.

**LD 43**                Load the program.

**EDD**                Invoke the data dump program.

**\*\*\*\***                Exit the program.

**19** Seat the CNI card in Core 0 and faceplate enable it.

**20** In Core 1, Stat the CNIs:

**LD 135**              Load the program.

**STAT CNI**            Get the status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***                Exit the program.

**21** Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.

**22** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

**RUNNING ROM OS**

**ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**23** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**24** Synchronize the hard drives:

**LD 137** Load the program.

**SYNC** Synchronize the hard drives.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

## Test the Cores

### Procedure 222

#### Testing Core/Net 1

From Core/Net 1, perform these tests.

- 1 Perform a redundancy sanity test:

<b>LD 135</b>	Load the program.
<b>STAT CPU</b>	Get status of CPU and memory.
<b>TEST CPU</b>	Test the CPU.

- 2 Check the LCD states

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

<b>LD 135</b>	Load the program.
<b>TEST LCDs</b>	Test LCDs.
<b>DSPL ALL</b>	

- 3 Test the CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI c s</b>	Get the status of CNI cards (core, slot).
<b>TEST CNI c s</b>	Test CNI (core, slot).

- 4 Test system redundancy.

<b>LD 137</b>	Load the program.
<b>TEST RDUN</b>	Test redundancy.
<b>DATA RDUN</b>	
<b>TEST CMDU</b>	Test the MMDU card.

- 5** Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x = system XMS.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6** Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8** Test the Fiber Rings

See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- 9 Check the status of the FIJI alarms.

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

**\*\*\*\*** Exit program.

- 10 Check applications such as CallPilot, Symposium, and Meridian Mail..

- 11 Check for dial tone.

---

**End of Procedure**

---

**Procedure 223**  
**Switching call processing**

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

---

**End of Procedure**

---



**Procedure 224**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

**1** Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get the status of CPU and memory.

**TEST CPU** Test the CPU.

**2** Check the LCD states

**a.** Perform a visual check of the LCDs.

**b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

**3** Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

**5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Test the Fiber Rings

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

- a. Check that the Fiber Rings operate correctly.

**LD 39** Load the program.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- b. If necessary, restore the Rings to Normal State.

**RSTR** Restore both Rings to HALF state.

- c. Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF)..

**STAT RING 1** Check the status of Ring 1. (HALF/HALF).

- 9 Check the status of the FIJI alarms.

**STAT ALRM** Query the alarm condition for all FIJI cards in all Network Groups.

\*\*\*\* Exit program.

- 10 Check applications (such as CallPilot and Symposium).

- 11 Check for dial tone.

---

**End of Procedure**

---

Post-conversion steps must now be performed. See “Post-conversion procedure” on [page 723](#).

# Add a Core Network Group to Option 81C/IGS CP3, CP4

## Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions.

Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 137 below.

**Table 137**  
**Prepare for upgrade steps (Part 1 of 2)**

Step	Page
Plan the upgrade	653
Upgrade checklists	653
Prepare	654
Identifying the proper procedure	654
Connect a terminal	655
Print site data	655

**Table 137**  
**Prepare for upgrade steps (Part 2 of 2)**

Step	Page
Perform a template audit	<a href="#">658</a>
Back up the database (data dump)	<a href="#">660</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan if you abort the upgrade.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade*

*Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify that the current patch or Dep lists are installed at the source platform.
- Verify that the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and keycode.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing

the procedure or ignoring the warning boxes could cause longer service interruptions.

**IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

**Procedure 225****Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration. See Table 138. Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 138**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN



**Table 138**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 138**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted templates are repaired and duplicated templates are removed. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 226

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When "EDD000" appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION** **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\* Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---

## Perform the upgrade

### Introduction

Figure 87 on [page 662](#) shows a Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21).




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add a Core Network Group to the Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21).

**Figure 87**  
**NT5D21 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP3, CP4 with IGS. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### CAUTION — Service Interruption

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements for CP3, CP4.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### CAUTION — Service Interruption

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 92 below describes the *minimum* equipment required to add a Core Network Group to Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21).

Additional equipment for increased Network capacity must be ordered separately.

**Table 139**  
**Minimum equipment required to add a Core Network Group to an Option 81C/FNF equipped with an NT5D21 shelf**

Order Number	Description	Quantity per system
NT8D80BZ	Cable, CPU Interface, 5 ft.	2
NT8D99AD	Cable, Network to Network, 6 ft.	2
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT5D30	Dual IGS card	2
NT8D76	IGS to IGM cable	4



## Tools

Table 140 below lists the tools required to upgrade a Nortel system. Special tools required in a procedure are listed in that procedure.

**Table 140**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Interconnect the network modules

On the back of each Core/Net module backplanes are 2 connectors labeled D and E.

### **Procedure 227** **Interconnecting the network modules**


- 1 Connect the NT8D99AD cable from the D connector in shelf 0 to the D connector in shelf 1 of the NT5D21 Core/Net Module.
- 2 Connect the NT8D99AD cable from the E connector in shelf 0 to the E connector in shelf 1 of the NT5D21 Core/Net Module.

---

**End of Procedure**

---

**Figure 88**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



## Add CNI cards if necessary

### Procedure 228 Adding CNI cards

If additional CNI cards are required, see Figure 89 on [page 667](#).


- 1 Faceplate *disable* CNI card.
- 2 Insert card into Core/Net module. Do not seat card into backplane at this time.

---

**End of Procedure**

---

**Figure 89**  
**NT5D21 Core/Net card cage**



## Install cards in the network modules

Network cards must be installed in the added Core/Net module as described below. Each card must be installed and enabled or disabled as indicated.

## Install and enable the QPC441 3PE cards

### Procedure 229

#### Installing and enable the QPC441 3PE cards.

- 1 Verify the QPC441F 3PE card settings.

The group and shelf number of each Core/Net module is determined by the switch settings on the 3PE card. Use the information in Table 141 on [page 669](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2**    Install a QPC441F 3PE card in slot 11 of each added Core/Net Module.  
Do not seat the cards yet.
- 3**    Attach the NT8D80BZ cables to the 3PE faceplates. Run 1 NT8D80BZ  
cable from the faceplate jack J4 of the QPC441 in Core 0 to the face plate  
jack of the QPC441 J4 connector.

- 4 Run 1 NT8D80BZ cable from the faceplate jack J3 of the QPC441 in Core 0 to the faceplate jack J3 of the QPC441 in Core.

**Table 141**  
**3PE card settings for the NT5D21 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	off				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

**End of Procedure**

#### **Procedure 230**

##### **Installing and enabling the Peripheral Signaling (Per Sig) cards**

- 1 Install a QPC43R Per Sig card into slot 4 of each added Core/Net module. Push the latches forward to lock the card in place.
- 2 Faceplate *enable* the cards.

---

**End of Procedure**

---

#### **Procedure 231**

##### **Disabling and inserting the NT8D17 Conf/TDS cards**

If the NT8D17 Conf/TDS cards are used in the system, follow the procedures below.

- 1 Faceplate *disable* the NT8D17Conf/TDS cards.
- 2 Insert an NT8D17 Conf/TDS card into each added Core/Net module.
- 3 Seat and faceplate *enable*. Do not plug the card into the backplane.

---

**End of Procedure**

---

## **Enable the Network Group**

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

## **Adding the CNI cards or ports**

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

Follow these procedures to activate the added CNI ports:

#### **Procedure 232**

##### **Disabling and insert the NT5D30 DIGS cards**

- 1 Faceplate *disable* the NT5D30 DIGS cards.
- 2 Insert the NT5D30 DIGS cards into slot 9 of each Core/Net Module.

- 3 Do not plug the cards into the backplane.

---

**End of Procedure**

---

**Procedure 233**  
**Checking that Core 0 is active**

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135** Load program.

**STAT CPU** Get the status of the CPUs.

- 2 If Core 1 is active, make Core 0 active:

**SCPU** Switch to Core 0 (if necessary).

**\*\*\*\*** Exit program.

---

**End of Procedure**

---

**Procedure 234**  
**Checking that Clock Controller 0 is active**

- 1 Check the status of the Clock Controllers:

**LD 60** Load program.

**SSCK 0** Get the status of Clock Controller 0.

**SSCK 1** Get the status of Clock Controller 1.



Core 0 is active, Clock 0 is active.

---

**End of Procedure**

---

**Procedure 235**  
**Placing CP 1 into parallel mode**

- 1    Set the CP card in Core 0 into maintenance.
- 2    Set the CNI cards in Core 1 to disable.
- 3    Place the CP card in Core 1 into maintenance.
- 4    Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**

---

**Procedure 236**  
**Defining the XCT and extenders to the added group**

- 1    On Core 1 only, define the XCT and extenders to the added group.

**Note:** See Table 141 on [page 669](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)



**<cr>** Continue to the last prompt.

**\*\*\*\*** Exit the program.

**2** Perform a data dump.

**LD 43** Load the program.

**EDD** Invoke the data dump program.

**\*\*\*\*** Exit the program.

Table 142 below specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 142**  
**Default CNI group assignments**

Group	CNI Slot Connections	3PE Faceplate Connection	cable
<b>0</b>	<b>Note:</b> Group 0 is hard-wired through the Core/Net module backplane: no cable is required.		
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>2</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>3</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>5*</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>5*</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<b>6*</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>6*</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>7*</b>	14 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>7*</b>	14 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available Network group. This table reflects the default factory settings.			
<b>Note 2:</b> *Fiber Network systems only.			

————— End of Procedure —————

### Procedure 237

#### Seating the remaining cards


- 1 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

- 2 Faceplate *enable* all cards in both network modules (3PE, PER SIG, XCT and DIGS).
- 3 Cable the added NT5D30 DIGS cards.

**Figure 90**

**NT8D36 Inter-group module connections for IGS cards**



**Table 143**  
**Default CNI group assignments**

Group	CNI Slot Connections	3PE Faceplate Connection	Cable
<b>0</b>	<b>Note:</b> Group 0 is hard-wired through the Core/Net module backplane: no cable is required.		
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>2</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>3</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>5*</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>5*</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<b>6*</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>6*</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>7*</b>	14 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>7*</b>	14 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<p><b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available Network group. This table reflects the default factory settings.</p> <p><b>Note 2:</b> *Fiber Network systems only.</p>			

- 4** In Core 1 only, seat the new CNI card and faceplate *enable*.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION**

**Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

In LD 135, switch call processing to Core 1:

- 5** In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 6** In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 7** In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 8** In Core/Net 1, press the MAN INT button.



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

9     Switch the clock controllers, if necessary.

<b>LD 60</b>	Load the program.
<b>SSCK n</b>	Get status of clock n where: n = 0 for clock controller 0 1 for clock controller 1
<b>SWCK</b>	Switch system clock from active to standby.  <b>Note:</b> Make clock controller 1 the active clock.
<b>****</b>	Exit the program.

10    In **Core 0 only**, define the XCT and Extenders to the added group.

**Note:** See Table 143 on [page 676](#).

<b>LD 17</b>	Load the program.
<b>REQ</b>	CHG
<b>TYPE</b>	CEQU
<b>XCT X</b>	X = the extended conference/TDS/MFS
<b>EXT0 3PE</b>	
<b>CNI s p g</b>	Core to Network Interface card location where: s = slot (9 to 12) p = port number (0 to 1) g = group number (0 to 7)
<b>EXT1 3PE</b>	

**CNI s p g**      Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**      Continue to the last prompt.

**\*\*\*\***      Exit the program.

**11** Data dump the software changes.

**LD 43**      Load the program.

**EDD**      Invoke data dump program.

**\*\*\*\***      Exit the program.

**12** Seat the CNI card in Core 0 and faceplate enable it.

**13** In Core 1, Stat the CNIs:

**LD 135**      Load the program.

**STAT CNI**      Get the status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***      Exit the program.

**14** Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.

**15** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

**RUNNING ROM OS**

**ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**16** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**17** Synchronize the hard drives:

**LD 137**                      Load the program.

**SYNC**                      Synchronize the hard drives.

**\*\*\*\***                      Exit the program.

---

**End of Procedure**

---

## Test the Cores

**Procedure 238**

**Testing Core/Net 1**

**From Core/Net 1**, perform the following tests.

**1** Perform a redundancy sanity test:

**LD 135**                      Load the program.

**STAT CPU**                  Get the status of CPU and memory.

**TEST CPU**                  Test the CPU.

**2** Check the LCD states.



**a.** Perform a visual check of the LCDs.

**b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL**

**3** Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

**4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

**5** Install the two system monitors. Test that the system monitors are working.

**LD 37** Load the program.

**ENL TTY x** Enable the XMS, where x = system XMS.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

**6** Clear the display and minor alarms on both Cores.

**LD 135** Load the program.

**CDSP** Clear the displays on the cores.

- CMAJ** Clear major alarms.
- CMIN ALL** Clear minor alarms.
- 7 Test the clocks.
  - a. Verify that the clock controller is assigned to the *active* Core.
    - LD 60** Load the program.
    - SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.
    - SWCK** Switch the Clock if necessary.
  - b. Verify that the Clock Controllers are switching correctly.
    - SWCK** Switch the Clock.
    - SWCK** Switch the Clock again.
- 8 Check the IGS status.
  - LD 39** Load the program.
  - STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 144).
  - \*\*\*\*** Exit program.

**Table 144**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3

**Table 144**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 1	Shelf 1	IGS/DIGS 5& 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

9 Check applications such as CallPilot, Symposium, and Meridian Mail.

10 Check for dial tone.

————— **End of Procedure** —————

**Procedure 239**  
**Switching call processing**

**LD 135** Load the program.

**SCPU** Switch call processing from Core/Net 1 to Core/Net 0.

————— **End of Procedure** —————

**Procedure 240**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

1 Perform a redundancy sanity test:

**LD 135** Load the program.

**STAT CPU** Get the status of CPU and memory.

**TEST CPU** Test the CPU.

2 Check the LCD states

a. Perform a visual check of the LCDs.

b. Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

3 Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get the status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

4 Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

5 Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

6 Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

**7** Test the clocks.

- a.** Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1.

**SWCK** Switch the Clock if necessary.

- b.** Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

**8** Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 145).

**\*\*\*\*** Exit program.

**Table 145**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11

**Table 145**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 9    Check applications (such as CallPilot and Symposium).
- 10   Check for dial tone.

————— **End of Procedure** —————

Post-conversion steps must now be performed. See “Post-conversion procedure” on [page 723](#).

## Add an NT8D35 Network Group to Option 81C/IGS CP3, CP4

### Prepare for upgrade

This document uses a source-to-target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes that indicate which condition the system should be in at that stage of the upgrade. If the system is not in the proper condition you must take corrective action.

Each section is written to maintain dial tone where possible and limit service interruptions. Each section assumes any NT8D35 Network module installation is complete. For NT8D35 installation information see the *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210).

**Table 146**  
**Prepare for upgrade steps**

Step	Page
Plan the upgrade	<a href="#">688</a>
Upgrade checklists	<a href="#">688</a>
Prepare	<a href="#">688</a>
Identifying the proper procedure	<a href="#">689</a>
Connect a terminal	<a href="#">690</a>
Print site data	<a href="#">690</a>
Perform a template audit	<a href="#">693</a>
Back up the database (data dump)	<a href="#">695</a>

## Plan the upgrade

Planning for an upgrade includes the following details:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure Sufficient power for new columns/modules or applications.
- Identify all applications such as CallPilot, SCCS, IP, or Meridian Mail that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Prepare a contingency plan if you abort the upgrade.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

## Upgrade checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter of the *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). Engineers may print this section for reference during the upgrade.

## Prepare

Preparing for an upgrade includes the following details:

- Identify and become familiar with all procedures.



- Verify that all installed applications meet the minimum software requirements for the target platform. See the “General software conversion information” chapter in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Verify the current patch or Dep lists are installed at the source platform.
- Verify the required patch or Dep lists are installed at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and keycode.
- Secure the target software and keycode.
- Verify the new keycode using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source-to-target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

## Connect a terminal

### Procedure 241 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.

The settings for the terminal are:

- a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 2 If only one terminal is used for both Core or Core/Net modules, connect the terminal from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print site data

Print site data to preserve a record of the system configuration (Table 147). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 147**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN

**Table 147**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 147**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx
		V stands for a virtual superloop and xxx is the number of the virtual superloop.
		xxx = 0-252 in multiples of four for MG 1000E
		xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted templates are repaired and duplicated templates are removed. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this LD until the audit is complete. If the LD is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump)

### Procedure 242

#### Performing a data dump

- 1 On the Meridian 1 Option 81C, log in to the system.
- 2 Load the Equipment Data Dump Program (LD 43). Always enter LD 43 from the source (current) media. At the prompt, enter:

**LD 43** Load the program.

- 3 When “EDD000” appears on the terminal, enter:

**EDD** Begin the data dump.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

\*\*\*\* Exit the program.



#### **IMPORTANT!**

Preserve database backup information for a minimum of five days.

---

**End of Procedure**

---

## Perform the upgrade

### Introduction

Figure 91 on [page 697](#) shows a Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21).




#### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

Complete the procedure in this section to add an NT8D35 Network Group to the Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21).



**Figure 91**  
**NT5D21 Core/Net shelf**



## Review upgrade requirements

This section describes the *minimum* equipment required for CP3, CP4. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

### Check equipment received

Before the upgrade, check that the equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Do not proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

### Check vintage requirements for existing hardware

Check the list below to make sure that existing hardware meets the minimum vintage requirements.

- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The QPC43 Peripheral Signaling cards must be minimum vintage R.

If equipment does not meet the requirements, replace it before you begin the upgrade.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Equipment that does not meet the minimum vintage requirements can cause system malfunctions and loss of call processing.

## Check required hardware

Table 148 below describes the *minimum* equipment required to add an NT8D35 Network Group to a Meridian 1 Option 81C/IGS CP3, CP4 (NT5D21). Additional equipment for increased Network capacity must be ordered separately.

**Table 148**

**Minimum equipment required to add an NT8D35 Network Group to an Option 81C/FNF equipped with an NT5D21 shelf**

Order Number	Description	Quantity per system
NT8D99AB	Cable, Network to Network, 2 ft.	5
NTND14	CNI to 3PE cables	4
QPC43R	Pack, Peripheral Signaling (PS)	2
QPC441F	Pack, 3 Port Extender (3PE)	2
NT8D17	Pack, Conference, Tone and Digit Switch (CT)	2
NT8D35	Module, Network AC/DC	2
NTRB34	3 port CNI <b>Note:</b> A vacant CNI port must available, otherwise 2 new 3-port CNIs must be added.	
NT9D89	Faceplate CNI to 3PE cable	
NT5D30	Dual IGS card	2
NT8D76	IGS to IGM cable	4
<b>Note:</b> The type of cabling is determined by available port assignment (4). Two for each Core of the same type is required.		

## Tools

Table 149 lists the tools required to upgrade a Nortel system. Special tools required in the procedure are listed.

**Table 149**  
**List of recommended tools**

Digital Multimeter (DMM)	Electric drill and drill bits
Pliers, needlenose	Hammer and sheet metal center punch
Pliers, standard	1/4" socket wrench
Screwdriver, 3/16" flat blade	3/8" socket wrench
Screwdriver, #2 Phillips	1/4" nut driver
Wire cutters	7/16" socket driver
Electrical insulation tape	11/32 Deep Socket
5/16" socket wrench	Flashlight

## Check personnel requirements

Nortel recommends that a minimum of two people perform the upgrade.

## Connect the Power and System Monitor

Follow the instructions in *Communication Server 1000M and Meridian 1: Large System Installation and Configuration* (553-3021-210) to connect the power, System Monitor or modules. The system must be in True Redundant mode.

## Interconnect the network modules

### Procedure 243

#### Interconnecting the network modules

The back of each network module backplane has five connectors: A, B, C, D and E. See Figure 92 on [page 702](#). The shelf 0 connectors in Network groups 1 through 7 must be connected to the shelf 1 connectors of the Network groups 1 through 7. For example, for Network group 1, the shelf 0 connector must be connected to the shelf 1 connector.k group.

- 1** Connect an NT8D99AB cable from the A connector in shelf 0 of Network group 1 to the A connector in shelf 1 Network group 1.
- 2** Connect the B connector in shelf 0 to the B connector in shelf 1.
- 3** Connect the C connector in shelf 0 to the C connector in shelf 1.
- 4** Connect the D connector in shelf 0 to the D connector in shelf 1.
- 5** Connect the E connector in shelf 0 to the E connector in shelf 1.
- 6** Connect the A, B, C, D, and E connectors between shelf 0 and shelf 1 for all other Network groups in the system (except group 0)


**Note:** All connections are made with an NT8D99AB cable.

---

**End of Procedure**

---

**Figure 92**  
**Network shelf 0 to shelf 1 backplane connections (groups 1 through 7)**



## Add CNI cards if necessary


### **Procedure 244** **Adding an NTRB34 CNI cards**

If additional NTRB34 CNI cards are required, see Figure 93.

- 1 Faceplate *disable* the NTRB34 CNI card.
- 2 Insert card into Core/Net module. Do not seat card into backplane at this time.

End of Procedure

**Figure 93**  
NT5D21 Core/Net card cage



## Connect the 3PE to CNI cables

### Procedure 245

#### Connecting the 3PE to CNI cables

The CNI slot and port connections are labeled on the 3PE backplane. Each 3PE card is connected from J3 and J4 of each 3PE faceplate to the 3PE backplane.

**Note:** See Table 150 on [page 705](#) for NT4N14 and NT9D89 cable connections.

- 1 Connect the NT4N14 or NT9D89 cables to J3 and J4 of the 3PE cards.
- 2 Connect the NT4N14 and NT9D89 cables to the Fanout Panel in the Core/Net or to the Faceplate connection in the Core/Net Module.



### IMPORTANT!

When configuring NTND14 cables, observe the following rules:

- Always use the shortest NTND14 cable.
- A network group requires four NTND14 cables, two to each half group. Both cables to each half group must be the same length.
- Check the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50 ft. cables are manufacture discontinued.



- 3 Table 150 on [page 705](#) specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 150**  
**3PE card settings for the NT8D35 Module**

Jumper Settings									
Set Jumper RN27 at E35 to “A”.									
Switch Settings									
D20 switch position:		1	2	3	4				
81, 81C (Note)		off	on	on	on				
Shelf	Group	D20 switch position:				5	6	7	8
0  (3PE cards connected to the a CNI in Core or Core/Net 0)	0					on	on	on	on
	1					on	on	off	on
	2					on	off	on	on
	3					on	off	off	on
	4					off	on	on	on
	5					off	on	off	on
	6					off	off	on	on
	7					off	off	off	on
1  (3PE cards connected to the a CNI in Core or Core/Net 1)	0					on	on	on	off
	1					on	on	off	off
	2					on	off	on	off
	3					on	off	off	off
	4					off	on	on	off
	5					off	on	off	off
	6					off	off	on	off
	7					off	off	off	off
<b>Note:</b> For option 81C systems, QPC441 vintage F or later must be used in all modules.									

**End of Procedure**

## Install cards in the network modules

Network cards must be installed in the added Network modules as described below. Each card must be installed and enabled or disabled as indicated.

### Install and enable the QPC441 3PE cards

#### Procedure 246

##### Installing and enable the QPC441 3PE cards.

- 1    Verify the QPC441F 3PE card settings.

Switch settings on the 3PE card determine the group and shelf number of each Network module. Use the information in Table 151 on [page 708](#) to verify that the 3PE cards in the added Network modules have the correct switch and jumper settings.

The FIJI card displays group and shelf setting.

- 2    Install a QPC441F 3PE card in slot 1 of each added Network module. Do not seat the cards yet.
- 3    Attach the cables to the QPC441F 3PE faceplates.

---

End of Procedure

---

### Install and enable the QPC43R Peripheral Signaling (Per Sig) cards

#### Procedure 247

##### Installing and enabling the Peripheral Signaling (Per Sig) cards

- 1    Install a QPC43R Per Sig card into slot 4 of each added Network module. Push the latches forward to lock the card in place.
- 2    Faceplate *enable* the cards.

---

End of Procedure

---

## Disable and insert the NT8D17 Conf/TDS cards

### Procedure 248

#### Disabling and inserting the NT8D17 Conf/TDS cards

- 1 Faceplate *disable* the NT8D17 Conf/TDS cards.
- 2 Insert a NT8D17 Conf/TDS card into each added Network module.
- 3 Seat and Faceplate *enable*.

---

End of Procedure

---

## Enable the Network Group

### Procedure 249

#### Disabling and inserting the NT5D30 DIGS cards

- 1 Faceplate *disable* the NT5D30 DIGS cards.
- 2 Insert the NT5D30 DIGS card into slot 2 of each NT8D35 network module.

- 3    Do not plug the cards into the backplane.

**Note:** If you are adding more than one Network Group, add one group at a time in software. Follow all the remaining procedures in this chapter to enable one group before enabling another group.

---

**End of Procedure**

---

**Table 151**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

## Adding the CNI cards or ports

**Note:** CNI cards can be enabled and connected on the *inactive* Core only.

Follow these procedures to activate the added CNI ports.

### Procedure 250

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing.

- 1 Verify that Core 0 is active.

**LD 135**            Load program.

**STAT CPU**        Get the status of the CPUs.

- 2 If Core 1 is active, make Core 0 active:

**SCPU**            Switch to Core 0 (if necessary).

**\*\*\*\***            Exit program.

---

**End of Procedure**

---

**Procedure 251**  
**Checking that Clock Controller 0 is active**

- LD 60

Load program.
- SSCK 0


Get the status of Clock Controller 0.
- SSCK 1

Get the status of Clock Controller 1.

---

**End of Procedure**

---



Core 0 is active, Clock 0 is active.

**Procedure 252**  
**Place CP 1 into parallel mode**

- 1 Set the CP card in Core 0 into maintenance.
- 2 Set the CNI cards in Core 1 to disable.
- 3 Place the CP card in Core 1 into maintenance.
- 4 Wait until CP 1 completes the INI before continuing.

---

**End of Procedure**

---

**Procedure 253**  
**Defining the XCT and extenders to the added group**

- 1 On Core 1 only, define the XCT and extenders to the added group.
- Note:** See Table 152 on [page 712](#).

- LD 17

Load the program.
- REQ

CHG
- TYPE

CEQU
- XCT X

X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**      Core to Network Interface card location  
 where:  
 s = slot (9 to 12)  
 p = port number (0 to 1)  
 g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**      Core to Network Interface card location  
 where:  
 s = slot (9 to 12)  
 p = port number (0 to 1)  
 g = group number (0 to 7)

**<cr>**      Continue to the last prompt.

**\*\*\*\***      Exit the program.

**2**      Perform a data dump

**LD 43**      Load the program.

**EDD**      Invoke the data dump program.

**\*\*\*\***      Exit the program.

Table 152 on [page 712](#) specifies the Network group assignments for each CNI slot and port. These are fixed and cannot be changed in software.

**Table 152**  
**Default CNI group assignments**

Group	CNI Slot Connections	3PE Faceplate Connection	Cable
<b>0</b>	<b>Note:</b> Group 0 is hard-wired through the Core/Net module backplane: no cable is required.		
<b>1</b>	12D (Core/Net backplane)	<b>J3</b>	NTND14
<b>1</b>	12F (Core/Net backplane)	<b>J4</b>	NTND14
<b>2</b>	13A (Core/Net backplane)	<b>J3</b>	NTND14
<b>2</b>	13C (Core/Net backplane)	<b>J4</b>	NTND14
<b>3</b>	13D (Core/Net backplane)	<b>J3</b>	NTND14
<b>3</b>	13F (Core/Net backplane)	<b>J4</b>	NTND14
<b>4</b>	14A (Core/Net backplane)	<b>J3</b>	NTND14
<b>4</b>	14C (Core/Net backplane)	<b>J4</b>	NTND14
<b>5*</b>	14D (Core/Net backplane)	<b>J3</b>	NTND14
<b>5*</b>	14F (Core/Net backplane)	<b>J4</b>	NTND14
<b>6*</b>	13 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>6*</b>	13 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>7*</b>	14 J1 (CNI-3 faceplate)	<b>J3</b>	NT9D89
<b>7*</b>	14 J2 (CNI-3 faceplate)	<b>J4</b>	NT9D89
<b>Note 1:</b> The default assignments in this table can be reconfigured with LD 17 if necessary. Any CNI port can support any available Network group. This table reflects the default factory settings.			
<b>Note 2:</b> *Fiber Network systems only.			

End of Procedure



**Procedure 254****Seating the remaining cards**

- 1 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate *disabled* before seating.

- 2 Faceplate *enable* all cards in both network modules (3PE, PER SIG, XCT, DIGS).

- 3 Seat the remaining cards (3PE, PER SIG, XCT, DIGS) in both network modules.

**Note:** Cards must be faceplate disabled before seating.

**Table 153****Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 4 In Core 1 only, seat the new CNI card and faceplate enable.



**IMPORTANT!**

Power down all applications such as Meridian Mail, CallPilot, and Symposium.



**CAUTION**

**Service Interruption**

Call processing is interrupted for approximately 10 minutes while the INI is completed.

---

**End of Procedure**

---

## Switch call processing to Core 1

### Procedure 255

#### Switching call processing to Core 1

- 1 In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 2 In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 3 In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 4 In Core/Net 1, press the MAN INT button.



**WARNING**

All call processing may be interrupted.



**IMPORTANT!**

Power up all applications such as Meridian Mail, CallPilot, and Symposium.



Core 1 is active, Clock 0 is active.

**5** Switch the clock controllers, if necessary.

**LD 60** Load the program.

**SSCK n** Get the status of clock n where:  
n = 0 for clock controller 0  
1 for clock controller 1

**SWCK** Switch system clock from active to standby.

**Note:** Make clock controller 1 the active clock.

**\*\*\*\*** Exit the program.

**6** In **Core 0** only, define the XCT and Extenders to the added group.

**Note:** See Table 150 on [page 705](#).

**LD 17** Load the program.

**REQ** CHG

**TYPE** CEQU

**XCT X** X = the extended conference/TDS/MFS

**EXT0 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**EXT1 3PE**

**CNI s p g**            Core to Network Interface card location  
where:  
s = slot (9 to 12)  
p = port number (0 to 1)  
g = group number (0 to 7)

**<cr>**                Continue to the last prompt.

**\*\*\*\***                Exit the program.

**7**    Data dump the software changes.

**LD 43**                Load the program.

**EDD**                Invoke the data dump program.

**\*\*\*\***                Exit the program.

**8**    Seat the CNI card in Core 0 and faceplate enable it.

**9**    In Core 1, Stat the CNIs:

**LD 135**              Load the program.

**STAT CNI**            Get the status of CNI card.

**Note:** If any CNIs are disabled they must be enabled.

**\*\*\*\***                Exit the program.

**10**   Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.

**11** Perform the following in uninterrupted sequence:

- Press and release the MAN RST button in Core/Net 0.
- When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

### **RUNNING ROM OS**

### **ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

**12** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

**13** Synchronize the hard drives.

**LD 137** Load the program.

**SYNC** Synchronize the hard drives.

**\*\*\*\*** Exit the program.

---

**End of Procedure**

---

## **Test the Cores**

### **Procedure 256**

### **Testing Core/Net 1**

**From Core/Net 1**, perform these tests.

**1** Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

**2** Check the LCD states

- a. Perform a visual check of the LCDs.
- b. Test LCDs.

**LD 135**            Load the program.

**TEST LCDs**        Test LCDs.

**DSPL ALL**

**3**    Test the CNI cards.

**LD 135**            Load the program.

**STAT CNI c s**      Get the status of CNI cards (core, slot).

**TEST CNI c s**      Test CNI (core, slot).

**4**    Test system redundancy.

**LD 137**            Load the program.

**TEST RDUN**        Test redundancy.

**DATA RDUN**

**TEST CMDU**        Test the MMDU card.

**5**    Install the two system monitors. Test that the system monitors are working.

**LD 37**             Load the program.

**ENL TTY x**         Enable the XMS, where x = system XMS.

**STAT XSM**         Check the system monitors.

**\*\*\*\***                Exit the program.

**6**    Clear the display and minor alarms on both Cores.

**LD 135**            Load the program.

**CDSP**              Clear the displays on the cores.

- CMAJ** Clear major alarms.
- CMIN ALL** Clear minor alarms.
- 7** Test the clocks.
- a.** Verify that the clock controller is assigned to the *active* Core.
- LD 60** Load the program.
- SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1).
- SWCK** Switch the Clock if necessary.
- b.** Verify that the Clock Controllers are switching correctly.
- SWCK** Switch the Clock.
- SWCK** Switch the Clock again.
- 8** Check the IGS status.
- LD 39** Load the program.
- STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 154).
- \*\*\*\*** Exit program.

**Table 154**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3

**Table 154**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 1	Shelf 1	IGS/DIGS 5& 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

- 9    Check applications such as CallPilot, Symposium, and Meridian Mail..
- 10   Check for dial tone.

\_\_\_\_\_ **End of Procedure** \_\_\_\_\_

**Procedure 257**  
**Switching call processing**

- LD 135**        Load the program.
- SCPU**        Switch call processing from Core/Net 1 to Core/Net 0.

\_\_\_\_\_ **End of Procedure** \_\_\_\_\_



**Procedure 258**  
**Testing Core/Net 0**

**From Core/Net 0**, perform these tests.

- 1** Perform a redundancy sanity test.

**LD 135** Load the program.

**STAT CPU** Get status of CPU and memory.

**TEST CPU** Test the CPU.

- 2** Check the LCD states

- a.** Perform a visual check of the LCDs.

- b.** Test LCDs.

**LD 135** Load the program.

**TEST LCDs** Test LCDs.

**DSPL ALL** Display all.

- 3** Test the CNI cards.

**LD 135** Load the program.

**STAT CNI c s** Get the status of CNI cards (core, slot).

**TEST CNI c s** Test CNI (core, slot).

- 4** Test system redundancy.

**LD 137** Load the program.

**TEST RDUN** Test redundancy.

**DATA RDUN**

**TEST CMDU** Test the MMDU card.

- 5** Test that the system monitors are working.

**LD 37** Load the program.

**STAT XSM** Check the system monitors.

**\*\*\*\*** Exit the program.

- 6 Clear the display and minor alarms on both Cores.

**LD 135**

**CDSP** Clear the displays on the cores.

**CMAJ** Clear major alarms.

**CMIN ALL** Clear minor alarms.

- 7 Test the clocks.

- a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load the program.

**SSCK x** Get the status of the clock controllers (x is "0" or "1" for Clock 0 or Clock 1).

**SWCK** Switch the Clock if necessary.

- b. Verify that the Clock Controllers are switching correctly.

**SWCK** Switch the Clock.

**SWCK** Switch the Clock again.

- 8 Check the IGS status.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number.) See Table 155 on [page 723](#).

**\*\*\*\*** Exit program.

**Table 155**  
**Shelf 0 and 1 IGS/DIGS card locations**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5 & 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**9** Check applications (such as CallPilot and Symposium).

**10** Check for dial tone.

---

**End of Procedure**

---

## Post-conversion procedure

### Introduction

This procedure verifies that the conversion process was successful and that system data converted completely. This is the last part of the total conversion procedure. Perform these steps *after* completing all other procedures for the system.

The site data should be printed before and after conversion. See Table 157 on page 729. If the data has changed, make the necessary updates on the **Target** release, and datadump to the new system media. Print out the items marked with an asterisk (\*) to be sure everything converted properly. All other items on Table 157 on page 729 are provided to be printed if desired.

Check the General Release Bulletin (GRB), and the Conversion notes (earlier in this document) to verify any database updates that need to be made as a result of conversion. Be sure to verify all SYSxxx messages that might appear during the conversion process. These messages might indicate some database updates are required.



#### **CAUTION — Service Interruption**

##### **Service Interruption**

Test call processing thoroughly. This can include more testing than is described in this procedure, depending on system configuration. This procedure is intended to show some of the basic tests performed to complete the conversion process.

**Note:** When parallel reload is complete, the attendant consoles will be in Night mode. If performing these procedures during the day, contact the attendant. If these procedures are taking place during the evening, it might not be desirable to perform these call processing steps.

## **Post-conversion steps**

Follow the steps in Procedure 259 to perform the post-conversion procedure.

### **Procedure 259**

#### **Performing the post-conversion procedure**

- 1 Print system data listed in Table 157 on [page 729](#). Verify that all information matches the printouts created before conversions. Make changes if necessary.
- 2 From any unrestricted telephone, dial the access code for an outside line (usually 9), and dial the listed Directory Number (DN) for the customer. Verify that the correct Incoming Call Indicator (ICI) lights at the attendant console.

- 3 If the customer is equipped with more than one console, transfer the call to another console.
- 4 Extend the call to a telephone, and release the call from the console.
- 5 From the called telephone, transfer the call back to the attendant.
- 6 Answer and release the call.
- 7 From any telephone dial the DN for the attendant. Verify that the correct ICI lights at the console, then release the call.
- 8 Busy-out one trunk group using a Trunk Group Busy (TGB) key on the console.
- 9 From any telephone with TGAR 0-7, dial the access code of the busied-out trunk group, to verify that the call is intercepted to the console and receives either overflow tone or a recorded announcement.
- 10 Restore the trunk group to the in-service state using the Trunk Group Busy (TGB) key on the console.
- 11 During the conversion procedure the Central Office might have busied-out the DID trunks. If DID trunks are equipped, from any unrestricted telephone, dial the access code for an outside line, and dial a DID number into the system.
- 12 If a private network is used, from any unrestricted telephone, dial the network access code and place a CDP, ESN, BARS/NARS, or ISDN call as applicable to the system.
- 13 If not done previously, set the time and date. If Call Detail Recording (CDR) is used, system message ERR225 will appear. This is normal.

**LD 02****STAD dd mm yyyy hh mm ss**

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

**Note:** Test all applications and call handling

- 14 If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.
- 15 Keep one copy of the **Source** software, (it was backed up in the pre-conversion procedure), in case you must reconvert. After the **Target** software runs well for a few weeks, return the original software to Nortel through the usual distribution channel.
- 16 Load LD 135 to test and switch CPUs.

<b>LD 135</b>	Load the program.
<b>TEST CPU</b>	Test CPU.
<b>SCPU</b>	Switch CPUs.
<b>****</b>	Exit LD.

- 17 Load LD 137 to get the status of the CMDUs and IOPs.

<b>LD 137</b>	Load the program.
<b>STAT</b>	Get the status of both CMDUs and IOPs.
<b>****</b>	Exit LD.

**Note:** Check MMDU in CP PII machines.

- 18 Load LD 43 to back up the other set of B1 disks. Insert the B1 disk in the active CMDU.

<b>LD 43</b>	Load the program.
<b>BKO</b>	Back up to the backup disks and the active CMDU.

**Note:** Back up additional 2 MByte floppy disks.

- 19** If not done previously, set the time and date. If Call Detail Recording (CDR) is used, the system message ERR225 will appear. This is normal.

### LD 02

#### STAD dd mm yyyy hh mm ss

dd = day (for example, 05 for the fifth)

mm = month (for example, 09 for September)

yyyy = year (last 2 or all four digits, for example, 92 or 1992)

hh = hour (in 24-hour time, for example, 13:00 for 1:00 pm)

mm = minute (for example, 25)

ss = seconds (for example, 00)

\*\*\*\* Exit LD.

**Note:** If equipped with FNF, perform steps 21-24. If equipped with IGS, perform step 20 below.

- 20** Test the IGS

**Note:** See the *Software Input/Output: Maintenance* (553-3001-511) for more information on LD 39 commands.

**LD 39** Load the program.

**STAT IGS X** Check the status of IGS (X = IGS/DIGS card number. See Table 156 below).

\*\*\*\* Exit program.

**Table 156**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 1 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 0	IGS/DIGS 0 & 2
Network Group 1	Shelf 0	IGS/DIGS 4 & 6
Network Group 2	Shelf 0	IGS/DIGS 8 & 10
Network Group 3	Shelf 0	IGS/DIGS 12 & 14
Network Group 4	Shelf 0	IGS/DIGS 16 & 18

**Table 156**  
**Shelf 0 and 1 IGS/DIGS card locations (Part 2 of 2)**

Network Group	Shelf	IGS/DIGS card locations
Network Group 0	Shelf 1	IGS/DIGS 1 & 3
Network Group 1	Shelf 1	IGS/DIGS 5& 7
Network Group 2	Shelf 1	IGS/DIGS 9 & 11
Network Group 3	Shelf 1	IGS/DIGS 13 & 15
Network Group 4	Shelf 1	IGS/DIGS 17 & 19
<b>Note:</b> The DIGS card should be located in slot 9 of the Core/Net shelf and slot 2 of the NT8D35 network shelf.		

**21** Check that Fiber Ring 1 operates correctly.

**LD 39** Load the program.

**STAT RING 1** Check the status of Ring 1.

**22** Reset the Rings:

**RSET** Reset the Rings and prepare them for redundancy.

**RSTR** Restore both Rings to HALF state.

**23** Check that the Rings operate correctly.

**STAT RING 0** Check the status of Ring 0 (HALF/HALF).

**STAT RING 1** Check the status of Ring 1. (HALF/HALF)



**24** If any Ring problems occur, correct them now.

**STAT ALRM <X> <Y>** To check the alarm status of individual FIJI cards or all FIJI cards. See *Software Input/Output: Administration* (553-3001-311) for more information.

**Note:** If equipped with IGS, you must STAT IGS.

**25** Verify that call processing operates correctly. this includes, but is not limited to the following:

- Check for dial tone.
- Make internal, external, and network calls.
- Check attendant console activity.
- Check DID trunks.
- Check any auxiliary processors.

**26** If auxiliary processors are working with the system, ensure they are powered up. Be sure the Application Module Links (AML) are up. DCH and AML messages might indicate problems during the conversion. Investigate any of these messages.

**27** Keep one copy of the **Source** software, (it was backed up in the pre-conversion procedure), in case you must reconvert. After the **Target** software runs well for a few weeks, return the original software to Nortel through the usual distribution channel.

Items marked with asterisks (\*) are required printout for conversion. Other items are recommended for a total system status.

**Table 157**  
**Print site data (Part 1 of 4)**

Site data	Print command
Terminal Blocks for all TNs	LD 20  REQ      PRT  TYPE     TNB  CUST     <cr>

**Table 157**

**Print site data (Part 2 of 4)**

Site data	Print command
Directory Numbers	LD 20 REQ PRT TYPE DNB CUST <cr>
Attendant Console data block for all customers	LD 20 REQ PRT TYPE ATT, 2250 CUST <cr>
*Customer Data Block for all customers	LD 21 REQ PRT TYPE CDB CUST <cr>
Route Data Block for all customers	LD 21 REQ PRT TYPE RDB CUST Customer number ROUT <cr> ACOD <cr>
*Configuration Record	LD 22 REQ PRT TYPE CFN

**Table 157**  
**Print site data (Part 3 of 4)**

Site data	Print command
*Software Packages	LD 22 REQ PRT TYPE PKG
*Software Issues, Patches, ROM and Tape ID	LD 22 REQ ISSP REQ ROM REQ TID
* Peripheral software versions	LD 22 REQ PRT TYPE PSWV
ACD data block for all customers	LD 23 REQ PRT TYPE ACD CUST Customer Number ACDN ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32 . IDC loop

**Table 157**  
**Print site data (Part 4 of 4)**

Site data	Print command
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27  REQ     PRT  TYPE     MISP  LOOP     loop number (0–158)  APPL     <cr>  PH     <cr>
DTI/PRI data block for all customers	LD 73  REQ     PRT  TYPE     DDB
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

**28** Obtain status of CNI cards.

<b>LD 135</b>	Load the program.
<b>STAT CNI</b>	Get the status of CNI cards.
<b>****</b>	Exit the program.

---

**End of Procedure**

---

---

# Installing IODU/C cards, CP cards, CP memory

---

## Contents


This section contains information on the following topics:

Installing memory on Meridian 1 Options 61C CP PII, 81C CP PII ..	734
Prepare for installation .....	734
Perform installation .....	745
Installing memory on Meridian 1 Option 51C .....	805
Prepare for installation .....	805
Perform installation .....	816
Installing memory on Meridian 1 Options 61C, 81, 81C .....	839
Prepare for installation .....	839
Perform installation .....	850
Installing a Call Processor card on Options 61C CP PII, 81C CP PII ..	900
Prepare for installation .....	900
Perform installation .....	912
Installing an IODU/C on Meridian 1 Options 61C, 81, 81C .....	958
Prepare for installation .....	958
Perform installation .....	969
Installing a Call Processor card on Option 51C .....	1004
Prepare for installation .....	1004
Perform installation .....	1015
Installing IODU/C on Meridian 1 Option 51C .....	1021
Prepare for installation .....	1021
Perform installation .....	1031

Installing a Call Processor on Options 61C, 81, 81C .....	1051
Prepare for installation .....	1051
Perform installation .....	1063
Upgrade to an NTRB53 Clock Controller .....	1098
Upgrades on the web. ....	1103

## Installing memory on Meridian 1

### Options 61C CP PII, 81C CP PII



**CAUTION WITH ESDS DEVICES**

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.

The NT4N43 CP PII Multi-Media Disk Unit (CP PII MMDU) is located in the extreme right hand slot next to the CP PII card. The CP PII MMDU contains the hard drive, floppy drive and CD-ROM drive.

Software must be installed on both Core hard drives. Follow the procedures in this section to complete the installation.

*Note:* To complete these procedures, the system must be working and connected to a terminal.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 158 below:

**Table 158**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">735</a>
Upgrade Checklists	<a href="#">736</a>
Preparing	<a href="#">736</a>
Identifying the proper procedure	<a href="#">737</a>
Connect a terminal	<a href="#">737</a>
Print Site Data	<a href="#">738</a>
Perform a template audit	<a href="#">740</a>
Back up the database (data dump and ABKO)	<a href="#">742</a>
Identify two unique IP addresses	<a href="#">744</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.

- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.



## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### **Procedure 260** **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1** Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2** The settings for the terminal are:
  - a.** 9600 Baud
  - b.** 8 data
  - c.** parity none
  - d.** 1 stop bit
  - e.** full duplex
  - f.** XOFF
- 3** If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print Site Data

Print site data to preserve a record of the system configuration (see Table 159). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 159**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 159**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

Table 159  
Print site data (Part 3 of 3)

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.

**CAUTION — Service Interruption****Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT****STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 261

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 262****Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**            Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**            Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.

**CAUTION — Service Interruption****Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5 Once the backup is complete, type:

\*\*\*\*            Exit program

---

**End of Procedure**

---

**Procedure 263**  
**Converting to 2 MByte database media**



**IMPORTANT!**

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

## **Identify two unique IP addresses**

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this



configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Verify memory

Determine whether the system requires additional memory.

## CS 1000 Release 4.5

Table 160 lists the memory requirements of CS 1000 Release 4.5.

**Table 160**  
**CS 1000 Release 4.5 memory requirements**

System type	Flash memory requirement	DRAM memory requirement	Total memory requirement
Meridian 1 Options 51C/61C with CP3 (68060) or CP4 (68060E)	64 MByte	64 MByte	128 MByte
Meridian 1 Options 81/81C with or without Fibre Network Fabric	64 MByte	96 MByte	160 MByte
Meridian 1 Option 61C CP PII	NA	256 MByte	256 MByte
Meridian 1 Option 81C CP PII with or without Fibre Network Fabric	NA	256 MByte	256 MByte
Meridian 1 Option 61C CP PIV	NA	512 MBytes	512 Mbytes
Meridian 1 Option 81C CP PIV with or without Fibre Network Fabric	NA	512 MBytes	512 Mbytes
<p><b>Note 1:</b> CP1 (68030) and CP 2 (68040) Call Processors are not supported.</p> <p><b>Note 2:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PII systems are equipped with 256 MByte.</p> <p><b>Note 3:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PIV systems are equipped with 512 Mbytes.</p>			

## Perform data dump

### Procedure 264 Backing up the current data

- 1 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 2 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin data dump

- 3 Check total memory allocation before the upgrade.

**LD 10**                      Load program

When the header for LD 10 is displayed, note the value associated with Total Memory. After the upgrade, compare Total Memory before and after the upgrade. Total Memory should be greater after the upgrade.

- 4 Exit the program:

\*\*\*\*                      Exit program



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump is not successful, do not continue. Contact the technical support organization. Correct any data dump problem before continuing.

---

**End of Procedure**

---

## Check the status of the hardware

Follow the steps in Procedure 265 to determine the status of the hardware.

### Procedure 265

#### Determining hardware status

- 1    Load LD 137 to check the status of the hard disks.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the hard disks
<b>TEST CMDU</b>	Perform hard and floppy disk test

- 2    Load LD 135 and check the status of the CPs, CNIs and memories.

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of both CPs and memory
<b>STAT CNI</b>	Get the status of all configured CNIs

---

**End of Procedure**

---

## Check that Core 0 is active

Check that Core 0 is active. If Core 1 is active, make Core 0 active:

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of the CPUs
<b>SCPU</b>	Switch to Core 0 (if necessary)

## Split the Cores

From the active side, split the cores:

<b>LD 135</b>	Load program
<b>SPLIT</b>	Enter Split on the active core.
<b>****</b>	Exit program



System is in split mode, CP 0 is active, clock 0 is active, all network cards in shelf 1 are software disabled.


## Memory upgrade

Follow the steps in Procedure 266 to upgrade the memory.

### **Procedure 266** **Upgrade memory**


- 1 Remove all cables connected to the faceplate of the standby Call Processor card on Core 1.
- 2 Hot unplug the card and place with the DIMM side-up on a flat, clean surface.
- 3 Hold the latches of the DIMM socket. See Figure 94.

**Figure 94**  
**Latches**



- 4    Press and rotate the latches from inside to outside carefully. See Figure 95 on [page 751](#).


**Figure 95**  
**Rotate latches**



- 5** Remove the 128 MByte memory module.

- 6    Keep the latches open and insert the 256MB module into the DIMM socket. Align the two notches on the module with the two keys in the DIMM socket. See Figure 98 on [page 754](#).


**Figure 96**  
**Insert 256MB module**






- 7 Hold the memory module as shown in Figure 97.

**Figure 97**  
**Hold memory module**




- 8    Push the module into the DIMM socket until it is locked by the latches. See Figure 98.

**Figure 98**  
**Lock latches**



- 9 Put the faceplate label on the faceplate of the card. See Figure 99.

**Figure 99**  
**Faceplate label**



- 10 Return the card to its slot and reconnect all original cables.

**End of Procedure**

## Install the software on Core/Net 1

Follow the steps in Procedure 267 to install the software on Core/Net 1.

### Procedure 267

#### Installing the software on Core/Net 1

- 1    Install the CD-ROM into the CD-ROM drive in the CP PII MMDU:
  - a.    Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b.    Place the CD-ROM disk into the holder with the disk label facing up. Use the four tabs to secure the CD-ROM drive.
  - c.    Press the button to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 2    Place the CP PII Install floppy disk into the CP PII MMDU floppy drive.

**Note:** If a problem is detected during the system verification, the install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact the technical support organization.

- 3    Press the manual RESET button on the CP PII card faceplate.

Before the install runs, the system validates hard disk partitioning which takes about five minutes.

```
Testing partition 0

    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 1

    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 2

    0 percent done...1 percent done.....99
    percent done....100 percent completed!
```

```
Disk physical checking is completed!

Validate hard drive partition number and size...

There are 3 partitions in disk 0:
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte

Disk partitions and sectors checking is
completed!
```

The system then checks the partitions for any errors. The screen displays the following for each partition.

```
Copyright (c) 1993-1996 RST Software Industries
Ltd. All rights reserved

ver: X.X FCS

Disk Check In Progress...

    total disk space (bytes) : XX
    bytes in each allocation unit: XX
    total allocation units on disk: XX
    bad allocation units: XX
    available bytes on disk: XX
    available clusters on disk: XX
    maximum available contiguous chain (bytes):
    XX
    available space fragmentation (%): XX
    clusters allocated: XX

Done Checking Disk.

    checks for PART_X OK!

    pmDosFsCheck is completed!
```

4    Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
      Day-Month-Year, Hour:Min:Sec
      Succession Enterprise Software/Database/
BOOTROM CDROM INSTALL Tool
      Does this System have a Signaling
Server.....? (Default - No)
      Please enter:
<CR> -> <n> - No
      <y> - Yes
      Enter Choice>
```

- 5 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```

                M A I N      M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will
    be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:

    <CR> -> <u> - To Install menu

             <t> - To Tools menu.

             <q> - Quit.

    Enter Choice> <CR>

>Validating Keycode

    The provided keycode authorizes the install of
    XXXXXXXX software

    (all subissues) for machine type XXXX

    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 6    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

```
Please confirm that this keycode matches the
CDROM Release

      Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to
Install Menu.

      <n> - No, the keycode does not match. Try
another keycode diskette.

      Enter Choice> <CR>

      >Obtain database file names
```



**7 Enter **b** to install the Software, Database and CP-BOOTROM.**

## I N S T A L L M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**8**    Verify the CD-ROM version.

```
Please insert the installation CDROM into the
drive on Core X.

        The labeled side of the CDROM should be
side up in the CDROM tray.

        Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with
s/w checking.

        <q> - Quit.

        Enter Choice> <CR>

The installation CDROM contains version XXXXXXXX_X.

        Please enter:

<CR> -> <y> - Yes, this is the correct version.
Continue.

        <n> - No, this is not the correct version.
Try another CDROM or keycode disk

        Enter Choice> <CR>

        >copying direct.rec from /cd0/0300_KMR.N33/
target/p/s11/direct.rec to /u/direct.rec

        >Updating /u/direct.rec

Do you want to install Dependency Lists?

        Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

        Enter choice> n

Note: To choose yes and install the Dependency Lists, proceed to
step 10, otherwise proceed to step 11.
```

**9 Choosing Yes for the Dependency Lists installation.**

```

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt
will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

        <y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the
user to deplist menu.

The Installation Status Summary for the choices
entered is displayed as shown below:

-----
                INSTALLATION STATUS SUMMARY
                -----

Option           Choice  Status      Comment
SW: CD to disk   yes                install for rel 400
Dependency Lists yes
Database         no
CP-BOOTROM       yes

```

```
Please enter:

<CR> -> <y> - Yes, start installation.

        <n> - No, stop installation. Return to the
Main Menu.

The installation continues with the removal of the
patch, reten and deplist directories and copying
the files from the CD to the hard disk.

>Erasing old file "/u/patch/p12749_1.cpp"

>Erasing old file "/u/patch/reten/reten.pch"

>Erasing old file "/u/patch/deplist/m16000_3.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
p12749_1.cpp" to "/u/patch/p12749_1.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
deplist/m16000_3.cpp" to "/u/patch/deplist/
m16000_3.cpp"
```

**Note:** The removal of patch, reten and deplist directories will happen only when it is a software upgrade or a new system installation regardless of the DepList installation menu selection.

The installation status summary after the installation will be as follows:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW:CD to disk   yes      ok      install rel 400
Dependency Lists yes      ok      core Version 1
                                   Terminals Version 2
Database        no
CP-BOOTROM      yes      ok

```

**Note:** Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing ISSP command in LD 22. If there are NO DepLists available on the installation CD the summary should appear as shown below:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW: CD to disk   yes      ok      from 300 to
400
Dependency Lists yes      ok      None Available
SW: disk to ROM  yes      ok      from x210300 to
x2103400
Database        no
CP-BOOTROM      yes      ok      from x210300 to
x210400
IOP-ROM         yes      ok      from 02.00 to 02.00

```

### Installation of DepList through software installation

**The DepList should be installed during the software installation if it is present with the install software.**

Do you wish to install Dependency Lists? (y/n/[a]bort) :

The installation continues as below:

INSTALLING NEW SOFTWARE AND FILES:

Erasing flash ROM

Installing new flash ROM software modules:

Programming: auxres

Programming: diskos

Programming: sl1res

Programming: ovlres

Programming: loadware

Programming: remupg

Calculating CRC-32 on flash ROM program store

Installing new directory record

Installing new files

Installing Dependency Lists

Building system loadware

Done.

Note: Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing the ISSP command in LD 22.

If the response to the above query is "NO", the user is prompted to confirm the selection.

For example:

Do you wish to install Dependency Lists? (y/n/[a]bort) : **n**

Are you sure? (y/n/[a]bort) : **y**

**10** Confirm all options before installing the software.

```

>Processing the Install Control file

>Installing release XXXXX

      INSTALLATION STATUS SUMMARY
-----

=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| SW: CD to disk | yes | | install for rel XXXXX|
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| Database | yes | | |
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| CP-BOOTROM | yes | | |

      Please enter:<CR> -> <y> - Yes, start
Installation.

      <n> - No, stop Installation. Return to the
Main Menu.

Enter Choice> <CR>

>Checking System Configuration

You selected to upgrade the system from release:
XXXX to release: XXXXX.

This will erase all old system files.

```

```
Database files will NOT be erased. You may
continue installing the software or quit now and
leave your system unchanged.
```

```
Please enter:
```

```
<CR> -> <a> - Continue with Upgrade.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

```
>Starting Software Install
```

```
          >Upgrading from release XXXX to release
XXXXXX
```

- 11** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B



The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**12** Continue with upgrade when prompted. Select a database to install.  
Confirm database transfer.

```
You selected to transfer the database from the  
floppy disk - release: XXXX to the hard disk on  
Core X. release: XXXX.
```

```
This will erase the database on the hard disk.
```

```
The database diskette has been inserted into the  
floppy disk drive.
```

```
If you quit now, the database will be left  
unchanged.
```

```
Please enter:
```

```
<CR> -> <a> - Continue with Database Install.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

The system then informs you of the database details and prompts you to confirm.

```
You have chosen to restore database dated:
Month Day Hour:Min:Sec:Year

      Please confirm.

      Please enter:

<CR> -> <y> - Yes, load.

      <n> - No, DO NOT load.

Enter Choice> <CR>
```

- 13** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

- 14** Enter <CR> when prompted, returning the system to the Install Menu.

**15** Enter **q** to quit.

```

                I N S T A L L      M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will be
    prompted throughout the installation and given the
    opportunity to quit at any time.

    Please enter:

    <CR> -> <a> - To install Software, CP-BOOTROM.
           <b> - To install Software, Database, CP-
    BOOTROM.
           <c> - To install Database only.
           <d> - To install CP-BOOTROM only.
           <t> - To go to the Tools menu.
           <k> - To install Keycode only.

           For Feature Expansion, use OVL143.

    <p> - To install 3900 set Languages.
    <q> - Quit.

    Enter Choice> q
```

**16** The system then prompts you to confirm and reboot.

```
You selected to Quit the Software Installation
Tool.

You may reboot the system or return to the Main
Menu.

Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.
      <m> - Return to the Main menu.
Enter Choice> <CR>
>Removing (temporary files)

>Rebooting system ...
```

Before completing the next procedure, wait for Core/Net 1 to initialize.

---

**End of Procedure**

---

## Check for peripheral software download

Access LD 22 and print the Target peripheral software version.  
(The Source peripheral software version was printed during the pre-conversion procedure.)

If there is a difference between the Source and Target peripheral software version, a forced download occurs during initialization when coming out of parallel reload. System initialization takes longer and established calls on IPE are dropped.

<b>LD 22</b>	Load program
<b>REQ</b>	Print
<b>TYPE</b>	PSWV
<b>ISS</b>	Print issue and release
<b>TID</b>	Print Tape/Aux ID
<b>ISSP</b>	Print System, DepList, and Patch information
<b>****</b>	Exit program

## Transfer call processing from Core/Net 0 to Core/Net 1



### **CAUTION — Service Interruption**

#### **Service Interruption**

Call Processing will be interrupted! Perform these next steps carefully. This is the point at which service is interrupted. Calls in process are interrupted, especially if Peripheral Software Download takes place. Some calls might be dropped.



### **WARNING**

System initialization may take up to 15 minutes or longer.

Follow the steps in Procedure 268 on [page 775](#) to transfer call processing from Core/Net 0 to Core/Net 1.



### **IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

**Procedure 268****Transferring call processing from Core/Net 0 to Core/Net 1**

- 1 From Core/Net 0, the active side, transfer call processing to Core/Net 1:

**LD 135** Load program

**CUTOVR** The inactive CP become active

---

**End of Procedure**

---

**IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

**Note:** On FNF based systems after the INI:

A FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring, download up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all Fiji's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process is not service affecting. Depending on the number of groups installed, this process may take up to 20 minutes per ring.



Core 1 is active, Clock Controller 1 is active with Core 0 in split mode.

## Test Core/Net 1

Follow the steps in Procedure 269 to test call processing on Core/Net 1.

### Procedure 269

#### Testing call processing on Core/Net 1

- 1    Check for dial tone.
- 2    Make internal, external, and network calls.
- 3    Check attendant console activity.
- 4    Check DID trunks.
- 5    Check any auxiliary processors.

---

**End of Procedure**

---

*Note:* From this point forward Core/Net 0 is being upgraded with new software.

## Upgrade hardware on Core/Net 1

### Memory upgrade

Follow the steps in Procedure 270 to upgrade the memory.


### Procedure 270

#### Upgrade memory

- 1    Remove all cables connected to the faceplate of the standby Call Processor card on Core 1.
- 2    Hot unplug the card and place with the DIMM side-up on a flat, clean surface.
- 3    Hold the latches of the DIMM socket. See Figure 100.




**Figure 100**  
**Latches**



- 4 Press and rotate the latches from inside to outside carefully. See Figure 101 on [page 778](#).


**Figure 101**  
**Rotate latches**



- 5    Remove the 128 MByte memory module.


- 6 Keep the latches open and insert the 256MB module into the DIMM socket. Align the two notches on the module with the two keys in the DIMM socket. See Figure 104 on [page 781](#).

**Figure 102**  
**Insert 256MB module**




- 7    Hold the memory module as shown in Figure 103.

**Figure 103**  
**Hold memory module**




- 8 Push the module into the DIMM socket until it is locked by the latches. See Figure 104.

**Figure 104**  
**Lock latches**



9 Put the faceplate label on the faceplate of the card. See Figure 105.

Figure 105  
Faceplate label



10 Return the card to its slot and reconnect all original cables.

End of Procedure

## Install software on Core/Net 0

Follow the steps in Procedure 271 on [page 783](#) to install the new software on Core/Net 0.

### Procedure 271

#### Installing the software and converting the database

- 1 Check that a terminal is connected to J25 on Core/Net 0.
- 2 In Core/Net 0, install the CD-ROM into the CD-ROM drive in the MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Press the button again to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 3 Place the CP PII Install floppy disk into the MMDU floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 4 Press the manual RESET button on the CP PII card faceplate.

Before the install runs, the system validates hard disk partitioning which takes about five minutes.

```
Testing partition 0

    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 1

    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 2
```

```
0 percent done...1 percent done.....99
percent done....100 percent completed!
```

```
Disk physical checking is completed!
```

```
Validate hard drive partition number and size...
```

```
There are 3 partitions in disk 0:
```

```
The size of partition 0 of disk 0 is XX Mbyte
```

```
The size of partition 0 of disk 0 is XX Mbyte
```

```
The size of partition 0 of disk 0 is XX Mbyte
```

```
Disk partitions and sectors checking is
completed!
```



The system then checks the partitions for any errors. The screen displays the following for each partition.

```
Copyright (c) 1993-1996 RST Software Industries
Ltd. All rights reserved

ver: X.X FCS

Disk Check In Progress...

    total disk space (bytes) : XX
    bytes in each allocation unit: XX
    total allocation units on disk: XX
    bad allocation units: XX
    available bytes on disk: XX
    available clusters on disk: XX
    maximum available contiguous chain (bytes):
    XX
    available space fragmentation (%): XX
    clusters allocated: XX

Done Checking Disk.

    checks for PART_X OK!

    pmDosFsCheck is completed!
```

**5**    Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
      Day-Month-Year, Hour:Min:Sec
      Succession Enterprise Software/Database/
BOOTROM CDROM INSTALL Tool
      Does this System have a Signaling
Server.....? (Default - No)
      Please enter:
<CR> -> <n> - No
      <y> - Yes
      Enter Choice>
```

- 6 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```

                                M A I N      M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will
    be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:

    <CR> -> <u> - To Install menu

              <t> - To Tools menu.

              <q> - Quit.

    Enter Choice> <CR>

>Validating Keycode

    The provided keycode authorizes the install of
    XXXXXXXX software

    (all subissues) for machine type XXXX

    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 7    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

```
Please confirm that this keycode matches the
CDROM Release

      Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to
Install Menu.

      <n> - No, the keycode does not match. Try
another keycode diskette.

      Enter Choice> <CR>

      >Obtain database file names
```

**8 Enter **b** to install the Software, Database and CP-BOOTROM.**

## I N S T A L L M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

9    Verify the CD-ROM version.

```
Please insert the installation CDROM into the
drive on Core X.

        The labeled side of the CDROM should be
side up in the CDROM tray.

        Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with
s/w checking.

        <q> - Quit.

        Enter Choice> <CR>

The installation CDROM contains version XXXXXXXX_X.

        Please enter:

<CR> -> <y> - Yes, this is the correct version.
Continue.

        <n> - No, this is not the correct version.
Try another CDROM or keycode disk

        Enter Choice> <CR>

        >copying direct.rec from /cd0/0300_KMR.N33/
target/p/s11/direct.rec to /u/direct.rec

        >Updating /u/direct.rec

Do you want to install Dependency Lists?

        Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

        Enter choice> n

Note: To choose yes and install the Dependency Lists, proceed to
step 10, otherwise proceed to step 11.
```

**10 Choosing Yes for the Dependency Lists installation.**

```

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt
will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

        <y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the
user to deplist menu.

The Installation Status Summary for the choices
entered is displayed as shown below:

-----
                INSTALLATION STATUS SUMMARY
                -----

Option           Choice  Status      Comment
SW: CD to disk   yes                install for rel 400
Dependency Lists yes
Database         no
CP-BOOTROM       yes

```

```
Please enter:

<CR> -> <y> - Yes, start installation.

        <n> - No, stop installation. Return to the
Main Menu.

The installation continues with the removal of the
patch, reten and deplist directories and copying
the files from the CD to the hard disk.

>Erasing old file "/u/patch/p12749_1.cpp"

>Erasing old file "/u/patch/reten/reten.pch"

>Erasing old file "/u/patch/deplist/m16000_3.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
p12749_1.cpp" to "/u/patch/p12749_1.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
deplist/m16000_3.cpp" to "/u/patch/deplist/
m16000_3.cpp"
```

**Note:** The removal of patch, reten and deplist directories will happen only when it is a software upgrade or a new system installation regardless of the DepList installation menu selection.



The installation status summary after the installation will be as follows:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW:CD to disk   yes      ok      install rel 400
Dependency Lists yes      ok      core Version 1
                                   Terminals Version 2
Database        no
CP-BOOTROM      yes      ok

```

**Note:** Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing ISSP command in LD 22. If there are NO DepLists available on the installation CD the summary should appear as shown below:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW: CD to disk   yes      ok      from 300 to
400
Dependency Lists yes      ok      None Available
SW: disk to ROM  yes      ok      from x210300 to
x2103400
Database        no
CP-BOOTROM      yes      ok      from x210300 to
x210400
IOP-ROM         yes      ok      from 02.00 to 02.00

```

### Installation of DepList through software installation

**The DepList should be installed during the software installation if it is present with the install software.**

Do you wish to install Dependency Lists? (y/n/[a]bort) :

The installation continues as below:

INSTALLING NEW SOFTWARE AND FILES:

Erasing flash ROM

Installing new flash ROM software modules:

Programming: auxres

Programming: diskos

Programming: sl1res

Programming: ovlres

Programming: loadware

Programming: remupg

Calculating CRC-32 on flash ROM program store

Installing new directory record

Installing new files

Installing Dependency Lists

Building system loadware

Done.

Note: Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing the ISSP command in LD 22.

If the response to the above query is "NO", the user is prompted to confirm the selection.

For example:

Do you wish to install Dependency Lists? (y/n/[a]bort) : **n**

Are you sure? (y/n/[a]bort) : **y**

**11** Confirm all options before installing the software.

```
>Processing the Install Control file
>Installing release XXXXX

      INSTALLATION STATUS SUMMARY
-----

=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| SW: CD to disk | yes | | install for rel XXXXX|
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| Database | yes | | |
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| CP-BOOTROM | yes | | |

      Please enter:<CR> -> <y> - Yes, start
Installation.

      <n> - No, stop Installation. Return to the
Main Menu.

Enter Choice> <CR>

>Checking System Configuration

You selected to upgrade the system from release:
XXXX to release: XXXXX.

This will erase all old system files.
```

```
Database files will NOT be erased. You may
continue installing the software or quit now and
leave your system unchanged.
```

```
Please enter:
```

```
<CR> -> <a> - Continue with Upgrade.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

```
>Starting Software Install
```

```
          >Upgrading from release XXXX to release
XXXXXX
```

- 12** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

- 13** Continue with upgrade when prompted. Select a database to install. Confirm database transfer.

```
You selected to transfer the database from the  
floppy disk - release: XXXX to the hard disk on  
Core X. release: XXXX.
```

```
This will erase the database on the hard disk.
```

```
The database diskette has been inserted into the  
floppy disk drive.
```

```
      If you quit now, the database will be left  
unchanged.
```

```
      Please enter:
```

```
<CR> -> <a> - Continue with Database Install.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

The system then informs you of the database details and prompts you to confirm.

```
You have chosen to restore database dated:
Month Day Hour:Min:Sec:Year

      Please confirm.

      Please enter:

<CR> -> <y> - Yes, load.

      <n> - No, DO NOT load.

Enter Choice> <CR>
```

- 14** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

- 15** Enter <CR> when prompted, returning the system to the Install Menu.

**16** Enter **q** to quit.

```

                I N S T A L L      M E N U

The Software Installation Tool will
install or upgrade Succession Enterprise System
Software, Database and the CP-BOOTROM. You will be
prompted throughout the installation and given the
opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.
        <b> - To install Software, Database, CP-
BOOTROM.
        <c> - To install Database only.
        <d> - To install CP-BOOTROM only.
        <t> - To go to the Tools menu.
        <k> - To install Keycode only.

        For Feature Expansion, use OVL143.
        <p> - To install 3900 set Languages.
        <q> - Quit.

Enter Choice> q
```

**17** The system then prompts you to confirm and reboot.

```
You selected to Quit the Software Installation
Tool.

You may reboot the system or return to the Main
Menu.

Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.
      <m> - Return to the Main menu.
Enter Choice> <CR>
>Removing (temporary files)

>Rebooting system ...
```

Before completing the next procedure, wait for Core/Net 0 to initialize.

---

**End of Procedure**

---



## Enable system redundancy

Follow the steps in Procedure 272 on [page 801](#) to enable system redundancy.

### **Procedure 272**

#### **Enabling system redundancy**

**1** From the active CPU, Core/Net 1, enable redundancy:

**LD 135** Load program

**JOIN** Synchronize the memory and drives

---

**End of Procedure**

---

## Test Core/Net 1 and Core/Net 0

Follow the steps in Procedure 273 on [page 802](#) to test Core/Net 1 and Core/Net 0.

### Procedure 273

#### Testing Core/Net 1 and Core/Net 0

From the active CPU, Core/Net 1, perform these tests:

- 1 Perform a redundancy sanity test using the following sequence.

<b>LD 135</b>	Load program
<b>STAT CNI c s</b>	Get status of cCNI cards
<b>STAT CPU</b>	Get status of CPU and memory
<b>TEST CPU</b>	Test the CP PII card in both Core/Nets
<b>TEST CNI c s</b>	Test each cCNI card (core, slot)
<b>STAT SUTL</b>	Get status of System Utility (main and Transition) cards
<b>TEST SUTL</b>	Test the System Utility (main and Transition) cards
<b>TEST IPB</b>	Test the Inter Processor Bus
<b>TEST LCD</b>	Test LCDs
<b>TEST LED</b>	Test LEDs

- 2 Test system redundancy:

<b>LD 137</b>	Load program
<b>TEST RDUN</b>	Test redundancy
<b>DATA RDUN</b>	
<b>TEST CMDU</b>	Test the CP PII MMDU card

**3 Switch Cores and test the other side (Core/Net 0).**

<b>LD 135</b>	Load program
<b>SCPU</b>	Switch cores
<b>TEST CPU</b>	Test the inactive Core/Net
<b>STAT CNI c s</b>	Get status of cCNI (both main and Transition) cards
<b>TEST CNI c s</b>	Test cCNI (both main and Transition) cards
<b>STAT SUTL</b>	Get status of System Utility card
<b>TEST SUTL</b>	Test System Util card
<b>TEST IPB</b>	Test Inter Processor Bus
<b>TEST LCD</b>	Test LCDs
<b>TEST LED</b>	Test LEDs

**4 Clear the display and minor alarms on both Cores.**

<b>CDSP</b>	Clear the displays on the Cores
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms

**5 Get the status of the Cores, CNIs, and memory.**

<b>STAT CPU</b>	Get the status of both Cores and redundancy
<b>STAT CNI c s</b>	Get the status of all configured cCNIs (both main and Transition) cards
<b>****</b>	Exit program

---

**End of Procedure**

---

## Perform a data dump

Follow the steps in Procedure 274 on [page 804](#) to perform a data dump.

### Procedure 274

#### Performing a data dump

- 1    Load the LD 43. At the prompt, enter:

**LD 43**                      Load program

- 2    Insert a floppy disk into the CP PII MMDU to capture the backup.

- 3    When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump

- 4    When “DATABASE BACKUP COMPLETE” or “DATADUMP COMPLETE” appears on the terminal, enter:

**\*\*\*\***                      Exit program



#### CAUTION — Service Interruption

##### Loss of Data

If the data dump is not successful, do not continue. Contact the technical support organization. Correct any data dump problem before continuing.

- 5    Proceed to “Post-conversion procedure” on [page 723](#).



The parallel reload procedure is complete.

---

**End of Procedure**

---

## Installing memory on Meridian 1 Option 51C



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with NT5D61 Input Output Disk Unit with CD-ROM (IODU/C) card(s). If the system is not equipped with the IODU/C card, do not use these procedures

The procedures in this section describe how to increase CP memory on CP3 and CP4 systems.

To better understand the process, read through the entire procedure before beginning the conversion.

The following section describes how to increase memory on Meridian 1 Option 51C systems **only**.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 161 below:

**Table 161**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">806</a>
Upgrade Checklists	<a href="#">807</a>
Preparing	<a href="#">807</a>
Identifying the proper procedure	<a href="#">807</a>
Connect a terminal	<a href="#">808</a>
Print Site Data	<a href="#">809</a>
Perform a template audit	<a href="#">811</a>
Back up the database (data dump and ABKO)	<a href="#">813</a>
Identify two unique IP addresses	<a href="#">815</a>

## Planning

Planning for an upgrade involves the following tasks:

- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.

- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing

the procedure or ignoring the warning boxes could cause longer service interruptions.



**IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### Procedure 275 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1    Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2    The settings for the terminal are:
  - a.    9600 Baud
  - b.    8 data
  - c.    parity none
  - d.    1 stop bit
  - e.    full duplex
  - f.    XOFF
- 3    If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---



## Print Site Data

Print site data to preserve a record of the system configuration (Table 162). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 162**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 162**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

**Table 162**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 276

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 277**

**Performing an ABKO (save the database to floppies)**

- 1     Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2     Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**                      Load program

- 3     Run the ABKO backup (LD 143).

**ABKO**                      Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4     If there are validation errors, repeat the procedure.



**CAUTION — Service Interruption**

**Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5     Once the backup is complete, type:

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 278**  
**Converting to 2 MByte database media****IMPORTANT!**

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

**Identify two unique IP addresses**

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this

configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Verify memory

Determine whether the system requires additional memory. Refer to Table 163 on [page 817](#) for memory requirement.



**Table 163**  
**Supported memory upgrade configurations (Part 1 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
48	32	16	NT5D10AA	NT5D03AA	16	0	0	0
64	32	32	NT5D10CA	NT5D03BA	16	16	0	0
					32	0	0	0
80	32	48	NT5D10EA	NT5D03CA	16	16	16	0
					16	32	0	0
96	32	64	NT5D10TA	NT5D03TA	16	16	16	16
					16	16	32	0
					32	32	0	0
112*	32	80	NT5D10UA	NT5D03UA	16	16	16	32
					16	32	32	0
128*	32	96	NT5D10VA	NT5D03VA	16	16	32	32
					32	32	32	0
96	64	32	N/A	N/A	16	16	0	0
					32	0	0	0
112	64	48	NT5D10JA	NT5D03EA	16	16	16	0
					16	32	0	0
128	64	64	N/A	NT5D03FA	16	16	16	16
128	64	64	NT5D10FB	NT5D03FB	16	16	16	16
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

**Table 163**  
**Supported memory upgrade configurations (Part 2 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
					16	16	32	0
					32	32	0	0
144*	64	80	NT5D10NA	NT5D03NA	16	16	16	32
					16	32	32	0
160*	64	96	NT5D10PB	NT5D03PB	16	16	32	32
					32	32	32	0
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

## CS 1000 Release 4.5

Table 164 lists the memory requirements of CS 1000 Release 4.5.

**Table 164**  
**CS 1000 Release 4.5 memory requirements**

<b>System type</b>	<b>Flash memory requirement</b>	<b>DRAM memory requirement</b>	<b>Total memory requirement</b>
Meridian 1 Options 51C/61C with CP3 (68060) or CP4 (68060E)	64 MByte	64 MByte	128 MByte
Meridian 1 Options 81/81C with or without Fibre Network Fabric	64 MByte	96 MByte	160 MByte
Meridian 1 Option 61C CP PII	NA	256 MByte	256 MByte
Meridian 1 Option 81C CP PII with or without Fibre Network Fabric	NA	256 MByte	256 MByte
Meridian 1 Option 61C CP PIV	NA	512 MBytes	512 Mbytes
Meridian 1 Option 81C CP PIV with or without Fibre Network Fabric	NA	512 MBytes	512 Mbytes
<p><b>Note 1:</b> CP1 (68030) and CP 2 (68040) Call Processors are not supported.</p> <p><b>Note 2:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PII systems are equipped with 256 MByte.</p> <p><b>Note 3:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PIV systems are equipped with 512 Mbytes.</p>			

### Perform a data dump

Follow the steps in Procedure 279 below to perform a data dump on the Meridian 1 Option 51C.

#### Procedure 279

##### Performing a data dump on the Meridian 1 Option 51C

- 1 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 2    When “EDD000” appears on the terminal, enter:  
     **EDD**                      Begin the data dump
- 3    When “DATABASE BACKUP COMPLETE” or “DATADUMP  
     COMPLETE” appears on the terminal, enter:  
     **\*\*\*\***                      Exit program

---

**End of Procedure**

---



**CAUTION — Service Interruption**

**Loss of Data**

If the data dump is not successful, do not continue.  
Contact the technical support organization. A data dump  
problem must be corrected before proceeding.



**IMPORTANT!**

Database backup information should be preserved for a  
minimum of 5 days.

---

## STAT the hardware on the Meridian 1 Option 51C

Follow the steps in Procedure 280 to determine the status of the hardware on the Meridian 1 Option 51C.

### Procedure 280

#### Determining the hardware status on the Meridian 1 Option 51C

- 1 Access LD 137 and get the status of the hard disk.

**LD 137** Load program

**STAT** Get the status of the hard disks

- 2 Access LD 135 and get status of the CP, CNI and memory.

**LD 135** Load program

**STAT CPU** Get the status of the CP and memory

**STAT CNI** Get the status of the CNI

---

**End of Procedure**

---

### Procedure 281

#### Remove CP card from Core/Net 1

- 1 Push the manual reset button on the CP card.
- 2 Release the button and immediately unlatch the card and remove it from the shelf.

---

**End of Procedure**

---



### IMPORTANT!

Power down all applications (Meridian Mail, CallPilot, Symposium).

## NT5D03, NT5D10 CP cards

Use the procedures in this section to complete the upgrade, or refer to “Install the DRAM SIMMs” on [page 856](#) and Appendix on [page 860](#) for detailed upgrade instructions.

Table 163 on [page 817](#) defines the memory upgrade paths for the following Motorola-based Call Processor cards:

- 68060E
- 68040

To perform a DRAM and/or Flash upgrade:

- Locate your existing processor vintage in Table 163 on [page 817](#).
- Locate the target processor vintage in Table 163 on [page 817](#).
- Compare the existing SIMM configuration with the target configuration.
- Determine what SIMMs must be added or deleted from the existing location.
- Add or delete DRAM SIMMs as required to achieve the target memory configuration.
- Install the Flash memory modules in an available Flash connector.
- Install the label and label inserts. Discard all unused labels.



The upgrade is complete.

## Install the DRAM SIMMs

### Procedure 282

#### Installing the DRAM SIMMs

- 1 Place the CP card SIMM-side up on the antistatic mat.
- 2 Locate the DRAM SIMM connectors (see Figure 106 on [page 824](#)).

- 3 Determine if your memory upgrade requires you to remove an existing DRAM SIMM (see Table 163 on [page 817](#)) If removal is required, remove the SIMM from the highest numbered slot available first (X8, X7, X6, etc.) To remove the DRAM SIMM:
  - a. Use a nonconducting screw driver to carefully move each latch away first from one end of the SIMM, and then the other end. The SIMM pivots away from the others until it is at approximately a 50- to 70-degree angle to the board (see Figure 106).
  - b. If the SIMM does not release from the latches, use your thumbnails, one on each latch, to release the latches. If the board has plastic latches, the latches are located on the side facing the card faceplate. If the board has metal latches, the levers protrude from each latch. Carefully move the latches outward simultaneously until the SIMM pivots away from the others and is at approximately a 50- to 70-degree angle to the board (see Figure 106 on [page 824](#)).


**CAUTION — Service Interruption**

Do not mix up the 32 MByte DRAM SIMM with the 16 MByte DRAM SIMM. The 16 MByte DRAM SIMM is labeled A0662646 or A0614334; the 32 MByte DRAM SIMM is labeled A0634230. Older 16 MByte DRAM SIMMs may not be labeled.

- 4 Working from left to right, install the 32 MByte SIMM(s) in the SIMM location designated X5, X6, X7 or X8 where appropriate (see Figure 106 on [page 824](#))
  - a. Orient the new SIMM so that the notch at one end of the SIMM aligns with the key at one end of the SIMM socket. Hold the SIMM at approximately a 50- to 70-degree angle and gently insert the SIMM into the socket. See Figure 106 on [page 824](#).
- 5 Using your thumbs and index fingers only (at the upper corners of the SIMM), carefully lean the SIMM toward the others until it is upright and the latch at each end of the SIMM snaps into place. If necessary, use a nonconducting screwdriver to help open each latch while you move the SIMM into the upright position. Apply the generic label over the existing label.
- 6 Select the correct labels for your CP card from the sheet provided.
- 7 Place the CP/memory configuration label at the top of the faceplate.

- 8    Place the engineering code/release level label on the bottom of the faceplate.
- 9    Discard unused labels.

**Figure 106**  
**NT5D10, NT5D03 card DRAM SIMM installation**



---

**End of Procedure**

---



## Install the Flash memory

### Procedure 283 Installing the Flash memory



#### **CAUTION — Service Interruption**

**Do not** remove the existing Flash SIMMS from the Call Processor board.

- 1 Place the CP card SIMM-side up on the antistatic mat.
- 2 Determine the location of the new Flash SIMM connectors.
- 3 Install the new 32 MByte Flash SIMM module in the appropriate slot:
  - a. Orient the new SIMM so that the notches on the bottom of the SIMM align with the notches on the connector.
  - b. Gently guide the Flash SIMM toward the connector socket.
  - c. When the Flash SIMM makes contact with the connector, apply pressure to one end of the Flash SIMM and close the latch connector.
  - d. Apply pressure to the other end of the Flash SIMM and close the latch connector.
- 4 Apply the generic label over the existing label.
- 5 Select the correct labels for your CP card from the sheet provided.
- 6 Place the CP/memory configuration label at the top of the faceplate.
- 7 Place the engineering code/release level label on the bottom of the faceplate.
- 8 Discard unused labels.
- 9 Update the Flash ROM using the Software Install Tool:

**Note:** For dual CPU systems, verify that the system is operating in split mode before activating the Software Install Tool.

- a. To activate the Software Install Tool, insert the Install disk into the inactive the IODU/C (or IOP/CMDU). Press the MAN RST button on the Call Processor card in the inactive Core.
- b. From the Main Menu, select <G>, to update the Flash ROMs from the hard disk.
- c. Select <Y> to confirm installation.
- d. Press <CR> to return to the Install Menu.
- e. Upon successful installation of software on the Flash ROMs, select <E> to update the CP-BOOT ROM.
- f. Repeat this procedure for the second Core.

---

**End of Procedure**

---

## Install new software on Meridian 1 Option 51C

Follow the steps in Procedure 284 below to install the new software on the Meridian 1 Option 51C.

### **Procedure 284**

#### **Installing the software and converting the database**

- 1 Install the CD-ROM into the CD-ROM drive in the MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Press the button again to close the CD-ROM disk holder. Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 2 Place the Install floppy disk into the MMDU floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 3 Press the manual RESET button on the CP card faceplate.

- 4 Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
    Day-Month-Year, Hour:Min:Sec
    Succession Enterprise Software/Database/BOOTROM
CDROM INSTALL Tool
    Does this System have a Signaling Server.....? (Default - No)
    Please enter:
<CR> -> <n> - No
    <y> - Yes
    Enter Choice>
```

- 5 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```
                M A I N   M E N U

    The Software Installation Tool will install or upgrade
    Succession Enterprise System Software, Database and the CP-
    BOOTROM. You will be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:
<CR> -> <u> - To Install menu
    <t> - To Tools menu.
    <q> - Quit.
    Enter Choice> <CR>
>Validating Keycode

    The provided keycode authorizes the install of XXXXXXXX
    software
    (all subissues) for machine type XXXX
    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 6    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

**7** Enter **b** to install the Software, Database and CP-BOOTROM.**I N S T A L L   M E N U**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**8**    Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

**9** Confirm all options before installing the software.

## INSTALLATION STATUS SUMMARY

=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
SW: CD to disk	yes		install for rel XXXXX	
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
Database	yes			
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
CP-BOOTROM	yes			

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 10** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B



The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**11** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**12** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**13** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**14** Enter **<CR>** when prompted, returning the system to the Install Menu.

15 Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 16** The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.

You may reboot the system or return to the Main Menu.

Remove all disks from the system before rebooting.

-----  
DO NOT REBOOT USING BUTTON!!!  
-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for the Core/Net to INI.

---

### End of Procedure

---



### IMPORTANT!

Power up all applications (Meridian Mail, CallPilot, Symposium).

## Complete the upgrade

### Procedure 285 Completing the upgrade

- 1 Perform a redundancy sanity test using the following sequence:

<b>LD 135</b>	Load program
<b>STAT CNI</b>	Get status of CNI card
<b>STAT CPU</b>	Get status of CPU and memory

- 2 Clear the display and minor alarms.

<b>CDSP</b>	Clear the displays on the Cores
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms
<b>****</b>	Exit program

- 3 Check dial tone.
- 4 Make internal, external and network calls.
- 5 Check attendant console activity.
- 6 Check DID trunks.

**Note:** Proceed to “Post-conversion procedure” on [page 723](#).

---

**End of Procedure**

---

## Installing memory on Meridian 1 Options 61C, 81, 81C



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with NT5D61 Input Output Disk Unit with CD-ROM (IODU/C) card(s). If the system is not equipped with the IODU/C card, do not use these procedures.

The procedure in this section is used to increase the memory of the NT5D10 or NT5D03 card

To better understand the process, read through and understand the entire procedure before beginning the conversion.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 165 below:

**Table 165**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">840</a>
Upgrade Checklists	<a href="#">841</a>
Preparing	<a href="#">841</a>
Identifying the proper procedure	<a href="#">842</a>
Connect a terminal	<a href="#">842</a>
Print Site Data	<a href="#">843</a>
Perform a template audit	<a href="#">845</a>
Back up the database (data dump and ABKO)	<a href="#">847</a>
Identify two unique IP addresses	<a href="#">849</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.



- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### Procedure 286 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1    Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2    The settings for the terminal are:
  - a.    9600 Baud
  - b.    8 data
  - c.    parity none
  - d.    1 stop bit
  - e.    full duplex
  - f.    XOFF
- 3    If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print Site Data

Print site data to preserve a record of the system configuration (Table 166). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 166**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 166**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

**Table 166**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 287

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

**\*\*\*\***                      Exit program

---

**End of Procedure**

---

**Procedure 288**

**Performing an ABKO (save the database to floppies)**

- 1    Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2    Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**                    Load program

- 3    Run the ABKO backup (LD 143).

**ABKO**                    Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4    If there are validation errors, repeat the procedure.



**CAUTION — Service Interruption**

**Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5    Once the backup is complete, type:

\*\*\*\*                    Exit program

---

**End of Procedure**

---



**Procedure 289**  
**Converting to 2 MByte database media****IMPORTANT!**

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

**Identify two unique IP addresses**

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Parallel reload the Meridian 1 Option 61C and Meridian 1 81/81C CP3 CP4

*Note:* This procedure does not include instructions for installing new IODU/C cards or CP cards. If required, refer to “Installing a Call Processor card on Options 61C CP PII, 81C CP PII” on [page 900](#) and “Installing a Call Processor card on Option 51C” on [page 1004](#).

Parallel reloads can be done from either CPU. For the purposes of this document, the parallel reload begins with CPU 0.

If during the software conversion a problem is detected and it is determined that the system should revert back to the source release follow the “Parallel reload procedures” in Book 1.

### Verify memory

Determine whether the system requires additional memory. Refer to “Installing IODU/C cards, CP cards, CP memory” on [page 733](#) for memory requirements and upgrade procedures.

### Perform a data dump

Follow the steps in Procedure 290 to perform a data dump.

#### **Procedure 290** **Performing a data dump**

- 1    Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  
     **LD 43**                      Load program
- 2    When “EDD000” appears on the terminal, enter:  
     **EDD**                      Begin the data dump

- 3 When "DATABASE BACKUP COMPLETE" or "DATADUMP COMPLETE" appears on the terminal, enter:

\*\*\*\*

Exit program



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump is not successful, do not continue. Contact the technical support organization. A data dump problem must be corrected before proceeding.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

---

**End of Procedure**

---

## **Determine status (STAT) of the hardware**

Follow the steps in Procedure 291 on [page 851](#) to determine the required hardware status.

### **Procedure 291 Obtaining hardware status**

- 1 Load LD 137 and get status of the hard disks.

**Note:** Be sure the hard disks are synchronized. If not, synchronize before proceeding.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the hard disks
<b>SYNC</b>	Synchronize hard disks if necessary (Synchronization may take up to 50 minutes)

**TEST CMDU**     Performs hard and floppy disk test

\*\*\*\*             Exit program

- 2**    Load LD 135 and determine the status of the CPs, CNIs and memory.

**LD 135**             Load program

**STAT CPU**         Get the status of both CPs and memory

**STAT CNI**         Get the status of all configured CNIs

- 3**    Test the standby (inactive) CP. Then switch CPs, and test again.

**TEST CPU**         Test standby (inactive) CP

Wait until the terminal returns a complete test message. The message “HWI533 or HWI534” does not mean the test has completed!

**SCPU**                Switch CPs

**TEST CPU**         Test the standby (inactive) CP

- 4**    Check total memory allocation before the upgrade.

**LD 10**                Load program

When the header for LD 10 is displayed, note the value associated with Total Memory. After the upgrade, compare Total Memory before and after the upgrade. Total Memory should be greater after the upgrade.

Exit the program:

\*\*\*\*             Exit program

**Note:** Testing the CPs can take up to 20 minutes for each test. When the test is complete, the memories are automatically synchronized.

---

**End of Procedure**

---

## Split the Core processors

Follow the steps in Procedure 292 to split the core processors.

### **Procedure 292**

#### **Splitting the Core processors**

- 1 Be sure CP 0 is active and CP1 is standby. If necessary, switch CPs again:

##### **STAT CPU**

**SCPU**            Switch CPs (if necessary)

**\*\*\*\***            Exit program

- 2 Verify that IODU/C 0 is active. If necessary, switch IODU/Cs.

##### **LD 137**

**STAT**            Get the status of IODU/C

**SWAP**           Switch IODU/Cs (if necessary)

**\*\*\*\***            Exit program

- 3 Connect a terminal from the CPSI port in Core/Net 1 to J25 of the I/O panel at the back of the Core/Net. Be sure it is configured as follows. The recommended baud rate is 9600, to be the same as the CPSI port.

**7 data bits, 1 stop bit, Space parity, Full-duplex, XON protocol**

- 4 Place CP 0 in Maintenance by setting the MAINT/NORM switch to MAINT.
- 5 In Core/Net 1, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.

- 6    Place CP1 in Maintenance by setting the MAINT/NORM switch to MAINT.

**Note:** Core 1 will now sysload. Allow the system to complete the sysload and INI. Review any sysload errors and correct before proceeding.



System is now in split mode, Core 0 active, Clock Controller 0 is active if equipped with FNF. Rings are in half/half mode.

---

**End of Procedure**

---

## NT5D03, NT5D10 CP cards

Use the procedures in this section to complete the upgrade, or refer to “Install the DRAM SIMMs” on [page 856](#) and “Install the Flash memory” on [page 860](#) for detailed upgrade instructions.

Table 167 on [page 855](#) defines the memory upgrade paths for the following Motorola-based Call Processor cards:

- 68060
- 68060E

To perform a DRAM and/or Flash upgrade:

- Locate your existing processor vintage in Table 167 on [page 855](#).
- Locate the target processor vintage in Table 167 on [page 855](#).
- Compare the existing SIMM configuration with the target configuration.
- Determine what SIMMs must be added or deleted from the existing location.
- Add or delete DRAM SIMMs as required to achieve the target memory configuration (see Figure 107 on [page 857](#) for the DRAM and Flash SIMM slot locations).
- Install the Flash memory modules in an available Flash connector.
- Install the label and label inserts. Discard all unused labels.

**Table 167**  
**Supported memory upgrade configurations (Part 1 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
48	32	16	NT5D10AA	NT5D03AA	16	0	0	0
64	32	32	NT5D10CA	NT5D03BA	16	16	0	0
					32	0	0	0
80	32	48	NT5D10EA	NT5D03CA	16	16	16	0
					16	32	0	0
96	32	64	NT5D10TA	NT5D03TA	16	16	16	16
					16	16	32	0
					32	32	0	0
112*	32	80	NT5D10UA	NT5D03UA	16	16	16	32
					16	32	32	0
128*	32	96	NT5D10VA	NT5D03VA	16	16	32	32
					32	32	32	0
96	64	32	N/A	N/A	16	16	0	0
					32	0	0	0
112	64	48	NT5D10JA	NT5D03EA	16	16	16	0
					16	32	0	0
128	64	64	N/A	NT5D03FA	16	16	16	16
128	64	64	NT5D10FB	NT5D03FB	16	16	16	16
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

**Table 167**  
**Supported memory upgrade configurations (Part 2 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
					16	16	32	0
					32	32	0	0
144*	64	80	NT5D10NA	NT5D03NA	16	16	16	32
					16	32	32	0
160*	64	96	NT5D10PB	NT5D03PB	16	16	32	32
					32	32	32	0
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								


## Install the DRAM SIMMs

### Procedure 293 Installing the DRAM SIMMs

- 1 Place the CP card SIMM-side up on the antistatic mat.
- 2 Locate the DRAM SIMM connectors (see Figure 107 on [page 857](#)).
- 3 Determine if your memory upgrade requires you to remove an existing DRAM SIMM (see Table 167 on [page 855](#)). If removal is required, remove the SIMM from the highest numbered slot available first (X8, X7, X6, etc.) To remove the DRAM SIMM.
  - a. Use a nonconducting screw driver to carefully move each latch away first from one end of the SIMM, and then the other end. The SIMM



**Figure 107**  
**NT5D10 or NT5D03 DRAM and Flash location**



pivots away from the others until it is at approximately a 50- to 70-degree angle to the board (see Figure 108 on [page 859](#)).

- b. If the SIMM does not release from the latches, use your thumbnails, one on each latch, to release the latches. If the board has plastic latches, the latches are located on the side facing the card faceplate. If the board has metal latches, the levers protrude from each latch. Carefully move the latches outward simultaneously until the SIMM pivots away from the others and is at approximately a 50- to 70-degree angle to the board (see Figure 108 on [page 859](#)).



#### **CAUTION — Service Interruption**

Do not mix up the 32 MByte DRAM SIMM with the 16 MByte DRAM SIMM. The 16 MByte DRAM SIMM is labeled A0662646 or A0614334; the 32 MByte DRAM SIMM is labeled A0634230. Older 16 MByte DRAM SIMMs may not be labeled.


- 4 Working from left to right, install the 32 MByte SIMM(s) in the SIMM location designated X5, X6, X7 or X8 where appropriate (Table 167 on [page 855](#)).
  - a. Orient the new SIMM so that the notch at one end of the SIMM aligns with the key at one end of the SIMM socket. Hold the SIMM at approximately a 50- to 70-degree angle and gently insert the SIMM into the socket. See Figure 108 on [page 859](#).
- 5 Using your thumbs and index fingers only (at the upper corners of the SIMM), carefully lean the SIMM toward the others until it is upright and the latch at each end of the SIMM snaps into place. If necessary, use a nonconducting screwdriver to help open each latch while you move the SIMM into the upright position. Apply the generic label over the existing label.
- 6 Select the correct labels for your CP card from the sheet provided.
- 7 Place the CP/memory configuration label at the top of the faceplate.
- 8 Place the engineering code/release level label on the bottom of the faceplate.
- 9 Discard unused labels.

---

**End of Procedure**

---

**Figure 108**  
**NT5D10, NT5D03 card DRAM SIMM installation**



## Install the Flash memory



### **CAUTION — Service Interruption**

**Do not** remove the existing Flash SIMMS from the Call Processor board.

#### **Procedure 294**

##### **Installing the Flash memory**

- 1 Place the CP card SIMM-side up on the antistatic mat.
- 2 Determine the location of the new Flash SIMM connectors (see Table 167 on [page 855](#))
- 3 Install the new 32 MByte Flash SIMM module in the appropriate slot:
  - a. Orient the new SIMM so that the notches on the bottom of the SIMM align with the notches on the connector.
  - b. Gently guide the Flash SIMM toward the connector socket.
  - c. When the Flash SIMM makes contact with the connector, apply pressure to one end of the Flash SIMM and close the latch connector.
  - d. Apply pressure to the other end of the Flash SIMM and close the latch connector.
- 4 Apply the generic label over the existing label.
- 5 Select the correct labels for your CP card from the sheet provided.
- 6 Place the CP/memory configuration label at the top of the faceplate.
- 7 Place the engineering code/release level label on the bottom of the faceplate.
- 8 Discard unused labels.

---

**End of Procedure**

---

## Install software on Core/Net 1

### Procedure 295

#### Installing the system software on Core/Net 1

- 1 Place the CP Install disk that corresponds with the installed CP card type into the IODU/C in Core/Net 1.
- 2 Install the CD-ROM into the CD drive:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Use the four tabs to secure the CD-ROM drive.
  - d. Press the button again to close the CD-ROM disk holder. Don't push the holder in by hand.
- 3 In Core/Net 1, perform the following three steps in uninterrupted sequence:
  - a. In Core/Net 1 press and release the MAN RST button on the CP card.
  - b. Set the MAINT/NORM switch on the CP card to MAINT.
  - c. Release the MAN RST button.

A Sysload begins (cold start). Wait for the Main Menu to appear on the terminal before proceeding.

**Note 1:** If the CD-ROM is not in the CD drive of the IODU/C, the installation procedure will not continue. Insert the CD-ROM into the drive to continue.

**Note 2:** If a problem is detected during the system verification, the Install process stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue. Contact the technical support organization.

- 4 Press <CR> to continue.
- 5 Log into the system. Enter the time and date, when prompted.

- 6    Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
    Day-Month-Year, Hour:Min:Sec
    Succession Enterprise Software/Database/BOOTROM
CDROM INSTALL Tool
    Does this System have a Signaling Server.....? (Default - No)
    Please enter:
<CR> -> <n> - No
    <y> - Yes
    Enter Choice>
```

- 7    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```
                M A I N   M E N U

    The Software Installation Tool will install or upgrade
    Succession Enterprise System Software, Database and the CP-
    BOOTROM. You will be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:
<CR> -> <u> - To Install menu
    <t> - To Tools menu.
    <q> - Quit.
    Enter Choice> <CR>
>Validating Keycode

    The provided keycode authorizes the install of XXXXXXXX
    software
    (all subissues) for machine type XXXX
    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 8** The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 9    Enter **b** to install the Software, Database and CP-BOOTROM.

I N S T A L L   M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**



**10** Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.

or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

11 Confirm all options before installing the software.

INSTALLATION STATUS SUMMARY

-----

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

SW: CD to disk	yes		install for rel XXXXX
----------------	-----	--	-----------------------

=====+=====+=====+=====

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

Database	yes		
----------	-----	--	--

=====+=====+=====+=====

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

CP-BOOTROM	yes		
------------	-----	--	--

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

---

553-3021-258

Standard 6.00

July 2006

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 12** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

- <1> Global 10 Languages
- <2> Western Europe 10 Languages
- <3> Eastern Europe 10 Languages
- <4> North America 6 Languages
- <5> Spare Group A
- <6> Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

- 13** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**14** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**15** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**16** Enter **<CR>** when prompted, returning the system to the Install Menu.

**17** Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 18 The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.  
You may reboot the system or return to the Main Menu.  
Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 1 to INI.

---

**End of Procedure**

---



---

## Determine peripheral software version

### Procedure 296

#### Checking peripheral software versions

- 1 Load LD 22 and print Target peripheral software version. The Source peripheral software version was printed during the pre-conversion procedure. If there is a difference between the Source and Target peripheral software version, a forced download will occur during initialization when coming out of parallel reload. System initialization will take longer and established calls on IPE will be dropped.

**LD 22**                      Load program

**REQ**                        PRT

**TYPE**                     PSWV

**\*\*\*\***                        Exit program

---

**End of Procedure**

---

## Switch call processing to Core/Net 1



### **CAUTION — Service Interruption**

#### **Service Interruption**

Call Processing will be interrupted! Perform these next steps carefully. This is the point at which service is interrupted. Calls in process are interrupted, especially if Peripheral Software Download takes place. Some calls might be dropped.



### **WARNING**

System initialization may take up to 15 minutes or longer.



### **IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

Follow the steps in Procedure 297 to switch call processing from Core/Net 0 to Core/Net 1.

### **Procedure 297**

#### **Switching call processing from Core/Net 0 to Core/Net 1**

- 1**    In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 2**    In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 3**    In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 4**    In Core/Net 1, press the MAN INT button.

---

**End of Procedure**

---



### **CAUTION — Service Interruption**

#### **Service Interruption**

The INI may take up to 15 minutes to complete.



### **IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

### **Procedure 298**

#### **Testing Core/Net 1**

From Core/Net 1, perform these tests:

- 1 Check dial tone.
- 2 Make internal, external and network calls.
- 3 Check attendant console activity.
- 4 Check DID trunks.
- 5 Check applications (CallPilot, Symposium, Meridian Mail, etc.).



CP1 is active, Clock 1 is active, IODU/C is active. If equipped, the FIJI ring is in half/half mode.

---

**End of Procedure**

---

**Procedure 299**

**Removing CP card from Core/Net 0**

- 1    Push the manual reset button on the CP card.
- 2    Release the button and immediately unlatch the card and remove it from the shelf.

---

**End of Procedure**

---

## **NT5D03, NT5D10 CP cards**

Table 168 on [page 877](#) defines the memory upgrade paths for the following Motorola-based Call Processor cards:

- 68060
- 68060E

To perform a DRAM and/or Flash upgrade:

- Locate your existing processor vintage in Table 168 on [page 877](#).
- Locate the target processor vintage in Table 168 on [page 877](#).
- Compare the existing SIMM configuration with the target configuration.
- Determine what SIMMs must be added or deleted from the existing location.
- Add or delete DRAM SIMMs as required to achieve the target memory configuration (see Figure 109 on [page 879](#) for the DRAM and Flash SIMM slot locations).
- Install the Flash memory modules in an available Flash connector.
- Install the label and label inserts. Discard all unused labels.

**Table 168**  
**Supported memory upgrade configurations (Part 1 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
48	32	16	NT5D10AA	NT5D03AA	16	0	0	0
64	32	32	NT5D10CA	NT5D03BA	16	16	0	0
					32	0	0	0
80	32	48	NT5D10EA	NT5D03CA	16	16	16	0
					16	32	0	0
96	32	64	NT5D10TA	NT5D03TA	16	16	16	16
					16	16	32	0
					32	32	0	0
112*	32	80	NT5D10UA	NT5D03UA	16	16	16	32
					16	32	32	0
128*	32	96	NT5D10VA	NT5D03VA	16	16	32	32
					32	32	32	0
96	64	32	N/A	N/A	16	16	0	0
					32	0	0	0
112	64	48	NT5D10JA	NT5D03EA	16	16	16	0
					16	32	0	0
128	64	64	N/A	NT5D03FA	16	16	16	16
128	64	64	NT5D10FB	NT5D03FB	16	16	16	16
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

**Table 168**  
**Supported memory upgrade configurations (Part 2 of 2)**


Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
					16	16	32	0
					32	32	0	0
144*	64	80	NT5D10NA	NT5D03NA	16	16	16	32
					16	32	32	0
160*	64	96	NT5D10PB	NT5D03PB	16	16	32	32
					32	32	32	0
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

## Install the DRAM SIMMs

### Procedure 300 Installing the DRAM SIMMs

- 1 Place the CP card SIMM-side up on the antistatic mat.
- 2 Locate the DRAM SIMM connectors (see Figure 109 on [page 879](#)).
- 3 Determine if your memory upgrade requires you to remove an existing DRAM SIMM (see Table 167 on [page 855](#)). If removal is required, remove the SIMM from the highest numbered slot available first (X8, X7, X6, etc.) To remove the DRAM SIMM.
  - a. Use a nonconducting screw driver to carefully move each latch away first from one end of the SIMM, and then the other end. The SIMM

**Figure 109**  
**NT5D10 or NT5D03 DRAM and Flash location**



pivots away from the others until it is at approximately a 50- to 70-degree angle to the board (see Figure 109 on [page 879](#)).

- b. If the SIMM does not release from the latches, use your thumbnails, one on each latch, to release the latches. If the board has plastic latches, the latches are located on the side facing the card faceplate. If the board has metal latches, the levers protrude from each latch. Carefully move the latches outward simultaneously until the SIMM pivots away from the others and is at approximately a 50- to 70-degree angle to the board (see Figure 109 on [page 879](#)).



#### **CAUTION — Service Interruption**

Do not mix up the 32 MByte DRAM SIMM with the 16 MByte DRAM SIMM. The 16 MByte DRAM SIMM is labeled A0662646 or A0614334; the 32 MByte DRAM SIMM is labeled A0634230. Older 16 MByte DRAM SIMMs may not be labeled.

- 4 Working from left to right, install the 32 MByte SIMM(s) in the SIMM location designated X5, X6, X7 or X8 where appropriate (Table 167 on [page 855](#)).
  - a. Orient the new SIMM so that the notch at one end of the SIMM aligns with the key at one end of the SIMM socket. Hold the SIMM at approximately a 50- to 70-degree angle and gently insert the SIMM into the socket. See Figure 109 on [page 879](#).
- 5 Using your thumbs and index fingers only (at the upper corners of the SIMM), carefully lean the SIMM toward the others until it is upright and the latch at each end of the SIMM snaps into place. If necessary, use a nonconducting screwdriver to help open each latch while you move the SIMM into the upright position. Apply the generic label over the existing label.
- 6 Select the correct labels for your CP card from the sheet provided.
- 7 Place the CP/memory configuration label at the top of the faceplate.
- 8 Place the engineering code/release level label on the bottom of the faceplate.
- 9 Discard unused labels.


---

**End of Procedure**

---



**Figure 110**  
**NT5D10, NT5D03 card DRAM SIMM installation**



## Install the Flash memory



### **CAUTION — Service Interruption**

**Do not** remove the existing Flash SIMMS from the Call Processor board.

### **Procedure 301**

#### **Installing the Flash memory**

- 1    Place the CP card SIMM-side up on the antistatic mat.
- 2    Determine the location of the new Flash SIMM connectors (see Table 167 on [page 855](#)).
- 3    Install the new 32 MByte Flash SIMM module in the appropriate slot:
  - a.    Orient the new SIMM so that the notches on the bottom of the SIMM align with the notches on the connector.
  - b.    Gently guide the Flash SIMM toward the connector socket.
  - c.    When the Flash SIMM makes contact with the connector, apply pressure to one end of the Flash SIMM and close the latch connector.
  - d.    Apply pressure to the other end of the Flash SIMM and close the latch connector.
- 4    Apply the generic label over the existing label.
- 5    Select the correct labels for your CP card from the sheet provided.
- 6    Place the CP/memory configuration label at the top of the faceplate.
- 7    Place the engineering code/release level label on the bottom of the faceplate.
- 8    Discard unused labels.

The Flash memory upgrade is complete.

## Install new software on Core/Net 0

### Procedure 302

#### Installing the software and converting the database

- 1 Check that a terminal is connected to J25 on Core/Net 0.
- 2 In Core/Net 0, install the CD-ROM into the CD-ROM drive in the MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Press the button again to close the CD-ROM disk holder. Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 3 Place the CP PII Install floppy disk into the IODU/C floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 4 Press the manual RESET button on the CP card faceplate.
- 5 Select yes or (no) when asked if a Signaling Server is connected.

System Date and Time now is:

Day-Month-Year, Hour:Min:Sec

Succession Enterprise Software/Database/BOOTROM  
CDROM INSTALL Tool

Does this System have a Signaling Server.....? (Default - No)

Please enter:

<CR> -> <n> - No

<y> - Yes

Enter Choice>

- 6    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

**MAIN    MENU**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu

<t> - To Tools menu.

<q> - Quit.

Enter Choice> <CR>

>Validating Keycode

The provided keycode authorizes the install of XXXXXXXX software

(all subissues) for machine type XXXX

(XXX processor on XXXX System)

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 7 The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 8 Enter **b** to install the Software, Database and CP-BOOTROM.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

9    Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

**10** Confirm all options before installing the software.

## INSTALLATION STATUS SUMMARY

=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
SW: CD to disk	yes		install for rel XXXXX	
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
Database	yes			
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
CP-BOOTROM	yes			

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 11** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B



The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**12** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**13** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**14** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**15** Enter **<CR>** when prompted, returning the system to the Install Menu.

16 Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 17 The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.

You may reboot the system or return to the Main Menu.

Remove all disks from the system before rebooting.

-----  
DO NOT REBOOT USING BUTTON!!!  
-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 0 to INI.

---

**End of Procedure**

---

## Exiting split mode

Follow the steps in Procedure 303 to exit the split mode.

### Procedure 303

#### Exiting the split mode

- 1    Connect CPSI port or maintenance SDI port.
- 2    Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.
- 3    Perform the following in uninterrupted sequence:
  - Press and release the MAN RST button in Core/Net 0.
  - When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

#### **RUNNING ROM OS**

#### **ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

- 4    In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

---

**End of Procedure**

---

## Test Core/Net 1 and Core/Net 0

Follow the steps in Procedure 304 to test Core/Net 0 and Core/Net 1.

### Procedure 304

#### Testing Core/Net 0 and Core/Net 1

- 1 Perform a redundancy sanity test using the following sequence:

##### LD 135

<b>STAT CNI</b>	Get status of CNI cards
<b>STAT CPU</b>	Get status of CPU and memory
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

- 2 Switch Core/Nets and test the other side (Core/Net 0)

<b>SCPU</b>	Switch Core/Nets
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

**Note:** Testing the Call Processor and CNI cards and synchronizing memory can take up to 20 minutes for each test. When the Call Processor test is complete, the Call Processor the memory is automatically synchronized.

- 3 Clear the display and minor alarms on both Core/Nets.

<b>CDSP</b>	Clear the displays on the Core/Nets
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms

- 4    Get the status of the Core/Nets, CNIs, and memory.

**STAT CPU**     Get the status of both Core/Nets

**STAT CNI**     Get the status of all configured CNIs and memory

**Note:** You may need to execute the STAT CNI command twice before receiving a response from the system.

\*\*\*\*            Exit program

---

**End of Procedure**

---

## Switch the Clocks

### Procedure 305 Switching the Clocks

- 1    Verify that the clock controller is assigned to the *active* Core.

**LD 60**            Load program

**SSCK *x***          Get the status of the clock controllers (*x* is “0” or “1” for Clock 0 or Clock 1)

**SWCK**            Switch the Clock (if necessary)

\*\*\*\*            Exit program

- 2    Verify that the Clock Controllers are switching correctly:.

**SWCK**            Switch the Clock

**SWCK**            Switch the Clock again

---

**End of Procedure**

---



---

## If equipped, stat the FIJI rings

### Procedure 306

#### Stat the rings

- 1 Check the status of Ring 0 and Ring 0.

**LD 39** Load program

**STAT RING** Get the status of Ring 0  
**0** (Ring state should be HALF/HALF)

- 2 Check the status of Ring 0 and Ring 1.

**LD 39** Load program

**STAT RING** Get the status of Ring 0  
**1** (Ring state should be HALF/HALF)

---

**End of Procedure**

---

## Synchronize the hard disks

### Procedure 307

#### Synchronizing the hard disks

- 1    Access LD 137 and synchronize the hard disks. Synchronization can take up to 50 minutes. To ensure that the contents of IODU/C 1 are copied to IODU/C 0, verify that IODU/C 0 is disabled.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the IODU/C and redundancy
<b>SYNC</b>	Enter “Yes” to synchronize disks (Wait until the memory synchronization successfully completes before continuing)
<b>TEST CMDU</b>	Perform hard and floppy disk test

- 2    Get the status of the CMDU's and be sure CMDU 0 is active. Switch if necessary.

<b>STAT</b>	Get the status of IODU/C and redundancy
<b>SWAP</b>	Switch CMDU (if necessary)
<b>STAT CMDU</b>	Get the status of the IODU/Cs (Be sure the same IODU/C and CPU are active)
<b>****</b>	Exit program

## Perform a data dump

### Procedure 308

#### Performing a data dump

- 1 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  
**LD 43** Load program
- 2 When “EDD000” appears on the terminal, enter:  
**EDD** Begin the data dump
- 3 When “DATABASE BACKUP COMPLETE” or “DATADUMP COMPLETE” appears on the terminal, enter the following:  
**\*\*\*\*** Exit program

---

#### End of Procedure

---



The Parallel Reload process is complete. The system is now running on the upgraded CP card.  
System is now in redundant mode.

Proceed to “Post-conversion procedure” on [page 723](#).

## Installing a Call Processor card on Options 61C CP PII, 81C CP PII



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with NT4N43 CP PII Multi-Media Disk Unit (CP PII MMDU). If the system is not equipped with the CP PII MMDU, do not use these procedures

The NT4N43 CP PII MMDU is located in the extreme right hand slot next to the CP PII card. The CP PII MMDU contains the hard drive, floppy drive and CD-ROM drive.

## Perform a parallel reload in Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII

Software must be installed on both Core hard drives. Follow the procedures in this section to complete the installation.

*Note:* To complete these procedures, the system must be working and connected to a terminal.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 169 below:

**Table 169**  
**Prepare for upgrade steps**

<b>Procedure Step</b>	<b>Page</b>
Planning	<a href="#">901</a>
Upgrade Checklists	<a href="#">902</a>
Preparing	<a href="#">902</a>
Identifying the proper procedure	<a href="#">903</a>
Connect a terminal	<a href="#">903</a>
Print Site Data	<a href="#">904</a>
Perform a template audit	<a href="#">907</a>
Back up the database (data dump and ABKO)	<a href="#">908</a>
Convert the 4 MByte database media to 2 MByte database media	<a href="#">910</a>
Identify two unique IP addresses	<a href="#">910</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.

- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.

- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### **Procedure 309**

#### **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1** Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2** The settings for the terminal are:
  - a.** 9600 Baud
  - b.** 8 data
  - c.** parity none
  - d.** 1 stop bit
  - e.** full duplex
  - f.** XOFF

- 3
- If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

End of Procedure

---

### Print Site Data

Print site data to preserve a record of the system configuration (Table 170). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

Table 170  
Print site data (Part 1 of 3)

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>



**Table 170**  
**Print site data (Part 2 of 3)**

Site data	Print command	
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop

**Table 170**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ TYPE LOOP APPL PH	PRT MISP loop number (0-158) <cr> <cr>
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



### **CAUTION — Service Interruption**

#### **Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

### **TEMPLATE AUDIT**

#### **STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

#### **STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
-

**TEMPLATE 0120 USER COUNT OK    CHECKSUM  
OK**

**TEMPLATE AUDIT COMPLETE**

## **Back up the database (data dump and ABKO)**

To back up system data, complete the following two procedures.

- 1**    Perform a data dump to save all system memory to the hard disk.
- 2**    Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### **Procedure 310 Performing a data dump**

- 1**    Log into the system.
- 2**    Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  
  
         **LD 43**                    Load program
- 3**    When “EDD000” appears on the terminal, enter:  
  
         **EDD**                    Begin the data dump



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\* Exit program

---

**End of Procedure**

---

**Procedure 311****Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143** Load program

- 3 Run the ABKO backup (LD 143).

**ABKO** Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.

**CAUTION — Service Interruption****Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

5    Once the backup is complete, type:

\*\*\*\*                      Exit program

---

End of Procedure

---

## Convert the 4 MByte database media to 2 MByte database media



### IMPORTANT!

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

## Identify two unique IP addresses

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the

*active* Core. The second IP address is defined for the *inactive* Core. In this configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Verify memory

#### CS 1000 Release 4.5

Table 171 lists the memory requirements of CS 1000 Release 4.5.

**Table 171**  
**CS 1000 Release 4.5 memory requirements**

System type	Flash memory requirement	DRAM memory requirement	Total memory requirement
Meridian 1 Options 51C/61C with CP3 (68060) or CP4 (68060E)	64 MByte	64 MByte	128 MByte
Meridian 1 Options 81/81C with or without Fibre Network Fabric	64 MByte	96 MByte	160 MByte
Meridian 1 Option 61C CP PII	NA	256 MByte	256 MByte
Meridian 1 Option 81C CP PII with or without Fibre Network Fabric	NA	256 MByte	256 MByte
Meridian 1 Option 61C CP PIV	NA	512 MBytes	512 Mbytes
Meridian 1 Option 81C CP PIV with or without Fibre Network Fabric	NA	512 MBytes	512 Mbytes
<p><b>Note 1:</b> CP1 (68030) and CP 2 (68040) Call Processors are not supported.</p> <p><b>Note 2:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PII systems are equipped with 256 MByte.</p> <p><b>Note 3:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PIV systems are equipped with 512 Mbytes.</p>			

### Perform data dump

#### Procedure 312 Backing up the current data



- 1 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 2 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin data dump

- 3 When "DATABASE BACKUP COMPLETE" or "DATADUMP COMPLETE" appears on the terminal, enter

**\*\*\*\***                      Exit program



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the data dump is not successful, do not continue.  
Contact the technical support organization. Correct any  
data dump problem before continuing.



### **IMPORTANT!**

Database backup information should be preserved for a  
minimum of 5 days.

---

**End of Procedure**

---

## Check the status of the hardware

### Procedure 313

#### Determining hardware status

- 1    Load LD 137 to check the status of the hard disks.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the hard disks
<b>TEST CMDU</b>	Perform hard and floppy disk test

- 2    Load LD 135 and check the status of the CPs, CNIs and memories.

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of both CPs and memory
<b>STAT CNI</b>	Get the status of all configured CNIs

---

**End of Procedure**

---

## Check that Core 0 is active

Check that Core 0 is active. If Core 1 is active, make Core 0 active:

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of the CPUs
<b>SCPU</b>	Switch to Core 0 (if necessary)

## Split the Cores

From the active side, split the cores:

<b>LD 135</b>	Load program
<b>SPLIT</b>	Enter Split on the active core
<b>****</b>	Exit program



The system is now in split mode with Core/Net 0 active and Clock Controller 0 active.

## Upgrade Core/Net 1 hardware

### Procedure 314

#### Upgrading Core/Net 1 hardware

- 1 Tag all faceplate cables on the CP card in Core/Net 1.
- 2 Disconnect all faceplate cables on the CP card in Core/Net 1
- 3 Remove the CP card from the system in Core/Net 1
- 4 Install the replacement CP card in Core/Net 1.

---

Revised 01/10/2010  
**End of Procedure**

---

## Install the software on Core/Net

### Procedure 315

#### Installing the software on Core/Net 1

- 1 Install the CD-ROM into the CD-ROM drive in the CP PII MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label facing up. Use the four tabs to secure the CD-ROM drive.
  - c. Press the button to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 2 Place the CP PII Install floppy disk into the CP PII MMDU floppy drive.

**Note:** If a problem is detected during the system verification, the install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact the technical support organization.

**3**    Press the manual RESET button on the CP PII card faceplate.

Before the install runs, the system validates hard disk partitioning which takes about five minutes.

```
Testing partition 0
    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 1
    0 percent done...1 percent done.....99
    percent done....100 percent done

Testing partition 2
    0 percent done...1 percent done.....99
    percent done....100 percent completed!

Disk physical checking is completed!

Validate hard drive partition number and size...

There are 3 partitions in disk 0:
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte

Disk partitions and sectors checking is
completed!
```

The system then checks the partitions for any errors. The screen displays the following for each partition.

```
Copyright (c) 1993-1996 RST Software Industries
Ltd. All rights reserved

ver: X.X FCS

Disk Check In Progress...

    total disk space (bytes) : XX
    bytes in each allocation unit: XX
    total allocation units on disk: XX
    bad allocation units: XX
    available bytes on disk: XX
    available clusters on disk: XX
    maximum available contiguous chain (bytes):
    XX
    available space fragmentation (%): XX
    clusters allocated: XX

Done Checking Disk.

    checks for PART_X OK!

    pmDosFsCheck is completed!
```

4    Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
      Day-Month-Year, Hour:Min:Sec
      Succession Enterprise Software/Database/
BOOTROM CDROM INSTALL Tool
      Does this System have a Signaling
Server.....? (Default - No)
      Please enter:
<CR> -> <n> - No
      <y> - Yes
      Enter Choice>
```

- 5 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```

                                M A I N      M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will
    be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:

    <CR> -> <u> - To Install menu

             <t> - To Tools menu.

             <q> - Quit.

    Enter Choice> <CR>

>Validating Keycode

    The provided keycode authorizes the install of
    XXXXXXXX software

    (all subissues) for machine type XXXX

    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 6    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

```
Please confirm that this keycode matches the
CDROM Release

      Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to
Install Menu.

      <n> - No, the keycode does not match. Try
another keycode diskette.

      Enter Choice> <CR>

      >Obtain database file names
```



**7 Enter **b** to install the Software, Database and CP-BOOTROM.**

## I N S T A L L M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**8**    Verify the CD-ROM version.

```
Please insert the installation CDROM into the
drive on Core X.

        The labeled side of the CDROM should be
side up in the CDROM tray.

        Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with
s/w checking.

        <q> - Quit.

        Enter Choice> <CR>

The installation CDROM contains version XXXXXXXX_X.

        Please enter:

<CR> -> <y> - Yes, this is the correct version.
Continue.

        <n> - No, this is not the correct version.
Try another CDROM or keycode disk

        Enter Choice> <CR>

        >copying direct.rec from /cd0/0300_KMR.N33/
target/p/s11/direct.rec to /u/direct.rec

        >Updating /u/direct.rec

Do you want to install Dependency Lists?

        Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

        Enter choice> n

Note: To choose yes and install the Dependency Lists, proceed to
step 10, otherwise proceed to step 11.
```

**9 Choosing Yes for the Dependency Lists installation.**

```

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt
will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

        <y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the
user to deplist menu.

The Installation Status Summary for the choices
entered is displayed as shown below:

-----
                INSTALLATION STATUS SUMMARY
                -----

Option           Choice  Status      Comment
SW: CD to disk   yes                install for rel 400
Dependency Lists yes
Database         no
CP-BOOTROM       yes

```

```
Please enter:

<CR> -> <y> - Yes, start installation.

        <n> - No, stop installation. Return to the
Main Menu.

The installation continues with the removal of the
patch, reten and deplist directories and copying
the files from the CD to the hard disk.

>Erasing old file "/u/patch/p12749_1.cpp"

>Erasing old file "/u/patch/reten/reten.pch"

>Erasing old file "/u/patch/deplist/m16000_3.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
p12749_1.cpp" to "/u/patch/p12749_1.cpp"

>Copying "/cd0/0400_UMR.N33/target/u/patch/
deplist/m16000_3.cpp" to "/u/patch/deplist/
m16000_3.cpp"
```

**Note:** The removal of patch, reten and deplist directories will happen only when it is a software upgrade or a new system installation regardless of the DepList installation menu selection.

The installation status summary after the installation will be as follows:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW:CD to disk   yes      ok       install rel 400
Dependency Lists yes      ok       core Version 1
                                   Terminals Version 2
Database        no
CP-BOOTROM      yes      ok

```

**Note:** Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing ISSP command in LD 22. If there are NO DepLists available on the installation CD the summary should appear as shown below:

```

-----
INSTALLATION STATUS SUMMARY
-----

Option          Choice    Status    Comment
SW: CD to disk   yes      ok       from 300 to
400
Dependency Lists yes      ok       None Available
SW: disk to ROM  yes      ok       from x210300 to
x2103400
Database        no
CP-BOOTROM      yes      ok       from x210300 to
x210400
IOP-ROM         yes      ok       from 02.00 to 02.00

```

### Installation of DepList through software installation

**The DepList should be installed during the software installation if it is present with the install software.**

Do you wish to install Dependency Lists? (y/n/[a]bort) :

The installation continues as below:

INSTALLING NEW SOFTWARE AND FILES:

Erasing flash ROM

Installing new flash ROM software modules:

Programming: auxres

Programming: diskos

Programming: sl1res

Programming: ovlres

Programming: loadware

Programming: remupg

Calculating CRC-32 on flash ROM program store

Installing new directory record

Installing new files

Installing Dependency Lists

Building system loadware

Done.

Note: Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing the ISSP command in LD 22.

If the response to the above query is "NO", the user is prompted to confirm the selection.

For example:

Do you wish to install Dependency Lists? (y/n/[a]bort) : **n**

Are you sure? (y/n/[a]bort) : **y**

**10** Confirm all options before installing the software.

```
>Processing the Install Control file
  >Installing release XXXXX

      INSTALLATION STATUS SUMMARY
-----

=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| SW: CD to disk | yes | | install for rel XXXXX|
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| Database | yes | | |
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| CP-BOOTROM | yes | | |

      Please enter:<CR> -> <y> - Yes, start
Installation.

      <n> - No, stop Installation. Return to the
Main Menu.

Enter Choice> <CR>

>Checking System Configuration

You selected to upgrade the system from release:
XXXX to release: XXXXX.

This will erase all old system files.
```

```
Database files will NOT be erased. You may
continue installing the software or quit now and
leave your system unchanged.
```

```
Please enter:
```

```
<CR> -> <a> - Continue with Upgrade.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

```
>Starting Software Install
```

```
          >Upgrading from release XXXX to release
XXXXXX
```

- 11** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B



The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**12** Continue with upgrade when prompted. Select a database to install.  
Confirm database transfer.

```
You selected to transfer the database from the  
floppy disk - release: XXXX to the hard disk on  
Core X. release: XXXX.
```

```
This will erase the database on the hard disk.
```

```
The database diskette has been inserted into the  
floppy disk drive.
```

```
        If you quit now, the database will be left  
unchanged.
```

```
        Please enter:
```

```
<CR> -> <a> - Continue with Database Install.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

The system then informs you of the database details and prompts you to confirm.

```
You have chosen to restore database dated:
Month Day Hour:Min:Sec:Year

      Please confirm.

      Please enter:

<CR> -> <y> - Yes, load.

      <n> - No, DO NOT load.

Enter Choice> <CR>
```

- 13** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

- 14** Enter <CR> when prompted, returning the system to the Install Menu.

**15** Enter **q** to quit.

```

                I N S T A L L      M E N U

The Software Installation Tool will
install or upgrade Succession Enterprise System
Software, Database and the CP-BOOTROM. You will be
prompted throughout the installation and given the
opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.
        <b> - To install Software, Database, CP-
BOOTROM.
        <c> - To install Database only.
        <d> - To install CP-BOOTROM only.
        <t> - To go to the Tools menu.
        <k> - To install Keycode only.

        For Feature Expansion, use OVL143.
        <p> - To install 3900 set Languages.
        <q> - Quit.

Enter Choice> q
```

**16** The system then prompts you to confirm and reboot.

```
You selected to Quit the Software Installation
Tool.

You may reboot the system or return to the Main
Menu.

Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.
      <m> - Return to the Main menu.
Enter Choice> <CR>
>Removing (temporary files)

>Rebooting system ...
```

Before completing the next procedure, wait for Core/Net 1 to initialize.

---

**End of Procedure**

---

## Check for peripheral software download

Access LD 22 and print the Target peripheral software version.  
(The Source peripheral software version was printed during the pre-conversion procedure.)

If there is a difference between the Source and Target peripheral software version, a forced download occurs during initialization when coming out of parallel reload. System initialization takes longer and established calls on IPE are dropped.

<b>LD 22</b>	Load program.
<b>REQ</b>	Print.
<b>TYPE</b>	PSWV.
<b>ISS</b>	Print issue and release.
<b>TID</b>	Print Tape/Aux ID.
<b>ISSP</b>	Print System, DepList, and Patch information
<b>****</b>	Exit program.

## Transfer call processing from Core/Net 0 to Core/Net 1



### **CAUTION — Service Interruption**

#### **Service Interruption**

Call Processing will be interrupted! Perform these next steps carefully. This is the point at which service is interrupted. Calls in process are interrupted, especially if Peripheral Software Download takes place. Some calls might be dropped.



### **WARNING**

System initialization may take up to 15 minutes or longer.

Follow the steps in Procedure 268 on [page 775](#) to transfer call processing from Core/Net 0 to Core/Net 1.



### **IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

**Procedure 316****Transferring call processing from Core/Net 0 to Core/Net 1**

- 1 From Core/Net 0, the active side, transfer call processing to Core/Net 1:

**LD 135** Load program

**CUTOVR** The inactive CP become active

**IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

---

**End of Procedure**

---

**Test Core/Net 1****Procedure 317****Testing call processing on Core/Net 1**

- 1 Check for dial tone.
- 2 Make internal, external, and network calls.
- 3 Check attendant console activity.
- 4 Check DID trunks.
- 5 Check any auxiliary processors.

---

**End of Procedure**

---



Core/Net 1 is active, Clock Controller 1 is active, and the system is in split mode. From this point forward, Core/Net 0 is being upgraded with new software.

## Upgrade Core/Net 0 hardware

### Procedure 318

#### Upgrading Core/Net 0 hardware

- 1    Tag all faceplate cables on the CP card in Core/Net 0.
- 2    Disconnect all faceplate cables on the CP card in Core/Net 0.
- 3    Remove the CP card from the system in Core/Net 0.
- 4    Install the replacement CP card in Core/Net 0.

---

**End of Procedure**

---

## Install software on Core/Net 0

### Procedure 319

#### Installing the software and converting the database

- 1    Check that a terminal is connected to J25 on Core/Net 0.
- 2    In Core/Net 0, install the CD-ROM into the CD-ROM drive in the MMDU:
  - a.    Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b.    Place the CD-ROM disk into the holder with the disk label showing.
  - c.    Press the button again to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 3    Place the CP PII Install floppy disk into the MMDU floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 4    Press the manual RESET button on the CP PII card faceplate.



Before the install runs, the system validates hard disk partitioning which takes about five minutes.

```
Testing partition 0

    0 percent done...1 percent done.....99
    percent done....100 percent done
```

```
Testing partition 1

    0 percent done...1 percent done.....99
    percent done....100 percent done
```

```
Testing partition 2

    0 percent done...1 percent done.....99
    percent done....100 percent completed!
```

```
Disk physical checking is completed!
```

---

```
Validate hard drive partition number and size...
```

```
There are 3 partitions in disk 0:
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte
The size of partition 0 of disk 0 is XX Mbyte
```

```
Disk partitions and sectors checking is
completed!
```

The system then checks the partitions for any errors. The screen displays the following for each partition.

```
Copyright (c) 1993-1996 RST Software Industries
Ltd. All rights reserved

ver: X.X FCS

Disk Check In Progress...

    total disk space (bytes) : XX
    bytes in each allocation unit: XX
    total allocation units on disk: XX
    bad allocation units: XX
    available bytes on disk: XX
    available clusters on disk: XX
    maximum available contiguous chain (bytes):
    XX
    available space fragmentation (%): XX
    clusters allocated: XX

Done Checking Disk.

        checks for PART_X OK!

        pmDosFsCheck is completed!
```

**5** Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:  
    Day-Month-Year, Hour:Min:Sec  
    Succession Enterprise Software/Database/  
BOOTROM CDROM INSTALL Tool  
    Does this System have a Signaling  
Server.....? (Default - No)  
    Please enter:  
<CR> -> <n> - No  
    <y> - Yes  
    Enter Choice>
```

- 6    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```

                                M A I N      M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will
    be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:

    <CR> -> <u> - To Install menu

             <t> - To Tools menu.

             <q> - Quit.

    Enter Choice> <CR>

>Validating Keycode

    The provided keycode authorizes the install of
    XXXXXXXX software

    (all subissues) for machine type XXXX

    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 7 The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the  
CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to  
Install Menu.

<n> - No, the keycode does not match. Try  
another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

**8**    Enter **b** to install the Software, Database and CP-BOOTROM.

I N S T A L L       M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**9** Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/  
target/p/s11/direct.rec to /u/direct.rec

>Updating /u/direct.rec

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists installation

<n> - No, Continue without Dependency Lists installation

Enter choice> n

**Note:** To choose yes and install the Dependency Lists, proceed to step 10, otherwise proceed to step 11.

10 Choosing Yes for the Dependency Lists installation.

```
Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists
installation

        <n> - No, Continue without Dependency Lists
installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt
will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

        <y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the
user to deplist menu.

The Installation Status Summary for the choices
entered is displayed as shown below:

-----
                INSTALLATION STATUS SUMMARY
                -----

Option           Choice  Status      Comment
SW: CD to disk   yes           install for rel 400
Dependency Lists yes
Database         no
CP-BOOTROM       yes
```



Please enter:

<CR> -> <y> - Yes, start installation.

<n> - No, stop installation. Return to the Main Menu.

The installation continues with the removal of the patch, reten and deplist directories and copying the files from the CD to the hard disk.

>Erasing old file "/u/patch/p12749\_1.cpp"

>Erasing old file "/u/patch/reten/reten.pch"

>Erasing old file "/u/patch/deplist/m16000\_3.cpp"

>Copying "/cd0/0400\_UMR.N33/target/u/patch/p12749\_1.cpp" to "/u/patch/p12749\_1.cpp"

>Copying "/cd0/0400\_UMR.N33/target/u/patch/deplist/m16000\_3.cpp" to "/u/patch/deplist/m16000\_3.cpp"

**Note:** The removal of patch, reten and deplist directories will happen only when it is a software upgrade or a new system installation regardless of the DepList installation menu selection.

The installation status summary after the installation will be as follows:

-----			
INSTALLATION STATUS SUMMARY			
-----			
Option	Choice	Status	Comment
SW:CD to disk	yes	ok	install rel 400
Dependency Lists	yes	ok	core Version 1 Terminals Version 2
Database	no		
CP-BOOTROM	yes	ok	

**Note:** Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing ISSP command in LD 22. If there are NO DepLists available on the installation CD the summary should appear as shown below:

-----			
INSTALLATION STATUS SUMMARY			
-----			
Option	Choice	Status	Comment
SW: CD to disk	yes	ok	from 300 to 400
Dependency Lists	yes	ok	None Available
SW: disk to ROM	yes	ok	from x210300 to x2103400
Database	no		
CP-BOOTROM	yes	ok	from x210300 to x210400
IOP-ROM	yes	ok	from 02.00 to 02.00

**Installation of DepList through software installation**

**The DepList should be installed during the software installation if it is present with the install software.**

Do you wish to install Dependency Lists? (y/n/[a]bort) :

The installation continues as below:

```
INSTALLING NEW SOFTWARE AND FILES:
Erasing flash ROM
Installing new flash ROM software modules:
Programming: auxres
Programming: diskos
Programming: slires
Programming: ovlres
Programming: loadware
Programming: remupg
Calculating CRC-32 on flash ROM program store
Installing new directory record
Installing new files
Installing Dependency Lists
Building system loadware
Done.
```

Note: Once the installation is complete and the system reboots, the PEPs that are installed will be automatically put into service. This can be seen by issuing the ISSP command in LD 22.

If the response to the above query is "NO", the user is prompted to confirm the selection.

For example:

```
Do you wish to install Dependency Lists? (y/n/[a]bort) : n
```

```
Are you sure? (y/n/[a]bort) : y
```

11 Confirm all options before installing the software.

```
>Processing the Install Control file

>Installing release XXXXX

      INSTALLATION STATUS SUMMARY
-----

=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| SW: CD to disk | yes | | install for rel XXXXX|
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| Database | yes | | |
=====+=====+=====+=====
| Option | Choice | Status | Comment |
=====+=====+=====+=====
| CP-BOOTROM | yes | | |

      Please enter:<CR> -> <y> - Yes, start
Installation.

      <n> - No, stop Installation. Return to the
Main Menu.

Enter Choice> <CR>

>Checking System Configuration

You selected to upgrade the system from release:
XXXX to release: XXXXX.

This will erase all old system files.
```

```
Database files will NOT be erased. You may
continue installing the software or quit now and
leave your system unchanged.
```

```
Please enter:
```

```
<CR> -> <a> - Continue with Upgrade.
```

```
<q> - Quit.
```

```
Enter Choice> <CR>
```

```
>Starting Software Install
```

```
                >Upgrading from release XXXX to release
XXXXXXXX
```

- 12** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

- <1> Global 10 Languages
- <2> Western Europe 10 Languages
- <3> Eastern Europe 10 Languages
- <4> North America 6 Languages
- <5> Spare Group A
- <6> Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

- 13** Continue with upgrade when prompted. Select a database to install.  
Confirm database transfer.

```
You selected to transfer the database from the
floppy disk - release: XXXX to the hard disk on
Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the
floppy disk drive.

      If you quit now, the database will be left
unchanged.

      Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> <CR>
```

The system then informs you of the database details and prompts you to confirm.

```
You have chosen to restore database dated:
Month Day Hour:Min:Sec:Year

      Please confirm.

      Please enter:

<CR> -> <y> - Yes, load.

      <n> - No, DO NOT load.

Enter Choice> <CR>
```

- 14** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

- 15** Enter <CR> when prompted, returning the system to the Install Menu.

**16** Enter **q** to quit.

```

                I N S T A L L   M E N U

    The Software Installation Tool will
    install or upgrade Succession Enterprise System
    Software, Database and the CP-BOOTROM. You will be
    prompted throughout the installation and given the
    opportunity to quit at any time.

    Please enter:

    <CR> -> <a> - To install Software, CP-BOOTROM.
           <b> - To install Software, Database, CP-
    BOOTROM.
           <c> - To install Database only.
           <d> - To install CP-BOOTROM only.
           <t> - To go to the Tools menu.
           <k> - To install Keycode only.

           For Feature Expansion, use OVL143.

           <p> - To install 3900 set Languages.
           <q> - Quit.

    Enter Choice> q
```



**17** The system then prompts you to confirm and reboot.

```
You selected to Quit the Software Installation
Tool.

You may reboot the system or return to the Main
Menu.

Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.
      <m> - Return to the Main menu.
Enter Choice> <CR>
>Removing (temporary files)

>Rebooting system ...
```

Before completing the next procedure, wait for Core/Net 0 to initialize.

---

**End of Procedure**

---

## Enable system redundancy

### Procedure 320

#### Enabling system redundancy

- 1    From the active CPU, Core/Net 1, enable redundancy:

**LD 135**                    Load program

**JOIN**                    Synchronize the memory and drives

---

**End of Procedure**

---



Core/Net 1 is active, Clock Controller 1 is active, and the system is in redundant mode. Core/Net 0 is inactive, Clock Controller 0 is inactive.

---

## Test Core/Net 1 and Core/Net 0

### Procedure 321

#### Testing Core/Net 1 and Core/Net 0

From the active CPU, Core/Net 1, perform these tests:

- 1 Perform a redundancy sanity test using the following sequence.

<b>LD 135</b>	Load program
<b>STAT CNI c s</b>	Get status of cCNI cards
<b>STAT CPU</b>	Get status of CPU and memory
<b>TEST CPU</b>	Test the CP PII card in both Core/Nets
<b>TEST CNI c s</b>	Test each cCNI card (core, slot)
<b>STAT SUTL</b>	Get status of System Utility (main and Transition) cards
<b>TEST SUTL</b>	Test the System Utility (main and Transition) cards
<b>TEST IPB</b>	Test the Inter Processor Bus
<b>TEST LCD</b>	Test LCDs
<b>TEST LED</b>	Test LEDs

- 2 Test system redundancy:

<b>LD 137</b>	Load program
<b>TEST RDUN</b>	Test redundancy
<b>DATA RDUN</b>	
<b>TEST CMDU</b>	Test the CP PII MMDU card

- 3**    Switch Cores and test the other side (Core/Net 0).
- |                     |   |
|---------------------|---|
| <b>LD 135</b>       | Load program  |
| <b>SCPU</b>         | Switch cores  |
| <b>TEST CPU</b>     | Test the inactive Core/Net                          |
| <b>STAT CNI c s</b> | Get status of cCNI (both main and Transition) cards |
| <b>TEST CNI c s</b> | Test cCNI (both main and Transition) cards          |
| <b>STAT SUTL</b>    | Get status of System Utility card                   |
| <b>TEST SUTL</b>    | Test System Util card                               |
| <b>TEST IPB</b>     | Test Inter Processor Bus                            |
| <b>TEST LCD</b>     | Test LCDs   |
| <b>TEST LED</b>     | Test LEDs   |
- 4**    Clear the display and minor alarms on both Cores.
- |                 |                                 |
|-----------------|---------------------------------|
| <b>CDSP</b>     | Clear the displays on the Cores |
| <b>CMAJ</b>     | Clear major alarms              |
| <b>CMIN ALL</b> | Clear minor alarms              |
- 5**    Get the status of the Cores, CNIs, and memory.
- |                     |   |
|---------------------|---|
| <b>STAT CPU</b>     | Get the status of both Cores and redundancy                             |
| <b>STAT CNI c s</b> | Get the status of all configured cCNIs (both main and Transition) cards |
| <b>****</b>         | Exit program  |

---

**End of Procedure**

---

## Perform a data dump

### Procedure 322

#### Performing a data dump

- 1 Load the LD 43. At the prompt, enter:

**LD 43**                      Load program

- 2 Insert a floppy disk into the CP PII MMDU to capture the backup.

- 3 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump

- 4 When “DATABASE BACKUP COMPLETE” or “DATADUMP COMPLETE” appears on the terminal, enter:

**\*\*\*\***                      Exit program



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump is not successful, do not continue. Contact the technical support organization. Correct any data dump problem before continuing.



The parallel reload procedure is complete.

## Installing an IODU/C on Meridian 1 Options 61C, 81, 81C



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with NT5D61 Input Output Disk Unit with CD-ROM (IODU/C) card(s). If the system is not equipped with the IODU/C card, do not use these procedures

This procedure is used to upgrade CP1, CP2, CP3 and CP4 systems with IOP/CMDU to IODUC cards.

To better understand the process, read through the entire procedure before beginning the conversion.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 172:

**Table 172**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">959</a>
Upgrade Checklists	<a href="#">960</a>
Preparing	<a href="#">960</a>
Identifying the proper procedure	<a href="#">961</a>
Connect a terminal	<a href="#">961</a>
Print Site Data	<a href="#">962</a>
Perform a template audit	<a href="#">964</a>
Back up the database (data dump and ABKO)	<a href="#">966</a>
Convert the 4 MByte database media to 2 MByte database media	<a href="#">968</a>
Identify two unique IP addresses	<a href="#">968</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.

- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.



## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### **Procedure 323** **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1** Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2** The settings for the terminal are:
  - a.** 9600 Baud
  - b.** 8 data
  - c.** parity none
  - d.** 1 stop bit
  - e.** full duplex
  - f.** XOFF
- 3** If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print Site Data

Print site data to preserve a record of the system configuration (Table 173). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 173**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 173**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

Table 173  
Print site data (Part 3 of 3)

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ	CHG
	TYPE	SUPL
	SUPL	Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.

**CAUTION — Service Interruption****Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT****STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 324

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 325****Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**                      Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**                      Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.

**CAUTION — Service Interruption****Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5 Once the backup is complete, type:

\*\*\*\*                      Exit program

---

**End of Procedure**

---

## Convert the 4 MByte database media to 2 MByte database media



### IMPORTANT!

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

## Identify two unique IP addresses

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this



configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Parallel reload the Meridian 1 Option 61C and Meridian 1 81/81C CP3 CP4

Use the parallel reload procedures to convert from one software release to a later release or to up-issue software within the same software release. These parallel reload procedures are for software conversions only. Do *not* use this procedure for any other purpose. Parallel reloads can be done from either CPU. For the purposes of this document, the parallel reload begins with CPU 0.

If during the software conversion a problem is detected and it is determined that the system should revert back to the source release follow the “Parallel reload procedures” in Book 1.

### Verify memory

Determine whether the system requires additional memory. Refer to “Installing IODU/C cards, CP cards, CP memory” on [page 733](#) for memory requirements and upgrade procedures.

---

**End of Procedure**

---

## Determine status (STAT) of the hardware

### Procedure 326

#### Obtaining hardware status

- 1 Load LD 137 and get status of the hard disks.

**Note:** Be sure the hard disks are synchronized. If not, synchronize before proceeding.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the hard disks
<b>SYNC</b>	Synchronize hard disks if necessary (Synchronization may take up to 50 minutes)
<b>TEST CMDU</b>	Performs hard and floppy disk test
<b>****</b>	Exit program

- 2 Load LD 135 and determine the status of the CPs, CNIs and memory.

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of both CPs and memory
<b>STAT CNI</b>	Get the status of all configured CNIs

- 3 Test the standby (inactive) CP. Then switch CPs, and test again.

<b>TEST CPU</b>	Test standby (inactive) CP
-----------------	----------------------------

Wait until the terminal returns a complete test message. The message "HWI533 or HWI534" does not mean the test has completed!

<b>SCPU</b>	Switch CPs
<b>TEST CPU</b>	Test the standby (inactive) CP

**Note:** Testing the CPs can take up to 20 minutes for each test. When the test is complete, the memories are automatically synchronized.

---

**End of Procedure**

---

## Split the Core processors

### Procedure 327

#### Splitting the Core processors

- 1 Be sure CP 0 is active and CP1 is standby. If necessary, switch CPs again:

#### STAT CPU

SCPU            Switch CPs if necessary

\*\*\*\*            Exit program

- 2 Verify that IODU/C 0 is active. If necessary, switch IODU/Cs.

#### LD 137

STAT            Get the status of IODU/C

SWAP           Switch IODU/Cs (if necessary)

\*\*\*\*            Exit program

- 3 Connect a terminal from the CPSI port in Core/Net 1 to J25 of the I/O panel at the back of the Core/Net. Be sure it is configured as follows. The recommended baud rate is 9600, to be the same as the CPSI port.

**7 data bits, 1 stop bit, Space parity, Full-duplex, XON protocol**

- 4 Place CP 0 in Maintenance by setting the MAINT/NORM switch to MAINT.
- 5 In Core/Net 1, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.

- 6    Place CP1 in Maintenance by setting the MAINT/NORM switch to MAINT.

**Note:** Core 1 will now sysload. Allow the system to complete the sysload and INI. Review any sysload errors and correct before proceeding.



System is now in split mode, Core 0 active, Clock Controller 0 is active if equipped with FNF. Rings are in half/half mode.

---

**End of Procedure**

---

## Upgrade Core/Net 1 Hardware

### Procedure 328

#### Upgrading hardware

- 1    Remove IOP/CMDU if replacing or upgrading to IODUC.
- 2    Install new CP cards in Core/Net 1.
- 3    Install new IODUC card in Core/Net 1.

**Note:** Ensure the provided security device is installed.

## Install software on Core/Net 1

### Procedure 329

#### Installing the system software on Core/Net 1

- 1    Place the CP Install disk that corresponds with the installed CP card type into the IODU/C in Core/Net 1.
- 2    Install the CD-ROM into the CD drive:
  - a.    Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b.    Place the CD-ROM disk into the holder with the disk label showing.
  - c.    Use the four tabs to secure the CD-ROM drive.
  - d.    Press the button again to close the CD-ROM disk holder. Don't push the holder in by hand.

- 3 In Core/Net 1, perform the following three steps in uninterrupted sequence:
  - a. In Core/Net 1 press and release the MAN RST button on the CP card.
  - b. Set the MAINT/NORM switch on the CP card to MAINT.
  - c. Release the MAN RST button.

A Sysload begins (cold start). Wait for the Main Menu to appear on the terminal before proceeding.

**Note 1:** If the CD-ROM is not in the CD drive of the IODU/C, the installation procedure will not continue. Insert the CD-ROM into the drive to continue.

**Note 2:** If a problem is detected during the system verification, the Install process stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue. Contact the technical support organization.

- 4 Press <CR> to continue.
- 5 Log into the system. Enter the time and date, when prompted.
- 6 Select yes or (no) when asked if a Signaling Server is connected.

System Date and Time now is:

Day-Month-Year, Hour:Min:Sec

Succession Enterprise Software/Database/BOOTROM  
CDROM INSTALL Tool

Does this System have a Signaling Server.....? (Default - No)

Please enter:

<CR> -> <n> - No

<y> - Yes

Enter Choice>

- 7    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

**MAIN MENU**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu

<t> - To Tools menu.

<q> - Quit.

Enter Choice> <CR>

>Validating Keycode

The provided keycode authorizes the install of XXXXXXXX software

(all subissues) for machine type XXXX

(XXX processor on XXXX System)

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 8 The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 9 Enter **b** to install the Software, Database and CP-BOOTROM.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**10**   Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX



**11** Confirm all options before installing the software.

## INSTALLATION STATUS SUMMARY

=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
SW: CD to disk	yes		install for rel XXXXX	
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
Database	yes			
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
CP-BOOTROM	yes			

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 12** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**13** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**14** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**15** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**16** Enter **<CR>** when prompted, returning the system to the Install Menu.

17 Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 18** The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.  
You may reboot the system or return to the Main Menu.  
Remove all disks from the system before rebooting.

-----  
DO NOT REBOOT USING BUTTON!!!  
-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 1 to INI.

---

### End of Procedure

---

**Note:** If the system fails to load, or system messages indicate data corruption, back out of the parallel reload process by performing the steps in “Back out of the parallel reload and re-install old software” in Book 1.


## Determine peripheral software version

### Procedure 330 Checking peripheral software versions

- 1
- Load LD 22 and print Target peripheral software version. The Source peripheral software version was printed during the pre-conversion procedure. If there is a difference between the Source and Target peripheral software version, a forced download will occur during initialization when coming out of parallel reload. System initialization will take longer and established calls on IPE will be dropped.

<b>LD 22</b>	Load program
<b>REQ</b>	PRT
<b>TYPE</b>	PSWV
<b>****</b>	Exit program


## Switch call processing to Core/Net 1



**CAUTION — Service Interruption**

**Service Interruption**

Call Processing will be interrupted! Perform these next steps carefully. This is the point at which service is interrupted. Calls in process are interrupted, especially if Peripheral Software Download takes place. Some calls might be dropped.



**WARNING**

System initialization may take up to 15 minutes or longer.



**IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

**Procedure 331****Switching call processing from Core/Net 0 to Core/Net 1**

- 1 In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 2 In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 3 In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 4 In Core/Net 1, press the MAN INT button.

**Note:** On FNF based systems after the INI:

A FIJI download will occur if the FIJI firmware on Bank 1 of the FIJI card is different from the firmware on the system hard drive (PSDL file). This is automatic and no attempt should be made to prevent the download. The system will switch full to one ring, download up to 4 FIJI cards on the opposite ring at a time. This process continues on both rings until all Fiji's have been downloaded. The rings will then reset and come into service with the highest firmware available. This process is not service affecting. Depending on the number of groups installed, this process may take up to 20 minutes per ring.

**CAUTION — Service Interruption****Service Interruption**

The INI may take up to 15 minutes to complete.



CP1 is active, Clock 1 is active, IODU/C is active. If equipped, the FIJI ring is in half/half mode. Call processing is now switched from Core/Net 0 to Core/Net 1.



**IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

**Procedure 332**

**Testing Core/Net 1**

From Core/Net 1, perform these tests:

- 1    Check dial tone.
- 2    Make internal, external and network calls.
- 3    Check attendant console activity.
- 4    Check DID trunks.
- 5    Check applications (CallPilot, Symposium, Meridian Mail, etc.).

---

**End of Procedure**

---

## **Upgrade Core/Net 0 Hardware**

**Procedure 333**

**Upgrading Core/Net 0 hardware**

- 1    Remove IOP/CMDU if replacing or upgrading to IODUC.
- 2    Install new CP cards in Core/Net 0.
- 3    Install new IODUC card in Core/Net 0.

---

**End of Procedure**

---

## Install new software on Core/Net 0

### Procedure 334

#### Installing the software and converting the database

- 1 Check that a terminal is connected to J25 on Core/Net 0.
- 2 In Core/Net 0, install the CD-ROM into the CD-ROM drive in the MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Press the button again to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 3 Place the CP PII Install floppy disk into the IODU/C floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 4 Press the manual RESET button on the CP card faceplate.
- 5 Select yes or (no) when asked if a Signaling Server is connected.

System Date and Time now is:

Day-Month-Year, Hour:Min:Sec

Succession Enterprise Software/Database/BOOTROM  
CDROM INSTALL Tool

Does this System have a Signaling Server.....? (Default - No)

Please enter:

<CR> -> <n> - No

<y> - Yes

Enter Choice>

- 6    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

**MAIN    MENU**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu

<t> - To Tools menu.

<q> - Quit.

Enter Choice> <CR>

>Validating Keycode

The provided keycode authorizes the install of XXXXXXXX software

(all subissues) for machine type XXXX

(XXX processor on XXXX System)

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 7 The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 8 Enter **b** to install the Software, Database and CP-BOOTROM.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

9    Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

**10** Confirm all options before installing the software.

## INSTALLATION STATUS SUMMARY

=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
SW: CD to disk	yes		install for rel XXXXX	
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
Database	yes			
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
CP-BOOTROM	yes			

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 11** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B



The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**12** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**13** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**14** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**15** Enter **<CR>** when prompted, returning the system to the Install Menu.

16 Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 17** The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.  
You may reboot the system or return to the Main Menu.  
Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 0 to INI.

---

**End of Procedure**

---

## Exit split mode

### Procedure 335

#### Exiting the split mode

- 1    Connect CPSI port or maintenance SDI port.
- 2    Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.
- 3    Perform the following in uninterrupted sequence:
  - Press and release the MAN RST button in Core/Net 0.
  - When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

#### **RUNNING ROM OS**

#### **ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

- 4    In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

---

**End of Procedure**

---

---

## Test Core/Net 1 and Core/Net 0

### Procedure 336

#### Testing Core/Net 0 and Core/Net 1

- 1 Perform a redundancy sanity test using the following sequence:

##### LD 135

<b>STAT CNI</b>	Get status of CNI cards
<b>STAT CPU</b>	Get status of CPU and memory
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

- 2 Switch Core/Nets and test the other side (Core/Net 0)

<b>SCPU</b>	Switch Core/Nets
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

**Note:** Testing the Call Processor and CNI cards and synchronizing memory can take up to 20 minutes for each test. When the Call Processor test is complete, the Call Processor the memory is automatically synchronized.

- 3 Clear the display and minor alarms on both Core/Nets.

<b>CDSP</b>	Clear the displays on the Core/Nets
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms

- 4    Get the status of the Core/Nets, CNIs, and memory.

**STAT CPU**    Get the status of both Core/Nets

**STAT CNI**    Get the status of all configured CNIs and memory

**Note:** You may need to execute the STAT CNI command twice before receiving a response from the system.

\*\*\*\*            Exit program

---

**End of Procedure**

---

## Switch the Clocks

### Procedure 337 Switching the Clocks

- 1    Verify that the clock controller is assigned to the *active* Core.

**LD 60**            Load the program

**SSCK *x***            Get the status of the clock controllers (*x* is “0” or “1” for Clock 0 or Clock 1)

**SWCK**            Switch the Clock (if necessary)

\*\*\*\*            Exit program

- 2    Verify that the Clock Controllers are switching correctly:.

**SWCK**            Switch the Clock

**SWCK**            Switch the Clock again

---

**End of Procedure**

---



---

**If equipped, stat the FIJI rings****Procedure 338****Stat the rings**

- 1** Check the status of Ring 0 and Ring 0.

**LD 39** Load the program

**STAT RING** Get the status of Ring 0  
**0** (Ring state should be HALF/HALF)

- 2** Check the status of Ring 0 and Ring 1.

**LD 39** Load the program

**STAT RING** Get the status of Ring 0  
**1** (Ring state should be HALF/HALF)

---

**End of Procedure**

---

## Synchronize the hard disks

### Procedure 339

#### Synchronizing the hard disks

- 1    Access LD 137 and synchronize the hard disks. Synchronization can take up to 50 minutes. To ensure that the contents of IODU/C 1 are copied to IODU/C 0, verify that IODU/C 0 is disabled.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the IODU/C and redundancy
<b>SYNC</b>	Enter “Yes” to synchronize disks (Wait until the memory synchronization successfully completes before continuing)
<b>TEST CMDU</b>	Perform hard and floppy disk test

- 2    Get the status of the CMDU's and be sure CMDU 0 is active. Switch if necessary.

<b>STAT</b>	Get the status of IODU/C and redundancy
<b>SWAP</b>	Switch CMDU if necessary
<b>STAT CMDU</b>	Get the status of the IODU/Cs. Be sure the same IODU/C and CPU are active
<b>****</b>	Exit program

## Perform a data dump

### Procedure 340

#### Performing a data dump

- 1 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  
**LD 43**                      Load program
- 2 When “EDD000” appears on the terminal, enter:  
**EDD**                      Begin the data dump
- 3 When “DATABASE BACKUP COMPLETE” or “DATADUMP COMPLETE” appears on the terminal, enter the following:  
  
\*\*\*\*                      Exit program



The Parallel Reload process is complete. The system is now running on the new IODUC.

System is now in redundant mode.

---

#### End of Procedure

---

**Note:** Proceed to “Post-conversion procedure” on [page 723](#).

## Installing a Call Processor card on Option 51C

This procedure is for systems equipped with IODU/C cards only. If your system is equipped with an IOP/CMDU or IOP and CMDU cards, refer to [page 1004](#).



### **CAUTION — Service Interruption**

#### **Service Interruption**

Installing the NT5D10 Call Processor card in the Meridian 1 Option 51C will require system downtime. Schedule for this when planning the system upgrade.

The Call Processor card must be removed from the system to perform this upgrade. This will cause loss of service to the whole telephone system. Plan the upgrade for a time when the impact to the telephone users will be minimal.

Installing an NT5D10 or NT5D03 Call Processor card in a Meridian 1 Option 51C system consists of:

- installing a new Call Processor card in the Core module.
- upgrading the system software and Call Processor ROMs.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 174 below:

**Table 174**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">1005</a>
Upgrade Checklists	<a href="#">1006</a>
Preparing	<a href="#">1006</a>
Identifying the proper procedure	<a href="#">1007</a>
Connect a terminal	<a href="#">1007</a>
Print Site Data	<a href="#">1008</a>
Perform a template audit	<a href="#">1010</a>
Back up the database (data dump and ABKO)	<a href="#">1012</a>
Identify two unique IP addresses	<a href="#">1014</a>
Complete the upgrade	<a href="#">1019</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.

- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### **IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### **Procedure 341** **Connecting a terminal**

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1** Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2** The settings for the terminal are:
  - a.** 9600 Baud
  - b.** 8 data
  - c.** parity none
  - d.** 1 stop bit
  - e.** full duplex
  - f.** XOFF
- 3** If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Print Site Data

Print site data to preserve a record of the system configuration (Table 175). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 175**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>



**Table 175**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

Table 175  
Print site data (Part 3 of 3)

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.

**CAUTION — Service Interruption****Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT****STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 342

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When “EDD000” appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” will appear once the data dump is complete.

**\*\*\*\***                      Exit program

---

**End of Procedure**

---

**Procedure 343****Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**            Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**            Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.

**CAUTION — Service Interruption****Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5 Once the backup is complete, type:

\*\*\*\*            Exit program

---

**End of Procedure**

---

**Procedure 344**  
**Converting to 2 MByte database media**



**IMPORTANT!**

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

## **Identify two unique IP addresses**

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this

configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Procedure 345

#### Installing the CP card and CS 1000 Release 4.5 software



#### **IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

At this time you will install the new Call Processor card and CS 1000 Release 4.5 system software if it is not already installed on the hard drive.

- 1 Connect a terminal to the CPSI port in the Core module to J25 of the I/O panel at the back of the core. Be sure it is configured as follows. The recommended baud rate is 9600, to be the same as the CPSI port.
- 2 7 data bits
- 3 1 stop bit
- 4 Space parity
- 5 Full duplex
- 6 XON protocol
- 7 Set the NORM/MAINT switch to MAINT, disengage the lock latches and remove the Call Processor card from the Core module.
- 8 Insert the Install diskette that corresponds to the Call Processor card you will be installing into the IODU/C.
- 9 Install the CD-ROM disk into the CD-ROM drive. To install the CD-ROM:
- 10 press the button on the CD-ROM drive to open the CD-ROM disk holder

- 11 place the CD-ROM disk into the holder with the disk label showing
- 12 press the button again to close the CD-ROM disk holder (don't push the holder in by hand)
- 13 Verify that the MAINT/NORM switch on the NT5D10 Call Processor card is set to NORM.
- 14 Verify that the ENB/DIS switch on the CNI card is set to ENB.
- 15 Insert the new Call Processor card in the same slot in the Core module and secure the lock latches.
- 16 The system will automatically load the software install program.
- 17 When the NT Logo Screen appears on the terminal, the Software Installation Tool has loaded. Press **<CR>** to go to the Install Main Menu.
- 18 Set the system date and time. When prompted to enter the time and date, enter it in the following format. A space or dash can be used to separate the items.  
  
19 dd mm yyyy  
   hh mm ss  
   or  
   dd-mm-yyyy  
   hh-mm-ss
- 20 At the Main menu select **<u>** to go to the Install menu.

Nortel Meridian - 1 Software/Database/PEROM CDROM INSTALL Tool (x11)

== ==

### MAIN MENU

The Software Installation Tool will install or upgrade Meridian-1 System Software, Database and the PE-ROM (both CP and IOP ROM). You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR>--> <u> - To Install menu.

<t> - To Tools menu.

<q> - Quit.

Enter choice > **u**

553-7780



- 21** Insert the Keycode diskette when prompted and select **<a>** to continue with the keycode validation.

Nortel Meridian - 1 Software/Database/PEROM CDROM INSTALL Tool (x11)

The Software Installation Tool will install or upgrade  
Succession Enterprise System Software, Database and the CP-BOOTROM.  
You will be prompted throughout the installation and given the  
opportunity to quit at any time.

Please enter:

**<CR>** -> **<u>** - To Install menu

**<t>** - To Tools menu.

553-7729

**<q>** - Quit.

Enter Choice>

>Validating Keycode

Once the keycode is validated against the Security Device, the Install menu is displayed.

- 22** When the Install menu appears, select the following options in sequence when you are prompted to do so:

**<a>** to install software, CP-BOOT ROM and IOP-ROM

**<y>** to start installation

**<a>** to continue with the upgrade

- 23** Following the software installation, install the CP-BOOT and IOP-ROMs. From the menu select the following:

**<a>** to continue with ROM upgrade

**<a>** to continue with ROM upgrade (CP-BOOT ROM)

**<y>** to start installation

**<a>** to continue with ROM upgrade (IOP-ROM)

- 24** Remove the diskette from the IODU/C.
- 25** Select the following options to quit and reload the system:
- |       |                      |
|-------|----------------------|
| <q>   | to quit              |
| <yes> | to confirm quit      |
| <a>   | to reboot the system |

The system will automatically perform a sysload and system initialization during which several messages will appear on the system terminal. Wait until initialization has finished (INI messages are no longer displayed on the system terminal) before continuing.

**Note 1:** SYS4695 is not an error message. This message is cleared when you perform a data dump.

**Note 2:** If you are converting from a Release prior to CS 1000 Release 4.5, the following message appears on the system terminal:

#### **DATA CONVERSION**

##### **RELEASE xx.xx TO RELEASE xx.xx**

- 26** Verify that the “DONE” message appears on the system terminal.

**Note:** The SYSTEM INI message may take 70 seconds or more to appear.



#### **IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

## Complete the upgrade

### Procedure 346 Completing the upgrade

To complete the Call Processor card upgrade, verify CPU and CNI status.

- 1 Verify CPU and CNI functionality:

<b>LD 135</b>	Load the overlay
<b>STAT CPU</b>	Check the CPU status
<b>STAT CNI</b>	Verify CNI functionality
<b>****</b>	Exit program

- 2 Backup the customer database to 2mb diskettes:

- 3 Load the Equipment Data Dump Program (LD 43). At the prompt, enter

<b>LD 43</b>	Load program
--------------	--------------

- 4 When "EDD000" appears on the terminal, enter

<b>EDD</b>	Begin the data dump
------------	---------------------



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump is not successful, do not continue; contact your technical support organization. A data dump problem must be corrected before proceeding.

- 5 When "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" appear on the terminal, enter:

<b>****</b>	Exit program
-------------	--------------

- 6    Evaluate the number of call registers and telephone buffers that are configured for the system. Refer to *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120).



The Call Processor card upgrade is complete.

---

**End of Procedure**

---

**Note:** Proceed to “Post-conversion procedure” on [page 723](#).

## Installing IODU/C on Meridian 1 Option 51C



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with IOP/CMDU cards. If the system is not equipped with the IOP/CMDU card, do not use these procedures.

This procedure is used to upgrade CP1, CP2, CP3 and CP4 systems with IOP/CMDU to IODUC cards.

To better understand the process, read through the entire procedure before beginning the conversion.

“Database transfer” in Book 1 must be completed before proceeding.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 176 below:

**Table 176**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">1022</a>
Upgrade Checklists	<a href="#">1023</a>
Preparing	<a href="#">1023</a>
Identifying the proper procedure	<a href="#">1024</a>
Connect a terminal	<a href="#">1024</a>
Print Site Data	<a href="#">1025</a>
Perform a template audit	<a href="#">1027</a>
Back up the database (data dump and ABKO)	<a href="#">1029</a>
Convert the 4 MByte database media to 2 MByte database media	<a href="#">1031</a>
Identify two unique IP addresses	<a href="#">1031</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.

- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### Procedure 347 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1    Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2    The settings for the terminal are:
  - a.    9600 Baud
  - b.    8 data
  - c.    parity none
  - d.    1 stop bit
  - e.    full duplex
  - f.    XOFF
- 3    If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

---

End of Procedure

---



## Print Site Data

Print site data to preserve a record of the system configuration ((Table 177) below). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 177**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>

**Table 177**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>

**Table 177**  
**Print site data (Part 3 of 3)**

Site data	Print command	
DTI/PRI data block for all customers	LD 73	
	REQ TYPE	PRT DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	
	REQ TYPE SUPL	CHG SUPL Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E  xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

*Note:* The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01**      The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

- 
- 

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## Back up the database (data dump and ABKO)

To back up system data, complete the following two procedures.

- 1 Perform a data dump to save all system memory to the hard disk.
- 2 Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

### Procedure 348

#### Performing a data dump

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



#### **CAUTION — Service Interruption**

##### **Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 349**

**Performing an ABKO (save the database to floppies)**

- 1    Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2    Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**                    Load program

- 3    Run the ABKO backup (LD 143).

**ABKO**                    Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4    If there are validation errors, repeat the procedure.



**CAUTION — Service Interruption**

**Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5    Once the backup is complete, type:

\*\*\*\*                    Exit program

---

**End of Procedure**

---

## Convert the 4 MByte database media to 2 MByte database media



### IMPORTANT!

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility.

All systems can be converted by Nortel in the software conversion lab.

## Identify two unique IP addresses

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Verify memory

Determine whether the system requires additional memory. Refer to Table 178 on [page 1032](#) for memory requirement.

**Table 178**  
**Supported memory upgrade configurations (Part 1 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
48	32	16	NT5D10AA	NT5D03AA	16	0	0	0
64	32	32	NT5D10CA	NT5D03BA	16	16	0	0
					32	0	0	0
80	32	48	NT5D10EA	NT5D03CA	16	16	16	0
					16	32	0	0
96	32	64	NT5D10TA	NT5D03TA	16	16	16	16
					16	16	32	0
					32	32	0	0
112*	32	80	NT5D10UA	NT5D03UA	16	16	16	32
					16	32	32	0
128*	32	96	NT5D10VA	NT5D03VA	16	16	32	32
					32	32	32	0
96	64	32	N/A	N/A	16	16	0	0
					32	0	0	0
112	64	48	NT5D10JA	NT5D03EA	16	16	16	0
					16	32	0	0
128	64	64	N/A	NT5D03FA	16	16	16	16
128	64	64	NT5D10FB	NT5D03FB	16	16	16	16
<p>* This configuration requires Release 24 or later.</p> <p>** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.</p>								



**Table 178**  
**Supported memory upgrade configurations (Part 2 of 2)**

Total Memory	Total FLASH	Total DRAM	Call Processor		Slot 0	Slot 1	Slot 2	Slot 3
			68060	68060E	X5	X6	X7	X8
					16	16	32	0
					32	32	0	0
144*	64	80	NT5D10NA	NT5D03NA	16	16	16	32
					16	32	32	0
160*	64	96	NT5D10PB	NT5D03PB	16	16	32	32
					32	32	32	0
* This configuration requires Release 24 or later.								
** The 68040 CP card is available in A and B vintages. When labeling the CP card, use the appropriate vintage suffix.								

## CS 1000 Release 4.5

Table 179 lists the memory requirements of CS 1000 Release 4.5.

**Table 179**  
**CS 1000 Release 4.5 memory requirements**

System type	Flash memory requirement	DRAM memory requirement	Total memory requirement
Meridian 1 Options 51C/61C with CP3 (68060) or CP4 (68060E)	64 MByte	64 MByte	128 MByte
Meridian 1 Options 81/81C with or without Fibre Network Fabric	64 MByte	96 MByte	160 MByte
Meridian 1 Option 61C CP PII	NA	256 MByte	256 MByte
Meridian 1 Option 81C CP PII with or without Fibre Network Fabric	NA	256 MByte	256 MByte
Meridian 1 Option 61C CP PIV	NA	512 MBytes	512 Mbytes
Meridian 1 Option 81C CP PIV with or without Fibre Network Fabric	NA	512 MBytes	512 Mbytes
<p><b>Note 1:</b> CP1 (68030) and CP 2 (68040) Call Processors are not supported.</p> <p><b>Note 2:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PII systems are equipped with 256 MByte.</p> <p><b>Note 3:</b> All new Meridian 1 Options 61C, 81C and CS 1000M SG/MG CP PIV systems are equipped with 512 Mbytes.</p>			

---

## STAT the hardware on the Meridian 1 Option 51C

### Procedure 350

#### Determining the hardware status on the Meridian 1 Option 51C

- 1 Access LD 137 and get the status of the hard disk.

**LD 137** Load program

**STAT** Get the status of the hard disks

- 2 Access LD 135 and get status of the CP, CNI and memory.

**LD 135** Load program

**STAT CPU** Get the status of the CP and memory

**STAT CNI** Get the status of the CNI

---

**End of Procedure**

---

## Using the Database Transfer Utility

### Procedure 351

#### Using the Database Transfer Utility

- 1 Place the database transfer utility disk that matches your system type into the floppy drive of Core/Net 1.
- 2 Press the manual reset button on the CP card in Core/Net 1.
- 3 When the Nortel Logo Screen appears on the terminal, the Database Transfer Utility has loaded. Press <CR> to continue.



#### **CAUTION — Service Interruption**

##### **Loss of Data**

When using the Database Transfer Utility, do not select options other than those specified by this procedure. Selecting any other options can result in operating system corruption.

- 4    When the Main Menu appears, select <d> *To install Database only.*
- 5    Select <c> *to transfer the previous system database (DBMT).* Follow all on-screen instructions. When DBMT is complete, press <CR> to return to the Main Menu.
- 6    Select <t> to go to the Tools Menu
  - <s>                    to archive existing database
  - <a>                    to continue with archive (insert 2.0 Mbyte diskette into the floppy drive in Core 1)
  - <a>                    diskette is now in floppy drive in side 1

The message “Database backup complete!” is displayed and the Tool menu reappears after the backup is successfully completed.

- 7    Remove the 2.0 Mbyte diskette containing the customer database from the IOP/CMDU floppy drive.



**IMPORTANT!**

Database backup information should be preserved for a minimum of 5 days.

- 8    When the database is converted to 2.0 Mbyte, place it in a safe place for use after the IOP/CMDU card is replaced with an IODU/C card, and continue with the system upgrade.

---

**End of Procedure**

---

## Upgrade Core/Net 1 Hardware

### Procedure 352


#### Upgrading Core/Net 1 hardware

- 1    Remove IOP/CMDU if replacing or upgrading to IODUC.
- 2    Install new CP cards in Core/Net 1.

**3** Install new IODUC card in Core/Net 1.

**Note:** Ensure the provided security device is installed (see Figure 111 on [page 1037](#)).

**Figure 111**  
**Security Device holder**



**End of Procedure**



**IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

## Install new software on Meridian 1 Option 51C

### Procedure 353

#### Installing the software and converting the database

- 1    Install the CD-ROM into the CD-ROM drive in the MMDU:
  - a.   Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b.   Place the CD-ROM disk into the holder with the disk label showing.
  - c.   Press the button again to close the CD-ROM disk holder. Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 2    Place the Install floppy disk into the MMDU floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 3    Press the manual RESET button on the CP card faceplate.

- 4 Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
    Day-Month-Year, Hour:Min:Sec
    Succession Enterprise Software/Database/BOOTROM
CDROM INSTALL Tool
    Does this System have a Signaling Server.....? (Default - No)
    Please enter:
<CR> -> <n> - No
    <y> - Yes
    Enter Choice>
```

- 5 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```
                M A I N   M E N U

    The Software Installation Tool will install or upgrade
    Succession Enterprise System Software, Database and the CP-
    BOOTROM. You will be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:
<CR> -> <u> - To Install menu
    <t> - To Tools menu.
    <q> - Quit.
    Enter Choice> <CR>
>Validating Keycode

    The provided keycode authorizes the install of XXXXXXXX
    software
    (all subissues) for machine type XXXX
    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 6    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names



**7** Enter **b** to install the Software, Database and CP-BOOTROM.**I N S T A L L   M E N U**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

8    Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

**9** Confirm all options before installing the software.

## INSTALLATION STATUS SUMMARY

=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
SW: CD to disk	yes		install for rel XXXXX	
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
Database	yes			
=====+=====+=====+=====				
Option	Choice	Status	Comment	
=====+=====+=====+=====				
CP-BOOTROM	yes			

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 10** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

<1>     Global 10 Languages

<2>     Western Europe 10 Languages

<3>     Eastern Europe 10 Languages

<4>     North America 6 Languages

<5>     Spare Group A

<6>     Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

**11** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**12** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**13** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**14** Enter **<CR>** when prompted, returning the system to the Install Menu.

15 Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**



- 16** The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.

You may reboot the system or return to the Main Menu.

Remove all disks from the system before rebooting.

-----  
DO NOT REBOOT USING BUTTON!!!  
-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for the Core/Net to INI.

---

### End of Procedure

---



### IMPORTANT!

Power up all applications (Meridian Mail, CallPilot, Symposium).

## Complete the upgrade

### Procedure 354 Completing the upgrade

- 1    Perform a redundancy sanity test using the following sequence:

<b>LD 135</b>	Load program
<b>STAT CNI</b>	Get status of CNI card
<b>STAT CPU</b>	Get status of CPU and memory

- 2    Clear the display and minor alarms.

<b>CDSP</b>	Clear the displays on the Cores
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms
<b>****</b>	Exit program

- 3    Check dial tone.
- 4    Make internal, external and network calls.
- 5    Check attendant console activity.
- 6    Check DID trunks.

**Note:** Proceed to “Post-conversion procedure” on [page 723](#).

---

**End of Procedure**

---

## Installing a Call Processor on Options 61C, 81, 81C



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected anti-static wrist strap when working on or near Meridian 1 equipment.



### WARNING

Use the procedures in this section if the system is equipped with NT5D61 Input Output Disk Unit with CD-ROM (IODU/C) card(s). If the system is not equipped with the IODU/C card, do not use these procedures.



### WARNING

#### Service Interruption

The Call Processor card must be removed from the system to perform this upgrade, causing loss of service to the entire telephone system. Plan to perform the upgrade when impact to telephone users is minimal.

This procedure is for systems equipped with IODU/C cards only. If your system is equipped with an IOP/CMDU or IOP and CMDU cards, they must be upgraded first.

Installing an NT5D10 or NT5D03 Call Processor card in a Meridian 1 Option 51C system consists of:

- Installing a new Call Processor card in the Core module.
- Upgrading the system software and Call Processor ROMs.

## Prepare for installation

This document implements a source to target approach to performing an upgrade. It is important to correctly identify the source platform, target platform and maintenance window required to perform the upgrade.

Each chapter features check boxes indicating what condition the system should be in at that stage of the upgrade. If the system is not in the proper condition steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 180 below:

**Table 180**  
**Prepare for upgrade steps**

Procedure Step	Page
Planning	<a href="#">1052</a>
Upgrade Checklists	<a href="#">1053</a>
Preparing	<a href="#">1053</a>
Identifying the proper procedure	<a href="#">1054</a>
Connect a terminal	<a href="#">1054</a>
Print Site Data	<a href="#">1055</a>
Perform a template audit	<a href="#">1058</a>
Back up the database (data dump and ABKO)	<a href="#">1059</a>
Convert the 4 MByte database media to 2 MByte database media	<a href="#">1062</a>
Identify two unique IP addresses	<a href="#">1062</a>

## Planning

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.

- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.
- Identify all applications (CallPilot, SCCS, IP, Meridian Mail etc.) that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.

## Upgrade Checklists

Upgrade checklists can be found in the “Upgrade checklists” chapter on [1159](#). Engineers may print this section in order to facilitate the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (553-3021-120)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine the current patch or Dep lists installed at the source platform.
- Determine the required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.

- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a source to target format. Each procedure features warning boxes and check boxes placed at critical points. Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



### IMPORTANT!

Database backup information should be preserved for a minimum of 5 days.

## Connect a terminal

### Procedure 355 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2 The settings for the terminal are:
  - a. 9600 Baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex

**f. XOFF**

- 3** If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

**End of Procedure****Print Site Data**

Print site data to preserve a record of the system configuration ((Table 181) below). Verify that all information is correct. Make corrections as necessary.

**Note:** Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 181**  
**Print site data (Part 1 of 4)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>

**Table 181**  
**Print site data (Part 2 of 4)**

Site data	Print command	
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue and tape ID	LD 22	
	REQ	ISS
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)



**Table 181**  
**Print site data (Part 3 of 4)**

Site data	Print command	
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)


Table 181  
Print site data (Part 4 of 4)

Site data	Print command
Superloops and XPEs	LD 97
	REQ
	CHG
	TYPE
	SUPL
	Vxxx
	V stands for a virtual superloop and xxx is the number of the virtual superloop.
	xxx = 0-252 in multiples of four for MG 1000E
	xxx = 96-112 in multiples of four for MG 1000T (See Table 29)
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.	

Perform a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



**CAUTION — Service Interruption**

**Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01**     The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## **Back up the database (data dump and ABKO)**

To back up system data, complete the following two procedures.

- 1**     Perform a data dump to save all system memory to the hard disk.
- 2**     Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

**Procedure 356**  
**Performing a data dump**

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**                      Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**                      Begin the data dump



**CAUTION — Service Interruption**

**Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*                      Exit program

---

**End of Procedure**

---

**Procedure 357**  
**Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**            Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**            Run the backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.



### **CAUTION — Service Interruption**

#### **Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PII.

- 5 Once the backup is complete, type:

\*\*\*\*            Exit program

---

**End of Procedure**

---

## Convert the 4 MByte database media to 2 MByte database media



### IMPORTANT!

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT and XT must be completed by Nortel Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility. See “Using the Database Transfer Utility” on [page 1035](#).

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

## Identify two unique IP addresses

Each CP PII system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this

configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

- Contact your systems administrator to identify two unique IP addresses before the upgrade.
- For instructions to configure these IP numbers, see “Configuring IP Addresses” in Book 1.

## Perform installation

### Parallel reload the Meridian 1 Option 61C and Meridian 1 81/81C CP3 CP4

**Note:** This procedure does not include instructions for installing new IODU/C cards or CP cards. If required, refer to “Installing a Call Processor card on Options 61C CP PII, 81C CP PII” on [page 900](#) and “Installing a Call Processor card on Option 51C” on [page 1004](#).

Parallel reloads can be done from either CPU. For the purposes of this document, the parallel reload begins with CPU 0.

If during the software conversion a problem is detected and it is determined that the system should revert back to the source release follow the “Parallel reload procedures” in Book 1.

### Verify memory

Determine whether the system requires additional memory. Refer to “Installing IODU/C cards, CP cards, CP memory” on [page 733](#) for memory requirements and upgrade procedures.

## Determine status (STAT) of the hardware

### Procedure 358

#### Obtaining hardware status

- 1    Load LD 137 and get status of the hard disks.

**Note:** Be sure the hard disks are synchronized. If not, synchronize before proceeding.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the hard disks
<b>SYNC</b>	Synchronize hard disks if necessary (Synchronization may take up to 50 minutes)
<b>TEST CMDU</b>	Performs hard and floppy disk test
<b>****</b>	Exit program

- 2    Load LD 135 and determine the status of the CPs, CNIs and memory.

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Get the status of both CPs and memory
<b>STAT CNI</b>	Get the status of all configured CNIs

- 3    Test the standby (inactive) CP. Then switch CPs, and test again.

<b>TEST CPU</b>	Test standby (inactive) CP
-----------------	----------------------------

Wait until the terminal returns a complete test message. The message "HWI533 or HWI534" does not mean the test has completed!

<b>SCPU</b>	Switch CPs
<b>TEST CPU</b>	Test the standby (inactive) CP

- 4    Check total memory allocation before the upgrade.

<b>LD 10</b>	Load program
--------------	--------------



When the header for LD 10 is displayed, note the value associated with Total Memory. After the upgrade, compare Total Memory before and after the upgrade. Total Memory should be greater after the upgrade.

Exit the program:

\*\*\*\* Exit program

**Note:** Testing the CPs can take up to 20 minutes for each test. When the test is complete, the memories are automatically synchronized.

---

**End of Procedure**

---

## Split the Core processors

### Procedure 359

#### Splitting the Core processors

- 1 Be sure CP 0 is active and CP1 is standby. If necessary, switch CPs again:

**STAT CPU**

**SCPU** Switch CPs if necessary

\*\*\*\* Exit program

- 2 Verify that IODU/C 0 is active. If necessary, switch IODU/Cs.

**LD 137**

**STAT** Get the status of IODU/C

**SWAP** Switch IODU/Cs (if necessary)

\*\*\*\* Exit program

- 3 Connect a terminal from the CPSI port in Core/Net 1 to J25 of the I/O panel at the back of the Core/Net. Be sure it is configured as follows. The recommended baud rate is 9600, to be the same as the CPSI port.

**7 data bits, 1 stop bit, Space parity, Full-duplex, XON protocol**

- 4 Place CP 0 in Maintenance by setting the MAINT/NORM switch to MAINT.

- 5    In Core/Net 1, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 6    Place CP1 in Maintenance by setting the MAINT/NORM switch to MAINT.

**Note:** Core 1 will now sysload. Allow the system to complete the sysload and INI. Review any sysload errors and correct before proceeding.



System is now in split mode, Core 0 active, Clock Controller 0 is active if equipped with FNF. Rings are in half/half mode.

---

**End of Procedure**

---

## Upgrade Core/Net 1 hardware

### Procedure 360

#### Upgrading Core/Net 1 hardware

- 1    Tag all faceplate cables on the CP card in Core/Net 1.
- 2    Disconnect all faceplate cables on the CP card in Core/Net 1
- 3    Remove the CP card from the system in Core/Net 1
- 4    Install the replacement CP card in Core/Net 1.

---

Document ID: 553-3021-258  
**End of Procedure**

---

## Install software on Core/Net 1

### Procedure 361

#### Installing the system software on Core/Net 1

- 1    Place the CP Install disk that corresponds with the installed CP card type into the IODU/C in Core/Net 1.
- 2    Install the CD-ROM into the CD drive:

- a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Use the four tabs to secure the CD-ROM drive.
  - d. Press the button again to close the CD-ROM disk holder. Don't push the holder in by hand.
- 3 In Core/Net 1, perform the following three steps in uninterrupted sequence:
  - a. In Core/Net 1 press and release the MAN RST button on the CP card.
  - b. Set the MAINT/NORM switch on the CP card to MAINT.
  - c. Release the MAN RST button.

A Sysload begins (cold start). Wait for the Main Menu to appear on the terminal before proceeding.

**Note 1:** If the CD-ROM is not in the CD drive of the IODU/C, the installation procedure will not continue. Insert the CD-ROM into the drive to continue.

**Note 2:** If a problem is detected during the system verification, the Install process stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue. Contact the technical support organization.

- 4 Press <CR> to continue.
- 5 Log into the system. Enter the time and date, when prompted.

- 6    Select yes or (no) when asked if a Signaling Server is connected.

```
System Date and Time now is:
    Day-Month-Year, Hour:Min:Sec
    Succession Enterprise Software/Database/BOOTROM
CDROM INSTALL Tool
    Does this System have a Signaling Server.....? (Default - No)
    Please enter:
<CR> -> <n> - No
    <y> - Yes
    Enter Choice>
```

- 7    The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

```
                M A I N   M E N U

    The Software Installation Tool will install or upgrade
    Succession Enterprise System Software, Database and the CP-
    BOOTROM. You will be prompted throughout the installation and
    given the opportunity to quit at any time.

    Please enter:
<CR> -> <u> - To Install menu
    <t> - To Tools menu.
    <q> - Quit.
    Enter Choice> <CR>
>Validating Keycode

    The provided keycode authorizes the install of XXXXXXXX
    software
    (all subissues) for machine type XXXX
    (XXX processor on XXXX System)
```

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 8** The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 9    Enter **b** to install the Software, Database and CP-BOOTROM.

I N S T A L L   M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**10** Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

11 Confirm all options before installing the software.

INSTALLATION STATUS SUMMARY

-----

Option	Choice	Status	Comment
SW: CD to disk	yes		install for rel XXXXX

-----

Option	Choice	Status	Comment
Database	yes		

-----

Option	Choice	Status	Comment
CP-BOOTROM	yes		

-----

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.



Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 12** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

- <1> Global 10 Languages
- <2> Western Europe 10 Languages
- <3> Eastern Europe 10 Languages
- <4> North America 6 Languages
- <5> Spare Group A
- <6> Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.

- 13** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**14** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**15** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**16** Enter **<CR>** when prompted, returning the system to the Install Menu.

**17** Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 18 The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.  
You may reboot the system or return to the Main Menu.  
Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 1 to INI.

---

**End of Procedure**

---

## Determine peripheral software version

### Procedure 362

#### Checking peripheral software versions

- 1 Load LD 22 and print Target peripheral software version. The Source peripheral software version was printed during the pre-conversion procedure. If there is a difference between the Source and Target peripheral software version, a forced download will occur during initialization when coming out of parallel reload. System initialization will take longer and established calls on IPE will be dropped.

<b>LD 22</b>	Load program
<b>REQ</b>	PRT
<b>TYPE</b>	PSWV
<b>****</b>	Exit program

## Switch call processing to Core/Net 1



### CAUTION — Service Interruption

#### Service Interruption

Call Processing will be interrupted! Perform these next steps carefully. This is the point at which service is interrupted. Calls in process are interrupted, especially if Peripheral Software Download takes place. Some calls might be dropped.



### WARNING

System initialization may take up to 15 minutes or longer.



**IMPORTANT!**

Power down all applications (Meridian Mail, CallPilot, Symposium).

**Procedure 363**

**Switching call processing from Core/Net 0 to Core/Net 1**

- 1    In Core/Net 0, disable the CNI cards by setting the ENB/DIS faceplate switches to DIS.
- 2    In Core/Net 0, set the DIS/ENB faceplate switch on the IODU/C card to DIS and unseat it.
- 3    In Core/Net 1, enable the CNI cards by setting the ENB/DIS faceplate to ENB.
- 4    In Core/Net 1, press the MAN INT button.



Call processing is now switched from Core/Net 0 to Core/Net 1.



**CAUTION — Service Interruption**

**Service Interruption**

The INI may take up to 15 minutes to complete.



**IMPORTANT!**

Power up all applications (Meridian Mail, CallPilot, Symposium).

---

**End of Procedure**

---



## Test Core/Net 1

### Procedure 364

#### Testing Core/Net 1

From Core/Net 1, perform these tests:

- 1 Check dial tone.
- 2 Make internal, external and network calls.
- 3 Check attendant console activity.
- 4 Check DID trunks.
- 5 Check applications (CallPilot, Symposium, Meridian Mail, etc.).



CP1 is active, Clock 1 is active, IODU/C is active. If equipped, the FIJI ring is in half/half mode.

---

**End of Procedure**

---

## Upgrade Core/Net 0 hardware

### Procedure 365

#### Upgrading Core/Net 0 hardware

- 1 Tag all faceplate cables on the CP card in Core/Net 0.
- 2 Disconnect all faceplate cables on the CP card in Core/Net 0.
- 3 Remove the CP card from the system in Core/Net 0.
- 4 Install the replacement CP card in Core/Net 0.

---

**End of Procedure**

---

## Install new software on Core/Net 0

### Procedure 366

#### Installing the software and converting the database

- 1 Check that a terminal is connected to J25 on Core/Net 0.
- 2 In Core/Net 0, install the CD-ROM into the CD-ROM drive in the MMDU:
  - a. Press the button on the CD-ROM drive to open the CD-ROM disk holder.
  - b. Place the CD-ROM disk into the holder with the disk label showing.
  - c. Press the button again to close the CD-ROM disk holder.  
Do not push the holder in by hand.

**Note:** If the CD-ROM is not in the CD-ROM drive, the installation will not continue. Insert the CD-ROM to continue.

- 3 Place the CP PII Install floppy disk into the IODU/C floppy drive.

**Note:** If a problem is detected during the system verification, Install stops, prints an error message, and aborts the installation. If the verification is not successful, do not continue; contact your technical support organization.

- 4 Press the manual RESET button on the CP card faceplate.
- 5 Select yes or (no) when asked if a Signaling Server is connected.

System Date and Time now is:

Day-Month-Year, Hour:Min:Sec

Succession Enterprise Software/Database/BOOTROM  
CDROM INSTALL Tool

Does this System have a Signaling Server.....? (Default - No)

Please enter:

<CR> -> <n> - No

<y> - Yes

Enter Choice>

- 6 The system then enters the Main Menu for keycode authorization. Remove the CP PII Install Program diskette and insert the Keycode diskette.

**MAIN MENU**

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu

<t> - To Tools menu.

<q> - Quit.

Enter Choice> **<CR>**

>Validating Keycode

The provided keycode authorizes the install of XXXXXXXX software

(all subissues) for machine type XXXX

(XXX processor on XXXX System)

**IMPORTANT!**

Remove install floppy disk at this time and insert the keycode diskette.

- 7    The screen displays the Install Menu. Confirm that the keycode matches the CD-ROM release.

Please confirm that this keycode matches the CDROM Release

Please enter:

<CR> -> <y> - Yes, the keycode matches. Go on to Install Menu.

<n> - No, the keycode does not match. Try another keycode diskette.

Enter Choice> **<CR>**

>Obtain database file names

- 8    Enter **b** to install the Software, Database and CP-BOOTROM.

#### I N S T A L L   M E N U

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **b**

**9** Verify the CD-ROM version.

Please insert the installation CDROM into the drive on Core X.

The labeled side of the CDROM should be side up in the CDROM tray.

Please enter:

<CR> -> <a> - CDROM is now in drive. Continue with s/w checking.

<q> - Quit.

Enter Choice> **<CR>**

The installation CDROM contains version XXXXXXXX\_X.

Please enter:

<CR> -> <y> - Yes, this is the correct version. Continue.

<n> - No, this is not the correct version. Try another CDROM.  
or keycode disk

Enter Choice> **<CR>**

>copying direct.rec from /cd0/0300\_KMR.N33/target/p/sl1/  
direct.rec to /u/direct.rec

>Updating /u/direct.rec

>Processing the Install Control file

>Installing release XXXXX

10 Confirm all options before installing the software.

INSTALLATION STATUS SUMMARY

-----

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

SW: CD to disk	yes		install for rel XXXXX
----------------	-----	--	-----------------------

=====+=====+=====+=====

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

Database	yes		
----------	-----	--	--

=====+=====+=====+=====

Option	Choice	Status	Comment
--------	--------	--------	---------

=====+=====+=====+=====

CP-BOOTROM	yes		
------------	-----	--	--

Please enter:<CR> -> <y> - Yes, start Installation.

<n> - No, stop Installation. Return to the Main Menu.

Enter Choice> **<CR>**

>Checking System Configuration

You selected to upgrade the system from release: XXXX to release: XXXXX.

This will erase all old system files.

---

553-3021-258

Standard 6.00

July 2006

Database files will NOT be erased. You may continue installing the software or quit now and leave your system unchanged.

Please enter:

<CR> -> <a> - Continue with Upgrade.

<q> - Quit.

Enter Choice> **<CR>**

>Starting Software Install

>Upgrading from release XXXX to release XXXXX

- 11** After a number of files are copied over, select a PSDL file to install. The PSDL file contains the loadware for all downloadable cards in the system and loadware for M3900 series sets.

Select one of the six PSDL files

- <1> Global 10 Languages
- <2> Western Europe 10 Languages
- <3> Eastern Europe 10 Languages
- <4> North America 6 Languages
- <5> Spare Group A
- <6> Spare Group B

The languages contained in each selection are outlined as follows.

- 1 – Global 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana.
- 2 – Western Europe 10 Languages English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Danish.
- 3 – Eastern Europe 10 Languages English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish.
- 4 – North America six Languages English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana.
- 5 – Spare Group A.
- 6 – Spare Group B.



**12** Continue with upgrade when prompted. Select a database to install.

Software release 4.x was installed successfully on Core X.

All files were copied from CDROM to the hard disk.

Please press <CR> when ready. **<CR>**

You will now perform the database installation.

Note: If you are installing the Database from a floppy disk, please insert the correct disk now. Perform data dump using the back up disk from Core/Net 1 and use this back up disk to install the customer database.

Please enter:

<CR> -> <a> - Install CUSTOMER Database

(the customer database diskette must be in the Core X disk drive).

<b> - Install DEFAULT Database

(the installation CDROM must be in the Core X disk drive).

<c> - Transfer the previous system Database.

<e> - Check the Database that exists on the hard disk.

<q> - Quit.

Enter Choice> **<CR>**

**13** Confirm database transfer.

You selected to transfer the database from the floppy disk - release: XXXX to the hard disk on Core X. release: XXXX.

This will erase the database on the hard disk.

The database diskette has been inserted into the floppy disk drive.

If you quit now, the database will be left unchanged.

Please enter:

<CR> -> <a> - Continue with Database Install.

<q> - Quit.

Enter Choice> **<CR>**

The system then informs you of the database details and prompts you to confirm.

You have chosen to restore database dated:

Month-Day-Hour Min:Sec:Year

Please confirm.

Please enter:

<CR> -> <y> - Yes, load.

<n> - No, DO NOT load.

Enter Choice> **<CR>**

**14** The system restores the database and provides a status summary.

**Note:** The hard drive on a new system displays an error message that no database is found on hard drive. This message can be ignored.

**15** Enter **<CR>** when prompted, returning the system to the Install Menu.

**16** Enter **q** to quit.

#### INSTALL MENU

The Software Installation Tool will install or upgrade Succession Enterprise System Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

<b> - To install Software, Database, CP-BOOTROM.

<c> - To install Database only.

<d> - To install CP-BOOTROM only.

<t> - To go to the Tools menu.

<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.

<q> - Quit.

Enter Choice> **q**

- 17 The system then prompts you to confirm and reboot.

You selected to Quit the Software Installation Tool.  
You may reboot the system or return to the Main Menu.  
Remove all disks from the system before rebooting.

-----

DO NOT REBOOT USING BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

<m> - Return to the Main menu.

Enter Choice> **<CR>**

>Removing (temporary files)

>Rebooting system ...

Before completing the next procedure, wait for Core/Net 0 to INI.

---

**End of Procedure**

---

## **Exit split mode**

### **Procedure 367**

#### **Exiting split mode**

- 1** Connect CPSI port or maintenance SDI port.
- 2** Enable the CNI cards by setting the ENB/DIS faceplate switch to ENB in Core/Net 0.
- 3** Perform the following in uninterrupted sequence:
  - Press and release the MAN RST button in Core/Net 0.
  - When SYS700 messages appears on the LCD display on Core/Net 0, set the MAINT/NORM switch to NORM in Core/Net 0.

In 60 seconds, the LCD lights and confirms the processes with:

#### **RUNNING ROM OS**

#### **ENTERING CP VOTE**

An HWI534 message indicates the start of memory synchronization. In 10 minutes, an HWI533 message on Core/Net 1 CSPI or SDI terminal indicates the memory synchronization is complete.

- 4** In Core/Net 1, set the MAINT/NORM switch on the CP card to NORM.

---

**End of Procedure**

---

## Test Core/Net 1 and Core/Net 0

### Procedure 368

#### Testing Core/Net 0 and Core/Net 1

- 1 Perform a redundancy sanity test using the following sequence:

##### LD 135

<b>STAT CNI</b>	Get status of CNI cards
<b>STAT CPU</b>	Get status of CPU and memory
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

- 2 Switch Core/Nets and test the other side (Core/Net 0)

<b>SCPU</b>	Switch Core/Nets
<b>TEST CPU</b>	Test the inactive Core/Net/Net
<b>TEST CNI c s</b>	Test each inactive CNI card

**Note:** Testing the Call Processor and CNI cards and synchronizing memory can take up to 20 minutes for each test. When the Call Processor test is complete, the Call Processor the memory is automatically synchronized.

- 3 Clear the display and minor alarms on both Core/Nets.

<b>CDSP</b>	Clear the displays on the Core/Nets
<b>CMAJ</b>	Clear major alarms
<b>CMIN ALL</b>	Clear minor alarms

- 4 Get the status of the Core/Nets, CNIs, and memory.

<b>STAT CPU</b>	Get the status of both Core/Nets
<b>STAT CNI</b>	Get the status of all configured CNIs and memory

- 5 Check for dial tone.

- 6 Make internal, external, and network calls.
- 7 Check attendant console activity.
- 8 Check DID trunks.
- 9 Check any auxiliary processors.

**Note:** You may need to execute the STAT CNI command twice before receiving a response from the system.

\*\*\*\* Exit program

---

**End of Procedure**

---

## Switch the Clocks

### Procedure 369 Switching the Clocks

- 1 Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load program

**SSCK  $x$**  Get the status of the clock controllers ( $x$  is “0” or “1” for Clock 0 or Clock 1)

**SWCK** Switch the Clock (if necessary)

\*\*\*\* Exit program

- 2 Verify that the Clock Controllers are switching correctly:.

**SWCK** Switch the Clock

**SWCK** Switch the Clock again

---

**End of Procedure**

---

## If equipped, stat the FIJI rings

### Procedure 370

#### Stat the rings

- 1    Check the status of Ring 0 and Ring 0.

**LD 39**                    Load program

**STAT RING**    Get the status of Ring 0  
**0**                    (Ring state should be HALF/HALF)

- 2    Check the status of Ring 0 and Ring 1.

**LD 39**                    Load program

**STAT RING**    Get the status of Ring 0  
**1**                    (Ring state should be HALF/HALF)

---

**End of Procedure**

---



---

## Synchronize the hard disks

### Procedure 371

#### Synchronizing the hard disks

- 1 Access LD 137 and synchronize the hard disks. Synchronization can take up to 50 minutes. To ensure that the contents of IODU/C 1 are copied to IODU/C 0, verify that IODU/C 0 is disabled.

<b>LD 137</b>	Load program
<b>STAT</b>	Get the status of the IODU/C and redundancy
<b>SYNC</b>	Enter "Yes" to synchronize disks (Wait until the memory synchronization successfully completes before continuing)
<b>TEST CMDU</b>	Perform hard and floppy disk test

- 2 Get the status of the CMDU's and be sure CMDU 0 is active. Switch if necessary.

<b>STAT</b>	Get the status of IODU/C and redundancy
<b>SWAP</b>	Switch CMDU (if necessary)
<b>STAT CMDU</b>	Get the status of the IODU/Cs (Be sure the same IODU/C and CPU are active)
<b>****</b>	Exit program

---

**End of Procedure**

---

## Perform a data dump

### Procedure 372

#### Performing a data dump

- 1    Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  
     **LD 43**                      Load program
- 2    When “EDD000” appears on the terminal, enter:  
     **EDD**                      Begin the data dump
- 3    When “DATABASE BACKUP COMPLETE” or “DATADUMP COMPLETE” appears on the terminal, enter the following:  
     **\*\*\*\***                      Exit program

---

#### End of Procedure

---

Proceed to “Post-conversion procedure” on [page 723](#).



The Parallel Reload process is complete. The system is now running on the upgraded CP card.

System is now in redundant mode.

## Upgrade to an NTRB53 Clock Controller

**Note:** The NTRB53 Clock Controller cannot be combined with a QPC775 or a QPC471 card.

### Procedure 373

#### Upgrading to an NTRB53 Clock Controller

- 1 Remove old equipment.



#### CAUTION — Service Interruption

Never connect Clock-to-Clock cable J3 between the old clock (QPC471 or QPC775) and the new clock (NTRB53).

- 2 For dual core systems, ensure the clock controller card being removed is on the inactive core. If you need to switch cores, go to LD 135 and enter:

#### LD 135

SCPU

Switch cores

\*\*\*\*

Exit the overlay

- 3 Disable the QPC775 or QPC471 Clock Controller card. At the prompt, enter:

LD 60

Load program

SSCK x

Get status of system clock where x = 0 or 1

- 4 If the clock is active, switch clocks. At the prompt, enter:

SWCK

Switch system clock from active to standby

SSCK x

Get status of system clock where x = 0 or 1

- 5 Ensure the other clock controller is active and in the free run mode. At the prompt, enter:

SSCK x

Get status of system clock where x = 0 or 1

TRCK FRUN

Set clock controller tracking to free run



#### CAUTION — Service Interruption

When the system is equipped with PRI and tracks to an external source, the T1 spans see slips and can exceed the thresholds. Voice quality over PRI can start to hear degradation.

- 6 Disable the clock controller card you are removing. At the prompt, enter:

DIS CC x

Disable system clock controller where x = 0 or 1

- 7    Set the ENL/DIS switch to DIS on the card being removed.  
**Note:** Disabling the clock causes the system message FIJI0022 to display.
- 8    Tag and disconnect the cables to the card being removing.
- 9    Unhook the locking devices on the card.
- 10   Pull the card out of the card cage.

---

**End of Procedure**

---

## Install new equipment

### Procedure 374 Installing new equipment

- 1    Set the ENB/DIS switch to DIS on the replacement card.
- 2    Set the option switches on the replacement card (NTRB53). Refer to Table 8, "Clock Controller switch settings for NTRB53", on page 102 in What's New for Meridian 1 (Release 25.4).
- 3    Insert the replacement card into the vacated slot and hook the locking devices.



#### **CAUTION — Service Interruption**

Never connect the Clock-to-Clock cable J3 between the old clock (QPC471 or QPC775) and the new clock (NTRB53)

- 4    Connect the reference cables (J1 and J2) to the replacement card.  
**Note:** Do not connect J3.
- 5    Set the ENB/DIS switch to ENB on the replacement card.
- 6    Software enable the card. At the prompt, enter:

**LD 60**

**ENL CC x**            Enable clock controller card, where x = 0 or 1

- 7 Verify that the card is active. At the prompt, enter:

<b>SSCK x</b>	Get status of system clock where x = 0 or 1
<b>****</b>	Exit the overlay

**Note:** Enabling the new clock card can initiate a F/W download. The card resets and executes a self test. This is recognized by the 2 faceplate LEDs flashing 3 times, indicating a pass. The completion of the download is indicated on the system terminal.

**Note:** Wait one minute before proceeding to the next step.

- 8 Switch to the core with the new clock. At the prompt, enter:

<b>LD 135</b>	
<b>SCPU</b>	Switch CPU



#### **CAUTION — Service Interruption**

Noise is experienced over local and trunk calls. System FIJI alarms are also displayed. The noise and alarms are resolved after the new clock begins tracking to the selected reference.

- 9 Faceplate-disable the old clock controller to force the newly installed clock controller to activate.
- 10 Connect the Clock-to-Clock faceplate cable to J3 of the new clock controller card in the active CPU side. This provides system clocking through this cable.

**Note:** The old and new clocks are cabled together. This is acceptable because the old clock was faceplate disabled in the previous step.

- 11    Verify that the clock controller is active. At the prompt, enter:

**LD 60**

**SSCK**

Get status of the new system clock, where x = 0 or 1.

**TRCK PCK**

Track primary clock, where x = 0 or 1.

**RCNT**

Resets all alarm counters of all digital cards.

**\*\*\*\***

Exit the overlay.

**Note:** Replacing the clock controller generates errors on the network equipment. It is recommended that all counters be reset.



**IMPORTANT!**

Perform the following steps in rapid succession to minimize potential slips on the PRI.

- 12    To replace the remaining QPC775 or QPC471 clock controller card, tag and disconnect the cables to the card being removed.
- 13    Unhook the locking devices on the card.
- 14    Pull the card out of the card cage.
- 15    Set the ENB/DIS switch to DIS on the replacement card.
- 16    Set the option switches on the replacement card (NTRB53). Refer to Table 8, "Clock Controller switch settings for NTRB53", on page 102 in the What's New for Meridian 1 (Release 25.40).
- 17    Insert the replacement card into the selected slot and hook the locking devices.
- 18    Connect the reference cables (J1 and J2) and the clock-to-clock cable (J3) to the replacement card.
- 19    Set the ENB/DIS switch to ENB on the replacement card.
- 20    Software disable and enable the card. At the prompt, enter:

**LD 60**

**DIS CC x**

Disable clock controller card, where x=0 or 1

**ENL CC x**

Enable clock controller card, where x=0 or 1

**Note:** If necessary, the clock card can download F/W.

- 21** Verify that the card is enabled. At the prompt, enter:

<b>SSCK x</b>	Get status of system clock, where x=0 or 1
<b>****</b>	Exit the overlay

**Note:** Wait two minutes before proceeding to next step.

- 22** Activate the new card and verify that it is active. At the prompt enter:

<b>LD60</b>	
<b>SWCK</b>	Switch system clock from active to standby
<b>SSCK x</b>	Get status of system clock, where x = 0 or 1
<b>TRCK PCK</b>	Track primary clock, where x = 0 or 1
<b>RCNT</b>	Reset alarm counters of all digital cards
<b>****</b>	Exit overlay

- 23** Set the clock source to the status it was in before the replacement procedure.

**Note:** Wait one minute between clock switch.

- 24** Verify clock switch-over and tracking. At the prompt, enter:

<b>SWCK</b>	Switch system clock from active to standby
<b>SSCK x</b>	Get status of system clock, where x = 0 or 1
<b>****</b>	Exit overlay

---

**End of Procedure**

---

## Upgrades on the web

The Multi Media Disk Unit (MMDU) upgrade on the Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII will be made available online.

To access this documentation online, click the **Technical Documentation** link under **Support** on the Nortel home page:

<http://www.nortel.com/>





---

# Using the Distributor Keycode Application

---

## Contents

This section contains information on the following topics:

<a href="#">Introduction . . . . .</a>	<a href="#">871</a>
<a href="#">Hardware and Software Requirements . . . . .</a>	<a href="#">872</a>
<a href="#">Installing DKA . . . . .</a>	<a href="#">872</a>
<a href="#">Adding the KDS network client in Dial-up Networking . . . . .</a>	<a href="#">878</a>
<a href="#">Downloading from KDS . . . . .</a>	<a href="#">882</a>
<a href="#">Reading from a File . . . . .</a>	<a href="#">890</a>
<a href="#">Manually entering a keycode . . . . .</a>	<a href="#">891</a>

## Introduction

The Distributor Keycode Application (DKA) is a Windows-based utility program which enables distributors to download keycodes from a remote server (known as Keycode Delivery Server (KDS)). DKA makes use of a standard Wizard Windows interface to guide the user’s operation.

***Note:*** Electronic retrieval of keycodes via DKA is not supported in European markets. If downloading keycodes from Europe, please refer to “Using the Keycode Retrieval Utility” on [page 47](#).

This section contains the following procedures:

- “Install DKA” on [page 1106](#)

- “Adding the KDS network client in Dial-up Networking” on [page 1112](#)
- “Downloading from KDS” on [page 1116](#)
- “Reading from a File” on [page 1123](#)
- “Manually enter a keycode” on [page 1124](#)

**Note:** The “Installing DKA” and “Adding the KDS connection in Dial-Up Networking” procedures must be completed before the “Downloading from KDS” procedure can be performed.

## Hardware and Software Requirements

To install and use the DKA program, certain requirements must be met:

- A PC or compatible computer with a Pentium or compatible Intel processor running the Windows 95 or Windows 95B operating system.
- A modem that supports 14.4kbps or less must be installed and configured on the PC. To ensure that a modem is configured correctly under Windows 95, configure a modem through the Control Panel (using 8 data bits, Parity None, Stop Bits 1). Additionally, the modem must be configured with the correct Dial Prefix (Access Code) used by the telephone system to access an outside line. This modem must access a standard analog telephone line.
- Approximately 5 MByte free hard drive space for installation of the DKA program and, if desired, storage of keycodes.
- Microsoft Dial-up Networking software must be installed on the PC (provided with Windows 95)
- The following procedures must be performed before downloading keycodes: “Installing DKA.” and “Adding the KDS connection in Dial-Up Networking .”

## Install DKA

Once it is determined that the PC and modem meet the system requirements listed above, the DKA program can be installed on the PC. Once the program is installed, make a Shortcut to the program to appear on the Windows desktop. Double-clicking this Shortcut provides easy access to the program.

**Procedure 375**  
**Installing the DKA program**


- 1 Locate the DKA Installation diskette.
- 2 Insert the diskette, label facing upwards, into the floppy drive on the PC.
- 3 Run the Windows Explorer application by clicking **Start | Program Files | Windows Explorer**.
- 4 In the **Windows Explorer** application, click the 3.5" Floppy drive (A:) from the left side of the window.
- 5 In the right side of the window, double-click the **Setup.exe** file (which has a computer icon to the left of it).

Wait for the **Setup** program to prepare for installation.

The Identification Screen is displayed.

- 6 Enter the requested information in the **Name** and **Company** fields. See Figure 112 below.


**Figure 112**  
**Identification screen**



- 7    Click **N**ext or press return.

The Software License screen is displayed. This screen contains a scrollable text box that contains the legal agreement governing the use of the DKA software. See Figure 113 below.


**Figure 113**  
**License agreement screen**



- 8    If accepting the terms of the license agreement, click the **N**ext button. If not accepting the terms, click **C**ancel and the program installation is stopped.


The Destination Directory screen appears. This screen indicates that the DKA program will be installed on the hard drive in a folder called DKA. See Figure 114 on [page 1109](#).

**Figure 114**  
**Destination directory**




- 9 Click **Next** or press return.
- 10 The Read Note screen appears. This screen is used to read any Read me files for the DKA program. See Figure 115 on [page 1110](#).

**Figure 115**  
**Read note screen.**



- 11 Read the contents of the Read Me files: Select the desired file, then click **Open**.
- 12 Click **N**ext or press return.  
The Install Completed screen appears. This screen indicates that the Distributor Keycode Application has been successfully installed on the PC. See Figure 116 on [page 1111](#).

**Figure 116**  
**Install Completed screen**



- 13** Click the **Finish** button to close the setup program.

---

**End of Procedure**

---

## **Create a Shortcut**

### **Procedure 376** **Creating a shortcut**

- 1** Select the **dka.exe** file located in the DKA folder on the (C:) drive.
- 2** Click on the **File** menu and drag down to **Create Shortcut**.  
A file called **Shortcut to dka.exe** appears in the DKA folder.
- 3** Click and drag the **Shortcut to dka.exe** file to a convenient location on the desktop and release.

---

**End of Procedure**

---

Now the Distributor Keycode Application can be accessed easily by double-clicking on the **Shortcut to dka.exe** file on the desktop.

## Adding the KDS network client in Dial-up Networking


Before keycodes can be downloaded, it is necessary to configure the Dial-up Networking KDS client. Dial-up Networking stores and manages all communication parameters (such as phone number, dial prefixes, user name, password) necessary for connecting to the Keycode Download Server.

### **Procedure 377** **Configuring Dial-up Networking**

- 1 Click the **Start** button on the lower left corner of the PC desktop and drag to **Programs\Accessories\Dial-up Networking**.
- 2 Double-click the **Make a New Connection** icon in the Dial-Up Networking window and enter the following:  
Type a name for the computer you are dialing:  
**Richardson KCD Server 1** (example)



- 3 Select a modem:  
The modem must support 14.4 kbps or less with the following configuration:  
**Data Bits 8, Parity None, Stop Bits 1**



- 4 Click **Next**. The telephone number entry screen appears. See Figure 117 on [page 1114](#). Enter the following for regions where the 888 Area Code is available:

Enter the Area Code as follows: 888


Telephone Number: 685-3923

Country code: United States of America

**Note 1:** The information entered in the Make New Connection window must match this information. If using DKA in a market other than the United States of America, ensure that the Area Code, Telephone Number, Dial Prefix, and Country code are configured correctly.

**Note 2:** In regions where the 888 Area Code is not applicable, the number which must be substituted is: **(972) 685-1764**. This number must be configured in Dial-Up Networking.

**Figure 117**  
**Make New Connection screen – telephone numbers.**



Make New Connection

Type the phone number for the computer you want to call:

Area code: 888 - Telephone number: 6853923

Country code: United States of America (1)

< Back Next > Cancel

- 5 Click **Next**.

A message is received that states a new Dial-Up Networking connection has been successfully completed.

- 6 Click **F**inish or press return to complete the procedure.

---

**End of Procedure**


---

## Configure the Type of Dial-Up Server

### Procedure 378

#### Configuring the Type of Dial-Up Server

- 1 Click the **Start** button on the lower left corner of the PC desktop and drag to **Programs\Accessories\Dial-up Networking**.
- 2 Click on **Richardson KCD Server 1**.




- 3 Select the **File** menu and choose **Properties**.
- 4 Click **Server Type...** to continue.
- 5 Configure the **Server Type** window with the following information:
  - Type of Dial-Up Server: PPP Windows 95 Windows NT 3.5 Internet
  - Advanced's: Enable software compression
  - Advanced network protocols: TCP/IP
  - TCP/IP Settings.....: *use the default settings*
- 6 Click **OK** or press return.
- 7 Click **OK** again to return to the Dial-Up Networking window.

---

**End of Procedure**

---



## Downloading from KDS

The following procedure is used to request and receive keycodes from a remote server, known as KDS (Keycode Delivery Server). This procedure assumes that you have already installed the DKA program as described in “Install DKA” on [page 1106](#), and have added and configured the Dial-up Networking client as described in “Adding the KDS network client in Dial-up Networking” on [page 1112](#).

**Procedure 379****Establishing the PPP connection to the KDS server via  
Dial-up Networking**

- 1 Double click on the Richardson KCD Server 1 Dial-Up Networking client. Enter user name "nortel-keycode" and password "97enable." Click the Connect button and verify that the modem dials a call and the Dial-Up Networking client successfully connects to the Richardson KCD Server 1.

Once the Dial-up Networking PPP connection has been established, continue with the download by starting the DKA application:


- 2 Double-click on the **Shortcut to DKA** icon on the PC desktop.

A gray screen appears that includes four menus and a Toolbar with buttons for essential commands.




- 3    Click on the **Tools** menu and select **Download Keycodes**.

The KDS Welcome screen appears.



- 4    Click Next or return to download a keycode from KDS.

The Build a Request List screen is displayed. This screen has four information fields which must be completed for each keycode request that is submitted.



- 5 Enter the information into the four fields as described in Table 182 below.

**Table 182**  
**“Build a Request List” fields**

Name of field	How the information is entered in the field
Product Name	Select the product family of the system for which you are requesting a keycode.
System ID	Enter the System ID for the system for which you are requesting a keycode.
NTI Number	Click in the field and type in the NTI Number for the system for which you are requesting a keycode (the NTI Number is the same as the NT order number).
File Name	<p>Enter a file name for the keycode you will be downloading.</p> <p>If the keycode will be downloaded to the hard drive ((C:) drive), use the following file naming convention: c:\DKA\&lt;System ID&gt;\NTI Number&gt;. When you click <u>A</u>dd, a.kcd file extension is added to the file name.</p> <p>If the keycode will be downloaded to a floppy diskette in the 3.5" Floppy drive (A:), the file name must be named “keycode” so the Meridian 1 can recognize the file. When you click <u>A</u>dd, a.kcd file extension is added to the file name.</p>

- 6 Click **Add** to continue. The request will appear in the Request List scroll box.

When a request is added to the list, another request may be added by filling out the fields with information for another keycode, and again clicking the Add button.

To remove a request from the list, select the request in the Request List scroll box and click the Delete button.

- 7 Click the **Next** or press return.

The KDS Billing Notice screen is displayed

- 8    Enter the information in Table 183 below into the KDS Billing Notice screen.

**Table 183**  
**Fields on the KDS Billing Notice screen**


Name of field	How the information is entered in the field
Distributor Name	Enter the name of the Distributor who is requesting the keycode(s).
User Name	Enter the name of the person requesting the keycode(s).
Telephone Number	Enter the telephone number that can be used to contact the individual who is requesting the keycode(s). For example: (408) 555-1212.

- 9    Click the **Next** button or press return.

- 10   Click **Next** or press return.

The KDS Download screen is displayed.


**Note:** The Dial-up Networking connection must have been established, as described in “Establishing the PPP connection to the KDS server via Dial-up Networking” on [page 1117](#).






- 11 Click **Start** to begin downloading the keycode(s).


**Note:** This starts the keycode download process. A socket connection is established over the existing PPP connection. Next, the provided login information is sent to the Keycode Delivery Server and verified. Then the requested keycodes are downloaded to your PC in the location you specified in the Build a Request List window. Status is displayed in the Download Status box.



- 12 Click **Next** to receive the “KDS Download Results” screen, summarizing the results of the download.



- 13 Double-click the network icon in the lower right corner of the screen.



- 14 The Dial-up Networking status window appears. Click the **Disconnect** button to end the connection to the network.

The “Download from KDS” procedure is complete. Refer to “Keycode Management, LD 143” in this document for keycode installation instructions.

If there was a problem downloading keycodes, the problem keycodes are listed in the “Unsuccessfully downloaded keycodes” scroll box.

**Note:** If the download was unsuccessful, verify that the correct telephone number and Dial Prefix are configured in Dial-up Networking.

When the requested keycode is downloaded from the Keycode Delivery System to your PC, refer to “Adding features and License limits” in Book 1 for keycode installation procedures.

---

**End of Procedure**

---

## Reading from a File

### **Procedure 380** **Reading from a File**

The following procedure is used to learn information about the properties of an existing keycode, or a keycode that was just downloaded from KDS. In this procedure you will specify a keycode file in a location on your hard drive or on a floppy diskette that is inserted in your floppy disk drive.

You will also specify a “Product type” to examine within the keycode file, in case there are multiple keycodes within the keycode file being examined.


This procedure assumes that you have already installed the DKA program as described in “Install DKA” on [page 1106](#).

- 1 Double-click on the **Shortcut to DKA** icon on the PC desktop.
- 2 Select **Open** from the **File** menu.

A navigation dialog box appears. In the navigation dialog box, locate the keycode. For a keycode residing on a floppy drive, this is the 3.5" Floppy drive (A:); for a keycode residing on the hard drive, this is most likely the C: drive.

- 3 Click **OK**.

The Keycode file is displayed in a format similar to the hardcopy Keycode Acknowledgment sent to a customer. The Keycode itself is displayed at the bottom of the file, in 21 rows of 16 characters each.



The "Reading from a KCD" procedure is complete.

End of Procedure

## Manually enter a keycode

### Procedure 381 Manually entering a keycode

The following procedure is used to manually enter a keycode for the purpose of creating and storing a keycode file.

This procedure assumes that you have already installed the DKA program as described in “Install DKA” on [page 1106](#).

- 1 Double-click on the **Shortcut to DKA** icon on the PC desktop.
- 2 Select **Manual Entry** from the **Tools** menu.

The Keycode Entry screen is displayed. This screen consists of rows and four columns (A-D) into which the keycode is entered four characters at a time. When 16 characters (four cells) are entered in a row, the program tries to validate that row. If the row does not validate, a red X appears to the left of that row to indicate invalidity.

	A	B	C	D
15	M000	000H	THS8	000E
16	8000	0000	0000	006T
17	0000	0000	0000	0000
18	0000	0000	02H0	007P
19	3w00	2C03	w006	803N
20	0006	0020	0080	004C
21	0000	0000	0000	0000
22				

The Clear All... button is used to erase all characters in the cells that have been entered on the Keycode Entry screen. A dialog box will prompt “Are you sure you want to clear the Keycode characters?” when this button is selected. Confirming the dialog erases all characters in all cells.

- 3    When the entire keycode has been entered, click the **Save...** button.

If the keycode is valid, the Save As screen is displayed. This screen allows you to specify the file name your keycode will be saved as and the directory where it will be saved.



- 4    From the **Save in** pull-down menu, select the drive location where you want to save the keycode.
- 5    In the **File Name** field, type the name you want your keycode file to be saved as. Note that the .kcd extension will be appended to that filename.

To save the keycode file nested within folders, double-click on the folder in which the keycode file will ultimately be saved. When you have navigated to the folder where you would like to save the keycode file, click the **Save** button.

- 6    Click **Save** or press return.

The keycode file has been saved as specified.

---

**End of Procedure**

---

---

# Terminal and modem connections

---

## Contents

This section contains information on the following topics:

[Introduction](#) ..... 1127

[Existing modems on upgraded systems](#) ..... 1142

[Available modem for an upgraded system](#) ..... 1142


## Introduction

During the system upgrade, a terminal must be connected to a serial data interface (SDI) port to provide an I/O interface to the system. When the upgrade is complete, a terminal (for local access) or a modem (for remote access) must remain permanently connected to an SDI port to provide a constant I/O interface to the system (see Figure 118 on [page 1128](#)).

When upgrading a dual CPU system, you may want to temporarily install additional terminals for split mode monitoring, or programming, or both.

**Note:** In Meridian 1 Option 61 and Meridian 1 Option 71, SDI cards can be temporarily installed in CPU slots during a software conversion. In Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII, I/O ports on the call processing (Call Processor) cards, can be used to monitor CPU operations. On the Meridian 1 Option 81C CP PII, COM 1 port on the call processing (CP PII) cards, can be used to monitor CPU operations. These configurations should not be used as the permanent I/O connection for the system because the port is only active when the associated CPU, or CPU, is active.

**Figure 118**  
**Terminal connection diagram**



For a modem connection to the Meridian 1, Bell 103/212 compatible dumb modems are recommended for all systems, except Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII.



**CAUTION — Service Interruption**

**Service Interruption**

If a Hayes command-set compatible (smart) modem is used at the Meridian 1 end, you *must* select the dumb mode of operation, Command Recognition OFF and Command Echo OFF, before connecting the modem to the SDI port. Refer to the modem instructions to set the mode of operation.



If a printer is connected to an SDI port (locally or remotely), you must disable XON/XOFF flow control, so no characters or signals are sent to the port, to avoid a “ping-pong” effect.

**Note:** For information specific to Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII, see “Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII terminal and modem connections” on [page 1135](#).

## Configure the system

### Procedure 382

#### Configuring the system

- 1 Install and cable a system terminal or a modem:
  - a. Unpack the terminal/modem and place it in its assigned location.
  - b. Install the terminal/modem according to the manufacturer's instructions.
  - c. Connect an NT8D95AJ cable to a matching connector on the terminal/modem.


**Note:** At a remote location, install and connect a compatible modem and terminal. Connect the NT8D95AJ cable to the modem.
- 2 Install and cable the SDI card:
  - a. Set the Enb/Dis switch to Dis (down).
  - b. See *Circuit Card: Description and Installation* (553-3001-211) to set the option switches for each port.
  - c. See Figure 119 for switch locations on an NT8D41 SDI Paddle Board. (The paddle board cannot be used in Meridian 1 Option 71 and Meridian 1 Option 81C CP PII.)
  - d. See Figure 120 for switch locations on an NTND02 MSPS Card. (The MSPS card is used in Option 21E only.)
  - e. Insert the SDI card into its assigned slot.
  - f. Cable the SDI card:
    - g. See Figure 121 to cable the NT8D41 SDI Paddle Board. (There is no faceplate on the paddle board; Figure 121 identifies the ports.)
    - h. See Figure 121 on [page 1133](#) to cable an NTND02 MSPS Card.

- i. See Figure 122 to cable a QPC841 Four-Port SDI Card.
  - j. Set the Enb/Dis switch to Enb (up).
- 3 Software enable the SDI card:
  - a. Define each SDI port in the Configuration Record (LD 17).
  - b. Enable each SDI port using the appropriate software program for the port application. Typical SDI applications and associated programs include:

Terminal and printer ports	LD 37
Call Detail Recording (CDR) ports	LD 42
Automatic Call Distribution (ACD) ports	LD 48


- 4 Connect an NT8D95AJ cable from the terminal, or modem, to the assigned SDI port.

**Figure 119**  
**Ports and switches on the NT8D41 SDI Paddle Board**




**End of Procedure**


**Figure 120**  
**Switch locations on the NTND02 MSPS Card**



**Figure 121**  
**Cabling diagram for the NT8D41 SDI Paddle Board**



**Figure 122**  
**Cabling diagram for the QPC841 Four-Port SDI Card**



## **Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII terminal and modem connections**

During the system upgrade and for continuing system operation, a terminal must be connected to an SDI port in a network slot to provide an I/O interface to the active CPU in the system.

In addition, a data terminal equipment (DTE) port and a data communication equipment (DCE) port on each NT4N64AA Call Processor Card can be used for direct access to the Core or Core/Network Module that houses the card.

The designations DTE and DCE refer to the function of the port, not the type of device that connects to the port. Therefore, a modem (which is DCE) connects to the DTE port at J21, and a terminal (which is DTE) connects to the DCE port at J25. Typically, the CPSI ports are preconfigured on I/O addresses four and five.

The data terminal equipment (DTE) port, COM 1 and a data communication equipment (DCE) port, COM 2 on each NT4N64 CP PII can be used for direct access to the Core or Core/Network Module that houses the card.

The Call Processor card ports (CPSI/COM1 COM2 ports) are active only when the CPU associated with the Call Processor card is active. Therefore, the CPSI/COM1 COM2 ports should not be used as the only I/O connection for the system.

When the upgrade is complete, you must leave a terminal or a modem connected to the system. One SDI port in a network slot must be permanently connected to a terminal or modem.

On the CPSI ports you can:

- disconnect the ports
- leave terminals connected for local monitoring
- connect modems for remote monitoring

The Black Box ABCDE-Switch, which provides up to four-to-one switching, is available from Nortel as part number A0377992. The switch box can be used to connect the SDI and CPSI/COM1 COM2 ports to a terminal or a

modem. If used, one switch box must be used for terminals and one for modems.

### **Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII terminal guidelines**

During an upgrade, you can connect terminals to the CPSI/COM1 ports for split mode monitoring, or programming, or both. (Due to the speed of the system messages displayed, personal computers are useful for file capture and review.) Terminals connected to the CPSI/COM1 ports can be installed as follows:

- One terminal connects to a CPSI/COM1 port in one CPU (the cable is switched from module to module as needed); one terminal is required in addition to the terminal for the SDI port connection (see Figure 123 on [page 1137](#)).
- One terminal connects to a switch box that connects to a CPSI/COM1 port in each CPU: one terminal and a switch box are required in addition to the terminal for the SDI port connection (see Figure 124 on [page 1139](#)).
- One terminal connects to a switch box that connects to an SDI port and to a CPSI/COM1 port in each CPU: one terminal and a switch box are required (see Figure 125 on [page 1140](#)).

The Meridian 1 Option 51C has only one CPU module and requires only one CPSI terminal connection and one SDI port connection. A single terminal with a switch box can be used.

### ***Connect a terminal to a CPSI port***

#### **Procedure 383**

#### **Connecting a terminal to a CPSI port**


Use the following procedure to connect a CPSI/COM1 port directly (no switch box) to a terminal (see Figure 123):

- 1 Set the terminal to 9600 baud, 7 data, space parity, one stop bit, full duplex, XON.
- 2 Connect an NT8D95 cable to a matching connector on the terminal.



- 3 Connect the NT8D95 cable to J25 on the I/O panel in the rear of the Core or Core/Network Module.
- 4 If you are using only one terminal for both CPSI/COM1 ports, switch the cable as needed. The terminal connected to the SDI port will always communicate with whichever CPU is active.

**Figure 123**  
**One terminal for the CPSI ports**



**End of Procedure**

### ***Connect a switch box and terminal to CPSI ports***

#### **Procedure 384**

#### **Connecting a switch box and terminal to CPSI ports**

Use the following procedure to connect CPSI/COM 1 ports to a switch box and a terminal (see Figure 124):

- 1 Set the terminal to 9600 baud, 7 data, space parity, one stop bit, full duplex, XON.
- 2 Connect an NT8D95 cable to the terminal and to the switch box.
- 3 Connect NT8D95 cables to a matching connector on the switch box.

- 4 If you are using an A0377992 ABCDE box, connect cables as follows:
- 5 Connect CPU 0 to connector A.
- 6 Connect CPU 1 to connector B.
- 7 Connect the NT8D95 cables from the switch box to J25 on the I/O panel in the rear of the Core/Network Modules.
- 8 To communicate directly with a CPSI/COM 1 port, switch the cable as needed. The terminal connected to the SDI port will always communicate with whichever CPU is active.

---

**End of Procedure**

---

***Connect a switch box and terminal to the SDI and CPSI ports***


**Procedure 385**

**Connecting a switch box and terminal to the SDI and CPSI ports**

Use the following procedure to connect CPSI/COM 1 ports to a switch box and a terminal (see Figure 124 and Figure 125):

- 1 Set the terminal to 9600 baud, 7 data, space parity, one stop bit, full duplex, XON.
- 2 Connect an NT8D95 cable to the terminal and to the switch box.
- 3 Connect NT8D95 cables to a matching connector on the switch box.
- 4 If you are using an A0377992 ABCDE box, connect cables as follows:
  - a. Connect CPU 0 to connector A.
  - b. Connect CPU 1 to connector B.
  - c. Connect the SDI port to connector D (connector C is common).
- 5 Connect NT8D95 cables from the switch box to J25 on the I/O panel in the rear of each Core or Core/Network Module.
- 6 Connect an NT8D95 cable from the switch box to the I/O panel slot for the SDI card.


**Figure 124**  
**One terminal and a switch box to two CPSI ports**



- 7** To communicate with the system in general, set the switch box to the SDI port. To communicate directly with a CPSI/COM 1 port, switch the cable as needed.

**End of Procedure**

**Figure 125**  
**One terminal and a switch box to the SDI and CPSI ports**



### **Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII modem guidelines**

You can connect a modem to an SDI port to remotely monitor general system operation. Or you can connect a modem to the CPSI/COM2 ports for debugging and patch downloading (through your Nortel representative). Or you may want a remote connection to both the SDI and CPSI ports.

At the Meridian 1 end (the local end), modems must be set to dumb mode (command recognition OFF, command echo OFF). Modems at the local end can be connected as follows:

- One modem connects to the SDI port and the cable is switched to each CPSI/COM2 port as needed (see Figure 126 on [page 1150](#)).
- One modem connects to a switch box that connects to the SDI and CPSI/COM2 ports (see Figure 127 on [page 1153](#)).

**Note:** The second method listed here is preferred. Other configurations, such as a separate modem for each port, are possible.

At the remote end, at least one modem (which can be set to smart mode), one terminal, and one RS-232 cable are required in all modem configurations.

Modems at the local end must meet the following required specifications to be compatible with Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII. Modems that meet the following recommended specifications must also meet the required specifications.

- required: true, not buffered, 9600 baud support (required for remote Nortel technical support)
- required: CCITT V.32 or V.32bis compliance
- recommended: the ability to adjust to lower and higher speeds, depending on line quality, while maintaining 9600 baud at local DTE
- recommended: V.42 error correction
- recommended: V.42 bis data compression

A dispatch or call back modem, normally connected to the SDI port, can be used if it meets the requirements. If you want to use a modem of this type that does not meet the requirements, the modem can only be used in addition to a modem that does meet specifications.

## Existing modems on upgraded systems

Any modem that meets the required specifications should be compatible with Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII.

The following modems listed below, are no longer available. However, if your system uses these modems now, they will work with the upgraded system:

- Hayes V-series ULTRA Smartmodem 9600
- UDS FastTalk V.32/42b
- US Robotics Courier HST Dual Standard V.32bis
- Motorola 28.8 Data/Fax

## Available modem for an upgraded system

The US Robotics, Sportster External 33.5 Data/Fax modem model is tested and verified as compatible. The US Robotics, Sportster External 33.5 Data/Fax modem is available through Nortel as part number A0663901.

### Configure the US Robotics 33.5 Data/Fax modem

#### **Procedure 386**

#### **Configuring the US Robotics 33.5 Data/Fax modem**

Use the following procedure to configure a US Robotics, Sportster External 33.5 Data/Fax modem for operation with Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII. This procedure must be done before you connect the modem to the Meridian 1 system. You need a terminal such as a PC computer, to configure the modem.

- 1 Turn the modem off.
- 2 Set the modem DIP switches as follows:
  - DIP switches 1, 3, 7, and 8 to ON (down).
  - DIP switches 2, 4, 5, and 6 to OFF (up).
- 3 Connect an RS-232 cable to the modem and to a terminal.

- 4 Set the terminal with the following values:
  - 9600 baud
  - 8 bits
  - 1 stop bit
  - no parity
- 5 Turn the modem on and enter each command listed below with a carriage return (press Enter or Return key):
  - AT&FLoad active profile
  - AT&H0Flow control disabled
  - AT&D3Resets on receipt of DTR
  - AT&S1Modem controls DSR
  - ATS0=1Answer after 1 ring
  - ATS2=128Escape character = ASCII 128
  - ATS7=60Pause 1s for carrier detection
  - ATQ1Quiet mode
  - AT&WStore active profile

The modem responds **OK** to every command (except for the last two commands ATQ1 and AT&W).

- 6 Disconnect the power cord and serial from the modem.
- 7 Set DIP switches 1 and 4 to ON (down) and the remaining switches OFF (up).

---

**End of Procedure**

---

## **Configuring an A0638930 Motorola 28.8 Data/Fax Modem**

Use the following procedure to configure a Motorola 28.8 Data/Fax Model 3400 modem for operation with Meridian 1 Option 61C CP PII and Meridian 1 Option 81C CP PII.

The modem can be configured:

- for local mode of operation
- for remote mode of operation

**Note:** After the modem is configured, power down of the modem will not result in loss of the configuration settings. However, by pushing the RESET button on the modem and holding it down until the “MR” light flashes 5 only, and by releasing the RESET button before the next 5 flashes start, will reset the modem to its factory default settings. It will then be necessary to reconfigure the modem to the settings required for operation with Meridian 1 systems.

### **Procedure 387**

#### **Installing the modem**

- 1    Unpack the modem and read the installation instructions included with the modem.
- 2    Position the modem in its designated space, install its power cord, and plug it into the power receptacle.
- 3    Connect a 25-pin RS-232 cable to the modem and to a terminal.

#### **i.    For Local configuration**

- a.   Set the terminal with these parameters:
  - 9600 baud
  - 8 data bits
  - 1 stop bit
  - no parity
- b.   Install the communication utility program shipped with the modem or use an appropriate alternate communication utility program such as Procomm, Telix, SmartCom, Bitcom, or CrossTalk.
- c.   Enter the following command string in one line, followed by the carriage return <cr>:

AT&F \Q0 &S1 S0=1 S7=60 S2=128 Q1 E0 &W &W1 <cr>



- d. After you press the carriage return <cr>, the modem will appear to have stopped functioning. This is normal.
- e. Power off the modem and connect it to a Call Processor CPSI or CP PII COM2 port in the Meridian 1 system. To do this:
  - Set the power switch to OFF.
  - Connect the NT8D95 cable between the modem and the J25 on the I/O panel at the rear of the Core/Network module.
  - Connect the modem to the telephone jack (RJ11) using the RJ11 telephone cord. If the cord is not supplied, use the NT8D46 cable.
  - Turn the power switch on the modem to ON.

The modem is now configured for local communication with the Meridian 1 system.

## **ii. For Remote configuration**

To configure a modem in the remote mode, connect the modem as described above in “Local configuration procedure” and proceed as follows:

- a. To place the modem in the remote configuration mode:
- b. Press and hold the RESET button until the “MR” light flashes 10 times. There is a 3 second pause before each set of five flashes are received. The “AA” light comes on at the beginning of the last five flashes and remains on.
- c. Do not release the RESET button until you receive all 10 flashes, the “MR”, and the “AA” lights are on. The modem is now placed in the remote mode.
- d. Dial up the modem at 9600 bps.
- e. Dialing up the modem at a baud rate other than 9600 bps will result in configuration errors.
- f. Enter five equal signs (= = = =) after you received the connection message.
- g. Press carriage return <cr> after the PASSWORD prompt appears.

- h. RC ESTABLISHED prompt will appear. Now you can enter the following commands, each followed by the carriage return <cr>:

ATQ0	<cr>	Disable Computer Flow Control
AT&S1	<cr>	DSR on when ready to accept data
ATS0=1	<cr>	Answer on the first ring
ATS7=60	<cr>	How long to wait for carrier
ATS2=128	<cr>	Escape sequence character
AT*NT	<cr>	Turn AT command set OFF (very important)
ATQ1	<cr>	Response display OFF
AT&W	<cr>	Write to first profile
AT&W1	<cr>	Write to second profile
AT*RQ	<cr>	End remote configuration and save changes



The modem is now configured for remote communication with the Meridian 1 system.

---

**End of Procedure**

---

## Configure an A0381391 UDS FastTalk modem

Use the following procedure to configure a UDS FastTalk modem for operation with Meridian 1 Option 61C CP PII and Meridian 1 Option 81/81C CP PII.

**Procedure 388****Configuring an A0381391 UDS FastTalk modem**

**Note:** With the exception of the smart/dumb mode jumper setting, configuration changes to the modem are made through software. The modem must remain in smart mode (as shipped) until the software configuration is complete.

- ATE                      turn off local character echo
- ATSO=2                enable autoanswer on second ring
- ATDT                   set for tone dialing (default is pulse dialing)
- AT&W                  store changes in profile 0
- AT&Y                  use profile 0 at power up

- 1 Disconnect the power cord, RS-232 cable, and any other cables from the modem.
- 2 Remove the top cover on the modem.
- 3 Stand the unit on its side.
- 4 Using a medium-size flat screwdriver, lightly pry the four lock tabs off the locks (located on the bottom of the case) and pull the cover away from the modem as the locks release.
- 5 Set the modem to smart mode.
- 6 Locate the option jumper. The jumper is located just to the left of the speaker (when viewed from the front of the modem).
- 7 Place the jumper on the two pins farthest from the speaker.
- 8 Connect a 25-pin RS-232 cable to the modem and to a terminal.
- 9 Set the terminal with these parameters:
  - 9600 baud (no other speeds will work)
  - 8 data bits
  - 1 stop bit
  - no parity

**Note:** The modem will communicate at 9600 bps *only*; the terminal or computer must be set to 9600 bps also.

- 10** Enter the following commands to set compatible parameters. Follow each command with a carriage return (press the “Return” or “Enter” key):

AT&F	load active profile containing factory settings
ATN0	select normal mode, error control disabled
ATQ0	set serial port flow control
ATV3	form-of-response message = DTE
AT&D2	modem disconnects when DTR signal is lost
AT&S1	select DSR control
ATS0=1	answer after 1 ring
ATS2=128	escape character = ascii 128
ATS7=60	pause 1 second for carrier detection
ATQ1	

- 11** After you enter this last command (ATQ1), the modem no longer responds with “OK”. Enter the next command:

AT&W	store active profile
------	----------------------

- 12** The modem should respond to every command (except the last two commands) with “OK”. If you do not get this response, turn the modem off and on and try again.
- 13** Disconnect the power cord and serial cable.
- 14** Set the modem to dumb mode:
- 15** Locate the option jumper. The jumper is located just to the left of the speaker (when viewed from the front of the modem).
- 16** Place the jumper on the two pins closest to the speaker.
- 17** Replace the cover on the modem.
- 18** Align the tabs, locks, and rear guide grooves.
- 19** Press the cover into place until the locks and the tabs snap together.

- 20 Reconnect the power cord and any other cables that will be used.

---

**End of Procedure**

---

## Connect a modem to an SDI port

Use the following procedure to connect an SDI port directly (no switch box) to a modem (see Figure 126 on [page 1150](#)):


### **Procedure 389**

#### **Connecting a modem to an SDI port**

- 1 At the remote end, connect an RS-232 cable to the terminal and to the modem.
- 2 At the remote end, connect the cable from the modem to an RJ11 telephone jack. (If a cable is required, connect an NT8D46 cable to the modem and to the RJ11 jack.)
- 3 At the local end, configure the modem:
  - a. If you are using a Motorola 28.8 Data/Fax modem, follow the instructions in this document. (See “Configuring an A0638930 Motorola 28.8 Data/Fax Modem” on [page 1143](#).)
  - b. If you are using an UDS FastTalk modem, follow the instructions in this document. (See “Configure an A0381391 UDS FastTalk modem” on [page 1146](#).)
  - c. If you are using a different type of modem, follow the manufacturer’s instructions to set the modem for 9600 baud, auto answer, dumb mode, command recognition OFF, command echo OFF.
- 4 At the local end, connect an NT8D95 cable to the SDI port on the I/O panel in the rear of the module and to the modem.
- 5 At the local end, connect the cable from the modem to an RJ11 telephone jack. (If a cable is required, connect an NT8D46 cable to the modem and to the RJ11 jack.)
- 6 To communicate with a CPSI/COM2 port, switch the cable from the modem to the port as needed:

- a. For debugging or monitoring, connect the cable to the *active* CPU at J21 on the I/O panel in the rear of the Core/Network Module.
- b. For patch downloading, connect the cable to the *inactive* CPU at J21 on the I/O panel in the rear of the Core or Core/Network Module.

**Figure 126**  
**Modem to SDI port**



————— End of Procedure —————

---

## Connecting a modem to a switch box and CPSI and SDI ports

### Procedure 390

#### Connecting a modem to a switch box and CPSI and SDI ports

Use the following procedure to connect SDI and CPSI ports to a switch box and a modem (see Figure 127 on [page 1153](#) and Figure 128 on [page 1154](#)):

- 1** At the remote end, connect an RS-232 cable to the terminal and to the modem.
- 2** At the remote end, connect the cable from the modem to an RJ11 telephone jack. (If a cable is required, connect an NT8D46 cable to the modem and to the RJ11 jack.)
- 3** At the local end, configure the modem:
  - a.** If you are using a Motorola 28.8 Data/Fax modem, follow the instructions in this document. (See “Configuring an A0638930 Motorola 28.8 Data/Fax Modem” on [page 1143](#).)
  - b.** If you are using an UDS FastTalk modem, follow the instructions in this document. (See “Configure an A0381391 UDS FastTalk modem” on [page 1146](#).)
  - c.** If you are using a different modem, follow the manufacturer’s instructions to set the modem for 9600 baud, autoanswer, dumb mode, command recognition OFF, command echo OFF.
- 4** At the local end, connect NT8D95 cables to
  - a.** J21 on the I/O panel in the rear of the Core or Core/Network Modules
  - b.** the SDI port on the I/O panel in the rear of the Network module
- 5** At the local end, connect NT8D84 cables to the SDI Paddle Board at the Core/Network backplane to the I/O panel in the rear of the Core/Network Module.
- 6** At the local end, connect NT8D95 cables from the I/O panels to a matching connector on the switch box.

If you are using an A0377992 ABCDE box, connect cables as follows:

- a.** Connect CPU 0 to connector A.
- b.** Connect CPU 1 to connector B.
- c.** Connect the SDI port to connector D (connector C is common).


- 7    At the local end, connect an NT8D95 cable from the switch box to the modem.
- 8    At the local end, connect the cable from the modem to an RJ11 telephone jack. (If a cable is required, connect an NT8D46 cable to the modem and to the RJ11 jack.)
- 9    At the local end, set the switch box as needed to communicate with the CPSI ports:
  - a.    During normal operation, set the switch to the SDI port.
  - b.    For debugging, set the switch to the *active* CPU.
- 10   For patch downloading, set the switch to the *inactive* CPU.

---


**End of Procedure**

---



**Figure 127****Modem to a switch box and SDI and CPSI ports (dual-column systems)**

**Figure 128**  
**Modem to a switch box and SDI and CPSI ports (single-column systems)**



---

# Troubleshooting the upgrade

---

## Contents

This section contains information on the following topics:

[Introduction . . . . .](#) 1155

[Troubleshooting procedures . . . . .](#) 1155

## Introduction

This appendix contains procedures that you can perform if you experience trouble after upgrading a system to a Meridian 1 Option 61C CP PII or Meridian 1 Option 81C CP PII. Look up all messages displayed on the terminal in the *Software Input/Output: System Messages* (553-3001-411).

## Troubleshooting procedures

Find the symptom listed below, and perform the appropriate corrective procedure.

**Procedure 391**  
**If the IOP/CMDU, IODU/C, or MMDU card fails the self-test**

- 1 Replace the card with a spare IOP/CMDU, IODU/C, or MMDU card.
- 2 Look for bent pins on the backplane connectors.
- 3 Replace the card cage.

---

**End of Procedure**

---

**Procedure 392**

**If the CP/CP PII Card or card fails the self-test**

- 1    Replace the card with a spare CP/CP PII card.
- 2    Look for bent pins on the backplane connectors.
- 3    Replace the card cage.

**Note:** Contact you Nortel representative for card or card cage replacement information.

---

**End of Procedure**

---

**Procedure 393**

**If “IOP Out of Service” appears on the Call Processor card LCD**

- 1    Check the cable connections on the rear of the backplane. Make sure backplane connector positions are correct (and no connectors are in row B or E).
- 2    Look for bent pins on the backplane connectors.
- 3    Replace the IOP/CMDU or IODU/C card with a spare card and make sure it completes its power-up tests successfully. Reset the Call Processor card to force it to rehunt the IOP or IOP/CMDU card.
- 4    If the Call Processor card finds the IOP/CMDU or IODU/C card, the original IOP/CMDU or IODU/C card is defective.
- 5    If the Call Processor card still fails to find the IOP/CMDU or IODU/C card, replace the card cage.

---

**End of Procedure**

---

**Procedure 394**

**If the system points to file corruption while loading software**

- 1** Place the A1 disk (IOP/CMDU) or the Install Program disk (IODU/C) in the floppy drive and reload (sysload) the system. The system will boot from the floppy, which contains the operating system software, and invoke the installation program. When the program installs the software on the hard drive, file-level corruption problems should be eliminated.
- 2** If the failure persists, because of a hard drive failure for example, replace the IOP/CMDU or IODU/C card with a spare card and try to load the software.

**Note:** If the database conversion or the data dump failed, contact your Nortel support representative.

---

**End of Procedure**

---



---

# Appendix A: Upgrade checklists

---

## Contents

This section contains information on the following topics:

Introduction . . . . .	1159
Site details . . . . .	1160
Upgrade details . . . . .	1160
Pre-upgrade checklists. . . . .	1161
Pre-conversion steps . . . . .	1164
Post-conversion checks . . . . .	1166
Quick reference . . . . .	1166
Software generic by machine type . . . . .	1170

## Introduction

The following section provides Large System upgrade checklists.

### Technical Support

Nortel can provide an Installation and Upgrade Support team to assist with PBX upgrades on a scheduled bases. This service is billable and a purchase order is required. Please refer to current price book for rates.

***Note:*** This service requires that a service request be opened in advance of the upgrade.

## Site details

**Table 184**  
**Site Details**

Customer Name	
Tape ID (LD 22)	
Modem Number (Core)	
Switch Room Telephone	
Baud Rate	
Modem Password	
PBX Password	
System Type	
Software Generic	

## Upgrade details

**Table 185**  
**Upgrade details**

Current Software - Generic	
Target Software - Generic	
Hardware being added	
Feature Upgrade	
License Upgrade	



## Pre-upgrade checklists

### Software Upgrade

#### Software audit

**Table 186**  
**Software audit**

<b>Software Audit</b>		
Perform the software audit prior to the scheduled upgrade.		
Take corrective action if answer is no		
	Yes	No
Software CD Ready		
Keycode Disk Ready		
Install Disk Ready		
DEP Patch Disk Ready		
Review Keycode Data Sheet - (SDID,PKGS,License,TID)		
Review Site Specific Patches - (Non MDCS)		
Read GRB for target Release – (Verify Memory Requirements)		

## License Upgrade

**Table 187**  
**Keycode audit**

Keycode Audit		
Perform the keycode Audit prior to the scheduled upgrade.		
Take corrective action if answer is no		
	Yes	No
Keycode Disk Ready		
Keycode Data Sheet Ready		
SDID Matches System		
TID Matches System		
Perform a KDIFF in LD 143 to compare keycodes		

## Conversion Required

**Table 188**  
**Conversion Procedures**

Conversion Procedures	
Upgrades between different machine types require some type of conversion.	
If the disk media is changing the database must be physically transferred	
between storage devices. Please select source and target media.	

**Table 189**  
**Typical Storage Media Changes Between machine Types (Part 1 of 2)**

Typical Storage Media Changes Between machine Types		
Source	Target	Procedure Required
Omega	IODUC	Direct cable transfer

**Table 189****Typical Storage Media Changes Between machine Types (Part 2 of 2)**

Omega	MMDU	Nortel Internal
CMDU	IODUC	4M - 2M media transfer
IODUC	MMDU	Disk to new Drive both use 2M Floppy Drives
MMDU	MMDU	Disk to new Drive

## Hardware Upgrade

### Hardware audit

**Table 190**  
**Hardware audit**

Hardware Audit		
Perform the Hardware Audit prior to the scheduled upgrade.		
	Yes	No
Verify Shipping List - Complete and Accurate		
Audit Site for new hardware locations		
Pre Run Cables if possible		
Review All switch settings for new cards		
Read all applicable NTP Procedures completely		

## Pre-conversion steps

**Table 191**  
**Pre-conversion steps (Part 1 of 2)**

Pre Conversion Steps
A capture file should be made of the following information using a PC or Printer.
Perform an overall system check:
LD 135 SCPU (ensure that the system is redundant)
LD 137 STAT/TEST CMDU
LD 96 STAT DCH
LD 48 STAT AML
LD 32 STAT
LD 60 STAT

**Table 191**  
**Pre-conversion steps (Part 2 of 2)**

LD 30 LDIS (Verify what Is disabled if any)
Get Software Information from LD 22
ISSP - Patches in service - Future Reference if required
TID/SLT - License Parameters - To compare with converted database
LD 21 - PRT CFN
LD 97 - PRT SUPL/XPEC
Run a Template Audit
LD 1 - Auto Run
Perform a Datadump
Backup at least two copies of the current database, retain the copies.
Print History File or System Event Log
LD 22 - Print AHST - Capture Systems Events to compare will new software if required
LD 117 - PRT SEL 500 - Same as above

## Post-conversion checks

**Table 192**  
**Post-conversion checks**

Post Conversion Checks
Perform these checks after a successful INI.
Test for dial tone
Stat D Channels for proper operation
Ensure that all XPEC's are in service via visual inspection
Ensure that all AUX applications are working
LD 30 LDIS (Verify that output is the same prior to upgrade)

## Quick reference

### IGS Cabling Chart - MultiGroup PBX - Opt 81/81C/CP (5 Groups Maximum)

**Table 193**  
**IGS cabling chart (Part 1 of 2)**

Net Group	Net Shelf	IGS Connector	IGS Net	Slot	Net	DIGS	Slot Connector	Intergroup connector	I G S	Clock
0	0	0	3	8	2	9	BOTTOM	J1	0	
0	0	1	2	9	2	9	TOP	J6	2	0
0	1	1	2	9	2	9	TOP	J17	3	1
0	1	0	3	8	2	9	BOTTOM	J22	1	
1	0	0	3	8	2	9	BOTTOM	J2	4	

**Table 193**  
**IGS cabling chart (Part 2 of 2)**

1	0	1	2	9	2	9	TOP	J7	6	0
1	1	1	2	9	2	9	TOP	J16	7	1
1	1	0	3	8	2	9	BOTTOM	J21	5	
2	0	0	3	8	2	9	BOTTOM	J3	8	
2	0	1	2	9	2	9	TOP	J8	1 0	0
2	1	1	2	9	2	9	TOP	J15	1 1	1
2	1	0	3	8	2	9	BOTTOM	J20	9	
3	0	0	3	8	2	9	BOTTOM	J4	1 2	
3	0	1	2	9	2	9	TOP	J9	1 4	0
3	1	1	2	9	2	9	TOP	J14	1 5	1
3	1	0	3	8	2	9	BOTTOM	J19	1 3	
4	0	0	3	8	2	9	BOTTOM	J5	1 6	
4	0	1	2	9	2	9	TOP	J10	1 8	0
4	1	1	2	9	2	9	TOP	J14	1 9	1
4	1	0	3	8	2	9	BOTTOM	J18	1 7	

**Note:** A DIGS Card is located in the card slot position for IGS 1 in all network shelves. The IGS 1 slot detects the clock signals from the active clock controller and distributes the clock to the entire group. Three out of four IGS cards can be disabled at any given time via LD 39, the IGS 1 that is associated with the active clock cannot be disabled via software, e.g. if clock 1 is active then IGS's 3,7,11,15 and 19 can never be disabled as they are providing clock for their respective network groups.



### Group/Loop/PS/FIJI/3PE Switch Settings

**Table 194**  
**Switch settings (Part 1 of 2)**

Group	Shelf	P S	Loops	Fiji*	3PE NT8D35 Net**	3PE NT5D21 Core Net**
0	0	0	0-16	0 0	off on on on on on on on	off on on off on on on on
0	1	1	16-31	0 1	off on on on on on on off	off on on off on on on off
1	0	2	32-47	1 0	off on on on on on off on	off on on off on on off on
1	1	3	48-63	1 1	off on on on on on off off	off on on off on on off off
2	0	4	64-79	2 0	off on on on on off on on	off on on off on off on on
2	1	5	80-95	2 1	off on on on on off on off	off on on off on off on off
3	0	6	96-111	3 0	off on on on on off off on	off on on off on off off on
3	1	7	112- 127	3 1	off on on on on off off off	off on on off on off off off
4	0	8	128- 143	4 0	off on on on off on on on	off on on off off on on on
4	1	9	144- 159	4 1	off on on on off on on off	off on on off off on on off
5	0	1 0	160- 175	5 0	off on on on off on off on	off on on off off on off on
5	1	1 1	176- 191	5 1	off on on on off on off off	off on on off off on off off
6	0	1 2	192- 207	6 0	off on on on off off on on	off on on off off off on on
6	1	1 3	208- 233	6 1	off on on on off off on off	off on on off off off on off

**Table 194**  
**Switch settings (Part 2 of 2)**

7	0	1 4	224- 239	7 0	off on on on off off off on	off on on off off off off on
7	1	1 5	240- 255	7 1	off on on on off off off off	off on on off off off off off

## Software generic by machine type

**Table 195**  
**Software generic by machine type**

System Type	Generic	System Type	Generic	Processors
ST	1011	Option 61	1111	CP1 - NT6D66 - 68030
STE	1511	Option 61 CP1	1811	CP2 - NT9D19 - 68040
NT	1111	Option 61 CP2	2311	CP3 - NT5D10 - 68060
XT	1211	Option 61 CP3	2511	CP4 - NT5D03 - 68060E
RT	1311	Option 61 CP4	2911	CPP - INTEL PII
Option 11	1411	Option 71	1211	CNI'S
Option 11	1411	Option 81 CP1	1611	Opt 81 - 8,9,10
Option 11C	2111	Option 81 CP2	1911	Opt 81C - 12,13,14
Compact	X27	Option 81 CP3	2611	CPP - c9,c10,c11,c12
Option 21	1011	Option 81 CP4	3011	Key Packages
Option21E	1511	Option 81C CP1	1611	Opt 81 - PKG 298
Option 51	1111	Option 81C CP2	1911	Opt 81C - PKG 299
Option 51 CP1	1711	Option 81C CP3	2611	CPP - PKG 299,368
Option 51 CP2	2211	Option 81C CP4	3011	FIJI - PKG 365
Option 51 CP3	2411	Option CP PII	3311	
Option 51 CP4	2811			

---

# Appendix B: Technical Assistance service

---

## Contents

This section contains information on the following topics:

Nortel Technical Assistance Centers. ....	1171
Services available .....	1174
Requesting assistance .....	1177

## Nortel Technical Assistance Centers

To help customers obtain maximum benefit, reliability, and satisfaction from their CS 1000E systems, Nortel provides technical assistance in resolving system problems. Table 196 on [page 1172](#) lists the centers that provide this service.

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel service program, contact one of the following Nortel Technical Solutions Centers.

**Table 196**  
**Customer Technical Services (Part 1 of 2)**

Location	Contact
Nortel Global Enterprise Technical Support (GETS) PO Box 833858 2370 Performance Drive Richardson, TX 75083 USA	North America  Telephone: 1 800 4NORTEL
Nortel Corp. P.O. Box 4000 250 Sydney Street Belleville, Ontario K8N 5B7 Canada	North America  Telephone: 1 800 4NORTEL
Nortel Service Center - EMEA	EMEA  Telephone: 00 800 8008 9009 or +44 (0)870 907 9009  E-mail: emeahelp@nortel.com
Nortel 1500 Concord Terrace Sunrise, Florida 33323 USA	Brazil Telephone: 5519 3705 7600 E-mail: entcts@nortel.com  English Caribbean Telephone: 1 800 4NORTEL  Spanish Caribbean Telephone: 1 954 858 7777  Latin America Telephone: 5255 5480 2170

**Table 196**  
**Customer Technical Services (Part 2 of 2)**

Location	Contact
Network Technical Support (NTS)	<p>Asia Pacific Telephone: +61 28 870 8800</p> <p>Australia Telephone: 1800NORTEL (1800 667835) or +61 2 8870 8800 E-mail: asia_support@nortel.com</p> <p>People's Republic of China Telephone: 800 810 5000 E-mail: chinatsc@nortel.com</p> <p>Japan Telephone: 010 6510 7770 E-mail: supportj@nortel.com</p> <p>Hong Kong Telephone: 800 96 4199 E-mail: chinatsc@nortel.com</p> <p>Taiwan Telephone: 0800 810 500 E-mail: chinatsc@nortel.com</p> <p>Indonesia Telephone: 0018 036 1004</p> <p>Malaysia Telephone: 1 800 805 380</p> <p>New Zealand Telephone: 0 800 449 716</p> <p>Philippines Telephone: 1 800 1611 0063 or 632 917 4420</p> <p>Singapore Telephone: 800 616 2004</p> <p>South Korea Telephone: 0079 8611 2001</p> <p>Thailand: Telephone: 001 800 611 3007</p>

## Services available

Services available through the Technical Assistance Centers include:

- diagnosing and resolving software problems not covered by support documentation
- diagnosing and resolving hardware problems not covered by support documentation
- assisting in diagnosing and resolving problems caused by local conditions

There are several classes of service available. Emergency requests (Class E1 and E2) receive an immediate response. Service for emergency requests is continuous until normal system operation is restored. Non-emergency

requests (Class S1, S2, and NS) are serviced during normal working hours.  
Tables 197 and 198 describe the service classifications.

**Table 197**  
**Technical service emergency classifications**

<b>Class</b>	<b>Degree of failure</b>	<b>Symptoms</b>
E1	Major failure causing system degradation or outage	<p>System out-of-service with complete loss of call-processing capability.</p> <p>Loss of total attendant console capability.</p> <p>Loss of incoming or outgoing call capability.</p> <p>Loss of auxiliary Call Detail Reporting (CDR) in resale application.</p> <p>Call processing degraded for reasons such as trunk group out-of-service:</p> <ul style="list-style-type: none"><li>• 10% or more lines out-of-service</li><li>• frequent initializations (seven per day or more)</li><li>• inability to recover from initialization or SYSLOAD</li><li>• consistently slow dial tone (eight seconds or more delay)</li></ul>
E2	Major failure causing potential system degradation or outage	<p>Standby CPU out-of-service.</p> <p>Frequent initializations (one per day or more).</p> <p>Disk drive failure.</p> <p>Two sets of disks inoperative.</p>

**Table 198**  
**Technical services non-emergency classifications**

Class	Degree of failure	Symptoms
S1	Failure that affects service	Software or hardware trouble directly and continuously affecting user's service or customer's ability to collect revenue.  Problem that will seriously affect service at in-service or cut-over date.
S2	Intermittent failure that affects service	Software or hardware faults that only intermittently affect service.  System-related documentation errors that directly result in or lead to impaired service.
NS	Failure that does not affect service	Documentation errors.  Software inconsistencies that do not affect service.  Hardware diagnostic failures (not defined above) that cannot be corrected by resident skills.  Test equipment failures for which a backup or manual alternative can be used.  Any questions concerning products.

Except as excluded by the provisions of warranty or other agreements with Nortel, a fee for technical assistance may be charged, at rates established by Nortel. Information on rates and conditions for services are available through Nortel sales representatives.



# Requesting assistance

Collect the information listed in Table 199 before you call for service.

**Table 199**  
**Checklist for service requests**

Name of person requesting service	_____
Company represented	_____
Telephone number	_____
System number/identification	_____
Installed software generic and issue (located on data disk)	_____
Modem telephone number and password (if applicable)	_____
Seriousness of request (see Tables 197 and 198)	_____
Description of assistance required	_____
	_____
	_____



---

## Appendix C: Software Installation Tool

---

This appendix details the screen displays and options of the CD-ROM Software Installation Tool (referred to as “Software Installation Tool”) that is compatible on Meridian 1 Option 51C, Meridian 1 Option 61C and Meridian 1 Options 81/81C equipped with the NT5D61 Input/Output Disk Unit with CD-ROM (IODU/C).

This tool is based on the existing Software Installation Tool, but has notable differences in menus, as well as new functionality to support installation of software from CD-ROM, copying of system software from Core to Core, copying of database from Core to Core, and Keycode installation.

The IODU/C card uses both a Security Device and an electronic keycode file. This keycode file is stored on a 2MB diskette and must be inserted into the IODU/C floppy drive and authenticated each time the Software Installation Tool is loaded and the Install Menu is accessed.

On systems equipped with an IODU/C, the database is stored on 2MB diskettes, not 4MB diskettes. A Database Transfer Utility diskette, specific to Call Processor type, is available to convert a 4MB database to a 2MB database. Refer to “Database transfer” in Book 3. For procedures on upgrading from systems equipped with IOP and CMDU or IOP/CMDU cards to IODU/C, see *Communication Server 1000M and Meridian 1: Large System Maintenance* (553-3021-500)

The Tools Menu has options for finding the CD-ROM status (option <g>), printing the Keycode (option <h>), printing information about the Security Device (option <i>), checking the customer-specific CD-ROM data (<j>),

manually creating a Keycode diskette (<k>), and archiving the database (<s>).



**WARNING**

Do not turn off the system during the installation process. If you need to quit the installation process, do so from within the Software Installation Tool before powering off the system.

Read and understand the entire procedure before attempting to perform an installation.

Before the Software Installation Tool is activated, verify that the system is in split mode (not applicable for Meridian 1 Option 51C) and that a terminal is connected to CPSI port J25 on the I/O panel (in the inactive Core for dual CPU systems). Meridian 1 Option 51C systems will be taken out of service.

To activate the Software Installation Tool, insert the Install diskette specific to the Call Processor type and the CD-ROM containing system software (if installing that component). Press the MAN RST button on the CP card in the same Core.

The IODU/C Software Installation Tool requires the following items:

- 2MB diskettes (used to store, backup, and restore the database)
- an Install diskette specific to the system's Call Processor card
- a Keycode diskette
- a CD-ROM containing system software

**Note:** If installing system software from CD-ROM (options <a>, <b>, or <c> from the Install Menu), insert the CD into the CD-ROM drive before loading the Software Installation Tool.

**CAUTION — Service Interruption****Loss of Data**


The screens shown in this procedure are examples. They are not intended to exactly represent the displays that will appear for the system, nor do the choices entered represent those to choose. Be sure to watch the terminal display, and follow the on-screen instructions.

Pay close attention to the menus when they appear; they display the options available at any given stage.

## Status Summary Charts

Status Summary Charts are displayed for the purpose of informing the user about what items will be installed or have been installed. This example is shown when option <b> (all components) is chosen from the Install Menu.

**Figure 129**  
**Status Summary screen example**



***Note:*** The screen might differ from this example.

The possible values and meanings for each column are defined below.

- Choice
  - **yes** indicates the item will be installed
  - **no** indicates the item was not selected, and will not be updated.
- Status
  - **quit** indicates the quit option was used, and the process was exited.
  - **ok** indicates the choice was installed successfully.

- **error** indicates the installation was not successful. A system message is given when the Software Installation Tool encounters a problem. Follow the actions required by the message.
- **ignore** applies to the CP ROM and IOP-ROM upgrade only. This appears when the process was exited when asked to replace a release and issue with the same release and issue.
- **blank** indicates the status is not yet determined if Choice = Yes. If Choice = No, the field remains blank.
- Comment
  - **from rel <number> to rel <number>** gives the Source and Target release and issue numbers.

## Messages

When the Software Installation Tool encounters a problem, a system message appears on the terminal display. These messages fall into two categories:

- warning
- non-warning


Warning messages are not critical errors. The Software Installation Tool proceeds with the installation following the appearance of this message. Refer to *Software Input/Output: Administration* (553-3001-311) for details regarding these messages.

Non-warning messages appear when a critical problem is encountered. The Software Installation Tool stops the process, and an action is recommended. When the action is complete, the Software Installation Tool can be restarted. In some cases, the tool allows the process to restart by pressing the carriage return <CR>.

## Introductory Screen

The first screen that appears after loading the NT5D61 Software Installation Tool is the Nortel Logo Screen shown in Figure 130 on [page 1184](#).

Figure 130  
Nortel logo screen






## Main menu

The Main menu screen seen in Figure 131 is displayed after <CR> is pressed from the NT Logo Screen. From this screen, select option <u> to go to the Install Menu, <t> to go to the Tools Menu, or option <q> to quit.

**Figure 131**  
**Main menu**




## Install Menu

**Note:** A Keycode diskette is required before accessing the Install Menu.

Before the Install Menu screen is displayed, you are prompted for the Keycode diskette to be inserted for validation against the Security Device.


### Figure 132 Keycode confirmation



Following successful Keycode validation, the Install Menu screen is displayed (Figure 133).

**Note:** If the Software Installation Tool is loaded on a Core equipped with an NT5D61BA IODU/C (which lacks a CD-ROM drive), options <a>, <b>, and <c> do not appear.

**Figure 133**  
**Install Menu screen**



Each option from the Install Menu is described in the following pages.

## Installing Software, CP-BOOT ROM, and IOP-ROM

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

This option, option <a>, is selected for the sequential installation of software, CP-BOOTROM, and IOP-ROM. Option <a> differs from option <b> in that the database is not installed. Use option <a> when going to a later software release or for a software upissue.

## Installing Software, Database, CP-BOOT ROM, and IOP-ROM

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

Option <b> is selected to sequentially install all components – software, database, CP-BOOTROM, and IOP-ROM.

Option <b> is used during the upgrade procedures from NT5D20 IOP/CMDU, NT6D63 IOP and NT6D64 CMDU to NT5D61 IODU/C cards or NT4N43CA CPP PII MMDU card.

## Installing Software only

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.


Option <c> is selected to install system software from the CD-ROM to the hard drive. When selecting option <c>, IOP-ROM and CP-BOOTROM are not installed.

## Installing Database only

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

The Database Menu (see Figure 134) of the Software Installation Tool is accessed by the <d> option on the Install Menu.

**Figure 134**  
**Database Installation options**



The following options are available for installing a database:

- Option <a> is to install the backup customer database from one or more 2MB diskettes.
- Option <b> allows installation from the CD-ROM containing the default database. This option is used on new systems which have no existing database.

- Option <d> copies the existing database from the redundant Core. This option is used when the database has already been installed on one Core. Use this option when upgrading from IOP/CMDU to IODU/C cards.
- Option <e> displays the version and issue of the current database residing on the Core. If database files are missing, error messages are printed.



#### Loss of Data

Before upgrading the system database, be sure a backup of the previous (source) database is on hand. Should any problems arise, it might be necessary to return to the previous database.

## Installing CP-BOOT ROM

For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

Option <e> is for installing new CP-BOOTROM. This option is used to install CP-BOOTROM while on Core 0 in a software upgrade, when software has already been installed using options <a> or <b> on Core 1, and software has already been copied onto Core 0 using option <o>.

When option <e> is selected, the next screen displayed shows the version of CP-BOOTROM being replaced and the version being installed, and the card slot where the CP-BOOTROM is being installed. When prompted, select <a> to continue with the CP-BOOTROM upgrade.

## Installing IOP-ROM

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

Option <f> is for installing new IOP-ROM. This option is used to install IOP-ROM while on Core 0 in a software upgrade, when software has already been installed using options <a> or <b> on Core 1, and software has already been copied onto Core 0 using option <o>, and CP-BOOTROM has been installed using option <e>.

When option <f> is selected, the next screen displayed prompts to choose whether to install the IOP-ROM from the hard disk (option <a>), or from CD-ROM (option <b>). If software has just been installed successfully, select option <a>. However, if software was not installed, select option <b> to install from CD-ROM.

after When option <f> is selected, the next screen displayed shows the version of IOP-ROM being replaced and version being installed, and the card slot where the IOP-ROM is being installed. When prompted, select <a> to continue with the IOP-ROM upgrade.

## Reinstalling CP-Software

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

This option is used if a flash programming error occurs during software installation through options <a>, <b>, or <c>. Option <g>, which assumes that software files have already been installed on the hard disk, copies these files from the hard disk to the Flash EEPROM.

## To copy system software from the other Core

**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

Option <o> is used during a software upgrade when software has already been installed on Core 1, and the Software Installation Tool has been loaded on Core 0.

**Note:** This option does not perform the installation of CP-BOOTROM (option <e>) or IOP-ROM (option <f>).

## To go to the Tools Menu

Option <t> displays the Tools Menu and its options, which are described beginning on [page 1194](#).

## To Install Keycode only

Option <k> is used to replace an existing Keycode.

## To quit


**Note:** For dual-CPU systems, verify that the system is operating in split mode before activating the Software Installation Tool.

Throughout the installation process, the option to quit is always available. Quitting with the Software Installation Tool quit commands is preferable to pressing the MAN RST button on the CP card, since quitting from the tool erases unneeded temporary files.

When done using the NT5D61 Software Install Tool, remove the diskette from the IODU/C and select option <q> to quit from the Installation menu. The terminal displays a confirmation to quit. Pressing <y> confirms the quit. See Figure 135.




**Figure 135**  
**Quit option – Installation Menu**



The final screen displayed before quitting is a reminder to remove the Install diskette from the IODU/C floppy drive before pressing <a> to reboot the system. See Figure 136 below.

The system automatically performs a Sysload, during which several messages appear on the system terminal. Wait for “DONE” and then “INI” messages to be displayed before continuing.

**Figure 136**  
**Quit screen**



## Tools Menu

To load the Software Installation Tool which contains the Tools Menu, insert the Install diskette which is compatible with the Call Processor card. Press the MAN RST button on the CP card to load the tool.

The first screen that appears after loading the NT5D61 Software Installation Tool is the Nortel Logo Screen shown in Figure 137.

**Figure 137**  
**Nortel logo screen**

```


Communication Server 1000 Software Software/Database/BOOTROM CDROM INSTALL Tool
=====

#####
#####
#####``#####
##### `` `#####
#####` #####`###
#####   #####` `###    NORTEL NETWORKS
#####   #####`   #####
#####   #####`   ##### Communication Server 1000 Software
`#####`   #####`
#####`   ##### Install Tool version XX
`#####   #####`
#####   `###` Copyright 1992 - 2004
##`##### #
## `#####
`# `#####
#####`
~~~~~`#####`

```

The screen seen in Figure 138 on [page 1196](#) is displayed after <CR> is pressed from the Nortel Logo Screen. From this screen, select option <t> to go to the Tools Menu

**Figure 138**  
**Main menu installation**




**Note:** Insertion of the Keycode diskette is not required for accessing the Tools Menu.

The Tools Menu has new options for finding the CD-ROM status (option <g>), printing the Keycode (option <h>), printing information about the Security Device (option <i>), checking the customer-specific CD-ROM data (<j>), manually creating a Keycode diskette (<k>), and archiving the database (<s>).

The Tools Menu is displayed in Figure 138.

**Figure 139**  
**Tools menu**



Each option from the Tools Menu is described in the following pages.

## Setting the system date and time

This option is used to change the system date and time for the system's internal clock. The correct date and time will ensure that files are time-stamped accurately.



### **WARNING**

#### **Time and Date**

Time and date must be set at time of installation to prevent problems on AUX products.

**Figure 140**  
**Set date and time screen**

Communication Server 1000 Software/Database/BOOTROM CDROM Install Tool  
=====

You have selected the option to set the system date and time.  
This will change the internal clock of your system to a new data  
and time.

The system date and time are also used by Install to time-stamp the new files  
created.

Pressing the carriage return at the prompt below will leave the  
system date or time unchanged.

Please enter the new date or time.

Current date is: Tuesday xx-xx-xxxx  
Enter new date (dd mm yyyy) ? xx x xxxx  
Date is set to: Wednesday xx-xx-xxxx

Current time is: 15:52:00  
Enter new time (hh mm ss) ? 15 05 45  
Time is set to: 15 05 45

System Date and Time now is:  
Wednesday xx-xx-xxxx, 15:05:46

553-7743revised

## Partitioning the hard disk

**Note:** Option <b> requires a password, and should only be performed by Nortel support personnel.



### CAUTION — Service Interruption

#### Loss of Data

Partitioning a disk erases all files from it.

## Displaying the hard disk partition size

Option <c> displays the partition sizes of the hard disk. The manufacturer and model number of the hard disk are also displayed. See Figure 141.

**Figure 141**  
**Partition information**

```

IODU 0
Hard Disk from: MAXTOR:7120SCS, Size:124MB,Sectors:248502
Unprotected   Part Size:30MB, Sectors: 60000
Spare         Part Size:30MB, Sectors: 60000
CardId        Part Size:1MB, Sectors: 2000
Protected     Part Size:60MB, Sectors: 120000
  
```

553-7742

## Regenerate the PDT password

Option <d> requires a password, and should only be performed by Nortel support personnel.

## To print the CD-ROM content

Option <g> is used to determine whether a CD-ROM exists on each IODU/ C, and whether its sectors are readable. After selecting <g>, three options are available:

- **Fast** readability test, which takes about 17 seconds for each CD-ROM and reads 1/30th of the CD-ROM sectors.

- **Extensive** readability test, which takes about 3 minutes for each CD-ROM and reads 1/4th of the CD-ROM sectors.
- **Total** readability test, which takes about 6 minutes for each CD-ROM and reads all sectors of the CD-ROMs.

*Note:* The failure of a CD-ROM drive to read a known good CD-ROM can indicate a problem with the CD-ROM drive.

## To print the Keycode content

Use option <h> to display the information contained in the current Keycode. The information displayed includes machine type, software version, License limits, and which feature packages are enabled.

See Figure 142 on [page 1201](#).



**Figure 142**  
**Current keycode**

```

System Serial Number      : 46379
Software Version          : 1811
System Type               : Option 61C
Call Processor            : CP68030
Release                   : 23
Issue                     : 30G
NTI Order Number          : 000000000000
NT SDID - 1               : 00000000
NT SDID - 2               : 00000000
Date and Time of Manufacture : 06/03/1998 - 14:53:38

```

Note: ( ) indicates that information is not available

ISM Limits:

```

Loop Limit                : 32
Sys TNs Limit              : 32767
ACD Agt Limit              : 32767
ACD DNs Limit              : 24000
AST Limit                  : 32767
DSL Limit                  : 100
LTID Limit                 : 100
DCH Limit                  : 64
AML Limit                  : 16
MPH DSL Limit              : 100
RAN CON Limit              : 32767
RAN RTE Limit              : 512
MUS CON Limit              : 1000
Brand Index                : 1

```

Options Packages:

```

0-2 4-5 7-25 28-29 232-55 57-65
67 70-77 79-81 84 86 88-93
95 98-105 107-109 111 113-121 125
127 129 132-134 136 139-140 145-151
153-155 157-160 162 164 170 172-175
178-181 186 191-192 196 202-212 214-216
218-219 222-225 227-229 231 233-235 240
242-243 245-248 250-251 253-256 258-259 262-263
286 290-293 296-297 301-303 305-310 313-316
321 323-324 327-335

```

553-7745

To print the Security Device content

Option <i> displays specific information about the Security Device, such as Serial Number. This enables the user to find information about the Security Device without removing the NT5D61 IODU/C card. See Figure 143.

Figure 143  
 Security device information

Engineering Code (Side x)	:NT5D61AA	
Card Serial Number	:06NNTM1831RRC3 IOP	
NT SDID	:20000080	
Security Device Type	:NT_TCH	
System Serial Number	:46379	553-7746

To check the customer-specific part of the CD-ROM

Use option <j> to check the readability of the Keycode-specified system software on the CD-ROM drive. Once all files have been checked successfully, the message **Checking directory /cdx/xxxx\_DMR.Nxx ended successfully** is displayed to indicate completion.

To manually create a Keycode diskette

Use option <k> to manually type in a keycode and save it to a 2MB diskette. Upon selecting this option, enter the characters into 21 Keycode entry lines of 16 characters each, which compose the Keycode file to be saved on a 2MB diskette in the floppy drive.

Characters can be entered on the Keycode entry lines in one of two ways:

- manually entering each 16-character line followed by a <CR>
- “pasting” each individual 16-character line, then pressing <CR> (available on a PC running Windows using the Copy command (Control-C) to copy a line of characters from a keycode file, positioning the cursor on the current Keycode entry line, and using the Paste command (Control-V) to paste the line).

If a line is entered which does not have 16 characters, a message is displayed requiring the line to be entered correctly.

### **To install Keycode only**

Use option <r> to replace an existing Keycode.

### **To archive the existing database**

Option <s> is one methods (the ABKO and BKO commands from LD 143 are other methods) available to backup the customer database to 2MB diskettes. The size of the backup files and the estimated number of 2MB diskettes required to store the database is displayed.

### **To check MDU connection**

Select option <z> to test the connection between a connected MDU and IODU/C.

### **To return to the Main Menu**

Select Option <m> to return from the Tools Menu to the Main Menu, to select to quit (<q>) or go to the Install Menu (<u>).



---

# Index

---

## Numerics

### 3PE

install additional cards, 135, 254, 309, 430, 667, 706

## A

### A0377992 Black Box ABCDE-Switches

modem connections, 1151  
system terminal connections, 1138

### A0377992 Black Box ABCD-Switches

system terminal connections, 1135

### ACD (Automatic Call Distribution) ports, 1130

## B

backup the database, 67, 742, 813, 847, 908, 966, 1012, 1029, 1059

Bell 103/212 modems, 1128

BKO, 67, 742, 813, 847, 908, 966, 1012, 1029, 1059

### Black Box ABCDE-Switches

modem connections, 1151  
system terminal connections, 1135, 1138

## C

### cables and cabling

system terminals, 1129

call back modems, 1141

call processing, effect of software upgrades on, 44

cards, troubleshooting circuit, 1155

CDR (Call Detail Recording) ports, 1130

### Clock Controller

status, 139  
switch active clock, 896, 1000, 1095

Configuring an A0638930 Motorola 28.8 Data/Fax Modem, 1143

### conversion media

defined, 44

### converting customer databases

failure in, 1157

country code, 1113

### CP (call processing) cards

system terminal connections, 1127, 1135

### CPIO ports

modem connections, 1140, 1149, 1151, 1153, 1154  
system terminal connections, 1135, 1136, 1137, 1138

### CPU

check status, 138  
switch active sides, 138

creating shortcuts, 1111

CTS, contacting, 1172

## D

### databases

verifying required updates, 270, 451, 549, 724

Database Transfer Utility, 1035

data dump, 67, 742, 813, 847, 908, 966, 1012, 1029, 1059

data dumps, performing  
failure in, 1157

DCE (data communication equipment), 1135

Dial-Up Networking®, 1112

Dial-Up Server, 1115

dispatch modems, 1141

Distributor Keycode Application, 47, 1105

DKA, 47, 1105

- Dial-Up Networking®, 1113
- hardware and software requirements, 1106
- installation, 1106
- Manual entry, 1124
- modem requirements, 1106
- Reading from a File, 1123

downloading keycodes, 1116

DTE (data terminal equipment), 1135

## E

error messages, 1183

## F

Fiber Network

- cable routing, 124, 170, 299, 344, 477, 576, 620
- verification and status, 104, 149, 151, 195, 198, 229, 232, 265, 268, 273, 323, 326, 370, 373, 408, 411, 446, 449, 454, 505, 508, 544, 548, 552, 599, 602, 647, 650, 682, 685, 719, 722, 727

fiber optic cable

- routing, 124, 170, 299, 344, 477, 576, 620

FIJI card

- sync cables, 123, 169, 298, 343, 477, 574, 618

file names, 1119

four-port SDI card cabling, 1134

## H

Hayes-compatible modems, 1128

## I

installation of DKA, 1106

I/O panels

- system terminal connections, 1127

## K

Keycode Delivery System (KDS), 1116

keycode download, 1116

keycodes

- downloading, 1116
- file name, 1119
- manual entry, 1124
- troubleshooting, 1122

## L

LD 17 program

- SDI ports, 1130

LD 32 program

- in 3PE Card replacement, 79, 99

LD 37 program

- 3PE Card replacement, 77, 78, 99, 100
- printer ports, 1130

LD 42 program, 1130

LD 48 program, 1130

## M

manually entering a keycode, 1124

modem configuration, 1113

modem requirements (DKA), 1106

modems, 1127

- cabling, 1129
- connections, 1128, 1140, 1149, 1151, 1153, 1154
- Motorola 28.8 Data/Fax modem, 1143
- system options 61C and 81, 1140
- USD FastTalk modem, 1146, 1147

Motorola 28.8 Data/Fax modem, 1143

MSPS cards  
switches, 1132

## **N**

network protocols, 1115  
NT5D61 Input/Output Disk Unit, 1179  
NT6D63 IOP Cards, troubleshooting, 1155  
NT6D66 Call Processing Cards  
system terminal connections, 1127, 1135  
NT6D66 CP Cards, troubleshooting, 1156  
NT8D41 SDI Paddle Boards  
cabling diagram, 1133  
ports and switches, 1131  
NT8D46 cable, 1149, 1151  
NT8D84 cable, 1151  
NT8D95AJ cable, 1129  
NT8D95 cable  
modem cabling, 1149, 1151  
system terminal cabling, 1136, 1137, 1138  
NTI number, 1119  
NTND02 MSPS Cards  
switches, 1132  
NT order number, 1119  
NT systems  
parallel reloads  
procedure, 805, 839, 958, 1051

## **O**

option 61  
system terminals, 1127  
option 61C  
modems, 1140  
option 61 systems  
parallel reloads  
procedures, 805, 839, 958, 1051  
option 71  
system terminals, 1127

option 81  
modems, 1140

## **P**

paddle boards  
cabling diagram, 1133  
ports and switches, 1131  
parallel reloads  
IODU/C systems, 850, 969, 1063  
procedure  
NT/RT/61 systems, 805, 839, 958, 1051  
Peripheral Signaling Cards  
in 3PE Card replacement, 79, 99  
Per Sig cards  
install, 137, 184, 219, 256, 311, 358, 397, 436,  
493, 532, 586, 635, 670, 706  
ping-pong effect, 1129  
post-conversion procedure  
steps, 271, 451, 549, 724  
printers  
port software enable, 1130  
SDI port connections, 1129  
printouts  
site data, 63, 114, 159, 204, 238, 276, 287, 333,  
380, 416, 456, 467, 514, 554, 565,  
609, 656, 691, 729, 738, 809, 843,  
904, 962, 1008, 1025, 1055

## **Q**

QPC841 Four-Port SDI Card cabling diagram, 1134

## **R**

read from a file, 1123  
release 23 memory requirements, 746, 819, 912,  
1034  
RS-232 cable  
modem cabling, 1149, 1151  
RT systems  
parallel reloads  
procedure, 805, 839, 958, 1051

## S

- SDI (serial data interface) ports
  - cabling diagram, 1134
  - modem connections, 1140, 1149, 1151, 1153, 1154
  - software enable, 1130
  - system terminal connections, 1127, 1129
- self-test failures, troubleshooting, 1155
- server type, 1115
- server types, 1115
- single CPU systems
  - call processing disruptions on, 44
- site data printouts
  - post-conversion procedure, 276, 554, 729
  - pre-conversion procedure, 63, 114, 159, 204, 238, 287, 333, 380, 416, 456, 467, 514, 565, 609, 656, 691, 738, 809, 843, 904, 962, 1008, 1025, 1055
- smart modems, 1128
- Software Installation Tool
  - description of menus, 900
- source software
  - defined, 45
- split mode monitoring, 1127, 1136
- switch boxes
  - modem connections, 1151, 1153, 1154
  - system terminal connections, 1137, 1138
- system ID, 1119
- system terminals
  - cabling, 1129
  - connections, 1128
  - CPIO port connections, 1135, 1136, 1137, 1138

## T

- target software, 45
- TCP/IP, 1115
- Technical Assistance Centers, 1171

## terminal

- connection and settings, 59, 113, 158, 203, 237, 286, 332, 379, 415, 466, 513, 564, 608, 655, 690, 737, 808, 842, 903, 961, 1007, 1024, 1054
- troubleshooting, 1122
- troubleshooting procedures, 1155

## U

- Unattended backup (BKO command), 67, 742, 813, 847, 908, 966, 1012, 1029, 1059
- USD FastTalk modem, 1146, 1147

## V

- V.42 modem standard, 1141
- verifying software conversion process, 270, 451, 549, 724

## X

- XON/XOFF flow control, 1129





Nortel Communication Server 1000

# **Communication Server 1000M and Meridian 1**

Large System Upgrade Procedures  
(Book 3 of 3)

**Copyright © 2006 Nortel Networks. All rights reserved.**

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

Nortel, Nortel (Logo), the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks.

To provide feedback or report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

Publication number: 553-3021-258

Document release: Standard 6.00

Date: July 2006

Produced in Canada

