

---

Meridian 1 Options 21 through 81C

# **System Programming Guide**

## System Programming Guide

---

PO Number: P0906780

Document Release: Standard 5.00

Date: June 1999

---

---

© 1995, 1999

All rights reserved

Printed in Canada

Information is subject to change without notice. Nortel Networks Corporation reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1, Meridian 1 and Digitone are trademarks of Nortel Networks Corporation.

# Revision history

**June 1999**

First standard release of documentation for software Release 24.2x

**December 1997**

First standard release of documentation for software Release 23.0x. Updates have been made to include information for the Option 81C, IODU/C, Network configuration, and Setting up service loops.

**October 1996**

First standard release of documentation for software Release 22.0x

**January 1996**

First standard release of documentation for software Release 21.1x

**September 1995**

First standard release of documentation for software Release 20.1x

---

# Contents

---

Revision history .....	iii
About this guide .....	vii
About the Meridian 1 .....	1
Configuring terminals .....	17
Configuring printers .....	37
Configuring a floppy disk for Options 21, 51, 61 and 71 .....	47
Configuring a hard disk for Options 21, 51, 61 and 71 .....	55
IODU/C Release 23 and later .....	63
Multi-purpose Serial Data Link .....	69
Incremental Software Management .....	81
Instant ISM .....	85
Configuring application module links .....	99
Configuring history and log files .....	111
Setting up passwords .....	121
Setting up system parameters .....	133
Network configuration .....	147
Service loops and circuits .....	159

<b>Configuring memory and buffers. . . . .</b>	<b>169</b>
<b>Configuring overlay options. . . . .</b>	<b>185</b>
<b>Setting digital telephone parameters . . . . .</b>	<b>197</b>
<b>Configuring Peripheral Equipment . . . . .</b>	<b>207</b>
<b>Entering customer data . . . . .</b>	<b>221</b>
<b>Setting up analog trunks . . . . .</b>	<b>247</b>
<b>Setting up digital and ISDN trunks . . . . .</b>	<b>307</b>
<b>510 Trunk Route Member Expansion . . . . .</b>	<b>343</b>
<b>Configuring tones . . . . .</b>	<b>347</b>
<b>Defining flexible feature codes . . . . .</b>	<b>357</b>
<b>Setting up speed call. . . . .</b>	<b>377</b>
<b>Configuring calling party name display . . . . .</b>	<b>391</b>
<b>Setting up telephones. . . . .</b>	<b>403</b>
<b>Setting up attendant consoles . . . . .</b>	<b>437</b>
<b>Setting up message filters (Release 21 and earlier) . . . . .</b>	<b>451</b>
<b>Completing programming. . . . .</b>	<b>463</b>
<b>Circuit Cards . . . . .</b>	<b>477</b>
<b>Terms and abbreviations . . . . .</b>	<b>497</b>
<b>Index . . . . .</b>	<b>535</b>

# About this guide

## Who should use this guide

This guide is intended for the novice Meridian 1 administrator or programmer. Use this guide when performing initial programming on a newly installed Meridian 1 system.

## How to use this guide

This guide contains detailed instructions for programming a Meridian 1 system. The instructions are divided up into a number of sections, each section addressing one particular aspect of Meridian 1 system operation. Each section is called a task. A task number appears in the top corner of the page.

To gain an understanding of the process of initial system configuration, read through the entire guide once before starting to program. Pay attention to descriptions of features and functions, and trace your way through flowcharts. Think about any kind of preparation or planning you may need to do before performing the actual programming.

Once you have read through the guide and have an understanding of the process of initial system configuration, return to the beginning of the guide. Perform the programming tasks in the order in which they appear in the guide. The order in which you perform the tasks is very important. Work through this guide from beginning to end.

---

## About this guide

---

Some features and options are beyond the scope of this guide. Make sure that you have access to other Meridian 1 documents, including:

- ◆ X11 features and services guides
- ◆ X11 input/output guides

## How the sections of this guide work

### About the Meridian 1

*About the Meridian 1* introduces the basics of the Meridian 1.

### Task sections

The bulk of this guide is made up of sections which explain how to perform tasks. Each task section has three parts: an introduction, a flowchart, and a step-action procedure. Use these sections in the order in which they appear.

#### Introduction (narrative)

The introduction provides you with what you should know about an aspect of Meridian 1 functionality before you program it.

#### Flowchart

The flowchart is a summary of the steps and decisions you must make while programming an area of functionality. Use it to make sure you have everything ready before you start programming.

#### Step-action procedure

Use this part of the task section to guide you through performing the programming part of the task. The procedure assumes you are comfortable with basic operation of the Meridian 1, and that you have read the narrative and flowchart parts of the section.

### Terms and abbreviations section

*Terms and abbreviations* provides a definition or explanation of a number of the terms and abbreviations used in this guide.

Index

The index at the back of this guide provides an easy way of finding information about specific subjects, features, prompts, responses and system messages.

How prompts and responses are represented

In this guide, the following conventions apply:

Prompts

Meridian 1 system prompts and messages appear in procedures in bold. The prompt appears at the far left, as shown underlined here:

<u><b>TYPE</b></u>	<b>PRI, PRI2</b>	Enter PRI to set thresholds for 1.5 Mbit/s PRI, or PRI2 to set thresholds for 2.0 Mbit/s PRI.
--------------------	------------------	---

Responses

In procedures

The responses or commands you may enter at a particular prompt appear in the procedures to the right of the prompt itself, as shown underlined here:

<b>TYPE</b>	<u><b>PRI, PRI2</b></u>	Enter PRI to set thresholds for 1.5 Mbit/s PRI, or PRI2 to set thresholds for 2.0 Mbit/s PRI.
-------------	-------------------------	---

---

## About this guide

---

### Variables

Some prompts allow a wide range of responses. If more than two or three responses are suitable for a particular prompt, the responses are not listed directly to the right of the prompt. Instead, for alphanumeric responses, `aaa` appears in the procedure and a list of responses is provided in the description. For numeric responses, a range of values is shown, as in the example here:

**DTT**      0-15 0-15      Enter the PAD level for digital TIE trunks.

In this example, the required response is two numbers separated by a space.

In some cases in procedures, an `×` or some other designator appears in place of this range of numbers. The explanation to the right of the response indicates the range that you can enter.

### Explanations

Explanations of what a prompt means or what the different responses do are provided for many prompts. In procedures this explanation appears to the right of the responses, as shown underlined here:

**TYPE**      PRI, PRI2      Enter PRI to set thresholds for  
1.5 Mbit/s PRI, or PRI2 to set  
thresholds for 2.0 Mbit/s PRI.



---

## About this guide

---

### Availability of product

Please check with your supplier if you have questions about which Nortel products (such as telephones, software features, or hardware) are available in your market area for a given release.

### Language standards and translations

This guide is written to North American English standards. Please see the *Terms and abbreviations* for equivalent terminology. We welcome suggestions for additions to these sections.

For versions of this guide in other than North American English, please check with your supplier or with Nortel.

### Additional Meridian 1 documentation

A number of Meridian 1 documents offer aids and resources that may help you during the initial programming of your Meridian 1. The aids are not required for basic configuration, but may make your planning and implementation more efficient. They may also help you during the programming of advanced or complex configurations.

---

## About this guide

---

This guide provides references to the following documents:

- ◆ *Basic Telecom Management Guide*, provided with this guide
- ◆ *Meridian IVR Installation Guide* (555-9001-210)
- ◆ *Software Features Guide*
- ◆ *Meridian Mail Modular Option EC Installation Guide*  
555-7061-210

See the Meridian 1 Planning and Engineering guide for

- ◆ *Meridian 1 Installation Planning* (553-3001-120)
- ◆ *Meridian 1 System Engineering* (553-3001-151)
- ◆ *Line Cards* (553-2201-1xx)
- ◆ *Digital Telephone Line Engineering* (553-2201-180)
- ◆ *Flexible Tone and Digit Switch Cards* (553-2711-180)
- ◆ *Multipurpose Serial Data Link Description* (553-3001-195)
- ◆ *Meridian 1 telephones* (553-3001-108)
- ◆ *Capacity engineering* (553-3001-149)
- ◆ *SL-1 telephone line cards* (553-2201-184)
- ◆ *System Overview* (553-3001-210)

See the Meridian 1 Software System Management guide for

- ◆ *Call Detail Recording Description and Formats* (553-2631-101)
- ◆ *X11 System Management Applications* (553-3001-301)

See the Installation and Maintenance guide for

- ◆ *Attendant console and set installation* (553-3001-215)

See the Automatic Call Distribution guide for

- ◆ *Automatic Call Distribution Feature Description* (553-2671-110)

---

## About this guide

---

See the ISDN Basic Rate Interface guide for

- ◆ *ISDN Basic Rate Interface Description* (553-3901-100)

See the Networking guide for

- ◆ *Electronic Switched Network Description* (309-3001-100)

## About this guide

---

# About the Meridian 1


## In this chapter

- About the Meridian 1 .....2
- Advanced Meridian 1 System Architecture .....10
- Planning for your Meridian 1 .....14
- Configuring your new system .....15

## About the Meridian 1

### About the Meridian 1

The Meridian 1 is a digital telephone switch intended for use by customers that need advanced calling and networking features. The Meridian 1 provides flexible voice and data services, high reliability, compatibility with a number of telecommunications environments, and the ability to upgrade component by component as requirements change.



### Meridian 1 description

The Meridian 1 product line consists of system types referred to as system options. A system option is made up of Universal Equipment Modules (UEMs) stacked one on top of another to form a column. Each column contains a pedestal, a top cap, and up to four modules. A system can have one column or multiple columns.

---

## About the Meridian 1

---

Each UEM is a self-contained unit that, when equipped, houses a cardcage and backplane, power and ground cabling, power units, I/O panels, circuit cards, and cables. When the cardcage is installed, the function of the UEM is established and the module is no longer “universal.” Meridian 1 modules are as follows:

- NT5K11 Enhanced Existing Peripheral Equipment Module  
options 21, 51, 51C, 61, 61C, 71, 81, and 81C
- NT5D21 Core/Network Module for options 51C, 61C, and 81C
- NT6D39 CPU/Network Module  
required for options 51 and 61
- NT6D60 Core Module  
required for option 81
- NT8D11 Common/Peripheral Equipment (CE/PE) Module  
required for options 21A, 21, and 21E
- NT8D13 Peripheral Equipment (PE) Module  
optional for options 21, 21E, 51, 51C, 61, 61C, 71, 81, and 81C
- NT8D34 CPU Module  
required for option 71
- NT8D35 Network Module  
required for options 71, 81, and 81C, optional for options 21, 21E, 51, 51C, 61, and 61C
- NT8D36 InterGroup Module  
required for options 71, 81, and 81C
- NT8D37 Intelligent Peripheral Equipment (IPE) Module  
required for options 51, 51C, 61, 61C, 71, 81, and 81C, optional for options 21 and 21E
- NT8D47 Remote Peripheral Equipment (RPE) Module  
optional for options 21, 21E, 51, 51C, 61, 61C, 71, 81, and 81C
- NT9D11 Core/Network Module  
for option 61C

## About the Meridian 1

---

**Note:** In addition, modules that house equipment for specific applications, such as Meridian Mail and Meridian Link, can be included in a column.

The pedestal generally houses a blower unit, air filter, Power Distribution Unit (PDU), and System Monitor.

The top cap provides airflow exits, input/output (I/O) cable entry and exit, and overhead cable-rack mounting. Thermal sensor assemblies for the column are attached to a perforated panel on top of the highest module in the column, under the top cap.

A system can have one column or multiple columns. To comply with FCC and CSA standards for containing electromagnetic interference and radio frequency interference (EMI/RFI), spacer kits connect the columns in a multiple-column system

### System options

#### Option 21A

Option 21A is a single-CPU system housed in a single CE/PE Module. This system has specialized power distribution, monitoring, and cooling systems that are optimized for the single-module operation.

#### Options 21, 21E

Options 21 and 21E are single-CPU systems. One CE/PE Module is required. In addition, IPE Modules, PE Modules, RPE Modules, and application modules can be used.

#### Option 51

Option 51 is a single-CPU system with parity-protected memory and a half-network group. One CPU/Network Module and one IPE Module are required. Additional IPE Modules, PE Modules, RPE Modules, and application modules can be used.



---

## About the Meridian 1

---

### Option 51C

Option 51C is a single-CPU system with a half-network group. One Core/Network Module and one IPE Module are required. Additional IPE Modules, PE Modules, RPE Modules, and application modules can be used.

### Option 61

Option 61 is a dual-CPU system with standby processing capability, fully redundant memory, and a full-network group. Two CPU/Network Modules and one IPE Module are required. Additional IPE Modules, PE Modules, RPE Modules, and application modules can be used.

### Option 61C

Option 61C is a dual-CPU system with standby processing capability, fully redundant memory, and a full-network group. Two Core/Network Modules and one IPE Module are required. Additional IPE Modules, PE Modules, RPE Modules, and application modules can be used.

### Option 71

Option 71 is a dual-CPU system with standby processing capabilities, fully redundant memory, and up to five full-network groups. The following modules are required:

- two CPU Modules
- one InterGroup Module
- a minimum of two Network Modules (provides one network group)
- a minimum of one IPE Module

Additional Network and IPE Modules are required for additional network groups. PE Modules, RPE Modules, and application modules can also be used.

---

## About the Meridian 1

---

### Option 81

Option 81 is a dual-CPU system with standby processing capabilities, fully redundant memory, and up to five full-network groups. Option 81 is equipped with two redundant disk drive units.

The following modules are required:

- two Core Modules
- one InterGroup Module
- a minimum of two Network Modules
- a minimum of one IPE Module

Additional Network and IPE Modules are required for additional network groups. PE Modules, RPE Modules, and application modules can also be used.

### Option 81C

Option 81C is a dual-CPU system with standby processing capabilities, fully redundant memory, and up to five full-network groups. Option 81C is equipped with two redundant input/output processor and disk drive unit combination packs.

The following modules are required:

- two Core/Network Modules (provide one network group)
- one InterGroup Module
- a minimum of two Network Modules (provides one network group)
- a minimum of one IPE Module

Additional Network and IPE Modules are required for additional network groups. PE Modules, RPE Modules, and application modules can also be used.

---

## About the Meridian 1

---

### Software

Meridian 1 software programs consist of instruction sequences that control call processing, peripheral equipment, administration, and maintenance functions. Several generic software programs with optional feature packages are available.

#### Office data

Office data describes the characteristics of the system in terms of configuration and call-dependent information, such as features and services. Office data is arranged in blocks defining peripheral equipment, system configuration, and transient data.

#### Resident programs

Resident programs stay in memory during system operation. Some resident programs are permanently programmed into the system read only memory (ROM). Other resident programs are automatically loaded into the system memory when the system is turned on.

**Note 1:** In options 51C and 61C, software for Release 23 runs on either of two Call Processor (CP) cards:

- the 48 MB (minimum) NT9D19 CP Card with the NT5D61 IODU/C Card or NT5D20 IOP/CMDU Card.
- the NT5D10 CP Card with the NT5D61 IODU/C Card or NT5D20 IOP/CMDU Card.

**Note 2:** In options 81 and 81C, software for Release 23 runs on the 64 MB (minimum) NT9D19 CP Card or NT5D10 CP Card, and the NT5D61 IODU/C Card or NT5D20 IOP/CMDU Card.

All software programs, including the nonresident programs listed in the following section are resident in, and accessible from, the memory on the cards listed above.

---

## About the Meridian 1

---

### Non-resident programs

Non-resident programs are stored on data disk and loaded into the overlay area of the system memory to perform specific tasks. Only one program may be loaded at a time and is removed from the overlay area when no longer needed. Non-resident programs can load automatically, under program control, or manually through software commands.

You can manually load non-resident programs into the system memory using the system terminal or maintenance telephone.

The non-resident programs provide the system interface for maintenance, service change, and traffic measurement. Each program is independent and has its own specific set of commands and formats. These programs do not interfere with system traffic or normal call processing.

There are five types of non-resident program:

- ◆ service change and print routines
- ◆ maintenance diagnostics
- ◆ traffic
- ◆ equipment data dump
- ◆ software audit

### Service change and print routines

Service changes on the Meridian 1 do not usually require hardware changes. Instead, you use service administration programs to create or modify all aspects of the system, from individual feature key assignments to complete system configurations.

There are also programs and print routines for retrieving data from the system to check the status of office data assignments.

---

## About the Meridian 1

---

### **Maintenance diagnostics**

Diagnostic programs are the primary tools for clearing system faults. You use diagnostic programs to automatically or manually test both common equipment and peripheral equipment. The programs may be loaded into the overlay area at the request of maintenance personnel, or as part of a daily maintenance routine automatically initiated by the system at a specified time.

### **Traffic**

All systems are equipped with traffic data accumulation programs. There is a traffic print program that examines the schedules, transfers data from accumulating to holding registers in accordance with schedules, and prints the traffic data. In addition, there is a traffic program used to query and modify schedules, options, and thresholds.

### **Equipment data dump**

After making service changes, you transfer the changes to disk in order to save them. When you run the equipment data dump program, all the office data in the read/write memory is written to the system disk. You can run the program automatically during the midnight routine or on a conditional basis (for example, after making a service change). You can run the program manually through the system terminal.

You can also use the data dump program to install a new generic software version or issue and capture protected data store information (such as speed call lists) that a user might change.

### **Software audit**

This program monitors system operation and gives an indication of the general state of the system. The program is concerned mainly with the system software. When a software problem is encountered, the program attempts to clear the problem automatically.

---

## About the Meridian 1

---

### Firmware

Firmware provides fundamental programs consisting of hard-wired logic instructions stored in programmable read-only memory (PROM). Firmware programs manipulate data in the central processor and control input/output operations, error diagnostics, and recovery routines.

### Advanced Meridian 1 system architecture

Options 51C, 61C, 81, and 81C “core” processor cards more than double the real-time call processing capacity of earlier processor cards, supports extensive networking, and provide intensive use of software features and applications, including call centers of up to 1000 agents.

The core software architecture incorporates a real-time multitasking operating system, as well as SL-1 code that delivers features and call processing. This architecture guarantees feature transparency to the user upgrading to the core CPU. The core architecture also provides significant operation, administration, and maintenance enhancements for the people who work closely with the system software and hardware.

All core overlays reside in dynamic random-access memory (DRAM) after they are loaded from the hard disk during an initial software load (software is shipped on redundant hard disks). The Resident Overlays featured in core based systems ensure subsecond speeds in accessing the overlays.

---

## About the Meridian 1

---

Along with software enhancements provided by X11 release 19, the capacity enhancement in the core architecture is provided by the core control complex. In the option 81 with Core Modules, the core control complex refers to the two Core Modules, Core 0 and Core 1. In the option 61C and option 81C with Core/Network Modules, the core control complex refers to the two Core/Network Modules, Core/Network 0 and Core/Network 1. In the option 51C, the core control complex refers to a Core/Network Module. The Core and Core/Network Modules are fully redundant, with Core 1 duplicating the contents of Core 0.

The backplane in the option 81 Core Modules is divided into two functional areas. The “interface” side houses a clock controller card, a three-port extender card, and up to two optional PRI/DTI cards. The “core” side provides an interprocessor bus (IPB).

The backplane in the options 51C, 61C, and 81C Core/Network Module is divided into “core” and “network” sides. The “network” side allows up to eight network cards to be installed for call processing capability.

The IPB is a very fast 32-bit address and data multiplexed multimaster bus that enables efficient communications with I/O interfaces and adjunct processors. The IPB is an asynchronous bus with speeds in the hundreds of megabits per second, resulting in a cumulative total speed many times greater than, for example, the 10-MB speed of Ethernet.

In each Core or Core/Network Module, the core side houses the following equipment:

- one Call Processor (CP) card
- one Input/Output Disk Unit with CD-ROM (IODU/C) or IOP/CMDU
- one (options 51C and 61C) or up to three (option 81C) core-to-network interface (CNI) cards
- CBT for option 81 or option 61C with NT9D11 Core/Network Module

---

## About the Meridian 1

---

Options 51C/61C/81/81C supports three types of CP cards:

- The NT6D66 CP card incorporates a 32-bit Motorola 68030 processor with single in-line memory modules (SIMMs) that provide a total of 24 or 48 MB of memory. Use the 48 MB version to run X11 Release 22 on option 51C or 61C.
- The NT9D19 CP card incorporates a 32-bit Motorola 68040 processor with single in-line memory modules (SIMMs) that provide a total of 48, 64, or 96 MB of memory. Use the 48 MB version to run X11 Release 22 on option 51C or 61C, and the 64 MB version to run X11 Release 22 on option 81 or 81C.
- The NT5D10 CP card incorporates a 32-bit Motorola 68060 processor with single in-line memory modules (SIMMs) that provide a total of 48, 64, 80, or 112 MB of memory. Use the 48 MB version to run X11 Release 23 on option 51C or 61C, and the 64 MB version to run X11 Release 23 on option 81 or 81C.

Cabling between the CP cards allows memory shadowing and dual-CPU operation.

The CNI card provides the interface between the IPB and the network shelf, and between the CP card and three-port extender cards in the network shelf. Each CNI card provides two ports. In a typical configuration, three CNI cards support five network groups.

Release 23 introduces the NT5D61 Input/Output Disk Unit with CD-ROM (IODU/C) for options 51C/61C/81/81C. The IODU/C replaces the IOP/CMDU card, using an industry-standard 2MB floppy drive and a CD-ROM drive (on the NT5D61AA vintage) to install system software from a CD-ROM.

The IODU/C uses a Security Device and an electronic Keycode rather than a Security Cartridge, to perform security authentication. The Keycode file contains information about which features the system provides as well as Incremental Software Management limits, which determine the various system limits, such as the number of Loops, TNs, RAN connections, etc., allowed.



---

## About the Meridian 1

---

The CBT card provides logical terminations to the 32-bit address/data multiplexed IPB signals across the core control section of the Core Module. For the Core/Network Module, the CBTs are replaced by hybrid bus terminators that are an integral part of the backplane of the Core/Network Module.

Core modules can diagnose faults in field-replaceable units for all core hardware, including cables. In case of a failure, a message in a natural language (such as English) appears on the system terminal and on the liquid crystal display (LCD) of the CP card. All messages can be stored in a file for future diagnostics.

### Customization

The information that describes specific system configuration and associated peripheral equipment is called office data. This data resides in the system memory and on disk.

Office data describes the characteristics of the system in terms of configuration and call-dependent information, such as features and services. Office data is arranged in blocks defining peripheral equipment, system configuration, and transient data.

## About the Meridian 1

---

### Planning for your Meridian 1

You can prepare for the configuration of your Meridian 1 before it arrives by planning your new telephone system. Your company needs to make decisions about:

- ◆ telephone extensions, including telephone numbers, types of telephones, and telephone options
- ◆ attendant consoles
- ◆ features
- ◆ value-added servers for applications such as Meridian Mail, Interactive Voice Response, or Automatic Call Distribution
- ◆ trunks linking the Meridian 1 to other telephone systems, including the public telephone network

Documents are available to help your company plan your telephone system. For information about hardware planning, refer to *Meridian 1 Installation Planning*. For more information about feature planning and provisioning, refer to *Meridian 1 System Engineering*.

Once your company plans your new telephone system, you can use this guide to create implementation sheets or worksheets listing the responses to specific prompts in various Meridian 1 overlay programs.

---

## About the Meridian 1

---

### Configuring your new system

This guide gives you the information you need to configure your new Meridian 1 with standard features and options. To use the procedures in this document, you should have prior experience with Meridian 1 administration.

Programming the Meridian 1 involves loading various overlay programs and using each one to enter a specific type of information. In some cases you may have to move back and forth between overlays to complete programming. The following flowchart shows a typical pathway through the overlays.

To perform the configuration, complete each of the tasks described in this guide in the order that they appear. Flowcharts and step-by-step procedures are provided to help you complete each task.

Some features and options are beyond the scope of this programming guide. Make sure that you have access to other Meridian 1 documents, including:

- ◆ input-output guides
- ◆ software feature guide

---

## About the Meridian 1

---

### System planning and programming examples

The following examples of system planning and programming are available in Meridian 1 documents:

- ◆ Electronic Switched Network configurations, in *Electronic Switched Network Description*
- ◆ digital telephone line engineering, in *Digital Telephone Line Engineering*
- ◆ call detail recording, in *Call Detail Recording Description and Formats*
- ◆ tone and digit switch programming, in *Flexible Tone and Digit Switch Cards*

### Planning forms

Planning forms serve as templates for your installation planning. Planning forms are available in the following Meridian 1 documents:

- ◆ *ISDN Basic Rate Interface Description*
- ◆ *X11 System Management Applications*
- ◆ *Multipurpose Serial Data Link Description*

### Worksheets

Several worksheets are available to help you plan for and perform configuration and feature implementation on the Meridian 1. Worksheets are forms that serve as templates for your installation planning. Worksheets are available in *Meridian 1 System Engineering*.


# Configuring terminals

## Purpose

System administrators communicate with the Meridian 1 through a text-based interface that lets them issue commands, enter data, or browse the Meridian 1 system database. You can use the text-based interface on any basic data terminal, including video data terminals, printer terminals, or computers running terminal emulation software.

A data terminal connected to the Meridian 1 may be:

- ◆ a system monitor
- ◆ an administration and maintenance terminal
- ◆ a background terminal for use in a hotel/motel environment



---

## Configuring terminals

---

A terminal can be connected directly to the Meridian 1, allowing programmers and administrators to work onsite, or it can be connected by way of modems, allowing remote access.

The Meridian 1 already has one terminal configured. This is the terminal you use to communicate with the Meridian 1. Use the procedures and information provided here to configure any additional terminals.

### Terminal types

The Meridian 1 uses data terminals in a number of different ways. A data terminal can play one of the following roles:

- ◆ system monitor
- ◆ background terminal
- ◆ maintenance terminal
- ◆ service change terminal
- ◆ traffic terminal

If you do not know what functions each terminal you are configuring will serve, refer to your installation plans. Brief descriptions are provided below.

#### System monitor

A system monitor operates as an output device only, displaying power, cooling, and general system error and status reporting.

To configure a terminal as a system monitor, enter YES in response to the XMS prompt in overlay 17.

#### Background terminal

A background terminal provides access to users in hotel/motel and other specialized environments, allowing them to monitor and control the Meridian 1.

To configure a terminal as a background terminal, enter BGD in response to the USER prompt in overlay 17.

---

## Configuring terminals

---

### Maintenance terminal

A maintenance terminal outputs system and maintenance messages, including AUD, BUG and ERR messages.

To configure a terminal as a maintenance terminal, enter MTC in response to the USER prompt in overlay 17.

### Service change terminal

A service change terminal allows access to the Meridian 1 system, customer and set database, and allows programmers and administrators to review or change the database or issue commands.

To configure a terminal as a service change terminal, enter SCH in response to the USER prompt in overlay 17.

### Traffic terminal

A service traffic terminal reports on traffic levels and events of interest to programmers and administrators.

To configure a terminal as a traffic terminal, enter TRF in response to the USER prompt in overlay 17.

## Configuring terminals

### Serial data interface ports

The Meridian 1 communicates with terminals through Serial Data Interface (SDI) ports. These SDI ports are found on several of the Meridian 1 circuit cards. These circuit cards include:

- ◆ NTND02 Misc/SDI/Peripheral Signalling Card
- ◆ NT8D41 Dual Port Serial Data Interface Paddle Board
- ◆ QPC687 CPU Card
- ◆ QPC139 Serial Data Interface
- ◆ QPC841 4-Port Serial Data Interface Card
- ◆ NT6D80 Multi-Purpose Serial Data Link Card
- ◆ QPC513 Enhanced Serial Data Interface Pack
- ◆ NT5K35 D-Channel Interface Card
- ◆ NT6D11 D-Channel Interface Card
- ◆ QPC757 D-Channel Interface Card

These cards reside in Network slots on the Meridian 1 switch. These cards require RS-232 cables with the exception of the Multi-purpose Serial Data Link (MSDL) card which requires a special cable (NTND27). The above circuit cards contain option switches, jumpers, or both that require the administrator to set, that will define the operating parameters of the SDI port on the card.

On a circuit card

- ON may be indicated by the word “on,” the word “up,” the word “closed,” the number “1,” an arrow pointing up or a solid dot (.).

- OFF may be indicated by the word “down,” the word “open,” the number “0,” or an arrow pointing down.



---

## Configuring terminals

---

See the section on circuit cards in this book for the various switch setting configurations of each card. The following section is a sample configuration of a maintenance terminal using a Multi-purpose Serial Data Link (MSDL) circuit card. This circuit card incorporates the most complex hardware configuration of the circuit cards listed.

### Sample Configuration of Maintenance Terminal on MSDL card.

The system administrator obtains the customers configuration requirements for the maintenance terminal. For this example, the customer requires:

- ◆ the maintenance terminal to be configured on an MSDL card.
- ◆ The interface mode will be Data Terminal Equipment (DTE).
- ◆ The terminal or device number to be seven.
- ◆ A baud rate of 9600.
- ◆ Use port 0 on the MSDL card

Before configuring the maintenance terminal on the Meridian 1, the MSDL card has to be configured to obtain the correct operating parameters. The list below provides the necessary steps to configure the MSDL card.


#### Steps required to hardware configure MSDL card

1. Remove the MSDL card (NT6D80) from it's current slot on the Meridian 1 switch or protective package. Handle the circuit card according to the Circuit card Precautions section in this book.
2. Using figure "553-0282T MSDL crd", set the Data Terminal Equipment (RS-232 DTE) switch settings for port 0. Find switch four (S4) and switch eight (S8). Both S4 and S8 should be in the off position.
3. Using figure "553-0282T MSDL crd", find switch 9 (S9) and switch 10 (S10). Set the device number to seven. To set the device number as 7, set S10 to 0 and S9 to 7.

## Configuring terminals

4. Insert the MSDL card into any NET slot on the Meridian 1 switch.

Figure 1



## Configuring terminals

Obtain the required cable for the MSDL card serial data interface port (NTND27) and connect it to port 0. Connect the other end to the data terminal.

### Step action to software configure MSDL card for a maintenance terminal

STEP	ACTION		
1	Log in.		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	Set up maintenance terminal.		
	>LD 17		
	REQ	CHG	
	TYPE	CFN	Enter CFN to change configuration
	ADAN	NEW TTY 7	Enter NEW TTY 7 to create a new input/output device number 7.
	CTYP	MSDL	Enter MSDL to specify the Multi-purpose Serial Data Link card.
	PORT	0	Active port number
	BPS	9600	Enter 9600 for the customer defined baud rate.
	USER	MTC	Enter MTC to specify the port as a maintenance port.
	REQ	****	Terminate the overlay by entering ****.
— continued —			

**24** System Programming Guide

of 560

**Configuring terminals****STEP ACTION****3 Enable the MSDL card.**

>LD 48

. ENL MSDL 7 FDL                      Enter ENL MSDL 7 to enable the MSDL card.

. STAT MSDL 7                      Enter STAT MSDL 7 to verify that the MSDL card is enabled.

. \*\*\*\*                      Terminate the overlay by entering \*\*\*\*.

**4 Enable the terminal port**

>LD 37

. ENL TTY 7                      Enter ENL TTY 7 to enable the terminal port.

. \*\*\*\*                      Terminate the overlay by entering \*\*\*\*.

— continued —

## Configuring terminals

### STEP ACTION

#### 5 Check your programming

>LD 22

**REQ** PRT Enter PRT.

**TYPE** ADAN TTY 7 Enter ADAN TTY 7 to verify the terminal port settings. These setting must match those of the terminal connected to the switch.

**REQ** \* \* \* \* Terminate the overlay by entering \* \* \* \*.

If possible, try all terminals to ensure that they are operating properly. If you cannot check all terminals at this time, review your programming to ensure that no errors were made.

#### 6 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

## Configuring terminals

STEP	ACTION
------	--------

— continued —

7	Verify that the data dump was successful.
---	---

On-screen or printed response:

NO GO BAD DATA

or

DATA DUMP COMPLETE

data dump successful

8	Terminate this overlay program.
---	---------------------------------

.

\* \* \* \*

9	Terminate this programming session.
---	-------------------------------------

Log off.

>LOGO

10	You have completed the programming required to configure terminals.
----	---



---

## Configuring terminals

---

### Modems

The Meridian 1 communicates with a data terminal by way of a modem in the same way it communicates with a local data terminal. A cable connects the modem to an interface card that has been configured to provide a terminal port.

To configure a terminal connected by way of a modem, respond to the same prompts used to configure a local modem. Configure the interface card using hardware switch settings to operate in DTE mode.

As well as programming the Meridian 1, you must configure the modem to auto-answer. Refer to the modem documentation for information about configuring the modem. Bell 103/212 compatible dumb modems are recommended to connect a remote data terminal. If a smart modem (such as a Hayes modem) is used, configure the modem for the dumb mode of operation (Command Recognition OFF, Command Echo OFF) before connecting the modem to the asynchronous port.

### Log files

The Meridian 1 can store information sent to terminals into log files. To create a log file, respond to the TTYLOG prompt in overlay 17 with a size for the log file. The maximum size is 65 Kbytes.

To turn off the log file, respond to the TTYLOG prompt in overlay 17 with 0.

Determine the size of the log file by estimating the level of traffic to the terminal. The busier the terminal, the larger the log file should be.

## Configuring terminals

### Single terminal access

If you configure your terminal to use an MSDL card, you can take advantage of the Single Terminal Access (STA) application to combine a number of different terminal functions on a single terminal. With STA, you can use one terminal to act as an administration terminal, a maintenance terminal, and a traffic monitoring terminal. STA can be particularly useful when configuring a remote terminal, since a single terminal and telephone line can provide access to the Meridian 1.

### Maintenance telephones

Administrators can use specially designated telephones to perform certain functions on the Meridian 1. Maintenance telephones allow the administrator to enter commands without using a data terminal. Maintenance telephones are not suited to initial system programming and are not discussed in this guide. For more information about using maintenance telephones, refer to the *Input/Output Guide*.

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.



## Configuring terminals

### Saving data

After adding or changing an I/O device by way of the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit overlay 17 by entering \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

## What to have ready

The following checklist summarizes the steps you should take before setting up your input/output requirements.

**Table 1**  
**Checklist**


Basic	Optional	Preparation
☐		Find out what terminals are needed, and where.
☐		Identify the card to be used for each terminal.
☐		Plan for any modems and telephone lines you may need.
☐		Consider implementing Single Terminal Access.

## What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure your terminals.

## Configuring terminals



The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.

## Configuring terminals

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of terminals.

STEP		ACTION	
1	Log in.		
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .			
2	Set up terminals.		
>LD 17			
REQ	CHG		
TYPE	CFN	Enter CFN to change the configuration record.	
ADAN	NEW TTY X	Enter NEW TTY and the device number to create a new terminal.	
CTYP	aaa	Enter the card type that will support the terminal from the selection below.	
To specify the card type		Enter	
multipurpose serial data link		MSDL	
four-port SDI		SDI4	
SDI paddle board		XSDI	
— continued —			

# Configuring terminals

STEP ACTION		
2 continued ...		
To specify the card type		Enter
Dual port SDI card		SDI2
four-port SDI		QSDI
Single Port SDI card		SDI
Single Port DCH card		SPDC
Enhanced SDI card		ESDI
Misc/SDI/Perip Signal card		MSPS
D-channel Interface card		DCHI
DNUM	X	x = 0 - 15  Enter the device number for I/O ports. All ports on the MSDL card address settings must match the DNUM value. For all other ports such as SDI, DCHI, etc., the device number should match the port address switch settings.
PORT	0	x = 0  Prompted only when CTYP = MSDL. A terminal port can only reside on port zero. X = 0
BPS	xxxxxx	Asynchronous baud rates. Only applies to software configurable cards (MSDL).  xxxxx =1200, 2400, 4800, 9600, 19200,48000,56000 or 64000
USER	aaa	Specify the user of the port.
— continued —		

## Configuring terminals

### STEP ACTION

**To specify the port user**

**Enter**

background terminal

BGD

maintenance terminal

MTC

service change terminal

SCH

traffic terminal

TRF

**XMS**

(NO) YES

Enter YES if the port is to be the system monitor.

Terminate the overlay by entering \*\*\*\*.

### 3 Enable the Terminal.

If you have configured an MSDL card, use the previous example to enable the card and terminal.

The follow the steps apply to all other terminals.

**>LD 37**

**.STAT**

Check the status of the newly configured terminal.

**.ENL TTY X**

Enable the terminal if it is disabled.

Terminate the overlay by entering \*\*\*\*.

— continued —

## 34 System Programming Guide

of 560

## Configuring terminals

STEP

ACTION

4

Check your programming.

>LD 22

REQ

PRT

Enter PRT.

TYPE

ADAN TTY X

Enter ADAN TTY and the device number to verify the terminal port settings. These setting must match those of the terminal connected to the switch.


REQ

\*\*\*\*

Terminate the overlay by entering \*\*\*\*.  
  
If possible, try all terminals to ensure that they are operating properly. If you cannot check all terminals at this time, review your programming to ensure that no errors were made.

5

Perform a data dump to permanently store the programming you have just completed.



CAUTION


Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43  
  
. EDD <cr>

— continued —

## Configuring terminals

STEP	ACTION
6	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p><b>NO GO BAD DATA</b></p> <p>or</p> <p><b>DATA DUMP COMPLETE</b></p> <p>data dump successful</p>
7	<p><b>Terminate this overlay program.</b></p> <p>.</p> <p>****</p>
8	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
9	<p><b>You have completed the programming required to configure terminals.</b></p>
	

## Configuring terminals


---



# Configuring printers

## Purpose

Printers are commonly used with the Meridian 1 to output Call Detail Recording (CDR) and traffic data. Printers are sometimes connected in parallel with administration or maintenance terminals to capture programming actions or commands.



---

## Configuring printers

---

### Applications

The following types of printer can be configured:

- ◆ Automatic Call Distribution (ACD) printer (for reports)
- ◆ background terminal
- ◆ software error printer
- ◆ CDR TTY port (outputting CDR records)
- ◆ Maintenance printer (printing AUD, BUG and ERR messages)
- ◆ traffic printer

To designate a specific application for a printer, respond to the USER prompt in overlay 17.


### Serial data interface ports

Refer to Serial data interface ports in Configuring terminals. Ensure that the SDI port is properly configured and Circuit Card address is configured.

## Configuring printers

### Traffic log files

The Meridian 1 is capable of outputting information about its traffic. During normal operation there can be large amounts of information generated. Traffic information is typically printed out on a high capacity high speed printer.



### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Configuring printers

### Saving data

After adding or changing an I/O device by way of the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit overlay 17 by entering \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

## What to have ready

The following checklist summarizes the steps you should take before setting up your printers.

**Table 2**  
**Checklist**


Basic	Optional	Preparation
☐		Identify your printing requirements.
☐		Select interface cards and applications for each printer.

## What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure your printers.

## Configuring printers



Configuring printers

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of printers.

STEP		ACTION	
1	Log in.		
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .			
2	Set up printers.		
>LD 17			
REQ	CHG		
TYPE	CFN	Enter CFN to change the configuration record.	
ADAN	NEW PRT X	Enter NEW TTY and the device number to create a new printer.	
CTYP	aaa	Enter the card type that will support the terminal from the selection below.	
To specify the card type		Enter	
multipurpose serial data link		MSDL	
four-port SDI		SDI4	
SDI paddle board		XSDI	
— continued —			

## Configuring printers

### STEP ACTION

#### 2 continued ...

To specify the card type Enter

Dual port SDI card SDI2

four-port SDI QSDI

Single Port SDI card SDI

Single Port DCH card SPDC

Enhanced SDI card ESDI

Misc/SDI/Perip Signal card MSPS

D-channel Interface card DCHI

**BPS**          xxxxx          Asynchronous baud rates. Only applies to software configurable cards (MSDL).

xxxxx =1200, 2400, 4800, 9600,  
19200,48000,56000 or 64000

**DNUM**          x          x = 0 - 15

Enter the device number for I/O ports. All ports on the MSDL card address settings must match the DNUM value. For all other ports such as SDI, DCHI, etc., the device number should match the port address switch settings.

**PORT**          0          x = 0

Prompted only when CTYP = MSDL. A terminal port can only reside on port zero. X = 0

**USER**          aaa          Specify the user of the port.

— continued —

## Configuring printers

STEP ACTION	
<b>2 continued ...</b>	
To specify the port user	Enter
ACD printer (for reports)	ACD
background terminal	BGD
software error printer	BUG
CDR TTY port (outputing CDR records)	CTY
Maintenance (including AUD, BUG and ERR messages)	MTC
traffic	TRF
<b>XMS</b> (NO) YES	Enter YES if the port is to be the system monitor.
<b>CUST</b> X	X = 0 - 99 Enter the customer number.
Terminate the overlay by entering ****.	
<b>3 Enable the terminal port</b>	
>LD 37	
. ENL PRT X	Enter ENL PRT and the port number to enable the terminal port.
. STAT	Enter the STAT command to verify that the port is enabled.
. ****	Terminate the overlay by entering ****.
— continued —	



## Configuring printers

### STEP ACTION

#### 4 Check your programming.

>LD 22

**REQ** PRT Enter PRT.

**TYPE** ADAN PRT X Enter ADAN PRT and the device number to verify the terminal port settings. These setting must match those of the printer connected to the switch.

**REQ** \* \* \* \* Terminate the overlay by entering \* \* \* \* .  
If possible, try all terminals to ensure that they are operating properly. If you cannot check all terminals at this time, review your programming to ensure that no errors were made.

#### 5 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Configuring printers

STEP	ACTION
6	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>or</p> <p>DATA DUMP COMPLETE</p>
7	<p><b>Terminate this overlay program.</b></p> <p>.</p> <p>* * * *</p>
8	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
9	<p><b>You have completed the programming required to configure printers.</b></p>
	

## Configuring a floppy disk for Options 21, 51, 61 and 71

### Purpose

The Meridian 1 allows the use of floppy disk drives. Floppy disks are used for loading software, for backing up databases, and for downloading logs. At system power-up or during a system reload, protected data store (office data) and program store information is automatically transferred from the disk drive (mass storage) unit to the system memory. During regular operation, the CPU accesses information from the memory.

If information in the protected data store is changed (such as a change in a telephone configuration), the information on the disk drive unit must be updated. Transferring data from the system memory to the disk drive unit is called a data dump. Data dumps can occur automatically or manually (when you issue software program commands).

The following types of disk drive units are used in Meridian 1 systems:

#### NTND15 FDU

The NTND15 Floppy Disk Unit is used in option 21E. It consists of two 3.5-inch floppy disk drives with a formatted capacity of 2.88 MB each; 5.76 MB total.

#### NTND16 Multi Disk Unit (MDU)

The NTND16 is used in options 51, 61, and 71. It consists of two 3.5-inch floppy disk drives with a formatted capacity 2.88 MB each; 5.76 MB total, and one 3.5-inch hard disk with 120 MB formatted capacity.

## Configuring a floppy disk for Options 21, 51, 61 and 71

### NT9D33 Small System Multi Disk Unit (SMDU)

The NT9D33 is used in option 21E and STE systems. It consists of two 3.5-inch floppy drives with a formatted capacity of 1.44 MB each; 2.88 MB total, and one 3.5-inch hard disk with a minimum formatted capacity of 20 MB.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### Saving data

After adding or changing an I/O device via the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit LD 17 with \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

## What to have ready

The following checklist summarizes the steps you should take before setting up your floppy disk drives.

**Table 3**  
**Checklist**

Basic	Optional	Preparation
Ⓓ		Identify your system configuration.

---

## Configuring a floppy disk for Options 21, 51, 61 and 71

---


### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure your floppy disk drives.

## Configuring a floppy disk for Options 21, 51, 61 and 71

The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.



## Configuring a floppy disk for Options 21, 51, 61 and 71

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of floppy disk drives.

STEP	ACTION		
1	<b>Log in.</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	<b>Set up floppy disk drives.</b>		
	Some responses may not be allowed depending upon machine type, options, and equipped packages.		
	>LD 17		
	REQ	CHG	
	TYPE	CFN	Enter ADAN to create a new I/O device.
	ADAN	CHG FDK X	Enter CHG FDK and device number to configure a floppy disk drive.
	NUMD	( 2 ) - 1	Specify the number of drives to be installed.
	FTYP	aa	Floppy type (aa = (3), 3S, or 5) (3) = 3.5 inch high density type 3S = 3.5 inch super density type 5 = 5.25 inch floppy type
— continued —			

## Configuring a floppy disk for Options 21, 51, 61 and 71

STEP ACTION

3 Check your programming.


>LD 22

REQ PRT Enter PRT.

TYPE ADAN FDK X Enter ADAN FDK and the device number to verify the Floppy disk configuration.

REQ \* \* \* \* Terminate the overlay by entering \* \* \* \*.

4 Perform a data dump to permanently store the programming you have just completed.



CAUTION

Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.


> LD 43

. EDD <Cr>

— continued —



## Configuring a floppy disk for Options 21, 51, 61 and 71

STEP	ACTION
5	<b>Verify that the data dump was successful.</b>  On-screen or printed response:  NO GO BAD DATA OR DATA DUMP COMPLETE
6	<b>Terminate this overlay program.</b>  .  * * * *
7	<b>Terminate this programming session.</b>  Log off.  >LOGO
8	<b>You have completed the programming required to configure floppy disk drives.</b>
	

## **Configuring a floppy disk for Options 21, 51, 61 and 71**

---

## Configuring a hard disk for Options 21, 51, 61 and 71

### Purpose

The Meridian 1 allows the use of hard disk drives. Hard disks are used for storing software and the Meridian 1 database. At system power-up or during a system reload, protected data store (office data) and program store information is automatically transferred from the disk drive (mass storage) unit to the system memory. During regular operation, the CPU accesses information from the memory.

If information in the protected data store is changed (such as a change in a telephone configuration), the information on the disk drive unit must be updated. Transferring data from the system memory to the disk drive unit is called a data dump. Data dumps can occur automatically or manually (when you issue software program commands).

The following equipment configurations include hard drives:

#### **NTND16 Multi Disk Unit (MDU)**

The NTND16 is used in options 51, 61, and 71. It consists of two 3.5-inch floppy disk drives with a formatted capacity 2.88 MB each; 5.76 MB total, and one 3.5-inch hard disk with 120 MB formatted capacity.

#### **NT9D33 Small System Multi Disk Unit (SMDU)**

The NT9D33 is used in option 21E and STE systems. It consists of two 3.5-inch floppy drives with a formatted capacity of 1.44 MB each; 2.88 MB total, and one 3.5-inch hard disk with a minimum formatted capacity of 20 MB.

---

## Configuring a hard disk for Options 21, 51, 61 and 71

---

### NT6D64 Core Multi Drive Unit (CMDU)

The NT6D64 is used in the Option 81 Core Module, and in options 51C and 61C with X11 release 19 and later. It consists of one 3.5-inch floppy disk drive with a formatted capacity of 2.88 MB, and one 3.5-inch hard disk with 120 MB formatted capacity.

### NT5D20 IOP/CMDU

The NT5D20 is used in options 51C, 61C, and 81C. It consists of one Input/output Processor (IOP), one 3.5-inch floppy disk drive with a formatted capacity of 2.88 MB, and one 3.5-inch hard disk with 120 MB formatted capacity.

**Note:** Two IOP/CMDUs, one in each Core/Network Module, are used in a redundant arrangement. Therefore, 2.88 MB of floppy disk storage, 120 MB of hard disk storage, and 48 MB of RAM are available in each module during system operation.

Certain Meridian 1 system options do not require or allow configuration of a hard disk drive. This section may not be needed for your system. Verify that your system is equipped with a hard disk drive and that disk drive configuration is required before proceeding. If you do not have to configure a hard drive, go to the next programming task.

To configure a hard drive on the Meridian 1, respond to the ADAN and NUMD prompts.

---

## Configuring a hard disk for Options 21, 51, 61 and 71

---

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### Saving data

After adding or changing an I/O device via the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit LD 17 with \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

---

## Configuring a hard disk for Options 21, 51, 61 and 71

---

### What to have ready

The following checklist summarizes the steps you should take before setting up your hard disk drive.

**Table 4**  
**Checklist**

Basic	Optional	Preparation
Ⓓ		Identify your system configuration.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.


A step-action table follows the flowchart. The table explains the programming steps necessary to configure your hard disks.

---

## Configuring a hard disk for Options 21, 51, 61 and 71

---

The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.



## Configuring a hard disk for Options 21, 51, 61 and 71

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of hard disk drives.

STEP ACTION	
1	Log in.
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
2	Set up hard disk drives.
Some responses may not be allowed depending upon machine type, options, and equipped packages.	
>LD 17	
REQ	CHG
TYPE	ADAN Enter ADAN to create a new I/O device.
ADAN	NEW HDK 0 Enter NEW HDK 0 to configure a hard disk.
NUMD	1-2 Specify the number of drives to be installed.
— continued —	



## Configuring a hard disk for Options 21, 51, 61 and 71

### STEP ACTION

#### 3 Check your programming.

If possible, try the hard disk drives to ensure that they are operating properly. If you cannot check the drives at this time, review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.

If	Do
the programming is correct	step 4
the programming is not correct	step 1

#### 4 Perform a data dump to permanently store the programming you have just completed.



##### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Configuring a hard disk for Options 21, 51, 61 and 71

STEP	ACTION
5	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>or</p> <p>DATA DUMP COMPLETE</p>
6	<p><b>Terminate this overlay program.</b></p> <p>.</p> <p>* * * *</p>
7	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
8	<p><b>You have completed the programming required to configure hard disk drives.</b></p>
	

## IODU/C Release 23 and later

### Purpose

Meridian 1 processors include the Thor processors: (options 51C, 61C, 81 and 81C). Thor systems have a very different architecture from the Omega systems (options 21, 21E, 51, 61 and 71). On Thor processors the number of software packages included is fixed: that is, all packages are included. Therefore, the storage requirements for Thor processors is fixed.

The configuration of Thor architecture is outside the scope of this guide. This section is for information purposes only.

### Software installation and SYSLOAD

On the Thor machines, the SL-1 program is loaded to hard disk via an external medium and then SYSLOAD is performed from the hard disk. (Due to the need to accommodate a much larger and growing SL-1 program, this is a departure from the Omega machines, on which the floppies and the hard disk were interchangeable as means of uploading the SL-1 program and SYSLOAD could be performed from either.) At present the software uploading medium is either a stack of 8-16 4MB floppy disks, on systems purchased prior to Release 23, or a CD-ROM, on systems purchased from Release 23 on. The SL-1 customer database is loaded to the hard disk on a separate floppy, which can be rewritten via a “backup” operation or reread to hard disk via a “restore” operation (LD 43).

The hard disk total capacity is a function of whatever is currently available from the manufacturers. At present, the disks being shipped with the Meridian 1 are 2GB. Whatever the total capacity, however, the actual storage capacity available to the Meridian 1 is determined

---

## IODU/C Release 23 and later

---

by the disk partitioning into the protected and unprotected area. Since Release 21 this has been set at 30MB for unprotected and 60MB for protected.

### **Pre-Release 23 : IOP/CMDU**

Prior to Release 23, the software uploading medium was a 4MB disk drive. The SL-1 program was read in from a stack of 4MB floppies. (A stack of 8 in Release 18 and a stack of 16 by Release 23.) This is being replaced in Release 23 by the introduction of the Input/Output Disk Unit with CD-ROM (IODU/C) card, which introduces a CD-ROM - floppy drive combination discussed in the next section. IODU/C preserves the architectural characteristics of the IOP/CMDU recognized by the rest of the system - the CP-IOP interface, and the Ethernet and SCSI capabilities of the IOP family.

### **Release 23 : IODU/C**

By means of the IODU/C feature, Release 23 introduces software delivery by CD-ROM to Meridian 1 systems. IODU/C incorporates a Keycode based S/W installation and feature expansion methodology. Highlights of IODU/C include:

Software delivery via CD plus single install floppy. This replaces the (large) stack of floppies required to install software in the past.

Replacement of single 4MB floppy drive with a 2MB drive.

The IODU/C hardware replaces the old IOP/CMDU pack in the exact same three slots; ie., the old and the new are incompatible. In Release 23 IODU/C will be shipped with all new systems and all hardware upgrades. The IOP/CMDU is still supported on upgrades to Release 23 that involve software only.

The following table provides the expected maximum floppy disk space required (before compression) by SL-1 databases for the supported option 51C/61C/81/81C machine types. These are conservative but realistic estimates; that is, not all sites with the given machine type will have databases as large as shown.

## IODU/C Release 23 and later

### Floppy Disk Space Requirements Projection for SL-1 Customer data

	<b>RIIs 23</b>
<b>51C with NT6D66 CP card</b>	0.534
<b>61C with NT6D66 CP card</b>	0.816
<b>81/81C with NT6D66 CP card</b>	2.087
<b>51C with NT9D19 CP card</b>	0.746
<b>61C with NT9D19 CP card</b>	1.169
<b>81/81C with NT9D19 CP card</b>	3.076
<b>51C with NT5D10 CP card</b>	0.955
<b>61C with NT5D10 CP card</b>	1.519
<b>81/81C with NT5D10 CP card</b>	4.055

## About the NT5D61 IODU/C card

The NT5D61 Input Output Disk Unit with CD-ROM (IODU/C) card introduces CD-ROM software delivery to Meridian 1 systems options 51C, 61C, 81 and 81C.

The software installation process for IODU/C based systems is similar to the process defined for IOP/CMDU or IOP and CMDU systems, with the following exceptions:

- software installation from CD-ROM and one Install Program diskette.
- During the software installation process, a security device and keycode diskette are used to activate features and ISM limits rather than a security cartridge.
- Database backup and restore is supported using an industry-standard 2 MB floppy drive rather than a 4 MB drive.

---

## IODU/C Release 23 and later

---

- For redundant systems, software is installed onto Core 1 and then copied to the other Core. This eliminates software installation onto both Cores. (CP-BOOT ROM and IOP-ROM must be upgraded on both Cores.)
- For redundant systems, the database is copied from the redundant side.
- Each processor type (68060, 68040, 68030) has a distinct Install Program and Database Transfer Utility diskette

### Software install kit

The IODU/C Software Install Kit consists of:

- a generic CD-ROM that contains nine software generics
- Install Program diskettes (one for each Call Processor card type, 68060, 68040, 68030)
- Keycode diskette
- Database Transfer Utility diskette
- Distributor Keycode Application diskette
- customer database diskettes

A complete software installation must be performed to:

- convert from one release to another
- convert to a later issue of the same release
- change software generic within the same release

### Security device

The IODU/C security device and keycode replace the functionality of the IOP/CMDU security cartridge. The security device is located in the top right corner of the IODU/C motherboard and controls the software feature functionality and Incremental Software Management (ISM) limits.

---

## IODU/C Release 23 and later

---

During software installation, the keycode must be validated against the information contained in the security device. To identify matching security devices and keycodes, refer to the 8-digit code on the security device and the keycode diskette label.

The security device is intended to serve the customer through system upgrades and features changes, and is to be replaced only if damaged.

### Keycodes

A keycode is an electronic file that resides on a diskette or your PC and is installed using Overlay 143 or the Meridian 1 Software Installation Tool.

A new keycode is required when converting software releases, adding features, modifying ISM limits, and when replacing a security device. During the software installation process, you will be prompted to install a keycode diskette.

In addition to receiving a keycode diskette from Northern Telecom, you can download a keycode from the Distributor Keycode Server to your PC hard disk and copy it to a standard 2 MB floppy diskette.

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

**IODU/C Release 23 and later**

---



# Multi-purpose Serial Data Link

## Purpose

The Multi-purpose Serial Data Link card facilitates smooth communications between the Meridian 1 system and peripheral devices or D-channels.

The following three D-channel options are covered:

- ◆ MSDL Idle Code Selection
- ◆ MSDL Port Overload Counter
- ◆ MSDL Status Enquiry Message Throttle

## MSDL Idle Code Selection

When a T1 carrier is disabled at the remote end, the remote T1 or ISDN PRI hardware raises a “Red Alarm” status and sends a “Yellow Alarm,” to the local (near end) Meridian 1. This takes all trunks and channels out of service, and responds to the remote end by sending an “Unassigned PCM” (FF) code. However, some switches do not recognize the “Unassigned PCM” code, and instead expect an “Idle PCM” (7F) code.

The Idle Code Selection feature allows a Meridian 1, upon receiving a “Yellow Alarm” condition from the remote end with a disabled T1 carrier, to be configured to respond by sending an “Idle PCM” code instead of an “Unassigned PCM” code. Therefore, a remote switch, such as a Lucent 5ESS, which expects to receive an “Idle PCM” code

## Multi-purpose Serial Data Link

---

can be cleared of a Red Alarm, the Meridian 1 can be cleared of a Yellow Alarm, and trunks and channels can be brought back into service.

### What's next?

A step-action table explains the programming steps necessary to activate the Idle Code Selection loop number.

## Multi-purpose Serial Data Link

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to programming MSDL Idle Code Selection.

STEP

ACTION


1

Log in.

For information on proper login procedures, see *Basic Programming Instructions* in *Basic Telecom Management*.

2

Activate a loop to send Idle PCM code.



CAUTION

Confirm that the remote end supports the “Idle PCM” code, before configuring this feature on a loop.

>LD 73

REQ

CHG

TYPE

DDB

ICS

xxx

Enter the Idle Code selection loop number to be activated.

xxx = 0-159

You have completed the programming required to activate a loop to send Idle PCM code.

END

---

## Multi-purpose Serial Data Link

---

### MSDL Port Overload Counter

The MSDL Port Overload Counter feature provides the capability of locking out individual MSDL ports when incoming messages through a port exceed or equal the port overload threshold of 200 messages in a two second time period. This applies to Meridian 1 options 51C, 61C, 81, and 81C systems running X11 release 24 or later software.

When any of the four ports on the MSDL card reaches the port overload threshold it is locked-out, but the operation of other ports on the MSDL card will not be affected.

The MSDL card is still subject to a card overload threshold, which will cause a lock-out if it receives 300 or more messages per two seconds. However, when an individual MSDL port becomes overloaded, the messages to that port are subtracted from the total card messages used in performing the card overload check. Furthermore, port overload checks have priority over card overload checks.

The overloaded port on the MSDL card is locked-out so that the card stops responding to the incoming messages from the overloaded port. This prevents the Meridian 1 CPU from servicing a very high incoming message rate from the port, which could cause system degradation.

#### **MSDL/MISP Interface Handler (MMIH)**

The MMIH provides a software interface between the MSDL/MISP card and the Meridian 1 software, and allows applications on the MSDL/MISP card to access each other through the interface.

Previously, the interface software maintained a counter of incoming messages on an MSDL application basis. When the sum of all messages received indicated an excessive incoming message rate, the MSDL card was locked-out.

Now, the Port Overload Counter feature modifies the MMIH so that incoming message counters are maintained for individual MSDL ports

This feature changes the functionality of the MMIH for an MSDL card, but the MISP remains unchanged.

---

## Multi-purpose Serial Data Link

---

### DCH/SDI/AML Application

The Port Overload Counter feature changes the DCH/SDI/AML Application to cause the MSDL port to lockout when the incoming messages exceed the Port Overload threshold value.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information about Nortel support services, contact your system supplier.

## What's next?

A step-action table explains the programming steps necessary to view the status of a MSDL card and ports.

## Multi-purpose Serial Data Link

The preceding material in this module contains essential information. You should be aware of this information before you proceed.


This step-action table covers the prompts related to upgrading ISM parameters.

STEP	ACTION
1	<p>Log in.</p> <p>For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i>.</p>
2	<p>Display the status of ports on a MSDL card for I/O Diagnostic.</p> <pre>&gt;LD 37 IOD000 .</pre> <pre>.STAT MSDL xx          MSDL xx: ENBL                         SDI 7 OVLD PORT 0                         DCH 11 OVLD PORT 1                         AML 12 OVLD PORT 2</pre> <p><b>Note:</b> Where xx = the physical MSDL number.</p>
3	<p>Display the status of an overloaded MSDL port running a SDI application.</p> <pre>&gt;LD 37 IOD000 .</pre> <pre>.STAT TTY xx          TTY XX: OVLD</pre> <p><b>Note:</b> Where xx = logical SDI number.</p> <p>— continued —</p>

## Multi-purpose Serial Data Link

STEP	ACTION
4	<p>Display the status of ports on a MSDL card for Link Diagnostic.</p> <pre>&gt;LD 48 .LNK000 .</pre> <pre>.STAT MSDL xx          MSDL xx: ENBL                         SDI 7 OVLD PORT 0                         DCH 11 OVLD PORT 1                         AML 12 OVLD PORT 2</pre> <p><b>Note:</b> Where xx = the physical MSDL number.</p>
5	<p>Display the status of an overloaded AML port on a MSDL card.</p> <pre>&gt;LD 48 .LNK000 .</pre> <pre>STAT AML xx          AML: xx MSDL: yy PORT: zz DES: LYR2: <b>OVLD</b></pre> <p><b>Note:</b> Where xx = logical AML number, yy = physical MSDL number, and zz = MSDL port</p>
6	<p>Display the status of ports on a MSDL card for PRI D Channel Diagnostic.</p>
7	<pre>&gt;LD 96 DCH000 .</pre> <pre>.STAT MSDL xx          SDI 7 OVLD PORT 0                         DCH 11 OVLD PORT 1                         AML 12 OVLD PORT 2</pre> <p><b>Note:</b> Where xx = physical MSDL number.</p>
— continued —	

## Multi-purpose Serial Data Link

STEP	ACTION
8	<p>Display the status of an overloaded MSDL port running a D Channel Application.</p> <pre>&gt;LD 96 .DCH000 .  .STAT DCH xx          DCH xx : <b>OVLD</b>                         DES:</pre> <p><b>Note:</b> Where xx = logical D Channel number.</p> <p>You have completed viewing the status of the MSDL card and ports with the applicable overlays.</p> <div></div>



---

## Multi-purpose Serial Data Link

---

### MSDL Status Enquiry Message Throttle

When a D-channel recovers from data link failure, in a Meridian 1 to Meridian 1 network interface, the “network” (master) side of the “network” side to “user” (slave) side interface sends a Status Enquiry message to the “user” side, for every established B-channel, to request the call state.

The Status Enquiry Message Throttle feature regulates the sending of Status Enquiry messages, by limiting the Status Enquiry messages sent within a 128 millisecond time period. The Network side of the interface uses a fixed number of Status Enquiry messages that is configurable per D-channel through a Status Enquiry Message Throttle (SEMT) parameter in LD 17. By reducing the number of Status Enquiry messages sent in a given 128 msec time period, this feature improves the amount of network congestion experienced after a D-channel recovers from data link failure. This also frees up some timeslots for call processing.

### What’s next?

A step-action table covers the prompts related to programming the SEMT parameter in Configuration Record 1 LD 17.

## Multi-purpose Serial Data Link

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to programming the SEMT parameter in Configuration Record 1 LD 17.

STEP ACTION		
1	Log in.	
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
2	LD 17 – Configure the Status Enquiry Message Throttle (SEMT) parameter.	
REQ	CHG	Change existing data.
TYPE	CEQU	Input/output devices.
ADAN	aaa DCH xx	Primary D-channel number: Where: aaa = NEW or CHG xx = 0-63
CTYP	MSDL	Multi-purpose Serial Data Link card.
GRP	0-4	Network Group number for options 81 and 81C.
DNUM	0-15	Device number for I/O ports.
<b>Note:</b> All ports on the MSDL card share the same DNUM. The MSDL card address settings must match the DNUM value.		
— continued —		

## Multi-purpose Serial Data Link

### STEP ACTION

#### 2 continued ...

PORT	0-3	Port number for the MSDL card.
USR	PRI	Primary Rate Interface. D-channel for ISDN PRA only.
IFC	SL1	Meridian SL-1 interface
DCHL	xxx	D-channel PRI loop number. Where xxx = 0-159.
OTBF	1-(32)-127	Output Request Buffer
DRAT		D-channel Transmission Rate
SIDE	NET	Network, the controlling switch.
SEMT	(1)-5	Number of Status Enquiry messages sent within 128 msec from the Network side.
<b>Note:</b> SEMT only applies to the "network" side interface of the Meridian 1 to Meridian 1 network.		
RLS	xx	Release ID of the switch at the remote (far) end of the D-channel.

You have completed the programming required to set the SEMT parameter.



## Multi-purpose Serial Data Link

---

# Incremental Software Management

## Purpose

The Incremental Software Management (ISM) feature provides flexibility and control over system configuration and implementation. With ISM, software ordering and pricing is based on the total count of:

- ◆ Terminal Numbers (TNs),
- ◆ Automatic Call Distribution (ACD) positions (agents and supervisors),
- ◆ ACD Directory Numbers (ACD-DNs and Control DNs),
- ◆ Associate Telephone (AST) DNs,
- ◆ Digital Subscriber Loops (DSLs),
- ◆ Logical Terminal Identifiers (LTIDs),
- ◆ D-channels (DCHs),
- ◆ Application Module Links (AMLs),
- ◆ Recorded Announcement (RAN) Broadcast routes, and
- ◆ RAN and Music Broadcast connections that are to be purchased for a system.

For specific system requirements and limits, refer to the *Pricing Manual*.

---

## Incremental Software Management

---

### ISM counters for X11 Release 24

With X11 Release 24, two ISM counters are added and changes are made to the counting criteria for three existing ISM counters. The new ISM counters are Digital Telephones and Analog Telephones. The changed ISM counters are ACD Agents, AST, and Mobility TNs. The Mobility TNs' counter name has been changed to Wireless Telephones.

The Digital Telephone ISM counter will count every Digital Telephone configured in Overlay 11, except wireless sets. This includes AST sets, ACD agents, and AST sets configured as ACD agents.

The Analog Telephone ISM counter will count every Analog Telephone configured in Overlay 10, except wireless sets and phantom sets. This includes AST sets, ACD agents, and AST sets configured as ACD agents.

### Modified ISM Counters

The ACD Agent counter is modified to exclude Meridian Mail and Call Pilot. All ACD Agents configured in Overlay 10 and 11 count as ACD Agents and Analog Telephones or Digital Telephones counters. See Table 5 for details. The port configured in Overlay 11 for Meridian Integrated Products such as MICB is an ACD Agent. It will count against ACD Agents and Digital Telephones counter.

The AST counter is modified to count against Digital Telephones and AST.

The Wireless Telephones counter (formerly named Mobility TNs) is modified to include CT2 and (M)DECT sets configured in Overlay 10 as well as the currently counted Microcellular sets configured in Overlay 11. See Table 5 for details.

## Incremental Software Management

**Table 5**  
**X11 Release 24 ISMs counted**

A TN configured in Overlay 10 and 11	Release 24 ISMs counted
A digital voice set	Digital Telephones
A digital data set	Digital Telephones
An ATA set	Digital Telephones
An MCA set	Digital Telephones
A Taurus set	Digital Telephones
An Analog set	Analog Telephones
A CLASS set	Analog Telephones
Line-Side T1/E1	Analog Telephones
A Phantom analog set	None
An MCMO (CT2) set	Wireless Telephones
An MDEC set	Wireless Telephones
An Microcellular set	Wireless Telephones
An ACD analog set	ACD Agents and Analog Telephones
An ACD Digital set	ACD Agents and Digital Telephones
An Meridian Mail/Call Pilot ACD port	None
An Meridian Integrated ACD port	ACD Agents and Digital Telephones
An analog AST set	AST and Analog Telephones
A digital AST set	AST and Digital Telephone
An analog AST and ACD set	AST, Analog Telephones and ACD Agents
An digital AST and ACD set	AST, Digital Telephones and ACD Agents
AST and Meridian Mail ACD	None

## Incremental Software Management

### ISM overlay headers

When an Overlay is loaded the available system memory and disk records are output in a header as follows:

With Release 24 and later software, Incremental Software Management (ISM) Header parameters for LD 10 will display as:

```
>ld 10
```

```
PBX000
```

```
MEM AVAIL: (U/P): nnnnnn USED U P: nnnnnn nnnnnn TOT: nnnnnn
DISK RECS AVAIL: xxx
```

```
TNS  AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
ACD AGENTS AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
ANALOGUE TELEPHONES AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
AST  AVAIL: xxx  USED:  xxx  TOT: xxx
```

With Release 24 and later software, Incremental Software Management (ISM) Header parameters for LD 11 will display as follows:

```
>ld 11
```

```
SL1000
```

```
MEM AVAIL: (U/P): nnnnnn USED U P: nnnnnn nnnnnn TOT: nnnnnn
DISK RECS AVAIL: xxx
```

```
TNS  AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
ACD AGENTS AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
AST  AVAIL: xxx  USED:  xxx  TOT: xxx
```

```
DIGITAL TELEPHONES AVAIL: xxx  USED:  xxx  TOT: xxx
```

**Note:** For all ISMs, other than TNs, if the limit of an ISM is set to the maximum value of 32767, the ISM information will not print.



# Instant ISM

## Purpose

The Incremental Software Management limits determine the maximum number of TNs, ACD positions, and other parameters on the Meridian 1. Previously, to increase ISM limits a user had to receive a keycode, deliver it to the Meridian 1, and perform a Sysload. This caused an undesirable service interruption.

The Instant Incremental Software Management (IISM) feature allows ISM limits to be upgraded on the Meridian 1 by delivering the keycode to the Meridian 1, *without* the need for a Sysload.

## Keycode management

During keycode activation via the existing prompts in overlay 143, if the keycode is eligible for instant activation (i.e., ISM parameters are the only parameters that have changed relative to the current system keycode, and no ISM limits are decreasing), the ISM limits will be upgraded “instantly.” Following successful activation, a system message introduced by the Instant ISM feature will be displayed. This message indicates that the keycode was accepted, ISM limits were increased, and that a Sysload is *not* required.

A keycode that is eligible for instant activation has ISM limits that are either unchanged or increased, has no addition or removal of feature packages, and has no changes to software release and issue, software generic, or AUX-ID.

---

## Instant ISM

---

If a keycode is not eligible for instant activation (i.e., ISM parameters are lowered, or software packages are changed), system message CCBR009 (“New keycode accepted. It will be activated during the next restart.”) is displayed and a Sysload *will* be required.

### System requirements

The Instant ISM feature applies to option 51C, 61C, 81, and 81C systems running X11 release 24 or later software.

Each system must be equipped with the NT5D61 IODU/C card to support this feature. The reason for this requirement is that keycode enabling of software (which implements the activation of ISM limits and packages) on these systems requires IODU/C.

ISM limits can only be unchanged or increased - if they are decreased, a Sysload is still required to enable them. This feature does not support adding or removing packages, or changing software release and issue, software generic, or AUX-ID, without the need for a Sysload.

The Meridian 1 does not treat the option 11C MOPT parameter as an ISM limit, but rather as a package. The Instant ISM feature does not support instant MOPT changes. If the MOPT parameter is changed, a Sysload will be required.

### System initialization

If system initialization occurs while a new keycode is being instantly activated, the Meridian 1 software will attempt to complete the keycode activation if at all possible. However, depending on when the initialization occurred, the software may not be able to complete keycode activation.

Therefore, after the system has completed initialization, the craftsperson should print the active ISM parameters via overlay 22. If the printed ISM parameters match the new keycode parameters, then the Meridian 1 software completed the keycode activation

successfully. If the ISM parameters printed are the pre-upgrade parameters, the craftsperson should load overlay 143 to verify whether the new keycode is still on the harddrive by using the “KSHO HD” command. If the new keycode is still on the hard drive, then the craftsperson needs to remove the keycode from the harddrive using the “KOUT” command, and then perform the new keycode installation process again. If the new keycode is not on the harddrive, the craftsperson should perform the new keycode installation process in overlay 143.

## Additional information

### **Incremental Software Management**

Instant ISM does not change the operation of the various ISM limits. Instant ISM simply allows the user to upgrade ISM limits without having to Sysload.

### **IS-41 Networking**

Instant ISM supports the MOB ISM parameter introduced by the IS-41 Networking feature in X11 release 24.

### **RAN and Music Broadcast**

Certain traffic reports peg the number of times the RAN and Music ISM limits had been reached. Due to the fact that ISM limits may change instantly (without a Sysload), a traffic report that is counting the ISM hits over a period may be checking against two different values consecutively. Therefore, for one single calculation period the report will have an aberration.

### **Electronic Brand Line (EBLN/BRAND)**

Unlike other ISM parameters which define the maximum configuration limits for various resources, the BRAND ISM parameter defines which Electronic Brand Line feature option the system is allowed to use.

---

## Instant ISM

---

The same limitation applies to the BRAND parameter as applies to other ISM limits, that is, the BRAND parameter must be unchanged or increased if the ISM limits are to be updated instantly without the need for a Sysload.

Once the BRAND ISM parameter has been increased, the user still has to load overlay 17, in order to configure the actual string that is to be displayed, as per existing operation.

Telephone displays that display brandline information (when in an idle state) will not have the brandline updated immediately. The update will occur on a set the next time LAMPAUDIT audits the set.

### What's next


Step-action tables explain the programming necessary for Instant ISM parameter upgrade operation for each option:

- ◆ Instant ISM parameter upgrade using a keycode diskette
- ◆ Instant ISM parameter upgrade using HyperTerminal

**Note:** For a dual-CPU (redundant) system, leave the system in full redundant mode (hard-disk and CPU redundancy).

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to upgrading ISM parameters.

STEP	ACTION
1	<p>Log in.</p> <p>For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i>.</p>
2	<p>Instant ISM parameter upgrade using a keycode diskette for options 51C - 81C without a sysload.</p> <pre>&gt;LD 143 CCB000 .</pre> <p>Insert the diskette into the floppy drive on the active IODU/C</p> <div>  <p><b>CAUTION</b> Ensure that the new keycode does not lower ISM limits or reduce features compared with the existing keycode.</p> </div>
3	<p>Compare keycodes.</p> <pre>.KDIF REC F0</pre> <p>Currently used keycode (REC) will be compared with the new keycode disk in floppy drive (F0).</p> <p>— continued —</p>

## Instant ISM

### STEP ACTION

#### 3 continued ...

On-screen or printed response. The limits show are for example purposes only.

Validating Keycode File /p/install/keycodes.rec .. OK

Validating Keycode File /f0/keycodes.kcd ... OK

System parameters:      1st keycode: 2nd keycode:

System Serial Number: 46XX                      46XX

Software Version:        2311                      2311

System Type:              Option 61C              Option 61C

Call Processor:            CP68040              CP68040

Release:                   24                      24

Issue:                     XX                      XX

NTI Order Number:

NT SDID - 1:

NT SDID - 2:

Date and Time of Manufacture:

Note:( ) indicates that information is not available

ISM Limits in the            1st keycode: 2nd keycode:

Loop Limit:                  32                      32

Sys TNs Limit:               10                      **11**

ACD Agt Limit:               10                      10

ACD DNS Limit:               10                      10

AST Limit:                   10                      10

.....

Common packages for both keycodes:

0-2 4-5 7-25 28-29 32-55 58-65

.....

Additional packages in the 2nd keycode:

< **30-31**



#### CAUTION

If the new keycode lowers ISM limits or reduces features, do not continue with the .KNEW command.

— continued —

STEP

ACTION

4

Activate the new keycode.

>.KNEW F0

F0 = candidate keycode on diskette in floppy drive /f0

If the keycode is eligible for activation, it will be activated without further user action, and the following system message is given:

CCBR020 New Keycode accepted and activated successfully. Sysload is not needed.

5

Load Overlay 22 and confirm the ISM parameters have been updated.

>LD 22

REQ           SLT

On-screen or printed response. The limits show are for example purposes only.

TNS	32767	LEFT	32765	USED	2
ACDN	24000	LEFT	24000	USED	0
AML	32	LEFT	32	USED	0

IDLE\_SET\_DISPLAY

6

You have completed the programming required to update ISM parameters from a diskette for options 51C - 81C without a Sysload.

END

## Instant ISM

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to upgrading ISM parameters.

STEP	ACTION
1	<p>Log in.</p> <p>For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i>.</p>
2	<p>Instant ISM parameter upgrade using HyperTerminal® for options 51C - 81C without a Sysload.</p> <p>On a PC, access the Meridian 1 system (via a modem) with HyperTerminal® (provided with Windows 95):</p> <p>Click the <b>Start button   Programs   Accessories   HyperTerminal</b>.</p> <p>Double-click the HyperTerminal client to the Meridian 1 system.</p> <p>Log into the Meridian 1 system.</p> <pre>&gt;LD 143 CCB000 .</pre> <p>.KUPL        to upload keycodes to the hard disk on the target system.</p> <p>Click the <b>Transfer</b> menu in HyperTerminal and select <b>Send Text File</b>.</p> <p>From the <b>Files of type</b> pull-down menu, select <b>All Files (*.*)</b>.</p> <p>Locate and select the keycode file on the PC. Use the <b>Look in</b> pull-down menu to select the drive on which the keycode is located.</p> <p>Click <b>Open</b>.</p> <p>The KUPL and keycode will be displayed. Example for display only.</p> <pre>KUPL 0001PBX 0101 9FPAMSRHNN17KRUAFFSPREQEVMTHIDHRKDJHRKEJR56</pre> <p>— continued —</p>



**STEP ACTION****2 continued ...**

Press the **Enter** key.

The KUPL and keycode will be displayed. Example for display only.

KUPL 0001PBX 0101

9FPAMSRHNN17KRUQAFFSPREQEVMTHIDHRKDJHRKEJR56

Press the **Enter** key.

The Keycode is checked for CRC errors and is uploaded to the hard disk.

**CAUTION**

Ensure that the new keycode does not lower ISM limits or reduce features compared with the existing keycode.

**3 Compare the keycode**

KDIF REC HD

Currently used keycode (REC) will be compared with the new keycode on the hard drive (HD).

— continued —

## Instant ISM

## STEP ACTION

**3 continued ...**

On-screen or printed response. The limits show are for example purposes only.

System parameters:      1st keycode: 2nd keycode:

System Serial Number: 46XX                      46XX

Software Version:      2311                      2311

System Type:              Option 61C      Option 61C

Call Processor:          CP68040          CP68040

Release:                  24                      24

Issue:                    XX                      XX

NTI Order Number:

NT SDID - 1:

NT SDID - 2:

Date and Time of Manufacture:

Note:( ) indicates that information is not available

ISM Limits in the      1st keycode: 2nd keycode:

Loop Limit:              32                      32

Sys TNs Limit:          10                      11

ACD Agt Limit:          10                      10

ACD DNS Limit:          10                      10

AST Limit:               10                      10

.....

Common packages for both keycodes:

0-2 4-5 7-25 28-29 32-55 58-65

.....

Additional packages in the 2nd keycode:

< **30-31**

**CAUTION**

If the new keycode lowers ISM limits or reduces features, do not continue with the .KNEW command.

— continued —

**STEP ACTION**

- 4** Activate the new keycode using the KNEW command.

.KNEW XX

XX = **HD** keycode source hard drive

XX = **F0** (floppy drive on Core 0) or **F1** (floppy drive on Core 1)

CCBR020 New Keycode accepted and activated successfully. Sysload is not needed.

- 5** Load Overlay 22 and confirm the ISM parameters have been updated.

>LD 22

REQ SLT

On-screen or printed response. The limits show are for example purposes only.

TNS	32767	LEFT	32765	USED	2
ACDN	24000	LEFT	24000	USED	0
AML	32	LEFT	32	USED	0
IDLE_SET_DISPLAY					

- 6** You have completed the programming required to update ISM parameters using HyperTerminal® for options 51C - 81C without a Sysload.



---

## Instant ISM

---

### Reverting to the previous keycode with the KRVR command


On options 51C, 61C, 81, and 81C systems, the KRVR command can be used to revert to the old keycode “instantly.”

**Note:** The terms “old” and “new” keycode as discussed here refer to the most recent previous KNEW command. The “old” keycode is the former keycode, prior to the KNEW command. The “new” keycode is the keycode that was activated by the KNEW command.

The old keycode is eligible for instant activation with the KRVR command if the only difference between the old keycode and the new keycode is that some or all of the ISM parameters in the old keycode are *higher*.

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to upgrading ISM parameters.

STEP	ACTION
1	Log in.
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .
2	Revert to the previous keycode with the .KRVR command.
	<pre>&gt;LD 143 CCB000 . .KRVR</pre> <p>If the keycode is eligible for instant activation, it will be activated without further user action, and the following system message is given:</p> <p>CCBR020 New Keycode accepted and activated successfully. Sysload is NOT needed!</p>
	You have completed the programming required to revert to the old keycode "instantly" for options 51C - 81C without a Sysload.
	

## Instant ISM


---

## Configuring application module links

### Purpose

The Application Module Link (AML) provides supervisory and control functions for the link that allows host computers and other external processors access to Integrated Services Digital Network (ISDN) network services on the Meridian 1. Tasks performed by the Application Module Link include link activation, fault detection, maintenance, and traffic reporting. The AML provides the association of telephones with one or more Directory Numbers (DN) with the host computer. This allows a computer to access basic telephone features of the Meridian 1. Telemarketing, electronic mail, and other features can take full advantage of ISDN services using the AML.

Procedures for entering the required information are provided later in this section.



---

## Configuring application module links

---

### Applications

A number of applications take advantage of Application Module Links (AML). The configuration of these applications is outside the scope of this guide. For more information about configuring applications, refer to the documentation for the specific application, or refer to the *Input/Output Guide*.

### Interface cards

AML requires the use of an Enhanced Serial Data Interface (ESDI) card or a Multipurpose Serial Data Line (MSDL) card.

AML ports are addressed by logical port number rather than by physical address. The logical number is defined at the ADAN prompt ADAN NEW AML 0-15. The association to the device number or physical address is defined at the DNUM prompt.

#### Multi-purpose Serial Data Interface (MSDL) Card

To configure an MSDL card, refer to the instructions in Task 1 of this guide. Once the MSDL switch settings are verified and the card is installed, use the procedure later in this section to complete programming.

#### QPC513 Enhanced Serial Data Interface (SDI) Card

To set the physical port number on the QPC513 Enhanced SDI card you must be on site at the Meridian 1 installation. Follow the detailed instructions in *Serial Data Interface Cards Description* to locate and remove the card.

Set the physical address using switch S2. The switch settings used to select the address vary depending on whether the card is Style A or Style B. The “Style” can be read on the printed circuit board silk screen. The address of the card is set to match the device address defined in software. (See Table 6.)



## Configuring application module links

**Table 6**  
**QPC513 Enhanced SDI Card address switch settings**

Device Number		Switch S2 style A				Switch S2 style B			
Port 1	Port 2	1	2	3	4	1	2	3	4
0	1	Off	Off	Off	On	Off	Off	Off	*
2	3	On	Off	Off	On	Off	Off	On	*
4	5	Off	On	Off	On	Off	On	Off	*
6	7	On	On	Off	On	Off	On	On	*
8	9	Off	Off	On	On	On	Off	Off	*
10	11	On	Off	On	On	On	Off	On	*
12	13	Off	On	On	On	On	On	Off	*
14	15	On	On	On	On	On	On	On	*

Switch S2 position 4 is not used on Style B cards.

Synchronous port address space is the same as asynchronous port address space. When selecting an address for the ESDI card, make sure that it will not conflict with an address currently being used by an asynchronous card.

The interface for each ESDI port is configured independently. You must configure ports both for the electrical interface (RS-232-C or high-speed) and the mode (DTE or DCE). With the proper options set, an ESDI port configured as DTE appears as a terminal to the user equipment, and an ESDI port configured as DCE appears as a modem to the user equipment. (See Table 7.)

## Configuring application module links

**Table 7**  
**QPC513 Enhanced SDI Card interface mode settings**

Mode	Port	Jumper socket designations	
Data communication equipment (DTE)	1	UA10	UA12
Data terminal equipment (DCE)	1	UA9	UA11
Data communication equipment (DTE)	2	UA17	UA19
Data terminal equipment (DCE)	2	UA16	UA18
RS-232-C interface	1	UB9	UB11
High-speed interface	1	UB10	UB12
RS-232-C interface	2	UB16	UB18
High-speed interface	2	UB17	UB19

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### Saving data

After adding or changing an I/O device by way of the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit overlay 17 by entering \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

## Configuring application module links

### What to have ready

The following checklist summarizes the steps you should take before setting up Application Module Links.

**Table 8**  
**Checklist**

Basic	Optional	Preparation
☐		Identify all application requirements.
☐		Select interface cards to provide each link.
☐		Specify parameters for each link.


### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure Application Module Links.

## Configuring application module links

The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.



Configuring application module links

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of Application Link Modules.

STEP	ACTION	
1	Log in.	
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
2	Set up Application Module Links.	
	<div>&gt;LD 17</div> <div><div>REQ</div><div>CHG</div></div> <div><div>TYPE</div><div>ADAN</div><div>Enter ADAN to create a new AML.</div></div> <div><div>ADAN</div><div>NEW AML 0-15</div><div>Enter NEW AML followed by a device number to create a new application module link.</div></div> <div><div>CTYP</div><div>aaa</div><div>Specify the I/O port card type.</div></div> <div><div>To specify the card type</div><div>Enter</div></div> <div><div>enhanced serial data interface</div><div>ESDI</div></div> <div><div>multipurpose serial data link</div><div>MSDL</div></div> <div><div>DNUM</div><div>0-15</div><div>Enter the device number for I/O ports.</div></div> <div><div>PORT</div><div>0-15</div><div>Enter the port number on MSDL cards.</div></div>	
— continued —		


## Configuring application module links

STEP ACTION		
<b>2 continued ...</b>		
<b>USER</b>	aaa	Specify the user of the port.
<b>To specify the port user</b>		<b>Enter</b>
	ACD printer (for reports)	ACD
	auxiliary processor link for IVMS	APL
	CDR data link	CDL
	communications management center	CMC
	command and status link	CMS
	intercept computer link	ICP5
	customer service changes (automatic set relocation and attendant administration)	CSC
	CDR TTY port (outputting CDR records)	CTY
	ACD/D high-speed AUX link	HSL
	ACD/D low-speed AUX link	LSL
	Meridian Mail administrator maintenance access	LSL
	Property Management System interface	PMS
<b>CUST</b>	0-99	Enter the customer number.
<b>SSUP</b>	(NO) YES	Specify if the port is used by the senior supervisor/load manager. Do not enter YES if you will be configuring the port for an ACD printer.
<b>APRT</b>	(NO) YES	Specify if the port is used by the ACD printer.
<b>AXQI</b>	20-255	Enter the size of the auxiliary input queue. The maximum is 255, or 25% of call registers, whichever is less.
<b>AXQO</b>	20-255	Enter the size of the auxiliary output queue.
— continued —		

Configuring application module links

STEP		ACTION
2 continued ...		
DES	aaa . . . a	Enter an AML port designation (up to 16 alphanumeric characters). Spaces are removed by the system. For example "MERIDIAN MAIL" becomes "MERIDIANMAIL". Use the underscore character instead, such as MERIDIAN_MAIL.
Terminate the overlay by entering ****.		
3 Check your programming.		
If possible, try all applications and links to ensure that they are operating properly. If you cannot check all links at this time, review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the <i>About the Meridian 1</i> section of this guide.		
If	Do	
the programming is correct	step 4	
the programming is not correct	step 1	
— continued —		

## Configuring application module links


STEP	ACTION
4	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>
5	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <pre>NO GO BAD DATA  or  DATA DUMP COMPLETE</pre>
6	<p><b>Terminate this overlay program.</b></p> <pre>.  ****</pre>
— continued —	



---

## Configuring application module links

---

STEP	ACTION
7	<b>Terminate this programming session.</b>  Log off.  >LOGO
8	<b>You have completed the programming required to configure Application Module Links.</b>
	

## Configuring application module links

---

# Configuring history and log files

## Purpose

The Meridian 1 maintains a running log of system events and traffic. This information is stored in log and history files, or output to printers.

## History file feature

If you have a printer connected to the system, each system message is printed as it is received. If you do not have a printer connected, you can use the History File to store a limited number of system messages in protected memory. The contents of the file may then be printed on demand. The messages stored are specified on a system basis and can be one or more of the following types:

- customer service changes (CSC)
- maintenance messages (MTC)
- service changes (SCH)
- software errors (BUG)
- initialization and sysload messages (INI and SYS)
- traffic messages (TRF)

The contents of the History File are erased during a sysload or if you change the History File's length. However, because the History File is located in protected data store, the contents survive an initialization.

---

## Configuring history and log files

---

You can change the length of the History File with the prompt HIST in the Configuration Record (LD 17). The maximum length of the file depends on the amount of protected data store available, which in turn depends on the number of system features that require protected data store.

If the History File is full, the first messages stored are replaced by incoming messages. If this happens, the system gives a “file overflow” message at the start of a printout so you know some information has been replaced by newer messages.


### TTY log files

With the Multi-User Login feature enabled, the log files associated with system TTY terminals record messages relating to service changes, traffic (if not redirected to a Traffic Log File), CDR activity, software bugs, and so forth. Messages recorded in a TTY Log File are not written to the History File.

## Configuring history and log files

### Traffic log files

The Meridian 1 is capable of outputting information about its traffic. During normal operation there can be large amounts of information generated. Traffic information is typically printed out on a high capacity high speed printer. If you choose not to use a printer, you can create a traffic log file instead.



You can create one traffic log file. All system-generated traffic reports are recorded in that file rather than in the History File, making these reports more accessible.

#### Log size

You can specify a size for the traffic log. The larger the log, the more memory it uses up and the greater its ability to buffer during overflow conditions.

#### Traffic parameters

Once you have created the traffic log file, set traffic monitoring parameters in overlay 2. For more information about overlay 2 and the traffic parameters, refer to the *Input/Output Guide*.

## Configuring history and log files

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### Saving data

After adding or changing an I/O device via the ADAN prompt sequence, the data is saved before ADAN is reprompted. This allows you to exit LD 17 with \*\*\*\* after I/O changes without having to carriage return through the remaining prompts.

### What to have ready

The following checklist summarizes the steps you should take before setting up your history and traffic log files.

**Table 9**  
**Checklist**

Basic	Optional	Preparation
☐		Define your history log file requirements and log size.
☐		Define your traffic log file requirements and log size.

---

## Configuring history and log files


---

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure your history and traffic log files.

## Configuring history and log files





Configuring history and log files

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of history and traffic files.

STEP ACTION

1 Log in.

For information on proper login procedures, see *Basic Programming Instructions* in *Basic Telecom Management*.

2 Set up a history file.

>LD 17

REQ	CHG	Enter CFN to change configuration record.
TYPE	ADAN	Enter ADAN to create a new history file.
ADAN	NEW HST	Enter NEW to create a new history file.
SIZE	(0) - 65534	Set the size of the history file buffer.
USER	aaa	Specify the message types to be stored in the History File (one of MTC, SCH, TRF, BUG, CSC).

Terminate the Overlay by entering \*\*\*\*.

— continued —

## Configuring history and log files

STEP	ACTION		
<b>3</b>	<b>Set up a traffic file.</b>		
	>LD 17		
	REQ	CHG	
	TYPE	CFN	Enter CFN to change configuration record.
	ADAN	NEW TRF	Enter NEW TRF to create a new traffic log.
	SIZE	(0) - 65534	Set the size of the traffic log.
	Terminate the overlay by entering ****.		
<b>4</b>	<b>Check your programming.</b>		
	>LD 22		
	REQ	PRT	Enter PRT.
	TYPE	ADAN HST	Enter ADAN HST to verify that a history file was created.
	REQ	PRT	Enter PRT.
	TYPE	ADAN TRF	Enter ADAN TRF to verify that a traffic file was created.
	REQ	****	Terminate the overlay by entering ****.
— continued —			

## Configuring history and log files

### STEP ACTION

- 5** Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

- 6** Verify that the data dump was successful.

On-screen or printed response:

NO GO BAD DATA

or

DATA DUMP COMPLETE

- 7** Terminate this programming session.

Log off.

>LOGO

- 8** You have completed the programming required to configure a history or traffic file.



## Configuring history and log files

---

# Setting up passwords

## Purpose

The Meridian 1 is protected from accidental and malicious tampering by passwords that control access to various overlays and customers, and to the system as a whole.

Configure passwords for all users using overlay 17.

Password control is sophisticated, allowing precise control of the areas of the system available to each password user. The Meridian 1 provides a number of different types of passwords letting you limit access to varying degrees.

## User names

You can force users to log in using a name as well as a password by turning on the login name option. To do this, enter YES at the LNAME\_OPTION prompt in overlay 17. When the option is turned on, ADMIN1 is applied to the current PWD1, ADMIN2 is applied to the current PWD2, USER0 is applied to the current Password 00, USER1 is applied to the current Password 01, and so on to USER 99.

## Multi-user login

With Multi-User Login enabled, more than one user can be logged in with the same combination of name and password. (No two login names can have the same password associated with them.)

---

## Setting up passwords

---

When a HOST user logs in, the outputs set up for the port are only output to that port. For example, if two ports are set up (by way of the USER prompt) to output BUG and SCH messages, and a HOST user logs in to one of these ports, the other port does not output BUG and SCH messages until the HOST user logs out. This feature removes the restriction that ports with the same output must operate at the speed of the slowest port.

### Basic passwords

Basic user passwords provide access to all the overlay programs available on the Meridian 1. They are intended for use by administrators who need access to the entire Meridian 1 system.

To change passwords, log into the Meridian 1 using an existing administration password.

### Administration passwords

The administration password is used to change passwords PW1, PWD2 and SPWD.

To change the first-level administration password, respond to the NPW1 prompt in overlay 17. To change a second-level administration password, respond to the NPW2 prompt.

### Logging in using the second-level administration password

If your system has the login name option enabled (LNAME\_OPTION set to YES), log in by entering ADMIN2 at the LOGIN prompt. Enter the current second level administration password at the PASS prompt.

---

## Setting up passwords

---

### Limited Access to Overlays passwords

If your Meridian 1 has the Limited Access to Overlays (LAPW) package installed, you can allow specific users access to specific overlay programs. This helps maintain system security and can prevent accidental and damaging changes to system data.

You can also use this feature to allow customer administrators direct access to their data on the Meridian 1. The LAPW feature lets you limit an administrator's access to a specific customer's or tenant's data.

Enter the Limited Access to Overlays password number at the LAPW prompt in overlay 17, the password itself at the PWnn prompt, and the overlays available to that password at the OVLA prompt. You can also specify customers available to the password at the CUST prompt, and tenants available at the TEN prompt.

To enable host mode access for the password, respond to the HOST prompt.

### Changing Limited Access to Overlays passwords

To change a password, enter the old password at the NPWD prompt in overlay 17, and the new password at the NLPW prompt.

### Security thresholds

Attempts at password breaking, or hacking, result in lock-outs of affected ports. Lock outs are logged on maintenance terminals and supervisory stations, providing an indication of potential security problems.

---

## Setting up passwords

---

To set the Failed Login Threshold (the number of failed logins needed to trigger a lockout of the port), respond to the FLTH prompt in overlay 17. To set a lock-out time (the time, in minutes, a port is locked out after the Failed Login threshold is exceeded), respond to the LOCK prompt.

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information about Nortel support services, contact your system supplier.



---

## Setting up passwords

---

### What to have ready

The following checklist summarizes the steps you should take before defining passwords.

**Table 10**  
**Checklist**


Basic	Optional	Preparation
☐		Choose user names.
☐		Choose a password for each user name.
	☐	Select appropriate failed login thresholds.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to define passwords.

## Setting up passwords



Setting up passwords

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to passwords.

STEP	ACTION		
1	Log in.		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	Define passwords.		
	>LD 17		
	REQ	CHG	
	TYPE	CFN	Enter CHG to change the Configuration record.
	PWD	YES	Enter YES to configure passwords.
	PWD2	x . . . x	Enter current second level administration password. This password is required to change existing passwords PW1, and PWD2.
— continued —			

## Setting up passwords

STEP	ACTION
<b>2 continued ...</b>	
	<p><b>LNAME_OPTION</b> YES, NO Enter yes to require a login name for password access.</p> <p>If you enter YES, each password currently in the system is given a default name which is used until you assign new names. The default names the system applies to the passwords are:</p> <ul style="list-style-type: none"> <li>— ADMIN1 for current PWD1</li> <li>— ADMIN2 for current PWD2</li> <li>— USER0 for current Password 00</li> <li>— USER1 for current Password 01 (and so on to USER 99)</li> </ul> <p>If you enter YES at the LNAME_OPTION prompt, the system types out:</p> <pre>DEFAULT LOGIN NAMES SAVED</pre> <p>If you change the option from YES to NO, the system assigns random passwords to prevent password duplication. The default password for PWD2 is output to the terminal when this option is disabled. The system types out:</p> <pre>WARNING: PASSWORDS WILL BE CHANGED TO DEFAULT VALUES. OK? (Y/N)</pre> <p>If you then enter Y, the following appears:</p> <pre>DEFAULT PASSWORDS SAVED PWD2 = &lt;pwd2 password&gt;</pre> <p>To find other default passwords assigned by the system, load overlay 22 and print PWD.</p>
— continued —	

Setting up passwords

STEP		ACTION
2 continued ...		
Continue specifying passwords:		
NPW1	x...x	Enter a new level 1 or PW1 Log-in password, or press Return. Valid characters are 0-9, A-Z and a-z. Length is 4-16 characters with Limited Access to Overlays (LAPW) package 164.
LOGIN_NAME	aaa...aaa	Log In name for password access.  When LNAME_OPTION is YES, the names must be associated with each Log In password. This can be up to 11 alphanumeric characters (0-9, A-Z, a-z).
NPW2	x...x	Enter a new second level administration password, or press Return. Valid characters are 0-9, A-Z and a-z. Length is 4-16 characters with Limited Access to Overlays (LAPW) package 164.
LOGIN_NAME	aaa...aaa	Log In name for password access.  When LNAME_OPTION is YES, the names must be associated with each Log In password. This can be up to 11 alphanumeric characters (0-9, A-Z, a-z).
LAPW	nn, Xnn	Enter the LAO Password number, or enter X followed by a password number to delete the number. Valid range is 0-99.
PWTP	(OVLY) SBA	Enter the password type of access Overlay access default or Set Based Administration password access.
— continued —		



## Setting up passwords

STEP	ACTION	
	PWnn	x...x
		Enter the Limited Access to Overlays password to be used for PWnn. Valid characters are 0-9, A-Z and a-z. Length is 4-16 characters with Limited Access to Overlays (LAPW) package 164.
	OVLA	xxx xxx...xxx
		Enter a list of overlay programs to be available using the password PWnn. Valid range is 1-99. Enter ALL to allow access to all overlays, or XALL to prevent access to all overlays.
	CUST	xxx xxx...xxx
		Enter a list of customers to be available using password PWnn. Enter ALL to allow access to all customers, or XALL to prevent access to all customers.
	HOST	YES, NO
		Enter YES to enable the HOST mode login for password PWnn.
	MAT	(NO), YES
		Enable MAT 5.0 Log in for password PWnn.
	OPT	xxxx
		Options for password PWnn. Multiple entries must be separated by a space. (See I/O guide)
	LAPW	nn, Xnn
		Create another LAO Password number, or enter X followed by a password number to delete the number. Valid range is 0-99.
	LOGIN_NAME	aaa...aaa
		Enter a new login name for password access, or press Return. Valid characters are 0-9, A-Z and a-z. Length is up to 11 characters.
	FLTH	0-(3)-7
		Enter a Failed Login Threshold (the number of failed logins needed to trigger a lockout of the port).
	TEN	xxx xxx...xxx
		Enter a list of tenants to be available using password PWnn. Valid range is 1-511. Enter ALL to allow access to all tenants, or XALL to prevent access to all tenants.
	LOCK	0-(60)-270
		Enter a lock-out time (the time, in minutes, a port is locked out after the Failed Login threshold is exceeded).
— continued —		

Setting up passwords

STEP		ACTION	
2 continued ...			
AUDT	(NO) YES	Enter YES to select an audit trail for password use, or NO to suppress the audit trail.	
SIZE	(0)–65534	Enter a word size for the audit trail buffer, or press the return key to assume default values. (This prompt appears only if you enable the audit trail.	
LLID	(NO) YES	Enter YES to provide an identification display of last login and failed login attempts, or NO to suppress the display.	
INIT	(YES) NO	Enter YES to reset locked out ports during a manual initialization, or NO to prevent resets.	
3 Check your programming.			
>LD 22			
REQ	PRT	Enter PRT.	
TYPE	PWD	Enter PWD.	
PWD2	xxxx	Enter the Level 2 password.	
REQ	****	Terminate the overlay by entering ****.	
— continued —			

## Setting up passwords

STEP	ACTION
4	<p>Perform a data dump to permanently store the programming you have just completed.</p> <div data-bbox="325 434 1008 601">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>
5	<p>Verify that the data dump was successful.</p> <p>On-screen or printed response:</p> <pre>NO GO BAD DATA  or  DATA DUMP COMPLETE</pre>
6	<p>Terminate this overlay program.</p> <pre>****</pre>
7	<p>Terminate this programming session.</p> <p>Log off.</p> <pre>&gt;LOGO</pre>
8	<p>You have completed the programming required to configure passwords.</p> <div data-bbox="612 1606 672 1666">  </div>



# Setting up system parameters

## Purpose

You can set system parameters that control how the Meridian 1 uses signal companding, how it handles timeslot faults, and how it uses signaling such as switch-hook flashes and pulse dialing.

The information you enter during this stage of basic configuration is described in detail below. Procedures for entering this information are provided later in this chapter.

**Note:** Attempts to readjust the system parameters without detailed system knowledge could cause severe disruption in service.

## System parameters

To use the  $\mu$ -Law international companding law, enter YES at the INTN prompt. To use the A-law international companding law, enter NO.

To set the maintenance threshold for timeslot continuity faults, respond to the CONT prompt. To set the maintenance threshold for cyclic redundancy check (CRC) continuity faults, respond to the CRCF prompt.

To set the switchhook flash time, respond to the FLSH prompt. To set the off-hook validation timer for an extended flexible analog line card, respond to the TOHY prompt.

To set the minimum time allowed for pulse dialing, respond to the TDP prompt. To set the maximum time for pulse dialing, respond to the TID prompt.

---

## Setting up system parameters

---

### Loss plans

The Meridian 1 compensates for line quality and line characteristics to provide uniform service over a variety of trunk and line types. In order to match itself to a particular type of trunk or line, the Meridian 1 needs information about the line.

As part of configuring EPE, you must enter loss and level information for each trunk. Loss planning can be complex, and is usually done before the Meridian 1 is installed.

#### Selecting tables

When creating a customized loss and level table, or disabling an active table, you must enter a second-level administration password.

To select the North American transmission plan for central-office trunks (COT), enter YES at the NATP prompt. If you are not using the North American transmission plan, enter NO.

Enter the B34 table type at the TTYP prompt. Enter the number of a predefined table, if one is to be used, at the TNUM prompt.

#### Trunk transmit and receive levels

##### Central office trunks

Enter receive and transmit levels for the central office trunk short-line class of service at the COTS prompt. Enter receive and transmit levels for the central office trunk long-line class of service at the COTL prompt.

##### Direct inward and outward dial trunks

Enter receive and transmit levels for the direct inward dial and direct outward dial short-line class of service at the DIDS prompt.

##### TIE trunks

Enter receive and transmit levels for the TIE trunk two-wire compensated class of service at the T2WT prompt. Enter receive and transmit levels for the TIE trunk two-wire uncompensated class of

---

## Setting up system parameters

---

service at the T2WN prompt. Enter receive and transmit levels for the TIE trunk two-wire via-network-loss (VNL) class of service at the T2WV prompt.

Enter receive and transmit levels for the TIE trunk four-wire compensated class of service at the T4WT prompt. Enter receive and transmit levels for the TIE trunk four-wire uncompensated class of service at the T4WN prompt. Enter receive and transmit levels for the TIE trunk four-wire via-network-loss (VNL) class of service at the T4WV prompt.

### Paging trunks

Enter a coded transmit relative input/output level for paging trunks at the PAGT prompt.

### Recorded announcement trunks

Enter a coded receive relative input/output level for recorded announcement trunks at the RANR prompt.

### Analog line cards

If your Meridian 1 has analog line cards installed, enter the analog line card unit short line class of service transmit and receive levels at the ALUS prompt. Enter the long line class of service transmit and receive levels at the ALUL prompt.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Setting up system parameters

### What to have ready

The following checklist summarizes the steps you should take before setting system parameters.

**Table 11**  
**Checklist**


Basic	Optional	Preparation
☐		Decide what system parameters must be set.
☐		Perform loss and level planning.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to set system parameters.

## Setting up system parameters



## Setting up system parameters

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the setting of system parameters.

STEP ACTION	
1	Log in.
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
2	Set loss and level plan parameters.
>LD 97	
REQ	CHG
TYPE	LOSP Change the Loss and Level plan parameters.
NATP	YES, NO Enter YES to select the North American Transmission Plan for generic XFCOT.
TTYP	STAT, DYNM Enter STAT to install a B34 Static Loss Plan Table, or DYNM to install a B34 Dynamic Loss Plan Alternative Level Table.
TNUM	1-27 Enter the predefined table number to be used. The range is 1-27 when using the B34 Static Loss Plan, and 1-5 when using the Alternative Level Table.
Respond to the PWD2 prompt if it appears:	
PWD2	xxxx Enter the Second Level Administration Password. This password is required to "Disable" an active table or "Create" a customized table.
— continued —	

## Setting up system parameters

STEP ACTION

2 continued ...

COTS	8-39 0-31	Enter levels for the Central Office Trunk Short line class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
COTL	8-39 0-31	Enter levels for the Central Office Trunk Long line class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
DIDS	8-39 0-31	Enter levels for the DID/DOD Short line class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T2WT	8-39 0-31	Enter levels for the TIE trunk 2-Wire TRC (Transmission Compensated) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T2WN	8-39 0-31	Enter levels for the TIE trunk 2-Wire NTC (Non-Transmission Compensated) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T2WV	8-39 0-31	Enter levels for the TIE trunk 2-Wire NTC (Non-Transmission Compensated) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T4WT	8-39 0-31	Enter levels for the TIE trunk 4-Wire TRC (Transmission Compensated) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T4WN	8-39 0-31	Enter levels for the TIE trunk 4-Wire NTC (Non-Transmission Compensated) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
T4WV	8-39 0-31	Enter levels for the TIE trunk 4-Wire VNL (Via Network Loss) class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.

— continued —

## Setting up system parameters

STEP ACTION		
<b>2 continued ...</b>		
<b>PAGT</b>	0-31	Enter levels for the paging trunk coded Transmit (D/A) input/output relative level.
<b>RANR</b>	8-39	Enter levels for the recorded announcement trunk coded Receive (A/D) input/output relative level.
Respond to the ALUS and ALUL prompts if they appear:		
<b>ALUS</b>	8-39 0-31	Enter levels for the Analog Line card Unit Short line class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
<b>ALUL</b>	8-39 0-31	Enter levels for the Analog Line card Unit Long line class of service. The first field is the Receive (A/D) level, the second field is the Transmit (D/A) level.
<b>3 Change Peripheral Equipment parameters.</b>		
<b>REQ</b>	CHG	
<b>TYPE</b>	SYSP	Enter SYSP to change system detection and PE parameters.
<b>INTN</b>	YES, NO	Enter YES to change the International companding law to $\mu$ -Law, or NO to change to A-law.
— continued —		



## Setting up system parameters

STEP ACTION		
<b>3 continued ...</b>		
<b>CODE</b>	0	
<b>CONT</b>	1-32767	Enter the maintenance threshold for number of continuity faults per timeslot.
<b>CRCF</b>	1-32767	Enter the Cyclic Redundancy Check (CRC) maintenance threshold for number of continuity faults per timeslot.
<b>FLSH</b>	120-768	Enter the switchhook flash time in milliseconds for 500/2500 sets (NT8D PE only).
<b>TOHY</b>	0-1275	Enter the off-hook validation timer for Extended Flexible Analog Line Card (XFALC)NT5K02.
<b>TDP</b>	15-1275	Enter the minimum time for dial pulse for NT5K02.
<b>TID</b>	0-1275	Enter a maximum time for dial pulse for NT5K02.
<b>TDPO</b>	0-1275	Enter a maximum time for dial pulse for NT5K02.
<b>TPF</b>	0-1275	Enter the post flash timer for NT5K02.
<b>MFRL</b>	0-3	Enter the multifrequency minimum Receiver Level for XMFC/XMFE (NT5K21) for Meridian 1 (superloop) only.
<b>Codes</b>	<b>Level Values</b>	
0	-28 dBmO	
1	-32 dBmO	
2	-36 dBmO	
3	-40 dBmO	
<b>P10R</b>	50-70	Enter a make-break ratio for 12 PPS dial pulse dialing. Range is 50% to 70%, in steps of 1. For example, at 70% the signal is on for 30 ms and off for 70 ms, making a 100 ms cycle for one pulse. To use on individual XUT, XUTJ and XEM trunks, set CLS to P12 in LD 14.
— continued —		

## Setting up system parameters

STEP ACTION		
<b>3 continued ...</b>		
<b>P20R</b>	50-70	Enter the make-break ratio for 20PPS dial pulse dialing. Range is 50% to 70%, in steps of 1. For example, at 70% the signal is on for 15 ms and off for 35 ms, making a 50 ms cycle for one pulse. To use on individual XUT, XUTJ and XEM trunks, set CLS to P20 in LD 14.
<b>INSO</b>	YES, NO	Enter YES to change installation options.
<b>DEFS</b>	YES, NO	Enter YES to accept default sets.
<b>DEF 2006</b>	xxyy	Enter a new default number for 2006 sets, where xx is the old default number.
<b>DEF 2008</b>	xxyy	Enter a new default number for 2008 sets, where xx is the old default number.
<b>DEF 2216</b>	xxyy	Enter a new default number for 2216 sets, where xx is the old default number.
<b>DEF 2616</b>	xxyy	Enter a new default number for 2616 sets, where xx is the old default number.
<b>DEF 500</b>	xxyy	Enter a new default number for 500 sets, where xx is the old default number.
<b>DEF 2500</b>	xxyy	Enter a new default number for 2500 sets, where xx is the old default number.
<b>FNUM</b>	www zzzz	Enter the first DN in the default numbering plan, (where www shows you the current setting).
<b>ISM</b>	YES, NO	Enter YES to enable Incremental Software Management.
<b>TNS</b>	0-32767	Set the maximum number of terminals.
<b>AGNT</b>	0-32767	Set the maximum number of ACD agents.
<b>ACDN</b>	0-32767	Set the maximum number of ACD directory numbers.
<b>AST</b>	0-32767	Set the maximum number of associated sets.
<b>DSL</b>	0-32767	Set the maximum number of digital subscriber loops.
— continued —		

## Setting up system parameters

STEP ACTION

3 continued ...

LTID	0-32767	Set the maximum number of logical terminal IDs.
MOPT	0-11	Select the Meridian Mail option.
KEY1	xxxxxxxx	Enter the first eight digit security key 1 provided by NT.
KEY2	xxxxxxxx	Enter the second eight digit security key 1 provided by NT.
KEY3	xxxxxxxx	Enter the third eight digit security key 1 provided by NT.
XPEC	0-95	Enter peripheral controller numbers. (Enter 0 to have the Meridian 1 assign controller numbers automatically.)
LOC	xxxxxx	Enter a location code for the peripheral controller. The code should be equal to the column number assigned to the system monitor and the universal equipment module that contains the controller.
MED	COP	Select copper cabling for the connection to the peripheral controller.
RGTP	8-16	Set the maximum number of 500/2500 telephones which can be rung at the same time. (Before allowing 16 concurrent ringers, make sure that the NT6D42CA Ringing Generator is installed. Otherwise, intermittent alarms may appear on the ringing generator.)
SUPL	0-156	Enter a Superloop number (a multiple of 4). To create a phantom loop for a third-party application, type <b>C</b> before the number. To create a phantom loop, type <b>N</b> before the number.

— continued —

## Setting up system parameters

STEP ACTION

3 continued ...

ST21	YES, NO	Enter YES if you are configuring an Option 21 system. For all other systems, enter NO.
SLOT	L, R	Specify the side of the slot the network card is installed in. If the card is located in the lower-numbered network pair (the left slot), enter L.
XPEO	x y z	Enter extended peripheral controller 0's number, starting segment, and ending segment. x = Controller number (1-95) for Superloop's shelf 0 y = starting shelf segment number (0-3) z = ending shelf segment number (0-3)
XPE1	x y z	Enter extended peripheral controller 1's number, starting segment, and ending segment. x = Controller number (1-95) for Superloop's shelf 0 y = starting shelf segment number (0-3) z = ending shelf segment number (0-3)


4 Check your programming.

Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.


If	Do
the programming is correct	step 5
the programming is not correct	step 1

— continued —

## Setting up system parameters

STEP	ACTION
5	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>
6	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <pre>NO GO BAD DATA or DATA DUMP COMPLETE</pre>
7	<p><b>Terminate this overlay program.</b></p> <pre>****</pre>
8	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <pre>&gt;LOGO</pre> <p style="text-align: center;">— continued —</p>

## Setting up system parameters

STEP	ACTION
9	You have completed the programming required to set system parameters.
	

# Network configuration

## Network switching

Network switching, based on digital multiplexed loops, interconnects peripheral ports. A loop transmits voice, data, and signaling information over a bidirectional path between the network and peripheral ports.

Network cards digitally transmit voice and data signals, using space switching and time division multiplexing technology. Network switching also requires service loops (such as conference and TDS loops), which provide call progress tones and outpulsing.

Two types of cards provide network switching control:

- the NT8D04 Superloop Network Card, which provides four loops grouped together in an entity called a superloop which supports Intelligent Peripheral Equipment cards
- the QPC414 Network Card, which provides two loops which support Peripheral Equipment cards

## Network organization

On most Meridian 1 system options, network loops are organized into groups. A system is generally configured as one of the following:

- a half-group system that provides up to 16 loops
- a full-group system that provides up to 32 loops
- a multiple-group system that provides up to 160 loops

## Network configuration


An additional switching stage is required between groups in multiple-group configurations. This switching stage, an extension of the originating and terminating network loops, is provided through the intergroup switch cards in Network Modules and the junctor board in the InterGroup Module.

### Superloop network configurations

By combining four network loops, the superloop network card makes 120 timeslots available to IPE cards. Compared to regular network loops, the increased bandwidth and a larger pool of timeslots increases network traffic capacity for each 120-timeslot bundle by 25 percent (at a P0.1 grade of service).

The NT8D37 IPE Module is divided into segments numbered 0–3 of four card slots each (see Figures 2). Segment 0 consists of slots 0–3, segment 1 consists of slots 4–7, segment 2 consists of slots 8–11, and segment 3 consists of slots 12–15.

**Figure 2**  
**Superloop segments in the IPE Module**





---

## Network configuration

---

A superloop is made up of NT8D04 Superloop Network cards, NT8D01AC or NT8D01BC Controller-4 or NT8D01AD Controller-2 cards, and from one to eight IPE segments. The NT8D01BC Controller-4 replaces the NT8D01AC and NT8D01AD Controller cards for replacements and new installations.

A number of superloop-to-segment configurations are possible:


- one segment per superloop requires four superloop network cards and one controller-4 card
- two segments per superloop requires two superloop network cards and one controller-2 card
- four segments per superloop requires one superloop network card and one controller-2 card
- eight segments per superloop requires one superloop network card and two controller-2 cards
- one segment per superloop/three segments per another superloop requires two superloop network cards and one controller-2 card
- two segments per superloop/six segments per another superloop requires two superloop network cards and two controller-2 cards

As an example of a superloop configuration, Figure 3 shows eight segments per superloop. If a segment in this configuration is equipped with analog line cards and trunk cards, a high concentration environment of 120 timeslots to 128–512 terminal numbers (TNs) is provided. If half of the data TNs on digital line cards are enabled, this configuration provides a concentration of 120 timeslots to 768 TNs.

For a detailed description of superloop-to-segment configurations, see *Meridian 1 system engineering* (553-3001-151).

## Network configuration

**Figure 3**  
**Eight segments per superloop**



## Intelligent peripheral equipment

Peripheral equipment is associated with network loops. Intelligent peripheral equipment (IPE) cards are supported by NT8D04 Superloop Network Card loops. The traffic requirements of all peripheral equipment cards provisioned on a particular network loop must match the traffic capacity of that loop.

---

## Network configuration

---

IPE cards are housed in the NT8D37 IPE Module or the NT8D11 CE/PE Module. PE and IPE cards cannot be mixed within a module.

Intelligent peripheral equipment includes:

- controller cards (XPE) that provide timing and control sequences and monitoring capabilities
- analog and digital line and trunk cards that provide interfaces to equipment outside the modules (such as telephones, data terminals, and trunks)

The IPE Module houses one NT8D01 Controller Card and up to 16 IPE cards (such as line and trunk cards), supporting up to 512 terminal numbers (256 voice and 256 data). The controller card is cabled to the NT8D04 Superloop Network Card.

**Note:** The controller card must be installed in the card slot labeled **Cont (for controller)**.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Network configuration

### What to have ready

The following checklist summarizes the steps you should take before configuring Superloops and controllers.

**Table 12**  
**Checklist**


Basic	Optional	Preparation
☐		Identify the network slot which the superloop card will reside in.
☐		Identify the number which will be used by the peripheral controller.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure loops and Superloops.

## Network configuration



## Network configuration

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of loops and Superloops.

STEP		ACTION	
<b>1</b>		<b>Log in.</b>	
		For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
<b>2</b>		<b>Define the XPE: Extended Peripheral Equipment shelf data block.</b>	
		<b>&gt;LD 97</b>	
	<b>REQ</b>	CHG	
	<b>TYPE</b>	XPE	Enter XPE to make changes to Extended Peripheral Equipment shelf data block.
	<b>XPEC</b>	( 0 ) - 95	Enter the Extended Peripheral Equipment Controller number to be created
	<b>LOC</b>	xxxxxxx	Location code for the Peripheral Controller
	<b>MED</b>	( COC )	Connection Media to Peripheral Controller (copper cabling).
	<b>RGTP</b>	( 8 ) 16	Ringling Generator Type (8 or 16 concurrent ringers; 16 requires NT6D42CA Ringling Generator). This prompt determines the maximum number of 500/2500 telephones which can be in the active ringling state at the same time.
— continued —			

## Network configuration

STEP ACTION	
<b>3 Configure Superloops.</b>	
<b>&gt;LD 97</b>	
<b>REQ</b>	CHG
<b>TYPE</b>	SUPL Enter SUPL to configure Superloop parameters.
<b>SUPL</b>	0-156 Enter a Superloop number (a multiple of 4). To create a phantom loop, precede the entry with C.
<b>ST21</b>	YES, NO Enter YES if you are configuring an Option 21 system, or NO if you are configuring another type of system.
<b>SLOT</b>	L, R Enter L if the Network card is in the left slot (the lower numbered network pair), or R if it is in the right slot (the higher numbered network pair).
<b>SUPT</b>	STD, CARR, FIRE Specify the Superloop type. Enter STD for normal copper cable connections between the XNET and XPEC, CARR for Carrier Link Superloop type connections between an LCI and RCI, or FIRE for fibre link connections between an FXNET and an FXPEC.
<b>XPE0</b>	1-95 0-3 0-3 Identify Extended Peripheral Equipment controller 0 (Configured in Step Action 2). Enter the controller number, the starting shelf segment number, and the ending shelf segment number.
— continued —	

Network configuration

STEP ACTION

3 continued ...

XPE1	1-95 0-3 0-3	Identify Extended Peripheral Equipment controller 1. Enter the controller number, the starting shelf segment number, and the ending shelf segment number.
XPEC	1-95	<p>Specify a SUPL. For copper connections, the block is built with all segments (0-3) of the peripheral shelf (RCI) which are associated with this SUPL (LCI). This ensures that one LCI is configured to only one RCI, and that all segments on the RCI are associated with the LCI.</p> <p>For fibre connections, the block is built with all segments (0-3) of the peripheral shelf (FXPEC) which are associated with this SUPL (FXNET). This ensures that one FXNET is configured to only one FXPEC, and that all segments on the FXPEC are associated with the FXNET.</p>
REQ	END	Exit the overlay.

4 Cable the Superloop to the XPE and check programming.

Cable the Superloop to XPE using the cable specified in Installation and Maintenance guide. Review your programming to ensure that no errors were made. Use overlay 97 to examine the contents of the database (REQ = PRT). For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.

If	Do
the programming is correct	step 5
the programming is not correct	step 1

— continued —



## Network configuration

### STEP ACTION

#### 5 Enable the superloop and XPE controller.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 32.

```
> LD 32
```

```
. ENLL xxx <cr>           Enable the superloop configured in step 3.
```

```
. ENXP xx <cr>           Enable the XPE configured in step 4
```

```
. **** <cr>             Exit the overlay.
```

**Note:** The LED on the superloop card will go out if the card is enabled. If the LED does not go out, check to see that the card is in the correct network slot (right or left) and enable the card again.

**Note:** The LEDs of the XPE when enabled should flash the controller number configured in step 3. If the LEDs do not flash the XPE number, suspect a cabling fault with the configured superloop card. Confirm that the superloop is enabled and is correctly cabled to the XPE card. Enable the XPE again.

#### 6 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

```
> LD 43
```

```
. EDD <cr>
```

— continued —

## Network configuration

STEP	ACTION
7	<b>Verify that the data dump was successful.</b>  On-screen or printed response: <b>NO GO BAD DATA</b> or <b>DATA DUMP COMPLETE</b>
8	<b>Terminate this programming session.</b>  Log off.  >LOGO
9	<b>You have completed the programming required to add Superloops.</b>
	

## Service loops and circuits

### Purpose

Service loops and circuits are required in call processing to provide specific functions to satisfy the requirements of a given application. They are system resources. Service circuits also consume system resources, such as physical space, real time, memory and so on. This section will describe how service loops serve trunks and telephone lines, provide conferencing and music.

### Service loop types

#### Tone and digit switch loops

The Tone and Digit Switch (TDS) loop is a part of the dual loop NT8D17 Conf/TDS card. The TDS loop in Meridian 1 provides dial tone, busy tone, overflow tone, ringing tone, audible ringback tone, DP or dual tone multifrequency (DTMF) outpulsing and miscellaneous tones. All these tones are provided through the maximum 30 time slots in the TDS loop.

In other words, the maximum number of simultaneous users of tone circuits is 30, whether it be 30 of one tone or a combination of many different types of tones. One TDS loop is normally recommended for each Network Module or half network group of 14 traffic loops. Additional TDS loops may be added if needed, but this is rare.

**Note:** The NT8D17 Conf/TDS card installs in any network slot, but it is recommended that at least one of these cards be installed in the slot addressing loops 0 and 1. In this case, the conference function of the card will address the odd numbered loop and the TDS function will address the even numbered loop.

---

## Service loops and circuits

---

### Conference loops

The Conference loop is a part of the dual loop NT8D17 Conf/TDS card. It provides circuits for 3-way or 6-way conferences. It can also broadcast music from a source to a maximum of 30 users simultaneously. In addition, a Conference loop also provides temporary hold for a variety of features, chief among them, the End to End Signaling. One Conference loop is normally recommended for each half network group or 14 traffic loops.

**Note:** The NT8D17 Conf/TDS card installs in any network slot, but it is recommended that at least one of these cards be installed in the slot addressing loops 0 and 1. In this case, the conference function of the card will address the odd numbered loop and the TDS function will address the even numbered loop.

### Terminal equipment loops

Terminal equipment loops serve telephones and other terminal devices. To create a single-density terminal equipment loop, respond to the TERM prompt. To create a double-density terminal equipment loop, respond to the TERD prompt. To create a quadruple-density terminal equipment loop, respond to the TERQ prompt.

### Music

MUSic is provided through conferencing a caller to a MUS source. Therefore, a Conference loop is required for the Music on Hold feature. Each set of 30 simultaneous music users will require a Conference loop, thus a NT8D17 Conf/TDS card, since these two service loops are not separable. For a small system, music users can share a conference loop with other applications.

---

## Service loops and circuits

---

### Application and hardware service loops

A number of applications and hardware require the configuration of specific service loops. The configuration of these service loops is outside the scope of this guide. For information about configuring hardware and applications, refer to the documentation for the specific application or hardware. An Example of some of these application or hardware is provided for information purposes.

#### Remote peripheral equipment loops

In addition to supporting peripheral equipment cards collocated with the common equipment, Meridian 1 systems may be configured to support Remote Peripheral Equipment (RPE). Depending on the type of transmission media required between the host site (Meridian 1 system) and the remote site and the type of peripheral equipment cards selected, the following RPE products are supported:

- Remote Peripheral Equipment
- Carrier Remote IPE
- Fiber Remote IPE
- Fiber Remote Multi-IPE

Each of these remote products allow the peripheral cards to be located remotely from the host system. In the case of Remote Peripheral Equipment (RPE) and Carrier Remote IPE, these products allow the system network interface to be converted and transported across commonly used T1 or E1 digital facilities including digital microwave radio. The Fiber Remote IPE and Fiber Remote Multi-IPE products provide the same network conversion requirements, but transported use fiber facilities instead of T1 or E1. All of these products offer the remote users the same level of feature functionality provided to the local users. Essentially, these remote products allow the remote peripherals to function as if they were collocated with the local peripheral equipment.

For more information, refer to the Remote Services Guide.

## Service loops and circuits



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### What to have ready

The following checklist summarizes the steps you should take before configuring loops and Superloops.

**Table 13**  
**Checklist**


Basic	Optional	Preparation
☐		Decide on the required number and types of loops.
☐		Identify the service loop slots to be programmed.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure loops and Superloops.

## Service loops and circuits



## Service loops and circuits

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of loops and Superloops.


STEP ACTION	
1	Log in.
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .
2	Define the Conference and Tone and digit switch loops.
	>LD 17
REQ	CHG
TYPE	CEQU Enter CEQU to make changes to common equipment parameters.
XCT	0, 2, . . . 158 Enter an even loop number for the NT8D17 Conference/TDS/MFS card. The Conference function is automatically assigned to the next higher (odd numbered) loop number. System prints: TDS n MFS n CNF n+1 This indicates that TDS and MFS functions are configured on the even loop "n" and conference function is configured on the next higher odd loop. Precede with X to remove. Both loops must be disabled first. Since TN 0 0 0 0 cannot be used in non-multigroup systems, it is recommended that Conference/TDS/MFS card be placed in loop 0. Configuring more than 16 conference loops may cause the system to lock up.
— continued —	



## Service loops and circuits

STEP ACTION		
2 continued ...		
REQ	END	Exit the overlay.
3 Enable the Conference and Tone and digit switch loops.		
>LD 34		
.	ENLX 1	Enable Conf/TDS/MFS card on loop I and I+1. This command can be used in LD 34, LD 38 and LD 46. Enables the entire combined Conference, Tone and Digit Switch, and MF Sender (NT8D17) card. Both the even numbered TDS/MFS/loop and adjacent conference loop are enabled (loop = 0, 2, 4,... 158). The Conf/TDS card is not enabled automatically when it is inserted.
REQ	****	Exit the overlay.
4 Check your programming.		
<p>Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 32 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.</p>		
If	Do	
the programming is correct	step 5	
the programming is not correct	step 1	
— continued —		


## Service loops and circuits

STEP	ACTION
5	<p>Perform a data dump to permanently store the programming you have just completed.</p> <div><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <p>&gt; LD 43</p> <p>. EDD &lt;cr&gt;</p>
6	<p>Verify that the data dump was successful.</p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>or</p> <p>DATA DUMP COMPLETE</p>
7	<p>Terminate this overlay program.</p> <p>****</p> <p>— continued —</p>

---

## Service loops and circuits

---

STEP	ACTION
8	<b>Terminate this programming session.</b>  Log off.  >LOGO
9	<b>You have completed the programming required to add loops and Superloops.</b>
	

## Service loops and circuits

---

# Configuring memory and buffers

## Purpose

Additional information which you must enter into the Meridian 1 includes:

- ◆ memory configuration
- ◆ buffer sizes

The information you enter during this stage of configuration is described in detail below. Procedures for entering this information are provided later in this chapter.

## Memory

The Meridian 1 can be equipped with different memory options, depending on your requirements and the type of Meridian 1 system you are configuring. Identify your memory configuration during basic configuration.

---

## Configuring memory and buffers

---

### Available configurations

The following memory configurations are available:

#### **128**

*Configuration 128* consists of a 128 Kbyte card as module 0. This configuration is available for all machine Options except 51, 61, and 71.

#### **128 128**

*Configuration 128 128* consists of two 128 Kbyte cards, or one 256 Kbyte card. This configuration is available for all machine Options except 51, 61, and 71.

#### **192**

*Configuration 192* consists of a 192 Kbyte card as module 0. This configuration is available for all machine Options except 51, 61, and 71.

#### **512**

*Configuration 512* consists of a 512 Kbyte card as module 0. This configuration is available for Option 21 systems.

#### **768**

*Configuration 768* consists of a 768 Kbyte card as module 0. This configuration is available for Options 21, 51, and 61.

#### **768 768**

*Configuration 768 768* consists of 768 Kbyte cards as module 0 and module 1. This configuration is available for Option 71.

#### **768 768 768**

*Configuration 768 768 768* consists of 768 Kbyte cards as module 0, module 1 and module 2. This configuration is available for Option 71.

#### **2M**

*Configuration 2M* consists of a 2 Mbyte card.

#### **4M**

*Configuration 4M* consists of a 4 Mbyte card.

---

## Configuring memory and buffers

---

### Buffer sizes

Buffers in the Meridian 1 act to increase high-traffic reliability on critical communications links, including Integrated Services Digital Network (ISDN) D-channel links, terminal console input and output links, and links to telephones. Buffers also serve to protect the integrity of the history file during periods of high activity.

Set the size of buffers based on the expected level of traffic and the need for reliability. When increasing buffer sizes, you are compromising the overall system memory capacity in favor of increased reliability.

### Buffer types

Meridian 1 buffers include:

- ◆ high-priority buffers
- ◆ low-priority buffers
- ◆ 500/2500 buffers
- ◆ Meridian 1 output buffers (OB)

### Password audit buffer

The Meridian 1 lets you track the use of passwords on the system. Use of passwords is written to an audit buffer.

To implement the monitoring of password usage, set the buffer size by responding to the AUDT and SIZE prompts. The size of the buffer depends on the level of activity on your system and the frequency of your security checks. If your system will have very active administrators, make the buffer size large. If the password audit is going to be checked very frequently, the password audit buffer can be smaller.

---

## Configuring memory and buffers

---

### History buffer

The history buffer serves to prevent loss of data being written to the history file. During periods of high system traffic, the output of event records may exceed the ability of the output device to store those records.

The History File stores system messages in Protected Data or P data and uses an SDI port address. The History File survives initialization, but is lost when SYSLOAD occurs or the length of the file is changed.

To set the size of the history file buffer, respond to the SIZE prompt.

### Traffic buffer

The traffic buffer serves to prevent loss of traffic data during periods of high system traffic. The buffer stores system messages in Protected Data or P data and uses an SDI port address. The traffic buffer survives initialization, but is lost when SYSLOAD occurs or the length of the file is changed.

To set the size of the traffic buffer, respond to the SIZE prompt.

### Additional information

For information about recommended buffer sizes, refer to *Meridian 1 System Engineering* and *Capacity Engineering*.

For more information about 500/2500 buffers, refer to *500/2500 Line Cards*. For more information about Meridian 1 output buffers, refer to *SL-1 Telephone Line Cards*.

For information about buffers used for ISDN Basic Rate Interface (BRI), refer to *ISDN Basic Rate Interface*.

If you are installing automatic call distribution (ACD) on the Meridian 1, refer to *Engineering and Assignment of Equipment* to identify additional impacts on Meridian 1 buffers.



---

## Configuring memory and buffers

---

### Traffic studies

Once you have defined your buffers, you need to perform traffic studies to ensure that the buffer parameters are appropriate. For more information about performing and evaluating traffic studies, refer to Task 30, “Completing programming.”

---

## Configuring memory and buffers

---

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

---

## Configuring memory and buffers

---

### What to have ready

The following checklist summarizes the steps you should take before configuring memory.

**Table 14**  
**Checklist**


Basic	Optional	Preparation
☐		Identify your memory configuration.
☐		Calculate your optimal buffer sizes.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure memory.

## Configuring memory and buffers



## Configuring memory and buffers

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of memory.

STEP ACTION		
<b>1 Log in.</b>		
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
<b>2 Set up the password audit trail buffer.</b>		
<b>REQ</b>	CHG	Request
<b>TYPE</b>	CFN	Enter CFN to modify the configuration record.
<b>PWD</b>	YES	Enter YES to modify the password parameters.
<b>PWD2</b>	x . . . x	Enter the current second level administration password.
<b>AUDT</b>	YES	Enter YES to enable a password use audit trail.
<b>SIZE</b>	( 0 ) - 65534	Enter a word size for the audit trail buffer. (Use a multiple of 50.)
<b>REQ</b>	****	Terminate the overlay by entering ****.
— continued —		

## Configuring memory and buffers

STEP ACTION

3 Set the history file and traffic log buffer sizes.

>LD 17

REQ	CHG	Request
TYPE	CFN	Enter CFN to modify the configuration record.
ADAN	CHG HST	Change the history file buffer.
SIZE	(0)–65534	Enter a size for the history buffer.
ADAN	CHG TRF	Change the traffic log buffer.
SIZE	(0)–65534	Enter a size for the traffic log buffer.
REQ	****	Terminate the overlay by entering ****.

4 Set the RPE buffer.

Not all systems require configuration of the Remote Peripheral Equipment (RPE) buffer. Respond to the RPEB prompt below if it appears.

REQ	CHG	Request
TYPE	CFN	Enter CFN to modify the configuration record.
PARM	YES	Enter YES to change system parameters.
RPEB	16–1000	Enter the number of RPE buffers.

— continued —

## Configuring memory and buffers

STEP	ACTION		
5	<b>Configure the CPUs.</b>		
	<p>Not all systems require configuration of CPUs. Respond to the prompts below if they appear.</p>		
	<b>REQ</b>	CHG	
	<b>TYPE</b>	CEQU	
	<b>EXT0</b>	x aaa bbb	Identify extenders for CPU0 (on Option 51, 61, 71, and 81 systems), where <ul style="list-style-type: none"> <li>• x is the group number</li> <li>• aaa is the extender type in the CPU shelf</li> <li>• bbb is the extender type on the network shelf</li> </ul>
	<b>EXT1</b>	x aaa bbb	Identify extenders for CPU1.
	<b>If the configuration is</b>	<b>Enter</b>	
	ACB cables or passive Bus Extender on CPU shelf 0, and no network shelf equipped	0-4 NIL NIL	
	Segmented Bus Extender on CPU shelf 0, and a 3-Port Extender on Network shelf, cabled to the SBE on CPU shelf 0	0-4 SBE 3PE	
	<b>SBE</b>	YES, NO	Enter YES if a segmented bus extender is equipped.
— continued —			

## Configuring memory and buffers

STEP	ACTION																						
<b>6</b>	<p><b>Configure the memory.</b></p> <p>Not all systems require configuration of memory. Respond to the MTYP prompt below if it appears.</p> <p><b>MTYP</b>        <b>xx xx</b>        Select a memory type.</p> <table> <tr> <th>If the configuration is</th><th>Enter</th></tr> <tr> <td>to be determined by prompt MEM</td><td>0</td></tr> <tr> <td>128K card for module 0, except on Options 51, 61 and 71</td><td>128</td></tr> <tr> <td>128K cards for modules 0 and 1, or one 128K card in one module and one 256K card in the other, except on Options 51, 61 and 71</td><td>128 128</td></tr> <tr> <td>192K card for module 0, and module 1 not equipped, except on Options 51, 61 and 71</td><td>192</td></tr> <tr> <td>512K card for module 0 on an Option 21</td><td>512</td></tr> <tr> <td>768K card for module 0 on an Option 21, 51 or 61</td><td>768</td></tr> <tr> <td>768K cards for modules 0 and 1 on an Option 71</td><td>768 768</td></tr> <tr> <td>768K cards for modules 0, 1 and 2 on an Option 71</td><td>768 768 768</td></tr> <tr> <td>2 Mbyte card</td><td>2M</td></tr> <tr> <td>4 Mbyte card</td><td>4M</td></tr> </table> <p>You can enter multiple responses (such as 2M, 2M) for Option 71 systems as long as the total does not exceed four mega-words per CPU. The memory types must be the same; that is, all 2M, or all 768K. You must perform a SYSLOAD to change the memory type from 786K to 2M, or vice versa.</p>	If the configuration is	Enter	to be determined by prompt MEM	0	128K card for module 0, except on Options 51, 61 and 71	128	128K cards for modules 0 and 1, or one 128K card in one module and one 256K card in the other, except on Options 51, 61 and 71	128 128	192K card for module 0, and module 1 not equipped, except on Options 51, 61 and 71	192	512K card for module 0 on an Option 21	512	768K card for module 0 on an Option 21, 51 or 61	768	768K cards for modules 0 and 1 on an Option 71	768 768	768K cards for modules 0, 1 and 2 on an Option 71	768 768 768	2 Mbyte card	2M	4 Mbyte card	4M
If the configuration is	Enter																						
to be determined by prompt MEM	0																						
128K card for module 0, except on Options 51, 61 and 71	128																						
128K cards for modules 0 and 1, or one 128K card in one module and one 256K card in the other, except on Options 51, 61 and 71	128 128																						
192K card for module 0, and module 1 not equipped, except on Options 51, 61 and 71	192																						
512K card for module 0 on an Option 21	512																						
768K card for module 0 on an Option 21, 51 or 61	768																						
768K cards for modules 0 and 1 on an Option 71	768 768																						
768K cards for modules 0, 1 and 2 on an Option 71	768 768 768																						
2 Mbyte card	2M																						
4 Mbyte card	4M																						
— continued —																							



Configuring memory and buffers

STEP ACTION

6 continued ...

CNI	s p g	Specify the core-to-network interface card location (slot 8-12, port 0-1, and group 0- 4).
-----	-------	--

Respond to the following prompts if they appear:

SMEM	YES , NO	Enter YES to choose a short one-pass memory test during manual Sysload, or NO to allow the normal six-pass test.
BATT	YES , NO	Enter YES if a battery backup for memory is installed.
REQ	END	Terminate your programming in overlay 17 and save your updates.


7 Check that your programming is correct.

Review your programming to ensure that it is correct, either by scrolling up in your terminal window or by reading the terminal's printer output. If you are using a terminal without scroll or printing capabilities, use overlay 20 to print out the data you have entered. For more information about overlay 20, see the beginning of this guide.

If	Do
the programming is correct	step 8
the programming is not correct	step 1

— continued —

## Configuring memory and buffers

STEP	ACTION
8	<p>Perform a data dump to permanently store the programming you have just completed.</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;Cr&gt;</pre>
9	<p>Verify that the data dump was successful.</p> <p>On-screen or printed response:</p> <pre>NO GO BAD DATA or DATA DUMP COMPLETE</pre>
10	<p>Terminate this overlay program.</p> <pre>. ****</pre>
11	<p>Terminate this programming session.</p> <pre>&gt;LOGO</pre>
— continued —	

---

## Configuring memory and buffers

---

STEP	ACTION
12	You have completed the programming required to configure memory.
	

## Configuring memory and buffers

---

# Configuring overlay options

## Purpose

A number of overlay program options are available, depending on your needs. Choose the options that best suit your maintenance requirements.

The information you enter is described in detail below. Procedures for entering this information are provided later in this section.

## Date and time

The Meridian 1 system clock provides the time and date used for display on telephones, for the timestamping of logs and call detail recording, and for the scheduling of automatic maintenance routines. Set the time and date in overlay 2 before configuring other overlay options.

## System ID

Each Meridian 1 system has a unique system ID number (SID) from 0000 to 9999. The system ID is used in reports and networking.

The 4-digit ID number can be printed or set by the following commands in overlay 2:

- ◆ To print the current SID: Enter TSID sid
- ◆ To change the SID: Enter SSID sid -- SID

---

## Configuring overlay options

---

For more information, see the step-action procedure later in this guide.

### Keeping overlays in cache memory

Up to 32 overlay programs can reside in the system memory. This reduces the overlay loading time to about one second.

The first time an administrator requests an overlay using the LD command, the overlay is loaded from disk and placed in the cache memory. If the cache area is full, the oldest used non-priority overlay in cache memory is replaced by the new overlay. Background or daily routine overlays are not stored in cache.

To set the number of overlay programs allowed to remain in the cache, respond to the CACH prompt. To specify which overlay programs are of highest priority, and will remain in the cache even when a new overlay is loaded, respond to the PRTY prompt.

**Note:** This feature is not applicable to Options 51C, 61C, 81 and 81C. On these Options, all overlays are loaded into memory.

### Background overlay programs

The Meridian 1 can run overlay programs continuously in the background during normal operations. Background overlay programs can perform ongoing diagnostics and maintenance without affecting system operation. You can specify as many background overlay programs as you need. The Meridian 1 loads these overlays sequentially.

To specify the overlay programs that are to run in the background, respond to the BKGD prompt.

---

## Configuring overlay options

---

### Traffic studies

Consider setting up traffic studies while configuring maintenance schedules and routines. Traffic studies monitor the performance of your system under typical working conditions, and provide the information needed to maintain a high level of service for end users.

For more information about configuring traffic studies and using the information they provide, refer to the *Basic Telecom Management Guide*.

### Automatic maintenance

The Meridian 1 can perform a number of automated maintenance routines at specified intervals or times. Automated maintenance helps to identify and correct faults before users become aware of them.

#### Message waiting lamp tests

The Meridian 1 can be set to test all message waiting lamps at a specified time (ideally when testing will not affect users). To set the time for lamp tests, respond to the PBXH prompt.

#### Daily routines

The Meridian 1 can run sets of diagnostic overlay programs at a specified time. To set the time for the running of daily routines, respond to the TODR prompt. To select the overlay programs to be run during the daily routine, respond to the DROL prompt.

#### Remote peripheral equipment loopback tests

The Meridian 1 can, as part of the daily routines, perform automated 2.0 Mbit/s remote peripheral equipment (RPE) loopback testing. This testing includes local loopback. To specify a loop for testing, respond to the TRLL prompt.

---

## Configuring overlay options

---

### Fault detection

When the Meridian 1 detects a fault during daily routines, it will automatically run a diagnostic program, overlay program 45, to identify the fault condition. To specify the number of times overlay 45 will run after a fault is detected, respond to the CY45 prompt.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. To maximize the effectiveness of your Meridian 1 administration efforts, take advantage of these courses and aids.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.



---

## Configuring overlay options

---

### What to have ready

The following checklist summarizes the steps you should take before setting up your overlay options.

**Table 15**  
**Checklist**


Basic	Optional	Preparation
	☐	Select overlay programs to reside in cache.
☐		Select overlay programs to run in background.
☐		Plan the implementation and scheduling of automated tests.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to set up overlay options.

## Configuring overlay options



## Configuring overlay options

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of overlay options.

STEP	ACTION
1	<p><b>Log in.</b></p> <p>For information on proper login procedures, see <i>Basic Programming Instructions in Basic Telecom Management</i>.</p>
2	<p><b>Check the date, time and system ID.</b></p> <p>&gt; LD 2</p> <ul style="list-style-type: none"> <li>• TSID    Print the system ID.</li> <li>• TTAD    Print the current time and date.</li> </ul> <p>The format of the printed date and time is day-of-week day month year hour minute second.</p> <p>If the time and date are incorrect, update them using the following command:</p> <ul style="list-style-type: none"> <li>• STAD day month year hour min sec</li> </ul> <p><b>Note:</b> Except for the year, the other entries in the time of day output are 2-digit numbers. The year may be any year from 1901 to 2099 inclusive. It may be entered as a full 4-digit field or as a 2-digit short form. The 2-digit short form is assumed to be in the range 1976 to 2075 and the appropriate addition is made when calculating the day-of-week and leap years.</p> <p>Leave overlay 2 by typing ****:</p> <ul style="list-style-type: none"> <li>•            ****            Leave overlay 2.</li> </ul> <p>— continued —</p>

## Configuring overlay options

STEP ACTION

3 Set up automatic maintenance routines and overlay options.

>LD 17		
REQ	CHG	
TYPE	CFN	Enter CFN to change the configuration record.
OVLY	YES	Enter YES to make changes to overlay area options.
SID	xxxxx	Enter the system ID number used for polling in ACD, CDR and traffic reports.
BKGD	xx xx	Enter the number of the diagnostic program to run in the background. More than one program can run in the background, each one running sequentially. Valid programs are 30, 33, 34, 35, 36, 37, 38, 40, 41, 43, 44, 45, 46, 53 and 135. (To remove an overlay, type X before the overlay number.)

More than one overlay can be run in background. They will run sequentially.

**Note:** The data dump routine LD 43 should be reserved for the DROL to preserve data integrity. On Option 51C and 61C systems, overlay 35 is replaced with overlay 135.

PBXH	00-23	Specify the hour at which message waiting lamp maintenance tests are performed.
TODR	00-23	Specify the time of daily routines.
DROL	xx xx	Specify the overlay programs run during daily routines. Valid programs are 30, 32, 33, 34, 35, 36, 37, 38, 40, 41, 43, 44, 45, 46, 51, 53, 60, 61 and 135. (To remove an overlay, type X before the overlay number.)


On Option 21A systems, overlay 35 is always run in the midnight routines even if you do not specify it. On Option 51C and 61C systems, overlay 35 is replaced with overlay 135.

— continued —


## Configuring overlay options

STEP ACTION		
<b>3 continued ...</b>		
<b>CACH</b>	(0) 2-32	Set the number of overlay programs stored in cache buffers. Enter 0 if all overlays are to load from the disk.
<b>PRTY</b>	xx xx xx	Specify priority overlays that are to stay in cache buffers when a new overlay is loaded.
<b>MULTI_USER</b>	(OFF) ON	Enter ON to allow more than one user to log in at a time, or OFF to limit logins to one user.
<b>TRLL</b>	1-31 1-31	Enter numbers for RPE local loopback, to perform complete 2.0 Mb/s RPE loop testing, including local loop back, in the RPE groups as part of the daily routine if applicable.
<b>CY45</b>	(0)-31	Set the number of times overlay 45 is to run once a fault is detected by the Meridian 1. Enter 0 to allow the system to operate without limiting the number of overlay 45 iterations.
<b>REQ</b>	END	Terminate overlay 17.
— continued —		

## Configuring overlay options

STEP	ACTION						
4	<p><b>Check that the overlay options you have programmed are in effect.</b></p> <p>Verify that you programmed the overlay options as intended, either by letting overlay options take effect, or by scrolling through or printing out overlay information.</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>everything is programmed properly</td><td>step 5</td></tr> <tr> <td>everything is not programmed properly</td><td>step 1</td></tr> </table>	<b>If</b>	<b>Do</b>	everything is programmed properly	step 5	everything is not programmed properly	step 1
<b>If</b>	<b>Do</b>						
everything is programmed properly	step 5						
everything is not programmed properly	step 1						
5	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>						
— continued —							

## Configuring overlay options

STEP	ACTION
6	<b>Verify that the data dump was successful.</b>  On-screen or printed response:  NO GO BAD DATA or DATA DUMP COMPLETE
7	<b>Terminate this overlay program.</b>  * * * *
8	<b>Terminate this programming session.</b>  Log off.  >LOGO
9	<b>You have completed the programming required to set your overlay options.</b>
	

## Configuring overlay options

---



# Setting digital telephone parameters

## Purpose

Meridian Digital Telephones are connected to the Meridian 1 by digital links. The links and the operation of Meridian Digital Telephones are controlled by system parameters. Configure these parameters in overlay 17.

The information you enter during this stage of basic configuration is described in detail below. Procedures for entering this information are provided later in this chapter.

**Note:** Attempts to readjust the digital telephone parameters without detailed system knowledge could cause severe disruption in service.

## Meridian Digital Telephones

Meridian Digital Telephones are digital telephones designed to operate with the Meridian 1. They feature adjustable volume controls, handset and headset operation, and automatic gain control.

---

## Setting digital telephone parameters

---

### Parameters

Programmable parameters control how the Meridian 1 communicates with Meridian Digital Telephones to provide voice paths, and how the telephones behave with regards to sidetones and volume levels.

#### CODEC coding

Three coding schemes are available for communicating with Meridian Digital Telephones:

- ◆ Mu law coding
- ◆ Inverted A law coding
- ◆ Even-bit interleaved A law coding

Mu law coding is used in North America. Inverted A law coding is used in Sweden. In other markets, any one of the three coding schemes may be in use.

#### Sidetone loudness

Sidetone loudness does not apply to M2216 telephones. To set sidetone loudness for all other Meridian Digital Telephones, respond to the SOLR prompt.

Changes to sidetone loudness do not take effect until you perform a SYSLOAD.

#### Automatic gain control

Automatic gain control (AGC) acts to maintain a constant volume level despite changing line levels and loudness of speech. To turn AGC on and off for Meridian Digital Telephones, respond to the AGCD prompt.

#### Volume reset

Volume reset operates to set volume levels back to default settings on Meridian Digital Telephones when a call is ended. To turn the volume reset option on or off, respond to the VOLR prompt.

## Setting digital telephone parameters

### Pad values

Respond to the DSET prompt in overlay 73 to set the pad values for Meridian Digital Telephones. Table 16 shows the relationship between pad code and gain or loss.

**Table 16**  
**Pad values**

Code	Value (dB)	Code	Value (dB)	Code	Value (dB)
0	0.0	9	+9.0	18	-4.0
1	+1.0	10	+10.0	19	-5.0
2	+2.0	11	+11.0	20	-6.0
3	+3.0	12	+12.0	21	-7.0
4	+4.0	13	+13.0	22	-8.0
5	+5.0	14	+14.0	23	-9.0
6	+6.0	15	-1.0	24	-10.0
7	+7.0	16	-2.0	25	Idle
8	+8.0	17	-3.0	26	+6.0

Positive dB represents loss, and negative dB represents gain.

Code 0 (pad value 0.0) is equivalent to no pad. It is used for Data Only (DTA) and Voice or Data (VOD) call types.

PCM signals are converted to silence when the pad value is 'idle'.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

## Setting digital telephone parameters

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### What to have ready

The following checklist summarizes the steps you should take before setting Meridian Digital Telephone parameters.

**Table 17**  
**Checklist**


Basic	Optional	Preparation
☐		Identify the CODEC coding scheme used in your market.
	☐	Decide what sidetone levels are required.
	☐	Decide what options are to be turned on or off, including AGC and volume reset.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to program Meridian Digital Telephone parameters.

## Setting digital telephone parameters



## Setting digital telephone parameters

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the programming of Meridian Modular Telephone parameters.

STEP ACTION																		
1	<b>Log in.</b>  For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .																	
2	<b>Set parameters for Meridian Digital Telephones.</b>  >LD 17  <table><tr><td><b>REQ</b></td><td>CHG</td><td></td></tr><tr><td><b>TYPE</b></td><td>ATRN</td><td>Enter ATRN to change parameters for Meridian Digital Telephones.</td></tr><tr><td><b>CODE</b></td><td>0-2</td><td>Select the CODEC coding law.</td></tr></table> <table><tr><td><b>To select</b></td><td><b>Enter</b></td></tr><tr><td>Mu law coding, for North America</td><td>0</td></tr><tr><td>A law coding inverted, for Sweden</td><td>1</td></tr><tr><td>A law coding even-bit interleaved</td><td>2</td></tr></table>	<b>REQ</b>	CHG		<b>TYPE</b>	ATRN	Enter ATRN to change parameters for Meridian Digital Telephones.	<b>CODE</b>	0-2	Select the CODEC coding law.	<b>To select</b>	<b>Enter</b>	Mu law coding, for North America	0	A law coding inverted, for Sweden	1	A law coding even-bit interleaved	2
<b>REQ</b>	CHG																	
<b>TYPE</b>	ATRN	Enter ATRN to change parameters for Meridian Digital Telephones.																
<b>CODE</b>	0-2	Select the CODEC coding law.																
<b>To select</b>	<b>Enter</b>																	
Mu law coding, for North America	0																	
A law coding inverted, for Sweden	1																	
A law coding even-bit interleaved	2																	
— continued —																		

## Setting digital telephone parameters

STEP ACTION

2 continued ...

SOLR	0-4	Select a sidetone objective loudness rating.
To select		Enter
7 dB offset		0
12 dB offset, recommended for North America		1
17 dB offset		2
22 dB offset		3
disabled sidetone		4
AGCD	YES, NO	Enter YES to turn off automatic gain control (AGC), or NO to turn on AGC.
VOLR	YES, NO	Enter YES to turn on volume reset, or NO to turn off volume reset.
REQ	END	Exit the overlay.


3 Set PAD levels for Meridian Digital Telephones.

>LD 73

REQ	NEW	
TYPE	DTI, PRI	Enter DTI or PRI to set PAD levels for for Meridian Digital Telephones
DSET	0-15 0-15	Enter the PAD level for Meridian Digital Telephones.
REQ	END	Exit the overlay.


— continued —

## Setting digital telephone parameters

STEP	ACTION						
4	<p><b>Check that your programming is correct.</b></p> <p>Review your programming to ensure that it is correct, either by scrolling up in your terminal window or by reading the terminal's printer output. If you are using a terminal without scroll or printing capabilities, use overlay 22 to print out the data you have entered. For more information about overlay 22, see the beginning of this guide.</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>parameters are correct</td><td>step 5</td></tr> <tr> <td>parameters are not correct</td><td>step 1</td></tr> </table>	<b>If</b>	<b>Do</b>	parameters are correct	step 5	parameters are not correct	step 1
<b>If</b>	<b>Do</b>						
parameters are correct	step 5						
parameters are not correct	step 1						
5	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43</pre> <pre>. EDD &lt;cr&gt;</pre> <p style="text-align: center;">— continued —</p>						



## Setting digital telephone parameters

STEP	ACTION
6	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>OR</p> <p>DATA DUMP COMPLETE</p>
7	<p><b>Terminate this overlay program.</b></p> <p>***</p>
8	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
9	<p><b>You have completed the programming required to define the parameters for Meridian Modular Telephones.</b></p>
	

## Setting digital telephone parameters

---

# Configuring Peripheral Equipment

## Purpose

Peripheral equipment on the Meridian 1 performs tasks including interface with telephones and with trunks to other telephone systems. To connect your Meridian 1 to its own telephones and to the outside world, you must configure your peripheral equipment.

Information about configuring telephones is provided in Task 27, “Setting up telephones”.

## Peripheral Equipment

Telephones and trunks make the connection with your Meridian 1 through cards that sit on shelves. The shelves are housed in modules called peripheral equipment modules.

More than one telephone or trunk can be connected to each card. The version of the card determines how many can be connected.

There are line cards for telephones and trunk cards for trunks. Unique cards have been designed for each type of telephone and trunk.

There are two versions of cards:

- ◆ Intelligent Peripheral Equipment (IPE)
- ◆ Peripheral Equipment (PE)

Intelligent line cards and trunk cards can have more telephones and trunks connected to them than the older, non-intelligent kinds of cards. This saves room and helps keep your system small.

---

## Configuring Peripheral Equipment

---

Intelligent cards are connected to Superloops. Non-intelligent cards are connected to Loops. Superloops have more timeslots than Loops.

Enhanced Peripheral Equipment (EPE) cards are sometimes called grey cards. They predate IPE cards. EPE cards depend on ENET for support. IPE cards are supported by Superloops.

### Tone senders and receivers

Peripheral equipment includes cards that send and receive tones used for signaling between telephones and telephone systems. As part of peripheral equipment configuration, you must set parameters that control the tone cards as a group.

Later in this guide, you will be asked to enter additional information about specific sending and receiving cards.

### Digitone receivers

Digitone receivers (DTR) listen to tone signals generated by telephones and other telephone systems and translate the signals into dial sequences. When a telephone user picks up the handset and starts dialing out, the DTR converts the tones the user's telephone transmits into a string of numbers (typically the telephone number being called), which the Meridian 1 then uses to process the call.

### Traffic

When installing Digitone receivers, consider the traffic load and the impact of extra traffic on the loop or Superloop to which the receiver is connected. Loops and Superloops perform best when they share equally in the total traffic load offered to the system.

Blockage within the system will be negligible if you keep the traffic load per loop or Superloop within the recommended guidelines. If all your existing loops or Superloops have reached their recommended capacity consider adding more to your system, especially if you will be adding more Digitone receivers, telephones, or data terminals in the future.

---

## Configuring Peripheral Equipment

---

### Prompts

To set the sensitivity of Digitone receivers (the minimum accept level), respond to the MINL prompt.

### Dial tone detectors

Dial tone detectors (DTD) are used by the Meridian 1 to detect dial tone on outgoing trunks. Dial tone detection is configured in software using DTR tables. The Meridian 1 allows up to seven DTR tables. Table 0 comes preconfigured with default settings, and cannot be removed.

You can change the frequency band, sensitivity, delay, and break delay used when detecting dial tone, customizing the Meridian 1 to the dial tone used in your country. Recommended settings for a number of countries are provided in the step-action table later in this section. If your country does not appear on the list, but uses a dial tone similar to one that does, try using the settings suggested for the listed country.

To select a DTR table, respond to the XTDT prompt. To set the frequency band for detection of the first dial tone, respond to the DFQ prompt. To set the sensitivity (the minimum signal level needed to detect the dial tone), respond to the MDL prompt. To set the break delay, respond to the BRK prompt.

### Detecting first- and second-stage dial tone

The Meridian 1 can discriminate between first- and second-stage dial tone by identifying the cadence, or pattern, or the dial tone. First stage dial tone typically has a steady cadence, for example.

To set the cadence type used to detect the first dial tone, respond to the CAD prompt. To set the cadence type used to detect second dial tone, respond to the SSC prompt.

---

## Configuring Peripheral Equipment

---

### Serial data link and signaling cards

Multipurpose serial data link (MSDL) cards provide an interface between the Meridian 1 and external devices. Card types include:

- ◆ Multi-purpose ISDN Signaling Link cards
- ◆ Basic Rate Interface Line and Trunk cards
- ◆ Basic Rate Interface Trunk Universal ISDN Protocol Engine cards
- ◆ Primary Rate Interface Universal ISDN Protocol Engine cards
- ◆ Serial Data Interface cards
- ◆ D-Channel cards
- ◆ Applications Module Link cards

To set the card type and downloading mode, respond to the FDLC prompt. The mode can be either F (for forced download after initialization), or C (for conditional download only if there is a major fault in the firmware or after a power failure).

**Note:** If you select forced download, the setting applies only to the first initialization that takes place after your entry. After an initialization, the system reverts to conditional download.

## Configuring Peripheral Equipment

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### What to have ready

The following checklist summarizes the steps you should take before setting up peripheral equipment.

**Table 18**  
**Checklist**


Basic	Optional	Preparation
Đ		Decide on dial tone detector configuration.
Đ		Decide on Digitone receiver configuration.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure peripheral equipment.

## Configuring Peripheral Equipment





## Configuring Peripheral Equipment

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of peripheral equipment.

STEP	ACTION		
1	<b>Log in.</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in the <i>Basic Telecom Guide</i> .		
2	<b>Set up dial tone detection.</b>		
	<b>&gt;LD 97</b>		
	<b>REQ</b>	CHG	
	<b>TYPE</b>	DTD	Change the Dial Tone Detection parameters.
	<b>XTDT</b>	0-7	Select an Extended Tone Detection Table.
	<b>DFQ</b>	0-15	Select the Dial Tone Frequency band for 1st dial tone.
	<b>In</b>	<b>Enter</b>	<b>To select</b>
	UK (330/440)	0	300-500 Hz
	UK (33/50)	3	0-500 Hz
	France	0	300-500 Hz
	Denmark	1	350-500 Hz
	Germany	1	350-500 Hz
	New Zealand	1	350-500 Hz
	Sweden	1	350-500 Hz
	Norway	1	350-500 Hz
	Spain	2	320-630 Hz
	Switzerland	4	355-550 Hz
	— continued —		

## Configuring Peripheral Equipment

STEP ACTION			
<b>2 continued ...</b>			
<b>MDL</b>	10-40	Select the Minimum Detect Level for 1st Dial Tone.	
<b>In</b>		<b>Enter</b>	<b>To select</b>
UK		30	30 dBm
France		24	24 dBm
Denmark		26	26 dBm
Holland		26	26 dBm
Germany		22	22 dBm
Sweden		28	28 dBm
Norway		30	30 dBm
Spain		32	32 dBm
Switzerland		30	30 dBm
<b>MYT</b>	100-1600	Select the Minimum Validation Time for 1st Dial Tone.	
<b>In</b>		<b>Enter</b>	<b>To select</b>
UK		300	300 ms
France		1000	1000 ms
Denmark		1200	1200 ms
Holland		1200	1200 ms
Germany		900	900 ms
Sweden		300	300 ms
Norway		1000	1000 ms
Spain		1000	1000 ms
Switzerland		400	400 ms
— continued —			

## Configuring Peripheral Equipment

STEP ACTION

2 continued ...

BRK	0-240	Set the Break Duration (maximum) for 1st Dial Tone.	
In		Enter	To select
UK		0	0 ms
France		32	32 ms
Denmark		0	0 ms
Germany		0	0 ms
Sweden		48	48 ms
Norway		0	0 ms
Spain		0	0 ms
Switzerland		0	0 ms
CAD	0-15	Set the Cadence type for 1st Dial Tone. Enter 0 for no cadence or continuous tone. Enter 1 for Italian complex cadence.	
SSC	0-15	Set the Cadence type for second stage dial tone. Enter 0 for no cadence or continuous tone. Enter 1 for Italian complex cadence.	

— continued —

## Configuring Peripheral Equipment

STEP ACTION	
<b>3 Configure Digitone receivers</b>	
<b>REQ</b>	CHG
<b>TYPE</b>	DTR
<b>MINL</b>	3-48
Change the Digitone Receiver parameters.	
Set the Minimum accept Level for Digitone receivers.	
<b>In</b>	<b>Enter</b>
<b>To select</b>	
UK	45
France	30
Denmark	25
Holland	30
Germany	30
Sweden	27
Norway	45
Spain	30
Switzerland	30
New Zealand	45
<b>MDL</b>	100-1600
Select the Minimum Validation Time for 1st Dial Tone.	
— continued —	


## Configuring Peripheral Equipment

STEP	ACTION		
4	Set parameters for MSDL and MISP cards.		
REQ	CHG		
TYPE	SYSM	Change the MSDL and MISP card parameters.	
FDLC	p1 p2 p3 p4	Select a card type and downloading mode.	
To select		For p1, enter	
Multipurpose serial data link cards		MSDL	
Multipurpose ISDN signaling link cards		MISP	
Basic rate interface line cards		BRIL	
Basic rate interface trunk cards		BRIT	
Basic rate interface Universal ISDN Protocol Engine		BRIE	
Primary rate interface Universal ISDN Protocol Engine		PRIE	
Serial data interface cards		SDI	
D-channel cards		DCH	
Application link module		AML	
To select		For p2, enter	
Forced download after initialization		F	
Download only after a major firmware fault or power failure		C	
— continued —			


## Configuring Peripheral Equipment

STEP		ACTION
<b>5 Change Sender parameters.</b>		
<b>REQ</b>	CHG	
<b>TYPE</b>	XCTP	Change the Sender parameters.
<b>CPAD</b>	0, 1	Enter 0 to use software PAD values, or 1 to use PAD values determined by switch settings (on circuit pack NT8D17).
<b>DTMF</b>	0-255	Enter the tone table index of the first DTMF digit used. For North American tones, enter 14.
<b>INTU</b>	YES, NO	Enter YES to insert intrusion tones in conferences, or NO to prevent intrusion tones.
<b>P10P</b>	0-255	Enter the tone table index for primary 10 pps sets. For North American tones, enter 30.
<b>S10P</b>	0-255	Enter the tone table index for secondary 10 pps sets. For North American tones, enter 31.
<b>20PPS</b>	0-255	Enter the tone table index for primary 20 pps sets. For North American tones, enter 32.
<b>6 Set Extended/Network Digitone parameters.</b>		
<b>REQ</b>	CHG	
<b>TYPE</b>	XNPD	Change the Extended/Network Digitone parameters.
<b>XNPD</b>	28	Enter 28, the network loop number for the Network/Digitone receiver (XNPD) card.
<p>The NT8D18 card contains a superloop and 8 Digitone Receivers. It is located in network slot 10 of an Option 21/21A and must be defined as superloop 28. The Digitone Receivers are defined in LD 13.</p>		
<b>XPEC</b>	0-95	Assign a peripheral equipment controller number. (If you enter 0, the Meridian 1 assigns numbers automatically.)
— continued —		

## Configuring Peripheral Equipment

STEP	ACTION						
7	<p><b>Check that your configuration is correct.</b></p> <p>Ensure that peripheral equipment is configured properly.</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>everything works</td><td>step 8</td></tr> <tr> <td>something does not work</td><td>step 1</td></tr> </table>	<b>If</b>	<b>Do</b>	everything works	step 8	something does not work	step 1
<b>If</b>	<b>Do</b>						
everything works	step 8						
something does not work	step 1						
8	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>						
9	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <pre>NO GO BAD DATA  or  DATA DUMP COMPLETE</pre> <p style="text-align: center;">— continued —</p>						

## Configuring Peripheral Equipment

STEP	ACTION
10	<b>Terminate this overlay program.</b>  * * * *
11	<b>Terminate this programming session.</b>  Log off.  >LOGO
12	<b>You have completed the programming required to configure peripheral equipment.</b>
	



# Entering customer data

## Purpose

Each customer in the Meridian 1 has a Customer Data Block (CDB). The CDB is a set of parameters that control specific features and options for the customer. Enter information for each customer who will be sharing the Meridian 1.

---

## Entering customer data

---

### Departmental listed directory numbers

You can group customer telephones together using the Departmental Listed Directory Number (DLDN) feature. Telephones ring as a group.

Each customer can have up to four DLDN groups. Each group is identified by one of the customer's listed directory numbers (LDN).

### Dial intercom groups

You can separate a customer's telephones into Dial Intercom Groups (DIG). Telephones within a group can call each other using one- or two-digit codes, providing intercom-like service. (Two-digit dialing is required for a DIG of more than ten stations.)

A total of 100 telephone extensions can belong to each DIG.

### Night service

Telecommunications needs change during non-business hours. Incoming calls may be routed to a security desk instead of to the attendant. Night service automatically changes the routing of calls during off hours, permitting incoming calls normally directed to the attendant to be routed to another destination.

#### Normal Night Service

With the feature active, the existing Night Service feature is enhanced by providing a night (NITE) prompt for applicable DID trunks. Night numbers for DID trunks can be defined in their respective trunk blocks against the prompt. Attendants will be able to change their night numbers by specifying their corresponding access codes and member numbers using the existing Flexible Night Service feature.

---

## Entering customer data

---

### Group Night Service

The customer is allowed to assign individual Public Switched Telephone Network (PSTN) trunks to one of ten night group numbers (0 to 9). Each Night group has up to ten night directory numbers associated with it. During Night Service, incoming calls on a trunk will be routed to one of the directory numbers associated with that trunk. The actual number called is determined by a Night Service Option number corresponding to the Night Group number programmed by the attendant during day service.

When an incoming call is routed to a busy directory number, an optional Night Call Waiting tone may be applied to that number to notify the user that a call is waiting. The call on the trunk will be queued until the night directory number becomes free.

The same feature requirements apply as for Night Service, as well as the following requirements:

- ◆ Enhanced Night Service does not apply to Auto-terminate trunks.
- ◆ Enhanced Night Service is permanently activated if the system has no attendant and the ENS option is set to YES. In this case, the Night Service Option Number can only be programmed from the Customer Data block (LD 15).
- ◆ Enhanced Night Service makes use of only one Speed Call list as the Night Number Table.
- ◆ The operation of the optional Night Call Waiting Tone is the same as those of the Call Waiting Tone.

Night Service Option 0 and Night Service Group 0 are reserved for the customer Night number and should not be programmed in LD 18.

---

## Entering customer data

---

### Feature interactions

#### Call Waiting

This feature will terminate incoming Night calls to busy DN's by applying Call Waiting. This will be done even if the Night DN is an analog (500/2500 type) telephone with Call Waiting Denied (CWD) Class of Service, or if the Night DN is a Meridian 1 telephone without a Call Waiting (CWT) key assigned.

All telephones (analog 500/2500 type and Meridian 1) will be given Night Call Waiting tone, if the NWT prompt in LD 15 was responded to with "YES", regardless of the Warning Tone (WTA, WTD) Class of Service setting of the set. Meridian 1 telephones will be given Night Call Waiting tone in the handset instead of the speaker buzz for Call Waiting.

#### Direct Inward System Access (DISA)

It is not possible to assign a Night Service Group Number to any trunk that is a member of a route which is set to auto-terminate on a DISA DN.

#### Multi-Tenant Service

Any restrictions that exist in the system preventing individual tenant access to certain routes will not be checked when programming the Night Number Table. It will be up to the craftsperson to ensure all such restrictions are taken into consideration.

The tenant to route restrictions will be enforced when an attempt is made to terminate an incoming call on a Night DN via the Night Number Table. If the termination to the Night DN is not allowed, overflow tone (fast busy) will be given to the incoming trunk.

#### Trunk Barring (Sets)

Any incoming call that is routed by Enhanced Night Service to a set from which it is barred will not be connected. Overflow tone (fast busy) will be given to the incoming trunk instead.

---

## Entering customer data

---

### Trunk to Trunk Barring

Any incoming trunk call that is routed to an outgoing PSTN trunk will be barred if Enhanced Night Service is active. Overflow tone will be given to the incoming trunk instead. This restriction is in addition to the configured trunk barring for the system.

### Warning Tone

All telephones (analog 500/2500 type and Meridian 1) will be given Night Call Waiting tone, if the NWT prompt in LD 15 was responded to with "YES", regardless of the Warning Tone (WTA/WTB) Class of Service setting of the set.

## Special prefix codes

Special prefix (SPRE) codes let telephone users access features that are not available as feature keys on their telephone sets. Users of 500/2500-sets can use SPRE codes to take advantage of advanced call features.

## Attendant directory number

The Attendant Directory Number lets internal telephone and TIE trunk users call the attendant by dialing a code (typically 0).

## Entering customer data

---

### Customer options

You can specify a number of options for each customer. These options are described below.

#### **Camp-on tone**

Camp-on tone is a tone provided to a caller waiting for a called telephone to become idle.

#### **Enhanced busy lamp field**

The customer can have an enhanced busy lamp field on M2250 attendant consoles.

#### **Incoming call indicators**

The customer can have either 10 or 20 incoming call indicators on M2250 attendant consoles. The default is 10.

#### **Trunk group busy lamp field**

This option lets users see on their telephone displays whether trunk groups to specific destinations are busy.


#### **Originating side ringing cadence**

The customer can have ringing cadence determined by the originating party.

## Entering customer data

### Intercept treatments


You must specify intercept treatments to be used for the customer under various situations. When a call cannot be completed, for whatever reason, it is intercepted by the system. The caller may hear a recorded announcement or some kind of tone.



## Entering customer data

### TIE trunk intercepts

When a caller places a call over a TIE trunk to an extension on your Meridian 1, and the call is blocked by your Meridian 1, the caller receives intercept treatment. You can specify what kind of treatment the caller gets.




553-0126T ECD



## Entering customer data

A caller coming into your Meridian 1 over a TIE trunk is likely to be someone calling from one of the customer's other offices. The caller can receive a busy signal, an overflow tone, or be routed to the attendant.




553-0127T ECD

## Entering customer data

### DID trunk intercepts


When a caller places a call over a DID trunk to an extension on your Meridian 1, and the call is blocked by your Meridian 1, the caller receives intercept treatment. You can specify what kind of treatment the caller gets.



553-0128T ECD

## Entering customer data

A caller coming into your Meridian 1 over a DID trunk is likely to be someone calling in from outside the customer. The caller can receive a busy signal, a recorded announcement, or be routed to the attendant.




553-0129T ECD

## Entering customer data

### Attendant console intercept treatments

When an attendant places a call, and the call is blocked by your Meridian 1, the attendant receives intercept treatment. You can specify what kind of treatment the attendant gets.




The attendant can receive a busy signal, overflow tone, or a recorded announcement.

## Entering customer data

### Call redirection

The Meridian 1 provides several forms of call redirection. Call Redirection by Time of Day applies to calls that are redirected by way of Call Forward No Answer or Hunt, to automatically forward to a second, alternate DN, typically after business hours. It allows up to four different alternate time periods to be defined in the Customer Data Block for unanswered (Call Forward No Answer) or busy (Hunt) calls.

Assign Call Redirection by Time of Day to individual telephones using Class of Service. You must also assign alternate time periods and redirection DN's for each telephone.



For example, in an office environment, you may have calls forward to the local attendant during the day, to the International Office from 5PM to 8PM, to the answering service from 8PM to 6AM, and then to the Head Office from 6AM to 8AM.

## Entering customer data

---

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Entering customer data

### What to have ready

The following checklist summarizes the steps you should take before entering customer data.

**Table 19**  
**Checklist**


Basic	Optional	Preparation
☐		Choose an attendant DN.
	☐	Decide what call routings will change during night service.
	☐	Identify departmental listed directory numbers.
	☐	Select special prefix codes.
	☐	Make lists of telephones to be included in dial intercom groups.
	☐	Decide on intercept treatments.
	☐	Plan time-of-day call redirections.
	☐	Select other customer options, as discussed earlier in this section.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to enter customer data.

## Entering customer data





## Entering customer data

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the input of customer data.

STEP	ACTION
1	<p><b>Log in.</b></p> <p>For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i>.</p>
2	<p><b>Print the configuration record.</b></p> <p>&gt;LD 21</p> <p>REQ           PRT</p> <p>TYPE           CDB           Print the configuration record.</p> <p>The system prints out the present customer data.</p> <p>REQ           *****</p> <p>The overlay program ends.</p> <p>Compare the existing data entries on the configuration printouts with the ones required for this installation and make the necessary changes as described in the following procedure.</p>
— continued —	

## Entering customer data

STEP		ACTION	
3	Create a customer number.		
>LD 15			
REQ	CHG		
TYPE	CDB	Create a new customer.	
CUST	0-99	Enter a customer number for the new customer.	
4	Set up departmental listed directory numbers.		
REQ	CHG		
TYPE	LDN_DATA	Define DLDNs.	
CUST	0-99	Enter the customer number.	
OPT	aaa	Specify options.	
DLDN	YES, NO	Enter YES to define DLDNs.	
LDN0	xxxx	Enter a listed DN 0.	
LDA0	1-63 ALL	Identify attendant consoles associated with LDN0.	
LDN1	xxxx	Enter a listed DN 1.	
LDA1	1-63 ALL	Identify attendant consoles associated with LDN1.	
— continued —			

## Entering customer data

STEP ACTION

4 continued ...

LDN2	xxxx	Enter a listed DN 2.
LDA2	1-63 ALL	Identify attendant consoles associated with LDN2.
LDN3	xxxx	Enter a listed DN 3.
LDA3	1-63 ALL	Identify attendant consoles associated with LDN3.
LDN4	xxxx	Enter a listed DN 4.
LDA4	1-63 ALL	Identify attendant consoles associated with LDN4.
LDN5	xxxx	Enter a listed DN 5.
LDA5	1-63 ALL	Identify attendant consoles associated with LDN5.
ICI	0-19 aaa	Turn on attendant incoming call indicators, where aaa is LD0 for incoming call indication of LDN0, LD1 for LDN1, LD2 for LDN2, LD3 for LDN3, LD4 for LDN4, and LD5 for LDN5.

5 Define dial intercom groups.

REQ	CHG	
TYPE	FTR_DATA	Enter FTR_DATA to set customer features.
CUST	0-99	Enter the customer number.
OPT	aaa	Specify options.
DGRP	0-2046	Specify the maximum number of dial intercom groups that can be assigned to the customer. (Enter 0 to disable dial intercom groups.)
INRG	YES, NO	Enter YES to turn on distinctive ringing for this customer's dial intercoms, or NO to leave distinctive ringing turned off.

— continued —

## Entering customer data

STEP		ACTION	
6 Program SPRE.			
SPRE	xxxx	Enter the code assigned as a special prefix (SPRE) code. (Press the RETURN key to leave SPRE unconfigured.)	
7 Set up night service.			
REQ	CHG		
TYPE	NIT_DATA	Enter NIT_DATA to configure night service.	
CUST	0-99	Enter the customer number.	
NIT1	xxx...x	Enter the first Night Service DN. (Press the RETURN key to disable Night Service.)	
TIM1	0-23 0-59	Enter the hour and minute when the first Night Service DN takes effect. TIM1 should be set earlier than TIM2, 3 or 4.	
		To remove the time and force the system to use a 24-hour clock, enter x.	
NIT2	xxx...x	Enter the second Night Service DN. (If you have no second DN, press the RETURN key.)	
TIM2	0-23 0-59	Enter the hour and minute when the second Night Service DN takes over.	
NIT3	xxx...x	Enter the third Night Service DN. (If you have no third DN, press the RETURN key.)	
TIM3	0-23 0-59	Enter the hour and minute when the third Night Service DN takes over.	
NIT4	xxx...x	Enter the fourth Night Service DN. (If you have no fourth DN, press the RETURN key.)	
TIM4	0-23 0-59	Enter the hour and minute when the fourth Night Service DN takes over.	
— continued —			

---

## Entering customer data

---

STEP		ACTION	
8	Specify an attendant DN.		
REQ	CHG		
TYPE	ATT_DATA	Enter ATT_DATA to set attendant console options.	
CUST	0-99	Enter the customer number.	
OPT	aaa	Specify options.	
ATDN	0-xxxx	Enter the attendant DN. (Press the RETURN key to assign 0 as the attendant DN.)	

## Entering customer data

STEP ACTION

9 Select additional options for the customer.


REQ	CHG	
CUST	0-99	Enter the customer number.
OPT	CFF	Select Call Forward forwarding party class of service.
OPT	CTA	Select camp-on tone.
OPT	DBA	Select flexible incoming tones.
OPT	IBL	Select enhanced busy lamp field (for the M2250 attendant console).
OPT	IC2	Select 20 incoming call indicators (instead of 10).
OPT	IHA	Select individual hold.
OPT	ILF	Select busy lamp field (for the QCW-type attendant console).
OPT	ITG	Select trunk group busy lamp field.
OPT	LOA	Select lockout.
OPT	ROR	Specify that originating side determines ringing cadence.
OPT	SBA	Select flexible incoming tones.
OPT	SVA	Select secrecy on attendant consoles.

— continued —

## Entering customer data


STEP		ACTION
<b>10 Define intercept treatments for invalid calls.</b>		
<b>REQ</b>	CHG	
<b>TYPE</b>	INT_DATA	Enter INT_DATA to define intercept treatments.
<b>CUST</b>	0-99	Enter the customer number.
<p>Default entries are shown for each of the following prompts. You can also enter OVF to specify overflow tone, ATN to specify attendant console, RAN to specify recorded announcement, or BSY to specify busy signal. NAP is used when no intercept treatment can be applied.</p>		
<b>ACCD</b>	OVF OVF OVF	ATN Enter an intercept treatment for calls to access-denied numbers (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
<b>CTVN</b>	OVF OVF OVF	ATN Enter an intercept treatment for calls to vacant numbers (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
<b>MBNR</b>	OVF OVF OVF	ATN Enter an intercept treatment for calls to maintenance-busy numbers (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
<b>CTRC</b>	OVF NAP OVF	NAP Enter an intercept treatment for a code or toll restricted call placed by a toll restricted station or Tie trunk (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
<b>CLDN</b>	NAP OVF NAP	NAP Enter an intercept treatment for calls to a listed DN (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
<b>RANR</b>	0-511	Enter a recorded announcement (RAN) route number for RAN intercepted calls (station calls, attendant calls, TIE trunk calls, and DID trunk calls).
— continued —		

## Entering customer data

STEP	ACTION						
11	<p><b>Check your programming.</b></p> <p>Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.</p> <table> <tr> <th>If</th><th>Do</th></tr> <tr> <td>the programming is correct</td><td>step 12</td></tr> <tr> <td>the programming is not correct</td><td>step 1</td></tr> </table>	If	Do	the programming is correct	step 12	the programming is not correct	step 1
If	Do						
the programming is correct	step 12						
the programming is not correct	step 1						
12	<p><b>Arrange for a data dump to be performed.</b></p> <table> <tr> <th>If</th><th>Do</th></tr> <tr> <td>you do not have access to LD 43</td><td>contact your system supplier</td></tr> <tr> <td>you have access to LD 43</td><td>step 13</td></tr> </table>	If	Do	you do not have access to LD 43	contact your system supplier	you have access to LD 43	step 13
If	Do						
you do not have access to LD 43	contact your system supplier						
you have access to LD 43	step 13						
13	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre> <p style="text-align: center;">— continued —</p>						



## Entering customer data

STEP	ACTION						
14	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA or DATA DUMP COMPLETE</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>data dump fails</td><td>contact your system supplier</td></tr> <tr> <td>data dump succeeds</td><td>step 15</td></tr> </table>	<b>If</b>	<b>Do</b>	data dump fails	contact your system supplier	data dump succeeds	step 15
<b>If</b>	<b>Do</b>						
data dump fails	contact your system supplier						
data dump succeeds	step 15						
15	<p><b>Terminate this overlay program.</b></p> <p>****</p>						
16	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>						
17	<p><b>You have completed the programming required to enter customer data.</b></p>						
							

## Entering customer data

---

# Setting up analog trunks

## Purpose

Trunks are communications channels that carry signaling and calls between telephone switches. Trunks link your Meridian 1 to other telephone switches, letting Meridian 1 users access your corporate telephone network or the public switched telephone network (PSTN).

The proper provisioning of trunks is essential to your telephone network access. If trunks are not properly provisioned, users may have difficulty placing calls to destinations served by other telephone switches.

## Trunks

Analog trunks can take many forms, including twisted pair cable, and channels on multiplexed cable. The provisioning in software of these different types of trunks is the same.

### Traffic

When planning to configure new trunks, you should consider the traffic load. Consider the impact of extra traffic load on the loop or Superloop to which the trunk is connected. Loops and Superloops perform best when they share equally in the total traffic load offered to the system.

Blockage within the system will be negligible when the traffic load per loop or Superloop is kept within the recommended guidelines. If all your existing loops and Superloops are at their recommended capacity, consider adding more to your system (especially if you will be adding more digitone receivers, telephones, or data terminals in the future).

## Setting up analog trunks

### Trunk types

#### Automatic Wake Up Recorded Announcement trunks

Automatic wake-up recorded announcement trunks carry the recorded announcements used for the Automatic Wake Up hospitality feature.

#### Common Controlled Switching Arrangement trunks


Common Controlled Switching Arrangement (CCSA) trunks provide connectivity between the Meridian 1 and other telephone switches employing CCSA switching. CCSA trunks carry both incoming and outgoing calls.

#### Central Office trunks

Central office trunks (COT) connect the Meridian 1 to central office (CO) telephone switches, typically part of the public switched telephone network (PSTN).

Incoming calls carried by a CO trunk are routed to the attendant, who then transfers the call to the appropriate extension.

CO trunks carry both incoming and outgoing calls.



---

## Setting up analog trunks

---


You can connect CO trunks to NT8D14AA Universal Trunk Cards.

### Direct Inward Dial trunks

Direct Inward Dial (DID) trunks connect the Meridian 1 to central office telephone switches and carry incoming telephone calls.

DID trunks give remote callers direct dial access to specific extensions on the Meridian 1. Each telephone on the Meridian 1 can have a unique telephone number accessible to callers on the public network.

DID trunks carry only incoming calls.



You can connect DID trunks to NT8D14AA Universal Trunk Cards.

### Foreign Exchange trunks

Foreign exchange (FEX) trunks connect the Meridian 1 to PSTN telephone switches outside the local area. FEX trunks carry both incoming and outgoing calls.

## Setting up analog trunks

You can connect FEX trunks to NT8D14AA Universal Trunk Cards.

### Music trunks

Music trunks carry the recorded music used for Music On Hold. You can connect music trunks to NT8D14AA Universal Trunk Cards.

### Paging trunks

Paging trunks connect the Meridian 1 to equipment used for paging.


Low resistance paging trunks can be connected to NT8D14AA Universal Trunk Cards. You can connect high resistance paging trunks to NT8D15AA E&M Trunk Cards.

### Recorded Announcement trunks

Recorded announcement (RAN) trunks carry the recorded announcements used by the Meridian 1. You can connect RAN trunks to NT8D14AA Universal Trunk Cards.

### TIE trunks

TIE trunks connect the Meridian 1 to a second Meridian 1 at a remote location. TIE trunks carry both incoming and outgoing calls, and make up the company's private network.



---

## Setting up analog trunks

---

You can connect TIE trunks to NT8D14AA Universal Trunk Cards.

### WATS trunks

Wide Area Telephone Service (WATS) trunks provide long distance telephone service within North America at reduced rates.

You can connect WATS trunks to NT8D14AA Universal Trunk Cards.

## Trunk options

### Extended trunks

To identify an extended trunk card, respond to the XTRK prompt in overlay 14. This prompt appears when you define the first Superloop.

Valid trunk cards for extended trunks include:

- ◆ Enhanced Extended Universal Trunk
- ◆ Extended CO trunk card
- ◆ Extended DID trunk card
- ◆ Extended E & M trunk card
- ◆ Extended Flexible E & M trunk card
- ◆ Extended Universal Trunk card

### Firmware timing

To enable Firmware Timing for trunk hook flash, respond to the FWTM prompt in overlay 14. Set this option on a trunk by trunk basis.

### Step-by-step trunks

To configure a step-by-step CO trunk, respond to the SXS prompt in overlay 16.

### PAD level compensation

Select a Pad Category table number by responding to the PDCA prompt in overlay 16.

You can manually define transmit and receive pad levels for analog COT and WATS trunks, analog Foreign Exchange trunks, and analog Direct Inward Dial trunks by responding to the ACO, AFX and ADD prompts in overlay 73. The default pad levels are listed in Table 20.

---

## Setting up analog trunks

---

**Table 20**  
**Default pad levels**

Connection type	Rx PAD Rx code	Rx PAD (dB)	Tx code	(dB)
ACO	11	+4.0	14	+1.0
AFX	11	+4.0	14	+1.0
ADD	11	+4.0	14	+1.0

### Companding

Two forms of signal companding are supported on Meridian 1 trunks: A-law and Mu-law companding. Select Mu-law or A-law companding by responding to the PCML prompt in overlay 16.

### Network Class of Service

The Meridian 1 lets you assign classes of service to trunks, providing control of trunk usage and restrictions in a way similar to telephone class of service. To specify the Network Class of Service group, respond to the NCOS prompt.

### Modem TNs

Specify the modem TN by responding to the MTN prompt in overlay 14. The modem TN can be up to seven digits long. You can also enter a Group Hunt pilot DN. The trunk class of service should be MIA.

### Private line DNs

To specify the Private Line Directory Number, respond to the PRDN prompt in overlay 14.

### Call Modification features restriction

You can allow or deny call modifications on a given trunk. To control the Call Modification restriction, respond to the CMF prompt in overlay 14.

### Release Link Trunk DN

To specify the Release Link Trunk Directory Number, respond to the RLDN prompt in overlay 14.



---

## Setting up analog trunks

---

### Night Service

To set up Night Service on trunks, define a Night Service group number and a Night Service DN. Respond to the NGRP and NITE prompts in overlay 14.

### Auto-terminate DN

To specify an Auto Terminate DN, respond to the ATDN prompt in overlay 14. The DN can be up to seven digits. You can also enter a Group Hunt pilot DN. If a DNIS route is defined, then the response must be an ACD DN. If no DN is assigned, the NITE number of the trunk is used. The auto-termination option must be selected for the trunk route in overlay 16.

### Manual DN

Enter a Manual Directory Number at the MNDN prompt in overlay 14. The DN can be up to seven digits. You can enter a Group Hunt pilot DN. The class of service should be MIA.

### Trunk Group Access Restriction

Trunk Group Access Restriction (TGAR) controls access to the exchange network, TIE trunks, CCSA trunks, and paging and dictation services. Telephones, TIE trunks, Direct Inward System Access (DISA) trunks, Meridian Mail channels, and Authorization Codes can be assigned a TGAR code, which is used to block access to certain trunk groups. There can be up to 32 TGAR codes in use on a system.

Specify a Trunk Group Access Restriction at the TGAR prompt in overlay 14.

### Trunk signaling

To set up trunk signaling on a trunk route, respond to the SIGL, XDIC, and EMTY prompts in overlay 16. Turn Carrier Pad on or off for 4-wire E&M duplex trunks by responding to the CPAD prompt. Configure Loop Dial Outpulsing (LOOP) or Battery Outpulsing by responding to the DLOP prompt.

---

## Setting up analog trunks

---

### Impedance

Set the termination impedance used for Extended E & M trunk cards and Extended Universal Trunk cards by responding to the TIMP prompt in overlay 14. Set the balance impedance by responding to the BIMP prompt.

### Incoming start arrangements

To specify which type of signaling will be used by the trunk to initiate digit sending or collection, respond to the STRI prompt in overlay 14. Your response should reflect the type of operation in use at the near end.

To select Delayed Dial, respond with DDL. The terminating trunk returns an off-hook to the originating trunk, which is interpreted as an instruction not to send digits immediately. This delay allows the terminating end to find and attach digit collections equipment. When the equipment is attached, the terminating end returns on-hook which is interpreted as a signal to start sending digits.

To select Immediate Start, respond with IMM. The terminating trunk is not expected to return a pulse telling the originating end to begin sending digits.

To select Wink or Fast Flash start, respond with WNK. The terminating trunk sends an off-hook/on-hook wink. The pulse is interpreted as a signal that digit collection equipment has been attached.

To select Off-Hook Wink for RLR trunks equipped with a signaling converter, respond with OWK. This mode of operation is similar to wink except that the Meridian 1 waits one second after seizure before sending a wink start pulse. This arrangement applies only to release link remote trunks.

To select Seize Acknowledge for CEPT L1 signaling, respond with SACK. This signaling arrangement is allowed only on TIE trunks using WR4 signaling.

---

## Setting up analog trunks

---

To select Proceed to Send signaling for CEPT L1 signaling, respond with PTSD. This arrangement is allowed only for TIE trunks using WR4 signaling.

To select the RON/TRON start arrangement, respond with RT.

### Outgoing start arrangements

To specify the type of outgoing start arrangement used on the trunk, respond to the STRO prompt in overlay 14. Your response to STRO determines which type of signaling will be used by the trunk to initiate digit sending or collection. Your STRO response should reflect the type of operation in use at the far end.

To select Delayed Dial Immediate Off-Hook Wink for RLR trunks equipped with a signaling converter, respond with DDL.

To select Seize Acknowledge for CEPT L1 signaling, respond with SACK. This response is allowed only for TIE trunks using WR4 signaling.

To select Proceed to Send for CEPT L1 signaling, respond with PTSD. This response is allowed only for TIE trunks using WR4 signaling.

To select a RON/TRON start arrangement, respond with RT.

To select a Wink or Fast Flash start arrangement, respond with WNK.

Specify whether answer and disconnect supervision is required by responding to the SUPN prompt. Specify the type of supervision by responding to the STYP prompt.

To select Automatic Guard Detection for outgoing trunks, respond to the SEIZ prompt.

### Country identification

To identify the country, respond to the PPID and BTID prompts in overlay 14.

---

## Setting up analog trunks

---

### Trunk cards

Trunk cards provide the interface between the Meridian 1 and any connected trunks. Trunk cards reside on peripheral equipment shelves.

Trunk Cards provide the interface between the Meridian 1 and all trunk facilities, including not only public and private network trunks (CO, TIE), but those that connect the Meridian 1 to special features (Recorded Announcement, Paging, and so forth).

The following trunk cards are discussed here:

- ◆ NT8D14AA Universal
- ◆ NT8D15AA E&M

#### Universal Trunk Cards

The Universal Trunk Card supports up to eight trunks.

The Universal Trunk Card can be used with any combination of CO, DID, FEX, RAN, Paging (low resistance), WATS, TIE, or Music trunks.

#### E&M trunk cards

The E&M Trunk Card supports up to four trunks.

The E&M Trunk Card can be used with any combination of two-wire E&M, four-wire E&M, four-wire duplex, Paging (high resistance), or Emergency Recorder trunks.

---

## Setting up analog trunks

---

### Network Attendant Service

Network Attendant Service is a feature that allows attendants to be shared by Meridian 1 switches across a network. Calls that would normally be routed to an attendant at a particular Meridian 1 may be routed to an attendant at a different Meridian 1, perhaps even at a different location, if the local attendant is unavailable.

To allow Network Attendant Service to operate over a trunk route, respond to the NASA prompt in overlay 16.

### Trunk routes

A trunk route is a set of trunks that link your Meridian 1 with a specific remote telephone switch. A trunk route carries all calls of a specific type between two switches.


A trunk route can consist of a single trunk, or multiple trunks. A single trunk route can include different types of physical trunk, but all the trunks in a trunk route must be set up the same way in software. Billing and routing information must be the same.

When you provision trunk routes, you are identifying the far end of each trunk available to the Meridian 1. When a call is dialed to a destination outside your Meridian 1, the Meridian 1 identifies the appropriate telephone switch at the destination and uses one of the trunks in the trunk route linking it to that switch.

For example, if your Meridian 1 serves the Head Office and it is linked to another Meridian 1 at the Sales Office by trunk route 21, it will route any call to the Sales Office over one of the trunks in route 21.

## Setting up analog trunks

### Examples of trunk routes



The Meridian 1 has certain maximum limits on the allocation of trunks and trunk routes. For more information about these limits, refer to the *System Overview*.

---

## Setting up analog trunks

---

Each route on the Meridian 1 belongs to a particular customer. On Meridian 1 systems serving more than one customer, you must allocate routes on a customer by customer basis.

### Route numbering

Route numbers uniquely identify a route on the Meridian 1. No two routes can the same number on the same Meridian 1.

A particular route has different route numbers at either end of the route. The route number does not have to be the same at both ends of the route. Route numbers on the Meridian 1 range from 0-511.

### Incoming and outgoing trunks

To configure the trunk route for incoming and outgoing trunks, respond to the ICOG prompt in overlay 16. You can set up the route for incoming only, outgoing only, or both incoming and outgoing trunks.

### Meridian 911 routes

Meridian 1 supports 911 trunk routes. Respond to the M911\_ANI prompt in overlay 16 to enable automatic number identification (ANI) on 911 routes. Specify the 911 ANI trunk type by responding to the M911\_TRK\_TYPE prompt and the NPID\_TLB\_NUM prompt.

### Private line routes

Private routes can be configured individually by the customer on any available CO trunk route. To configure a private line route, respond to the PRIV prompt in overlay 16.

### Radio Paging routes

Radio Paging routes connect the Meridian 1 to radio paging equipment. To configure a route for radio paging, respond to the RPA prompt in overlay 16.

### TIE trunk routes

To configure TIE trunk routes, respond to the CNYT, DDMI, and ATDN prompts in overlay 16.

---

## Setting up analog trunks

---

### DID trunk routes and IDC

To configure Incoming DID Digit Conversion for DID trunk routes, respond to the IDC, DCNO, NDNO, DEXT and DNAM prompts in overlay 16.

### DOD trunk routes and charging

Configure the method of charging for a DOD trunk route by responding to the CHRG prompt in overlay 16. You can charge by the block or by the line.

### Electronic Switched Network

Respond to the ESN prompt to enable ESN pad control. Respond to the INAC and SPN prompts to insert an ESN Access Code to incoming private network calls.

### Earth-orbiting satellite routes

The Meridian 1 can accommodate routes over satellite links. Satellite links have special timing needs due to the delays in end-to-end transmission. To configure a trunk route that uses an earth-orbiting satellite, respond to the SAT prompt in overlay 16.

### Internal and external routes

The Meridian 1 lets you designate trunks as being internal or external. You can use these designations to control call and intercept treatments and other trunk properties. Trunk routes connecting your Meridian 1 to other nodes within your company are usually designated Internal. Trunk routes to points outside your company are usually designated External.

To designate a trunk route as internal or external, respond to the RCLS prompt in overlay 16.

### Far end port types

#### Analog TIE trunk routes

For analog TIE trunks, enter ATT at the PTYP prompt. When the Meridian 1 has one or more digital satellite trunk routes or DST to any digital satellite telephone switch that includes OPX telephones, respond with AOT.



---

## Setting up analog trunks

---

If the trunk route uses earth-orbiting satellites, enter AST at the PTYP prompt.

### Analog CO trunk routes

For analog CO trunks, enter ACO at the PTYP prompt. For analog toll office trunks, enter ATO.

## Auto termination

To enable auto-termination on a trunk route, respond to the AUTO prompt in overlay 16. Other auto-terminate options include Automatic Camp-On and ACD DNIS.

### Automatic Camp-on

The Automatic Camp-on option camps calls on to busy auto-terminate lines. To enable to disable this option, respond to the ACMP prompt in overlay 16.

### ACD DNIS routes

To identify an ACD DNIS route, respond to the DNIS prompt. To set the number of DNIS digits, respond to the NDGT prompt. Select the first or last DNIS digits by responding to the WDGT prompt.

To include the DNIS number in CDR records, respond to the DCDR prompt.

## Automatic Number Identification (ANI) route

To identify an in-band ANI route, respond to the IANI prompt.

Set the ANI identifier number at the ANTK prompt. Together with the ANLD and ANI Listed DN defined in overlay 15, the total number of digits must be no less than 7.

Enable or disable the ANI dial tone at the ANDT prompt.

---

## Setting up analog trunks

---

### Recorded announcement trunk routes

Select a recording device for each RAN trunk by responding to the RTYP prompt in overlay 16. Enter AUD for Audichron or Cook 212 units, CAP for Code-a-Phone units, CK2 for Cook 201 or QAY1 units, CKM for Cook 201 Multichannel units, CON for NT7M Digital Recorders, and DGT for 213300 and 213400 Digital Recorders.

Specify the number of recorded-announcement repetitions by responding to the REP prompt. Set the treatment provided once the recorded announcement ends by responding to the POST prompt. You can disconnect callers or route them to the attendant.

Set up the RAN start arrangement by responding to the STRT prompt. You can connect calls to the recording immediately (which may stop ringback well before the recording starts), or delay the call connection until the beginning of the recording.

YOU can turn Return Answer Supervision on or off at the ASUP prompt. You can also have Return Answer Supervision sent only to CO trunk originators.

### CAMA trunk routes

To configure the signaling interface for CAMA trunks, respond to the SIGL prompt in overlay 16.

To configure the format for CAMA trunk signaling, respond to the FORM prompt. Three formats are available: M1A, M2B, and M3C.

### Trunk tromboning

To turn trunk tromboning on or off for a trunk route, respond to the TRMB prompt in overlay 16. If tromboning is turned on, incoming calls on the route may be routed directly back out on the same route. If tromboning is turned off, incoming trunk calls on the route may not be routed directly back out on the same route.

---

## Setting up analog trunks

---

### Outgoing trunk member selection

You can control the way that the Meridian 1 selects outgoing trunks by responding to the SRCH prompt. Linear hunting starts with the highest trunk number (used for two-way trunks). Round robin hunting starts with the trunk next lower from the one last seized (used for outgoing trunks).

### Alternate trunk routes

Set the alternate trunk route for outgoing trunks by responding to the STEP prompt.

### Access codes

Specify the access code for the trunk route at the ACOD prompt. Ensure that the access code fits into the established numbering plan.

### Calling party privacy (CPP)

Enable the calling party privacy option by responding to the CPP prompt in overlay 16. When the option is turned on, the CPP feature is recognized on the trunk route.

To turn on the CPP flag for incoming trunk calls tandemed to this trunk route, respond to the TCPP prompt.

Specify a privacy indicator for Digitone trunks by responding to the DTPI prompt. You can specify up to four digits. (Only the first digit can be an asterisk.)

Specify a privacy indicator for dial pulse trunks by responding to the DPPI prompt. You can specify up to four digits.

### Trunk Group Access Restriction

To configure Trunk Group Access Restriction (TARG), respond to the TARG prompt in overlay 16 with the TARG range.

### ADM

#### Trunk guard timer

To set the ADM trunk guard timer, respond to the ATGT prompt in overlay 16.

---

## Setting up analog trunks

---

### Step-forward ring cycles

To specify the number of ADM step-forward ring cycles, respond to the ASTP prompt in overlay 16.

### Scheduled Access Restriction

Select a Scheduled Access Restriction (SAR) group for a trunk route by responding to the SGRP prompt in overlay 16.

### Code restriction

Specify the actual outgoing toll digits to be ignored for code restriction by responding to the OABS prompt. (This option is useful for handling 1+ type calls.)

### CAMA trunk routes

Set the CAMA trunk route category digits at the CAT prompt in overlay 16. Set the identification digit for CAMA trunk routes at the ID prompt.

### Super Trunk groups

To turn the Super Trunk feature on or off for the trunk route, respond to the STRK prompt in overlay 16. If the feature is turned on, select the length of digit outpulsing at the SPTO prompt. Enter YES to select 3 digit outpulsing on ANI calls, or NO to select 7-10 digit outpulsing.

### KP signal suppression

Turn KP signal suppression on or off at the ANKP prompt in overlay 16.

### Japan central office trunks

Specify the number of Japan CO digits at the JDGT prompt in overlay 16. This indicates the number of address digits sent from the CO to the Meridian 1. If you do not know the number of digits being sent, set the parameter to (4).

### Identification of outgoing calls

To turn identification of outgoing calls on or off, respond to the AIOD prompt in overlay 16.

---

## Setting up analog trunks

---

Specify the AIOD customer number at the ACNO prompt. Specify the AIOD route number at the ARNO prompt and the AIOD identifier number at the ATTK prompt.

### Signaling arrangement

Configure the signaling arrangement at the SIGO prompt in overlay 16. Enter STD for the standard signaling arrangement. For NCOS, TCOS and CCBQ call types enter ESN2. To include network transfer and Satellite Link Control, enter ESN3.

Enter ETN for electronic TIE network signaling.

### Call Detail Recording

To turn CDR on for incoming calls, respond to the INC prompt in overlay 16. To turn CDR on for outgoing calls, respond to the OAL prompt. To turn CDR on for outgoing toll calls, respond to the OTL prompt.

Specify the contents of CDR records by responding to the LAST, TTA, ABAN, QREC, CDRX, OPA, CCO, AIA and OPD prompts.

Specify the number of digits to record at the NDP prompt.

### North American toll scheme

To select the North American toll scheme, respond to the NATL prompt in overlay 16. Specify toll digits at the TDG prompt.

### Special service list number

Enter the Special Service List (SSL) number at the SSL prompt in overlay 16. The SSL number is used to identify special service calls on route. The list must be defined in overlay 18.

### Equal access restrictions

To enable or disable equal access restrictions, respond to the EQAR prompt in overlay 16. To control North American toll calls, respond to the NTOL prompt. To control International toll calls, respond to the ITOL prompt.

---

## Setting up analog trunks

---

### Tone detector

To determine the requirement for a tone detector, respond to the TDET prompt in overlay 16. Select a tone table by responding to the TTBL prompt. (Tone tables are defined in overlay 56.)

### Malicious Call Trace

Enable or disable the Malicious Call Trace (MCT) signal at the MCTS prompt in overlay 16. Define the call trace request string at the MCCD prompt. Specify the digit string delay time at the MCDT prompt.

Turn the MCT alarm on or off for external calls at the ALRM prompt.

### Called Party Control

Turn Called Party Control on or off at the CDPC prompt in overlay 16.

### Call Number Identification

Set the number of digits that need to be received before CNI is requested by responding to the NCNI prompt in overlay 16.

To have the Meridian 1 request CNI after an ESN code is dialed, respond to the CNIE prompt.

To turn on Call Number Identification Trace, respond to the CNIT prompt. The system will request CNI digits only if the dialed station has MCTA class of service.

### Busy Tone time

You can specify a Busy Tone Time at the BTT prompt in overlay 16. The BTT is the duration of busy or overflow tone to be returned on DID routes.

### ANI

For some configurations you can configure a Local Exchange Code (LEC). The LEC is used for ANI messages. Define the LEC at the LEC prompt in overlay 16. Specify any additional digits to be used in ANI sequences at the ADDG prompt.

---

## Setting up analog trunks

---

You can specify an ANI category for an incoming trunk by responding to the CAC prompt when the CIST package is equipped. CAC is used in ANI messages on outgoing trunks connected to this trunk route. You can also configure an ANI DN at the ANDN prompt. Set the remote DN length used to extract the necessary number of DN digits from caller ID at the RDNL prompt.

### Acknowledgement seizure signal

Turn Acknowledgement Seizure Signal on or off at the ACKW prompt in overlay 16.

### Periodic Clearing signal

Turn the Periodic Clearing Signal on or off at the PECL prompt in overlay 16.

### Trunk disconnection time

You can control the trunk disconnection time by responding to the DCTI prompt in overlay 16. Specify the time, in seconds, that an extension is allowed to ring or be On-Hold or Call Park before the trunk is disconnected. You can also turn trunk disconnection off by entering 0.

### Monitoring

You can turn monitoring on or off for the route by responding to the MON prompt.

## Setting up analog trunks

### Analog trunk examples (Overlay 16 and 14)

#### 1. Creating a Central Office Trunk (COT)

1 Create a Route Data Block (RDB) for the COT in Overlay 16			
>LD 16			
REQ	NEW		
TYPE	RDB	Enter RDB to create a route data block.	
CUST	0	Enter 0 as the customer number.	
ROUT	1	Enter 1 as the route number to be created.	
TKTP	COT	Trunk type will be central office trunk.	
PTYP	ACO	Specify the port type as the far end to be analog central office.	
ICOG	IAO	COT is incoming and outgoing.	
ACOD	9	Enter 9 as the access code for this route.	
TARG	0	Enter 0 for the trunk access restriction group.	
— continued —			



## Setting up analog trunks

### 1 continued ...

**CNTL**      NO      Use the default values for controls and timers.

**REQ**      \* \* \* \*      Enter \* \* \* \* to exit Overlay.

### 2 Create a Trunk Data Block for the COT in Overlay 14

>LD 14

**REQ**      NEW

**TYPE**      COT      Enter COT to create a COT trunk data block.

**TN**      4 0 7 0      Enter the terminal number.

**XTRK**      XUT      Enter XUT to specify the Extended Universal Trunk card (Rel 19 and later) for this example.

**CUST**      0      Enter 0 as the customer number.

**RTMB**      1 1      Enter route number as 1 and member number as 1.

**SIGL**      GRD      There are two types of COT signaling; ground start (GRD) and loop start (LOP).

**CLS**      UNR      Enter UNR for unrestricted class of service.

**REQ**      \* \* \* \*      Enter \* \* \* \* to exit Overlay.

## Setting up analog trunks

### 2. Creating a TIE trunk

1 Create a Route Data Block (RDB) for the TIE		
<b>REQ</b>	NEW	
<b>TYPE</b>	RDB	Enter RDB to create a route data block.
<b>CUST</b>	0	Enter 0 as the customer number.
<b>ROUT</b>	2	Enter 1 as the route number to be created.
<b>TKTP</b>	TIE	Trunk type will be central office trunk.
<b>PTYP</b>	ACO	Specify the port type as the far end to be analog central office.
<b>ICOG</b>	IAO	COT is incoming and outgoing.
<b>ACOD</b>	8	Enter 8 as the access code for this route.
<b>TARG</b>	0	Enter 0 for the trunk access restriction group.
<b>CNTL</b>	NO	Use the default values for controls and timers.
<b>DLTN</b>	YES	Provide dial tone back to far end.
<b>REQ</b>	****	Enter **** to exit Overlay.
— continued —		

## Setting up analog trunks

2 Create a Trunk Data Block for the COT		
REQ	NEW	
TYPE	TIE	Enter COT to create a COT trunk data block.
TN	4 0 7 1	Enter the terminal number.
XTRK	XUT	Enter XUT to specify the Extended Universal Trunk card (Rel 19 and later) for this example.
CUST	0	Enter 0 as the customer number.
RTMB	1 2	Enter route number as 1 and member number as 1.
SIGL	LDR	There are six types of TIE signaling; two wire duplex (DX2), four-wire duplex (DX4), E&M two wire (EAM), E&M four-wire (EM4), loop dial repeating (LDR) and outgoing automatic, incoming dial (OAD).
CLS	UNR	Enter UNR for unrestricted class of service.
REQ	****	Enter **** to exit Overlay.

## Setting up analog trunks

---

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Setting up analog trunks

### What to have ready

The following checklist summarizes the steps you should take before setting up analog trunks and trunk routes.

**Table 21**  
**Checklist**


Basic	Optional	Preparation
☐		Decide what trunk routes are needed.
☐		Decide what types of trunks and what quantity of trunks are needed on each trunk route.
☐		Consider trunk options.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure analog trunks and trunk routes.

## Setting up analog trunks



## Setting up analog trunks

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of analog trunks.

STEP	ACTION		
1	<b>Log in.</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	<b>Set PAD levels for analog trunks and lines.</b>		
	<b>&gt;LD 73</b>		
	<b>REQ</b>	NEW	
	<b>TYPE</b>	DDB	
	<b>FEAT</b>	PAD	Enter PAD to change PAD values.
	<b>PDCA</b>	1-16	Enter the PAD category table number.
	<b>DFLT</b>	1-16	Enter the PAD category table number to be used as default.
	Respond to the following prompts if they appear. If you see a prompt not listed here, press the carriage return to continue to the next prompt.		
	<b>ACO</b>	0-15 0-15	Enter the PAD level for analog CO or WATS trunks.
	<b>AFX</b>	0-15 0-15	Enter the PAD level for analog FEX trunks.
	<b>ADD</b>	0-15 0-15	Enter the PAD level for analog DID trunks.
	<b>XUT</b>	0-15 0-15	Enter the PAD level for analog CO trunks.
	<b>XEM</b>	0-15 0-15	Enter the PAD level for analog TIE trunks.
	<b>REQ</b>	END	Exit the overlay.
— continued —			

## Setting up analog trunks

STEP	ACTION		
3	Create trunk routes.		
	>LD 16		
	REQ	NEW	
	TYPE	RDB	Enter RDB to create trunks.
	CUST	0-99	Enter the customer number.
	ROUT	0-511	Enter the route number.
— continued —			



## Setting up analog trunks

STEP	ACTION	
4	Create a trunk.	
TKTP	xxx	Select a trunk type.
To select		Enter
add-on data module associated with a data interface card		ADM
automatic incoming outgoing dial trunk		AID
automatic wake-up trunk for recorded announcement or music		AWR
common control switching arrangement and automatic number identification		CAA
central automatic message accounting (CAMA)		CAM
central office trunk		COT
common control switching arrangement access line		CSA
dictation trunk		DIC
direct inward dialing (DID) trunk		DID
foreign exchange (FEX) trunk		FEX
Meridian Communications Unit port		MCU
music trunk		MUS
paging trunk		PAG
recorded announcement trunk		RAN
emergency recorder trunk (for ACD)		RCD
TIE trunk line		TIE
TIE trunk for Sweden		TIE ATL
wide area telephone service trunk		WAT
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>M911_ANI</b>	YES, NO	Enter YES to allow reception of automatic number identification for Meridian 911 routes, or NO to prevent reception.
Respond to the following prompts, if they appear:		
<b>M911_TRK_TYPE</b>	911T, 911E	Enter 911T to select an E911 tandem connection, or 911E to select an end-office connection.
<b>NPID_TBL_NUM</b>	0-7	Select a Meridian 911 route table.
<b>PRIV</b>	YES, NO	Enter YES if the new route is a private line route.
<b>RPA</b>	YES, NO	Enter YES if the new route is a radio paging route.
<b>ESN</b>	YES, NO	Enter YES to enable ESN pad control for the NT8D15 card, or NO to disable ESN pad control.
<b>CNYT</b>	YES, NO	Enter YES to route to a conventional switch.
<b>DDMI</b>	0-255	Select a basic alternate route or network alternate route. (If you are selecting a basic alternate route, the range is 0-127.)
<b>ATDN</b>	0-xxxx	Enter the attendant DN of the conventional main, ESN main, ESN node, or ETN node.
<b>SAT</b>	YES, NO	Enter YES if the new trunk route is carried over an earth orbiting satellite.
<b>RCLS</b>	EXT, INT	Enter INT if the route class is marked as Internal.
<b>DTRK</b>	YES, NO	Enter NO.
— continued —		

## Setting up analog trunks

STEP ACTION

4 continued ...

IFC	xxx	Select an interface type for the new route.
To select	Enter	
Meridian DMS-100		D100
1TR6 for Germany		1TR6
Ericsson AXE-10 for Australia		AXEA
Ericsson AXE-10 for Sweden		AXES
Meridian DMS-250		D250
Japan D70		D70
AT&T ESS4		ESS4
AT&T ESS5		ESS5
EuroISDN		EURO
Numeris for France		NUME
Meridian SL-100		S100
Meridian SL-1		SL1
SYS-12 for Norway		SS12
SwissNet for PRI2		SWIS
Telecom New Zealand		TCNZ
Interface ID for ISO QSIG		ISIG
Interface ID for ETSI QSIG		ESIG
SBN	YES, NO	Enter YES to send billing number, or NO not to send it.

— continued —

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>CNTY</b>	xxx	Identify the country.
<b>To select</b>		<b>Enter</b>
Austria		AUS
Denmark		DEN
Finland		FIN
Germany		GER
Italy		ITA
Norway		NOR
Portugal		POR
Sweden		SWE
Holland		DUT
Ireland		EIR
Switzerland (BRI only)		SWI
ETS 300 102 basic protocol		ESTI
<b>SIDE</b>	NET, USR	Specify the Meridian 1 node type. Enter NET for Network, or USR for User.
<b>OVL R</b>	YES, NO	Enter YES to allow overlap receiving, or NO to prevent it.
<b>DIDD</b>	0-15	Specify the digits to ignore during overlap receiving on DID calls.
<b>OVL S</b>	YES, NO	Enter YES to allow overlap sending, or no to prevent it.
<b>OVL T</b>	0-8	Set the Inter-INFO timer used during overlap sending.
<b>PGPN</b>	0-15	Specify the protocol set group (which must be pre-defined in overlay 27).
<b>— continued —</b>		

## Setting up analog trunks

STEP ACTION

4 continued ...

RCAP	xxx	Specify remote capabilities. NCT for Network Call Trace RVQ for Remote Virtual Queuing ND1 for Network Name Display 1 ND2 for Network Name Display 2
TRO	YES, NO	Enter YES to allow trunk optimization, or NO to prevent it.
INAC	YES, NO	Enter YES to insert ESN access codes in incoming private network calls, or NO to leave calls unchanged.
SPN	YES, NO	Enter YES to insert SPN's AC first, to search for a valid UDP number, or NO to prevent insertion.
INC_T306	0-30	Set the incoming T306 timer.
OUT_T306	0-30	Set the outgoing T306 timer.
PTYP	aaa	Specify the far-end port type.
AUTO	YES, NO	Enter YES if the trunk route is to auto-terminate.
ACMP	YES, NO	Enter YES if calls to busy auto-terminate lines are to automatically camp-on, or NO if calls are not to camp-on.
DNIS	YES, NO	Enter YES if this trunk route is ACD DNIS.
NDGT	3, 4	Specify the number of DNIS digits.
WDGT	L, R	Enter L if the last four DNIS digits are to be sent on APL and HSL, or R if the first four digits are to be sent.
DCDR	YES, NO	Enter YES if the DNIS number is to be included in the CDR records, or NO if they are not to be included.
IANI	YES, NO	Enter YES if this route uses in-band Automatic Number Identification, or NO if the route does not.
RTYP	aaa	Specify the recording device for RAN trunks.

— continued —

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>REP</b>	1-15	Set the number of repetitions for recorded announcements.
<b>POST</b>	DIS, ATT	Specify the treatment given to calls that have received recorded announcement.
<b>STRT</b>	IMM, DDL	Specify the trunk route start arrangement.
<b>ASUP</b>	YES, NO, CO	Enter YES if answer supervision is returned to the originator by RAN, or NO if it is not. Enter CO if answer supervision is to be returned only to CO trunks.
<b>SIGL</b>	BEL, NT4, NT5	Specify the signaling interface for CAMA trunks.
<b>FORM</b>	M1A, M2B, M3C	Specify the format for CAMA signaling.
<b>ICOG</b>	IAO	Enter IAO for incoming and outgoing trunks.
<b>RANX</b>	YES, NO	Enter YES if calls diverted to external trunks are to receive RAN, or NO if RAN is not required.
<b>RANR</b>	0-511	Specify the RAN route number for the desired RAN route.
<b>TRMB</b>	YES, NO	Enter YES to allow trunk tromboning, or NO to prevent it.
<b>SRCH</b>	LIN, RRB	Specify the search method for outgoing trunk members.
<b>STEP</b>	0-511	Specify the alternate trunk route for outgoing trunks.
<b>ACOD</b>	IAO, ICT, OGT	Enter IAO for trunk routes that are both incoming and outgoing, ICT for trunk routes that are incoming only, or OGT for trunk routes that are outgoing only.
<b>CPP</b>	YES, NO	Enter YES to enable the Calling Party Privacy Flag, or NO to disable it.
— continued —		

## Setting up analog trunks

STEP		ACTION
<b>4 continued ...</b>		
<b>TCPP</b>	YES, NO	Enter YES to set the CPP flag for incoming trunk calls tandemed to this trunk route, or no to leave the flag unset.
<b>DTPI</b>	nnnn	Specify the privacy indicator for a Digitone trunk. (The default is *67.)
<b>DPPI</b>	nnnn	Specify the privacy indicator for a dial-pulse trunk. (The default is 1167.)
<b>TARG</b>	1-15	Specify the Trunk Access Restriction Group (TARG) number.
<b>ATGT</b>	0-60	Set the ADM trunk guard timer.
<b>ASTP</b>	1-15	Set the number of ADM step-forward ring cycles.
<b>SGRP</b>	0-999	Specify the Scheduled Access Restriction (SAR) Group number.
<b>OABS</b>	0-9	Specify the actual outgoing toll digits to be ignored for Code Restriction.
<b>IABS</b>	0-3	Specify the number of incoming digits to be absorbed.
<b>CAT</b>	00-99	Specify the CAMA trunk route category digits.
<b>ID</b>	0-9	Specify the identification digit for CAMA trunk routes.
<b>STRK</b>	YES, NO	Enter YES to enable the Super Trunk group feature, or NO to disable it.
<b>SPTO</b>	YES, NO	Enter YES to enable the Super Trunk option, or NO to disable it.
<b>ANKP</b>	YES, NO	Enter YES to suppress the KP signal, or NO to allow the signal.
<b>INST</b>	0-99999999	Specify the insert.
— continued —		

## Setting up analog trunks

STEP ACTION		
4 continued ...		
JDGT	1-4	Specify the Japan central office digits.
IDC	YES, NO	Enter YES to allow incoming DID digit conversion on this route, or NO to prevent it.
DCNO	0-254	Specify the day IDC tree number.
NDNO	0-254	Specify the night IDC tree number.
DEXT	YES, NO	Enter YES to display external dialed digits, or NO to prevent display.
DNAM	YES, NO	Enter YES to display the IDC name, or NO to prevent display.
AIOD	YES, NO	Enter YES to allow identification of outgoing calls, or NO to prevent identification.
ACNO	0-99	Set the AIOD customer number.
ARNO	0-511	Set the AIOD route number.
ATTK	xxxx	Set the AIOD identifier number.
ANTK	xxxx	Set the ANI identifier number.
SIGO	aaa	Specify the signaling arrangement.
MFC	YES, NO	Enter YES to enable Multifrequency Compelled Signaling, or NO to disable it.
MFEI	0-127	Specify the MFE table number for incoming calls.
AUTM	YES, NO	Enter YES to enable MFE automatic mode, or NO to disable it.
DIGS	4-5	Specify the number of digits expected in MFE automatic mode.
SGL	YES, NO	Enter YES to return an MFE Idle signal, or NO to return a normal MFE signal.
— continued —		



## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>MFEO</b>	0-127	Set the MFE table number for outgoing calls.
<b>MFEA</b>	YES, NO	Enter YES if access code signals are used in the signaling, or NO if they are not.
<b>MFED</b>	0-9	Set the first digit of special service calls.
<b>MFKI</b>	1-127	Set the MFK table number for incoming calls.
<b>AUTM</b>	YES, NO	Enter YES to enable automatic mode, or NO to disable it.
<b>DIGS</b>	4-5	Specify the number of digits expected for MFK automatic mode.
<b>MFKO</b>	0-127	Set the MFK table number for outgoing calls.
<b>LOCD</b>	6-7	Set the number of digits used in a local call by the far end central office.
<b>CHRG</b>	BLOK, LINE	Enter BLOK to charge DOD calls by the block, or LINE to charge calls by the line.
<b>MFCI</b>	1-127	Specify the MFC incoming table number.
<b>R2MD</b>	YES, NO	Enter YES to enable R2 modification, or NO to prevent it.
<b>DIG#</b>	1-9	Specify the number of digits involved in R2 modification.
<b>SGL</b>	YES, NO	Enter YES to return an MFC Idle signal, or NO to return a normal MFC signal and tone.
<b>BSSU</b>	YES, NO	Enter YES to select backward signal suppression for undefined signals, or NO to prevent suppression.
<b>MFCO</b>	1-127	Specify the MFC outgoing table number.
<b>OPP</b>	NORM, ATT	Enter NORM for normal busy or intercept treatments of operator-originated calls, or ATT for routing to an attendant.
<b>SWP</b>	ATT, NORM	Specify busy and intercept treatment for the subscriber with priority. Enter NORM for normal treatment, or ATT for routing to the attendant.
— continued —		

## Setting up analog trunks

STEP ACTION		
4 continued ...		
CCNI	YES, NO	Enter YES to enable call number indicator (CNI) on the route, or NO to disable CNI.
CNTL	YES, NO	Enter YES to make changes to controls and timers.
TIMR	aaa xxx	Set the trunk timers by enter a timer mnemonic, followed by the timer value (in milliseconds).
SST	xxx	Set the seizure supervision timer (in seconds).
DTD	YES, NO	Enter YES to change dial tone detection parameters.
MDTD	1-31	Set the minimum dial tone detection delay (in seconds).
DTDF	1-15 1-15	Specify the dial tone detector fail threshold.
SCDT	YES, NO	Enter YES to use secondary dial tone detection on the route, or NO to discard secondary dial tone detection.
TABL	1-31	Set the flexible dial tone detection table number.
XTDT	0-7	Set the extended tone detection table number.
2 DT	YES, NO	Enter YES to enable secondary dial tone, or NO to disable it.
NEDC	ORG, ETH	Set near-end disconnect control.
FEDC	aaa	Set far-end disconnect control.
CPDC	YES, NO	Enter YES if the Meridian 1 is the only controlling party on incoming calls, or NO if there are other controlling parties.
SPCT	IMM, DLY	Set up speech path cut through.
DLTN	YES, NO	Enter YES to enable dial tone on originating calls, or NO to disable it.
ANDT	YES, NO	Enter YES to enable ANI dial tone, or NO to disable it.
HOLD	ic dc ht	Set the hold failure threshold.
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>SEIZ</b>	ic dc	Set the seize failure threshold.
<b>RGFL</b>	ic dc	Set the ring failure threshold.
<b>RVSD</b>	ic dc	Set the reversed wired CO trunk threshold.
<b>ILLR</b>	ic dc	Set the illegal ring threshold.
<b>SVFL</b>	ic dc	Set supervision failure.
<b>OPCB</b>	YES, NO	Enter YES to enable operator call back, or NO to disable it.
<b>IMBI</b>	YES, NO	Enter YES to enable immediate breakin for the route, or NO to disable the option.
<b>IMBC</b>	YES, NO	Enter YES to enable immediate call back, or NO to disable it.
<b>TOBO</b>	YES, NO	Enter YES to enable toll operator breakout, or NO to disable it.
<b>BTCG</b>	YES, NO	Enter YES to enable Busy Tone to Calling Party, or NO to disable it.
<b>IHT</b>	2-62	Specify the number of seconds for call back.
<b>OHT</b>	0-62	Set up CGPC call disconnect.
<b>OHTT</b>	0-62	Set Toll Outgoing CGPC call disconnect.
<b>SRT</b>	1-1023	Specify the number of minutes a set is kept on hold to a trunk on an outgoing CDPC call.
<b>CGPC</b>	YES, NO	Enter YES to enable Calling Party Control, or NO to disable it.
<b>CDCT</b>	YES, NO	Enter YES to enable Called Party Control, or NO to disable it.
<b>DDO</b>	YES, NO	Enter YES to enable Delay Digits Outpulsing for DOD and CO trunks, or NO to disable it.
<b>DRNG</b>	YES, NO	Enter YES to enable North American Distinctive Ringing for incoming calls, or NO to disable it.
<b>NDRI</b>	0-4	Specify the Network Distinctive Ringing index.
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>BTUA</b>	YES, NO	Enter YES to enable Block Transfer of Unanswered Calls, or NO to disable the option.
<b>CDR</b>	YES, NO	Enter YES to enable Call Detail Recording, or NO to disable it.
<b>INC</b>	YES, NO	Enter YES to enable generation of CDR records on incoming calls, or NO to disable it.
<b>LAST</b>	YES, NO	Enter YES to enable printing of CDR content for redirected calls, or NO to disable it.
<b>BILN</b>	YES, NO	Enter YES to enable the Billing Number Required option, or NO to disable it.
<b>BLEN</b>	1-16	Specify the billing number length.
<b>BNUM</b>	0-9999	Specify the billing number.
<b>BDSP</b>	YES, NO	Enter YES to display the billing number, or NO to suppress display.
<b>TTA</b>	YES, NO	Enter YES to output Time To Answer in CDR, or NO to suppress output.
<b>ABAN</b>	YES, NO	Enter YES to output abandoned call records for the route, or NO to suppress output.
<b>QREC</b>	YES, NO	Enter YES to output CDR ACD Q initial connection records, or NO to suppress output.
<b>OAL</b>	YES, NO	Enter YES to enable CDR on outgoing calls, or NO to disable it.
<b>OTL</b>	YES, NO	Enter YES to enable CDR on outgoing toll calls, or NO to disable it.
<b>AIA</b>	YES, NO	Enter YES to enable Answered Call Identification, or NO to disable the option.
<b>OAN</b>	YES, NO	Enter YES to start CDR timing on answer supervision of outgoing calls, or NO to prevent it.
<b>OPD</b>	YES, NO	Enter YES to record outpulsed digits in CDR, or NO to prevent recording.
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>CDRX</b>	YES, NO	Enter YES to print CDRX records on multiple call transfer for non-PPM outgoing calls, or NO to prevent printing.
<b>NDP</b>	INC, EXC 0-32	Specify the number of digits to be suppressed. Enter INC to suppress the first digits, or EXC to suppress the last digits.
<b>CDRY</b>	YES, NO	Enter YES to generate CDR Public Network Feature Invoke records, or NO to prevent generation.
<b>OPA</b>	YES, NO	Enter YES to generate CDR or CDAS records for PPM pulses, or NO to prevent generation.
<b>CCO</b>	YES, NO	Enter YES to print CDR records for no PPM or AOC count, or NO to prevent printing.
<b>NATL</b>	YES, NO	Enter YES to select North American toll scheme, or NO to use another toll scheme.
<b>TDG</b>	xx...xx	Specify toll digits.
<b>SSL</b>	1-15	Specify Special Service List number.
<b>CFWR</b>	YES, NO	Enter YES to enable Call Forward Restriction, or NO to disable it.
<b>IDOP</b>	YES, NO	Enter YES to enable the Identify Originating Party option, or NO to disable it.
<b>VRAT</b>	YES, NO	Enter YES to answer an attendant-extended call over VNS immediately on the incoming bearer trunk, or NO to prevent answer.
<b>MUS</b>	YES, NO	Enter YES to enable Music On Hold, or NO to disable it.
<b>MRT</b>	0-511	Specify the Music Route number.
<b>MR</b>	RVD, NO	Set Message Registration.
<b>PANS</b>	YES, NO	Enter YES if pseudo-answer can be sent on some types of trunks as soon as end-of-dialing is detected, or NO if it can not.
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>RACD</b>	YES, NO	Enter YES to include route traffic information in ACD reports, or NO to exclude information.
<b>RUCS</b>	0-9999	Enter the route unit cost.
<b>RURC</b>	xy	Specify the route unit reference cost.
<b>RUCF</b>	xy	Specify the route unit conversion factor.
<b>RPPM</b>	xxx	Specify the real-time periodic pulse metering polling time (in seconds).
<b>A1MR</b>	YES, NO	Enter YES if Answer is the first meter pulse, or NO if it is not.
<b>MANO</b>	YES, NO	Enter YES if the trunk route is manual outgoing, or NO if it is not.
<b>EQAR</b>	YES, NO	Enter YES to enable Equal Access Restrictions, or NO to disable it.
<b>NTOL</b>	DENY, ALOW	Enter DENY to deny North American toll calls (1+ calls), or ALOW to allow them.
<b>ITOL</b>	DENY, ALOW	Enter DENY to deny International toll calls (011+ calls), or ALOW to allow them.
<b>DTOS</b>	YES, NO	Enter YES to allow dial tone on outgoing seizure, or NO to suppress it.
<b>FRL</b>	0-7 0-254	Specify the facility restriction level.
<b>OHQ</b>	YES, NO	Enter YES to enable Off-hook Queuing, or NO to disable it.
<b>OHQT</b>	0-63	Specify the Off-hook Queuing threshold.
<b>CBQ</b>	YES, NO	Enter YES to enable Call Back Queuing, or NO to disable it.
<b>NDIG</b>	2-7	Set the number of digits.
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>AUTH</b>	YES, NO	Enter YES to enable Authcode, or NO to disable it.
<b>FGNO</b>	0-127	Enter the Feature Group D block number.
<b>TDET</b>	YES, NO	Enter YES if a tone detector is required, or NO if it is not.
<b>TTBL</b>	0-31	Set the Tone Table number.
<b>ACNI</b>	YES, NO	Enter YES to enable Accept Call Number Identification, or NO to disable it.
<b>OHTD</b>	YES, NO	Enter YES to enable Off-hook Timer Delay, or NO to disable it.
<b>PLEY</b>	0-7	Set the priority level.
<b>OPR</b>	YES, NO	Enter YES for an Outpulsing Route, or NO for other routes.
<b>OPDL</b>	0-8064	Specify the outpulsing delay, in milliseconds.
<b>PRDL</b>	YES, NO	Enter YES to allow Partial Dial timing, or NO to prevent it.
<b>EOS</b>	YES, NO	Enter YES to enable the End-of-Selection Signal, or no to deny it.
<b>DNSZ</b>	0-7	Specify the number of digits expected on DID routes.
<b>RCAL</b>	NO, ATT, DRA	Configure Recall.
<b>MCTS</b>	YES, NO	Enter YES to enable Malicious Call Trace Signal, or NO to disable it.
<b>MCCD</b>	0-8	Enter the Malicious Call Trace request string.
<b>MCDT</b>	0-4	Set the Malicious Call Trace delay time (in seconds).
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>CDPC</b>	YES, NO	Enter YES to enable Called Party Control, or NO to disable it.
<b>ALRM</b>	YES, NO	Enter YES if Malicious Call Trace Alarm is allowed for external calls, or NO if it is not allowed.
<b>NCNI</b>	0-7	Set the number of digits to be received before CNI is requested.
<b>CNIE</b>	YES, NO	Enter YES to request CNI after the defined number of digits are received.
<b>CNIT</b>	YES, NO	Enter YES to enable Call Number Identification Trace, or NO to disable it.
<b>BTT</b>	2-254	Set the Busy Tone Time.
<b>LEC</b>	0-9999999	Set the Local Exchange Code (used for building ANI messages).
<b>ADDG</b>	0-9	Specify the additional digit to be used in ANI sequences.
<b>CAC</b>	0-9	Specify an ANI category for an incoming trunk.
<b>ANDN</b>	0-9999999	Set the ANI DN.
<b>RDNL</b>	0-7	Specify the route DN length for ANI.
<b>ACKW</b>	YES, NO	Enter YES to enable the Acknowledgement Seizure Signal, or NO to disable it.
<b>PECL</b>	YES, NO	Enter YES to enable the Periodic Clearing Signal, or NO to disable it.
<b>DCTI</b>	0-511	Set the time (in seconds) that an extension is allowed to ring, be on hold, or call parked, before the trunk is disconnected.
<b>MON</b>	YES, NO	Enter YES to enable monitoring for the route, or NO to disable monitoring.
— continued —		



## Setting up analog trunks

STEP ACTION		
<b>4 continued ...</b>		
<b>TIDY</b>	xxxx yyyy	Specify the trunk identity.
<b>FRIN</b>	YES, NO	Enter YES to enable Forward Release Indefinitely, or NO to disable it.
<b>FRRC</b>	0-15	Set the Forward Release Repetition count.
<b>FRRS</b>	YES, NO	Enter YES to enable Forward Release Repetition Seize, or NO to disable it.
<b>FRRD</b>	128-384	Specify the Forward Release Repetition Delay (in milliseconds).
<b>RRBS</b>	YES, NO	Enter YES to enable Repeat Release Before Seize, or NO to disable it.
<b>RLSM</b>	0-15	Set the release mechanism.
<b>CCB</b>	YES, NO	Enter YES to enable Collect Call Blocking, or NO to disable it.
<b>CCB1</b>	512-4992	Set Collect Call Blocking delay timer 1 (in milliseconds).
<b>CCB2</b>	500-2550	Set Collect Call Blocking delay timer 2 (in milliseconds).
<b>CCBA</b>	YES, NO	Enter YES to allow Collect Call Blocking, or NO to deny it.
<b>ATTR</b>	YES, NO	Enter YES to enable AC15 Timed Reminder Recall, or NO to disable it.
<b>TRRL</b>	YES, NO	Enter YES if the recall signal may be received on the route, or NO if it may not be received.
— continued —		

## Setting up analog trunks

STEP ACTION

5 Set up Automatic Trunk Maintenance.

REQ	NEW, CHG	
TYPE	ATM	
CUST	0-99	Enter the customer number.
ROUT	0-511	Enter the route number.
T100	n . . . n	Specify the T100 test line DN.
PADT	0-63	Enter the pad factor for T100 test line, in dB.
STND	YES, NO	Enter YES to select a standard T100 test line.
NMNL	27-90	Set the noise maintenance limit.
NOUT	27-90	Set the noise out-of-service limit.
NTOF	YES, NO	Enter YES to enable near-to-far measurement, or NO to disable it.
REF	n . . . n	Specify the reference loop-around DN.
TST	n . . . n	Specify the test loop-around DN.
PADL	0-63	Set the pad factor for loop-around.
EML	0-15	Set the expected measured loss.
LMNL	0-15	Set the loss deviation maintenance limit.
LOUT	0-15	Set the loss-of-service deviation limit.
DSBL	0-100	Set the percentage of trunks to be disabled.
MXTI	0-15	Set the maximum time.

— continued —

## Setting up analog trunks

STEP	ACTION	
6	Set up Automatic Trunk Maintenance schedules.	
REQ	NEW, CHG	
TYPE	SCH	
CUST	0-99	Enter the customer number.
HOUR	0-23	Set the hour to start ATM tests.
ROUT	0-511	Enter the route number.
MDMP	YES, NO	Enter YES to enable Modem Data Module Pair, or NO to disable it.
MRAT	5-30	Set the modem ring again timer.
DTYP	aaa	Select the inbound/outbound data port.
ADCP	YES, NO	Enter YES to enable the All-Digital Connection Prefix, or NO to disable it.
OAMP	0-127	Set the Outbound Modem Pool route number.
IAMP	0-127	Set the Inbound Modem Pool route number.
REQ	END	Exit the overlay.
— continued —		

## Setting up analog trunks

STEP	ACTION	
7	Create a trunk.	
	>LD 14	
	REQ	NEW Define a new trunk.
	TYPE	xxxx Enter the trunk type.
	To select	Enter
	automatic wake-up trunk for recorded announcement or music	AWR
	common control switching arrangement and automatic number identification	CAA
	central automatic message accounting (CAMA)	CAM
	central office trunk	COT
	common control switching arrangement access line	CSA
	dictation trunk	DIC
	direct inward dialing (DID) trunk	DID
	foreign exchange (FEX) trunk	FEX
	integrated service access call-by-call route	ISA
	music trunk	MUS
	paging trunk	PAG
	recorded announcement trunk	RAN
	recorder trunk	RCD
	release link main trunk	RLM
	release link remote trunk	RLR
	TIE trunk line	TIE
	wide area telephone service trunk	WAT
— continued —		

## Setting up analog trunks

STEP ACTION		
<b>7 continued ...</b>		
<b>TN</b>	L S C U	Enter a Terminal Number for the trunk (Loop, Shelf, Card and Unit).
<b>CDEN</b>	SD, DD, 4D	Select the card density (either single, double or quad density). Press the carriage return to select the default.
Respond to the following prompts if they appear:		
<b>XTRK</b>	XUT, XEM, EXUT	Specify the extended trunk card type.
<b>FWTM</b>	YES, NO	Enter YES if firmware trunk-hook flash timing is controlled by the trunk card firmware.
<b>SXS</b>	YES, NO	Enter YES if the trunk is a Central Office step-by-step trunk.
<b>SICA</b>	1-16	Enter the signaling category table number.
<b>PDCA</b>	1-16	Enter the Pad category table number.
<b>PCML</b>	MU, A	Enter the PCM loss mode to be used for voice calls on the trunk.
<b>CUST</b>	xx	Enter the customer number for this trunk.
<b>NCOS</b>	xx	Enter the Network Class of Service group.
<b>RTMB</b>	xx yy	Enter the route number and member number.
<b>PRDN</b>	xxxx	Specify a Private Line DN.
<b>CMF</b>	YES, NO	Enter YES to allow call modifications, or no to deny them.
<b>NGRP</b>	0-9	Select a Night Service group number.
<b>RLDN</b>	xxxx	Specify a Release Line Trunk DN.
<b>NITE</b>	xxxx	Specify a Night Service DN.
<b>ATDN</b>	xxxx	Specify an Auto-Terminate DN.
<b>MNDN</b>	xxxx	Specify a Manual DN.
— continued —		

## Setting up analog trunks

STEP ACTION		
<i>7 continued ...</i>		
<b>TGAR</b>	0-31	Select a Trunk Group access restriction. (To remove an existing restriction, enter 0.)
<b>SIGL</b>	aaa	Select a trunk signaling method.
<b>To select</b>		<b>Enter</b>
ALS signaling on CO trunks with ground start		ALS
2-wire duplex signaling		DX2
4-wire duplex signaling		DX4
E&M 2-wire signaling		EAM
E&M 4-wire signaling		EM4
ground start signaling		GRD
loop calling with disconnect clear signaling		LDC
loop dial repeating signaling		LDR
loop calling with guarded clear signaling		LGR
loop start signaling		LOP
outgoing automatic and incoming dial signaling		OAD
2280 Hz 4-wire signaling		WR4
<b>XDIC</b>	MUT, NOR	Enter MUT to select mute outpulsing for DIC trunks, or NOR to select normal outpulsing.
<b>EMTY</b>	aaa	Specify the E&M type.
<b>To select</b>		<b>Enter</b>
E&M 4-wire Type 1		EAM
E&M 4-wire Type 2		EM4
E&M 4-wire British Post Office		BPO
<b>CPAD</b>	COUT, CIN	Enter COUT to set the carrier pad out for 4-wire E&M duplex trunks.
<b>LDOP</b>	LOOP, BOP	Enter LOOP to select loop dial outpulsing, or BOP to select battery outpulsing for Loop Dial Repeating signaling.
— continued —		

## Setting up analog trunks

STEP ACTION

7 continued ...

<b>TIMP</b>	xxx	Select a termination impedance.
<b>To select</b>		<b>Enter</b>
impedance for a RAN trunk		1200
impedance for all other trunks		600 or 900
<b>BIMP</b>	xxx	Select a balance impedance.
<b>To select</b>		<b>Enter</b>
3-component complex impedance		3COM
600 ohm impedance		600
900 ohm impedance		900
<b>STRI</b>	xxx	Specify an incoming start arrangement.
<b>To select</b>		<b>Enter</b>
delayed dial start		DDL
immediate start		IMM
off-hook wink start		OWK
CEPT1 signaling seize acknowledge start		SACK
CEPT1 signaling Proceed to Send start		PTSD
wink or fast flash start		WNK
RON/TRON start arrangement sent by near end on incoming seizure		RT

— continued —

## Setting up analog trunks

STEP ACTION

7 continued ...

STRO	xxx	Specify an outgoing start arrangement.
To select		Enter
delayed dial start		DDL
immediate start		IMM
off-hook wink start		OWK
CEPTL1 signaling seize acknowledge start		SACK
CEPTL1 signaling Proceed to Send start		PTSD
wink or fast flash start		WNK
RON/TRON start arrangement sent by near end on incoming seizure		RT
SUPN	YES, NO	Enter YES if you require disconnect supervision on the trunk.
STYP	aaa	Specify the type of disconnect supervision for the trunk.
To select		Enter
incoming and outgoing supervised LOP CO, FEX, or WATS trunk		BST
polarity sensitive pack		PSP
polarity insensitive pack		PIP
Japan CO trunk		JCO
Japan DID trunk		JDID
battery supervised CO trunk		BAT
ARF supervised trunk		ARF
Loop Break Supervision trunk		LBS
Busy Tone supervised trunk		BTS
SEIZ	YES, NO	Enter YES to enable Automatic Guard Detection for an outgoing trunk.

— continued —



## Setting up analog trunks

### STEP ACTION

#### 7 continued ...

**PPID**      0–15      Select a PPM country identification number.

In	Enter	To select
UK	0	50 Hz
France	1	12 kHz
France	2	50 Hz
Germany	3	16 kHz
Egypt	3	16 kHz
Venezuela	3	16 kHz
Indonesia	3	16 kHz
Finland	3	16 kHz
Turkey	3	16 kHz
Turkey	4	12 kHz
Ireland	4	12 kHz
Switzerland	4	12 kHz
Portugal	4	12 kHz
Italy	4	12 kHz
Spain	4	12 kHz
Lebanon	4	12 kHz
Denmark	5	12 kHz
Norway	6	16 kHz
Belgium	6	16 kHz
Holland	7	50 Hz
Australia	8	12 kHz/50 Hz

— continued —

## Setting up analog trunks

STEP		ACTION
7 continued ...		
BTID	0-15	Select a Busy Tone country identifier.
In		Enter
Germany		3
Ireland		3
Switzerland		4
Denmark		5
Norway		6
Kuwait		6
Chile		6
Venezuela		6
Indonesia		6
Thailand		6
Korea		6
— continued —		


## Setting up analog trunks

STEP ACTION	
7 continued ...	
In	Enter
Holland	7
Australia	8
Mexico	8 or 10
Ireland	9
Taiwan	10
Brazil	10
Tortola	10
Singapore	11
Argentina	12
Italy	12 or 13
Lebanon	13
Turkey	14
— continued —	


## Setting up analog trunks

STEP ACTION		
7 continued ...		
CLS	aaa	Select a Class of Service.
Enter:	UNR for Unrestricted COS CTD for Conditionally Toll Denied COS CUN for Conditionally Unrestricted COS FR1 for Fully Restricted Class 1 FR2 for Fully Restricted Class 2 FRE for Fully Restricted SRE for Semi-Restricted TLD for Toll Denied APN for ACD priority not required COS APV for ACD priority required COS BARD for Barring Denied COS BARA for Barring Allowed COS CND for Calling Party Denied COS CNA for Calling Party Allowed COS CORX for CO Ringback not provided COS CORP for CO Ringback provided COS DIP for Dial Pulse COS DTN for Digitone COS MFC for R2 Multifrequency Compelled Signaling COS MFE for Multifrequency Signaling for Socotel COS MFR for Multifrequency Receiver for Feature Group D COS DRPD for DTR PAD value denied COS DRPA for DTR PAD value allowed COS ECD for Echo Cancelling Denied COS ECA for Echo Cancelling Allowed COS LNT for Loop Start Non-Supervisory Trunk COS LPR for Low Priority COS HPR for High Priority COS MID for Manual Incoming Denied COS MIA for Manual Incoming Allowed COS MFK for Multifrequency Signaling for KD3 NTC for Non-Transmission Compensated COS TRC for Transmission Compensated COS	
REQ	END	Exit the overlay.
— continued —		

## Setting up analog trunks

STEP	ACTION						
8	<p><b>Check your programming.</b></p> <p>Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the <i>About the Meridian 1</i> section of this guide. If possible, test the trunks to ensure that they are operating.</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>the programming is correct</td><td>step 9</td></tr> <tr> <td>the programming is not correct</td><td>step 1</td></tr> </table>	<b>If</b>	<b>Do</b>	the programming is correct	step 9	the programming is not correct	step 1
<b>If</b>	<b>Do</b>						
the programming is correct	step 9						
the programming is not correct	step 1						
9	<p><b>Arrange for a data dump to be performed.</b></p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>you do not have access to LD 43</td><td>contact your system supplier</td></tr> <tr> <td>you have access to LD 43</td><td>step 10</td></tr> </table>	<b>If</b>	<b>Do</b>	you do not have access to LD 43	contact your system supplier	you have access to LD 43	step 10
<b>If</b>	<b>Do</b>						
you do not have access to LD 43	contact your system supplier						
you have access to LD 43	step 10						
10	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43.</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre> <p style="text-align: center;">— continued —</p>						

## Setting up analog trunks

STEP	ACTION						
11	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA or DATA DUMP COMPLETE</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>data dump fails</td><td>contact your system supplier</td></tr> <tr> <td>data dump succeeds</td><td>step 12</td></tr> </table>	<b>If</b>	<b>Do</b>	data dump fails	contact your system supplier	data dump succeeds	step 12
<b>If</b>	<b>Do</b>						
data dump fails	contact your system supplier						
data dump succeeds	step 12						
12	<p><b>Terminate this overlay program.</b></p> <p>*****</p>						
13	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>						
14	<p><b>You have completed the programming required to configure analog trunks.</b></p>						
							

# Setting up digital and ISDN trunks

## Purpose

Digital trunks carry signaling and calls in a digital format between telephone switches. Digital trunks provide greater quality than analog trunks and allow the use of advanced signaling and network features.

There are different types of digital trunks. These include:

- ◆ digital trunk interface (DTI)
- ◆ Integrated Services Digital Network (ISDN)

The proper configuration of digital trunks is essential to your telephone network access and features. If trunks are not properly provisioned, users may have difficulty placing calls to destinations served by other telephone switches, or may not be able to use the network features available to them.

---

## Setting up digital and ISDN trunks

---

### Digital trunks

Digital trunks can take many physical forms, including twisted pair cable, channels on multiplexed cable, and fibre optic links. The provisioning in software of these different types of physical trunk is the same. Configuration depends on the way a trunk will be used and billed.

#### Traffic

When planning to configure new trunks, you should consider the traffic load. Consider the impact of extra traffic load on the loop or Superloop to which the trunk is connected. Loops and Superloops perform best when they share equally in the total traffic load offered to the system.

Blockage within the system will be negligible when the traffic load per loop or Superloop is kept within the recommended guidelines. If all your existing loops and Superloops are at their recommended capacity, consider adding more to your system (especially if you will be adding more digitone receivers, telephones, or data terminals in the future).

#### Trunk types

##### Japan Digital Multiplex Interfaces

Japan Digital Multiplex Interface (JDMI) trunks provide connectivity between the Meridian 1 and other telephone switches in the Japanese market. JDMI trunks carry both incoming and outgoing calls.

##### 1.5 Mbit/s DTI trunks

1.5 Mbit/s Digital Trunk Interface (DTI) trunks provide digital connectivity between the Meridian 1 and other telephone switches in the North American market. DTI trunks carry both incoming and outgoing calls.

##### 2.0 Mbit/s DTI trunks

2.0 Mbit/s Digital Trunk Interface (DTI) trunks provide digital connectivity between the Meridian 1 and other telephone switches. DTI trunks carry both incoming and outgoing calls.



---

## Setting up digital and ISDN trunks

---

### DTI trunk options

Many trunk options exist. For detailed discussions of DTI trunk options and trunk provisioning, refer to the *X11 Features and Services Guide* and the *Software Guide*.

### Signaling Category

Select a Signaling Category table number by responding to the SICA prompt in overlay 14.

### Channel order


You can specify the order in which channels are allocated. To specify the channel order, respond to the INC prompt.

## Setting up digital and ISDN trunks

### ISDN trunks

#### Basic rate interface

Basic rate interface (BRI) ISDN trunks provide 2 B + D ISDN access to end users. For more information about ISDN BRI configuration, refer to *ISDN Basic Rate Interface Administration*.




---

## Setting up digital and ISDN trunks

---

### Primary rate interface

Primary rate interface (PRI) ISDN trunks provide either 23 B + D or 30 B + D ISDN access to end users. For more information about ISDN PRI configuration, refer to *ISDN Primary Rate Interface Administration*



### ISDN 23B + D

Primary rate interface (PRI) ISDN 23 B + D trunks provide ISDN digital connectivity between the Meridian 1 and other telephone switches in the North American market. ISDN trunks carry both incoming and outgoing calls.

### ISDN 30B + D

Primary rate interface (PRI) ISDN 30 B + D trunks provide ISDN digital connectivity between the Meridian 1 and other telephone switches. ISDN trunks carry both incoming and outgoing calls.


## Setting up digital and ISDN trunks

### D-channels

An ISDN trunk carries call traffic only. The signaling used to control the trunk is carried over a separate set of links, called D-channels. The D-channels allow two telephone switches to negotiate channels on a trunk and handle call setup and control.

The D-channels between switches can be carried over cable, modem connections, or other data connections. There are two D-channels for each ISDN trunk. The primary D-channel carries all the signaling traffic. The backup D-channel remains idle unless the primary D-channel fails.

The Meridian 1 treats the D-channels as input/output devices. To configure a D-channel for an ISDN trunk, respond to the ADAN and USER prompts in overlay 17.



---

## Setting up digital and ISDN trunks

---

### Trunk routes

Digital trunk routes operate in the same way as analog trunk routes. A trunk route carries all calls of a specific type between two switches.

Some digital trunk options are described here. In addition, a number of trunk options described in the previous section apply.

### Integrated Service Access Route

To set a route up for Integrated Service Access (ISA), enter YES at the ISAR prompt in overlay 16. You need to specify a route number, facility indicator, and Service Identification at the RTN, FACY and SID prompts.

Set the minimum and maximum numbers of channels at the MIN and MAX prompts.

Specify the Network Class of Service group number and the Class of Service at the PRIM, NCOS and COS prompts.

Select Trunk Group Access Restrictions at the TGAR prompt.

### Network Attendant Service

Network Attendant Service is a feature that allows attendants to be shared by Meridian 1 switches across a network. Calls that would normally be routed to an attendant at a particular Meridian 1 may be routed to an attendant at a different Meridian 1, perhaps even at a different location, if the local attendant is unavailable.

To allow Network Attendant Service to operate over a trunk route, respond to the NASA prompt.

---

## Setting up digital and ISDN trunks

---

### Digital trunk route options

#### Protocol set group

To select a protocol set, respond to the PGPN prompt. (Protocol set groups must already be defined in overlay 27 before you can select them.)

#### Integrated Services Digital Network (ISDN)

Enter YES at the ISDN prompt to make a trunk route an ISDN route. Specify the mode of operation at the MODE prompt. Specify the DCHI port number at the DCHI prompt. Set the interface at the IFC prompt.

Respond to the TRO prompt to enable or disable trunk optimization.

#### Priority designation

You can specify a priority designation for DPNSS ISDN trunks. To set the priority, respond to the PRIO prompt in overlay 14.

#### Malicious Call Trace

Enable or disable the Malicious Call Trace (MCT) signal at the MCTS prompt in overlay 16. Define the call trace request string at the MCCD prompt. Specify the digit string delay time at the MCDT prompt.

Set the MCT request timer at the MCTM prompt. This is the delay in disconnection that occurs when the far-end goes on-hook (for AXE-10 D-channels).

Specify the MCT tandem disconnect delay at the MTND prompt. This is the delay in disconnect operation at the node closest to the CO (for AXE-10 interfaces).

Turn the MCT alarm on or off for external calls at the ALRM prompt.

#### Line identity options

Set the Line Identities option by responding to the LID prompt in overlay 16. Enter 0 to suppress the sending of ISDN Line Identities, 1 to send identities, or 2 to convert and then send identities. Specify the Line Identities conversion tree number at the LCNO prompt. (The tree number is a DCNO tree defined in overlay 49.)

---

## Setting up digital and ISDN trunks

---

### ISDN Programming Example

Primary Rate Interface (PRI) must be configured before defining the DCH links or Primary Rate Access (PRA) applications. The following example outlines configuring PRI loops, DCHI interface, DCH link and ISDN trunk route and trunks (B-Channel). No feature applications will be programmed other than Basic Call Service. Only the prompts listed require responses.

#### Hardware Configuration

The Primary Rate Interface hardware requirements for this example include:

- ◆ The ISDN Primary Rate Interface card (QPC720). This card requires two network card slots and has to be configured for Extended Frame Format (ESF). Cable jack J3 is connected to J2 on the Network card (QPC414) via a NT8D45 cable. Cable jack J4 is connected to J4 of the second Meridian 1 QPC720 card.
- ◆ D-channel Handler Interface card (QPC757). This card requires one network slot and has to be configured for Data Communication Equipment (DCE) option. The D-channel requires one of the fifteen input/output ports. Cable jack J2 connects to J5 of the QPC720 card via the QCAD328 cable.
- ◆ Clock Controller circuit card (QPC775). Cable Jack marked PRI J2 connects to J1 Ref 1 on the QPC720 card.
- ◆ Network Card (QPC414). This card requires one network slot and must be configured for Option B: T-1 facilities (including PRT/DTI) service.

Refer to section on circuit cards for hardware switch settings and to TASK 1 for an example of configuring a circuit card.

## Setting up digital and ISDN trunks

### Software Configuration

Programmers note: Configuration is almost identical on both switches. However, in Overlay 17, one Meridian 1 must be configured as the master (MAS) and the other as the slave (SLAV). In Overlay 73, the most reliable Meridian 1 provides clocking (PREF) whereas the other system is set to free run (FRUN).

STEP	ACTION		
1	Log in.		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	Define threshold parameters and Clock synchronization		
	>LD 73		
	REQ	NEW	
	TYPE	DDB	Enter DDB to configure the digital data block.
	TRSH	15	Enter a threshold value of 15 for this example.
	REQ	****	Enter **** to terminate Overlay.
3	Use Overlay 17 to add a PRI loop		
	>LD 17		
	REQ	CHG	Request
— continued —			



## Setting up digital and ISDN trunks

STEP		ACTION
<b>3 continued ...</b>		
<b>TYPE</b>	CFN	Enter CFN to change the configuration record.
<b>CEQU</b>	YES	Enter YES to make changes to common equipment.
<b>DLOP</b>	9 24 ESF	Where 9 is the PRI digital loop number and 24 is the number of data calls allowed on this PRI and ESF is the frame format used.
<b>MODE</b>	PRI	select Primary Rate Interface mode.
<b>LCMT</b>	B8S	code substitution method - <b>Must match the far -end</b> and the facility equipment.
<b>YALM</b>	FDL	Yellow alarm method-- prompted only if the frame format is ESF -- <b>Must match the far end.</b>
<b>TRSH</b>	15	The maintenance threshold table to be used for this PRI loop, as configured in overlay 73.
<b>DTIC</b>	12	Enter the starting network loop slot for the PRI card -on non-Network loops (i.e. network expansion shelf or module), enter carriage return and ignore the SCH2035 message. Not prompted on the Option 11 system.
<b>REQ</b>	****	Enter **** to terminate the Overlay.
— continued —		

## Setting up digital and ISDN trunks

STEP		ACTION
<b>4 Add a DCHI card and the D-channel interface.</b>		
	<b>&gt;LD 17</b>	
<b>REQ</b>	CHG	Enter CHG
<b>TYPE</b>	CFN	Enter CFN to change configuration record.
<b>ADAN</b>	NEW DCH 5	Enter NEW DCH 5 to create a D-channel. This port number must match the hardware I/O address on the DCHI card.
<b>CTYP</b>	DCHI	Enter DCHI to configure the D-channel on a D-channel interface card.
<b>DNUM</b>	5	Enter 5 as the available device number. That means that the DCHI card address switch settings must match the DNUM response.
<b>USR</b>	PRA	Enter PRA which means the D-channel is for ISDN PRA only.
<b>IFC</b>	SL1	Enter SL1 to define the interface type as Meridian 1t o Meridian 1.
<b>DCHL</b>	9	Enter 6 as the PRI loop number which will be carrying the D-channel as it's 24th channel.
— continued —		

## Setting up digital and ISDN trunks

STEP ACTION		
4 continued ...		
SIDE	NET	Enter NET to define one side of the PBX-to-PBX interface as the master. Enter USR at the other Meridian 1.  <b>Note:</b> the D-channel will not establish itself if the “master” and “slave” are improperly matched (I.E both ends are programmed as masters).
RLS	xx	Enter the X11 software release of the far-end (i.e. software release 21.0x enter 21.
REQ	* * * *	Enter **** to terminate Overlay.
5 Use Overlay 15 to define a PRA customer.		
>LD 15		
REQ	CHG	Enter CHG
TYPE	CDB	Enter CDB to change customer data block
	NET	Release 21 and later gate opener.
CUST	0	Enter 0 as the customer number.
ISDN	YES	Enter YES to equip the customer with ISDN.
PNI	1	Customer private network identifier.
— continued —		

## Setting up digital and ISDN trunks

STEP ACTION		
5 continued ...		
HNPA	NPA	Telephone area code for this Meridian 1.
REQ	****	Enter **** to terminate Overlay.
6 Use Overlay 16 to define a PRA customer		
>LD 16		
REQ	NEW	Enter CHG
TYPE	RDB	Enter RDB to create a route data block.
CUST	0	Enter 0 as the customer number.
ROUT	100	Route number for this example.
TKTP	TIE	TIE trunk only, allowed between Meridian 1's.
DTRK	YES	Enter YES to specify trunk type as digital.
DGTP	PRI	Enter digital trunk type for route is Primary Rate Interface.
ISDN	YES	Enable ISDN option.
— continued —		

## Setting up digital and ISDN trunks

STEP		ACTION
<b>6 continued ...</b>		
<b>MODE</b>	PRA	Route is used for PRA only.
<b>IFC</b>	SL1	Interface type: Meridian 1 to Meridian 1.
<b>PNI</b>	1	Customer private network identifier <b>-must be the same as the CDB PNI at the far end.</b>
<b>CHTY</b>	BCH	Signalling type -prompted if DTRK is YES.
<b>CTYP</b>	<CR>	Call type.
<b>INAC</b>	YES	Insert Access Code. This prompt only appears on a TIE route and must be set to YES.
<b>ICOG</b>	IAO	Incoming and outgoing trunk route.
<b>ACOD</b>	4	Access code for the trunk route. The access code must not conflict with the numbering plan.
<b>TGAR</b>	0	Trunk access group restriction.
<b>REQ</b>	****	Enter **** to terminate Overlay.
— continued —		

## Setting up digital and ISDN trunks

STEP		ACTION
<b>7 Use Overlay 14 to configure the ISDN trunks</b>		
	<b>&gt;LD 14</b>	
<b>REQ</b>	NEW 24	Enter the multiple create command NEW 24 to create 24 new trunk members.
<b>TYPE</b>	TIE	Tie trunks only allowed between Meridian 1's.
<b>TN</b>	9 1	Enter the digital loop number (DLOP) as specified in step 3 and the starting channel number.
<b>CUST</b>	0	Enter 0 as the customer number.
<b>TGAR</b>	0	Trunk group access restriction. Notice for Release 22 the default is 1 which will automatically block direct access.
<b>CLS</b>	UNR	Enter UNR to specify an unrestricted service.
<b>REQ</b>	****	Enter **** to terminate Overlay.
— continued —		

## Setting up digital and ISDN trunks


STEP ACTION	
<b>8 Use Overlay 73 to configure Clock's reference source</b>	
<b>&gt;LD 73</b>	
<b>REQ</b>	CHG Request.
<b>TYPE</b>	DDB Change the digital data block.
<b>PREF</b>	9 Primary reference source for clock controller. Enter the PRI loop number (DLOP in LD 17) that the QPC720 pack is physically connected.
<b>SREF</b>	9 Secondary reference source for clock controller --prompted only if primary source is not free-run. Use only if Meridian 1 system is equipped with dual CPU.
<b>REQ</b>	**** Enter **** to terminate Overlay.
<b>9 Check D-channel configuration in Overlay 22</b>	
<b>&gt;LD 22</b>	
<b>REQ</b>	PRT Request.
<b>TYPE</b>	ADAN DCH 5 Print configuration for d-channel 5.
— continued —	

## Setting up digital and ISDN trunks

STEP	ACTION	
9 continued ...		
REQ	****	Enter **** to terminate Overlay.
10	Check TIE trunks configuration in Overlay 20	
>LD 20		
REQ	PRT	Request.
TYPE	TIE	Print all TIE trunks.
REQ	****	Enter **** to terminate Overlay.
11	Enable digital trunk interface in LD 60	
>LD 60		
.ENLL	9	Enable PRI loop 9.
.STAT	9	Verify that the loop and all channels are enabled.
REQ	****	Enter **** to terminate Overlay.
— continued —		



## Setting up digital and ISDN trunks

STEP	ACTION	
12	Enable the D-channel in Overlay 96	
	<pre>&gt;LD 96</pre>	
	<pre>.ENL DCH 5</pre>	Enable D-channel 5.
	<pre>.STAT DCH 5</pre>	Verify that the D-channel created in step 4 is enabled.
	<pre>REQ      * * * *</pre>	Enter **** to terminate Overlay.
13	Terminate this programming session.	
	Log off.	
	<pre>&gt;LOGO</pre>	
14	You have completed the programming required to configure a digital trunk.	
		

## Setting up digital and ISDN trunks

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### What to have ready

The following checklist summarizes the steps you should take before setting up digital trunks and trunk routes.

**Table 22**  
**Checklist**


Basic	Optional	Preparation
☐		Decide what digital trunk routes are needed.
☐		Decide what types of digital trunks and what quantity of trunks are needed on each trunk route.
☐		Consider the applicable digital trunk options.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure digital trunks and trunk routes.

## Setting up digital and ISDN trunks



## Setting up digital and ISDN trunks

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of trunks.

STEP	ACTION		
1	<b>Log in.</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	<b>Define threshold parameters and Clock synchronization</b>		
	<b>&gt;LD 73</b>		
	<b>REQ</b>	NEW	
	<b>TYPE</b>	DDB	Enter DDB to configure the digital data block.
	<b>TRSH</b>	0-15	Enter a threshold value of 15 for this example.
	<b>REQ</b>	****	Enter **** to terminate the Overlay
3	<b>Use Overlay 17 to add a PRI loop</b>		
	<b>&gt;LD 17</b>		
	<b>REQ</b>	CHG	Request.
— continued —			

## Setting up digital and ISDN trunks

STEP ACTION		
<b>3 continued ...</b>		
<b>TYPE</b>	CFN	Enter CFN to change the configuration record.
<b>CEQU</b>	YES	Enter YES to make changes to common equipment.
<b>DLOP</b>	xxx dd ff	where xxx is the PRI digital loop number and dd is the number of data calls allowed (0-24) on this PRI (default 24) and ff is the frame format used (D2, D3, D4, ESF) where default is ESF.
<b>MODE</b>	PRI	select Primary Rate Interface mode.
<b>LCMT</b>	(B8S) AMI	code substitution method - <b>Must match the far -end</b> and the facility equipment.B8S--B8ZS code substitution and AMI--B7 code substitution rule. This prompt is misleading since both B7 and B8ZS employ AMI (Alternate Mark Inversion) line encoding method. The preferred method is B8ZS to get 64K clear channel as long as the I1 carrier equipment supports it.
<b>YALM</b>	(FDL) DG2	Yellow alarm method-- prompted only if the frame format is ESF -- <b>Must match the far end.</b> Use FDL with ESF and use DG2 with non-ESF. If not prompted then DG2 is set automatically.
<b>TRSH</b>	0-15	The maintenance threshold table to be used for this PRI loop, as configured in overlay 73.
— continued —		

## Setting up digital and ISDN trunks

STEP ACTION

3 continued ...

DTIC	xxx	Enter the starting network loop slot for the PRI card -on non-Network loops (i.e. network expansion shelf or module), enter carriage return and ignore the SCH2035 message.
REQ	****	Enter **** to terminate the Overlay.

4 Add a DCHI card and the D-channel interface.

>LD 17		
REQ	CHG	Enter CHG
TYPE	CFN	Enter CFN to change configuration record.
ADAN	NEW DCH 0-15	Enter NEW DCH 5 to create a D-channel. This port number must match the hardware I/O address on the DCHI card.
CTYP	DCHI ,MSDL	Enter card type to configure the D-channel.
DNUM	0-15	Enter 5 as the available device number. That means that the DCHI card address switch settings must match the DNUM response.

— continued —

## Setting up digital and ISDN trunks

STEP		ACTION
<b>4 continued ...</b>		
<b>USR</b>	PRA	Enter PRA which means the D-channel is for ISDN PRA only.
	SHA	--D-channel for ISL in "shared" mode, used for both ISDN PRA and ISL
	ISLD	ISL: C-channel for ISL in "dedicated mode".
<b>IFC</b>	(DS100)	Interface type-- Meridian 1 to DMS-100
	ESS4	Meridian 1 to AT&T ESS4
	ESS5	Meridian 1 to AT&T ESS5
	S100	Meridian 1 to SL-100
	D250	Meridian 1 to DMS-250
	SL1	Meridian 1 to Meridian 1
<b>ISLM</b>	1-382	--Number of ISL B-channel (trunks) controlled by the D-channel (no default value).
<b>DCHL</b>	0-159	PRI loop number which will be carrying the D-channel as it's 24th channel.
<b>SIDE</b>		Meridian 1 node type.
	(USR)	Slave to the controller
	NET	Network, the controlling switch
Prompted only if IFC=SL1, ESIG or ISIG. Opposite sides of the PBX-PBX interface must be set as NET or USR. The call processing software uses these labels to handle call collision.		
— continued —		

## Setting up digital and ISDN trunks

STEP ACTION		
4 continued ...		
RLS	xx	Enter the X11 software release of the far-end (i.e. software release 21.0x enter 21.
REQ	****	Enter **** to terminate Overlay.
5 Use Overlay 15 to define a PRA customer.		
>LD 15		
REQ	CHG	Enter CHG
TYPE	CDB	Enter CDB to change customer data block
	NET	Release 21 and later gate opener.
CUST	0-99	Enter 0 as the customer number.
LDNO	xxxx	Enter the customers listed directory number.
ISDN	YES	Enter YES to equip the customer with ISDN.
— continued —		



## Setting up digital and ISDN trunks

STEP		ACTION
<b>5 continued ...</b>		
<b>PNI</b>	1-32700	Customer private network identifier. This number identifies the entire private network to which this customer belongs. All systems belonging to this network will have the same PNI, unless this is a multi-customer Meridian 1 system (in which case each customer within the PBX must be assigned a unique PNI).
<b>HNPA</b>	NPA	Telephone area code for this Meridian 1. Sent as part of setup message as calling line identification for public type calls outside your Area code.
<b>HNXX</b>	NXX	telephone local exchange code for this Meridian 1. Sent as part of setup message as calling line identification for public type calls.
<b>REQ</b>	****	Enter **** to terminate Overlay.
— continued —		

## Setting up digital and ISDN trunks

STEP		ACTION
<b>6 Use Overlay 16 to define digital route data block</b>		
	<b>&gt;LD 16</b>	
<b>REQ</b>	NEW	Enter CHG
<b>TYPE</b>	RDB	Enter RDB to create a route data block.
<b>CUST</b>	xx	xx = 0 - 99
		Enter 0 as the customer number.
<b>ROUT</b>	0-127	Route number. This range applies for all machines.
<b>TKTP</b>	TIE	TIE trunk only, allowed between Meridian 1's.
	ISA	Integrated Service Access route or Call-by-Call route type.
<b>DTRK</b>	YES	Enter YES to specify trunk type as digital.
<b>DGTP</b>	PRI	Enter PRI trunk type for route.
<b>ISDN</b>	YES	Enable ISDN option.
<b>MODE</b>	PRA	Route is used for PRA only.
	ISLD	--TIE route used for ISL members.
— continued —		

## Setting up digital and ISDN trunks

STEP ACTION		
<b>6 continued ...</b>		
<b>IFC</b>	(DS100)	Interface type-- Meridian 1 to DMS-100
	ESS4	Meridian 1 to AT&T ESS4
	ESS5	Meridian 1 to AT&T ESS5
	S100	Meridian 1 to SL-100
	D250	Meridian 1 to DMS-250
	SL1	Meridian 1 to Meridian 1
<b>PNI</b>	1-32700	Customer private network identifier <b>-must be the same as the CDB PNI at the far end.</b>
<b>CHTY</b>	BCH	Signalling type -prompted if DTRK is YES.
<b>CTYP</b>	<CR>	Call type.
<b>INAC</b>	YES	Insert Access Code. This prompt only appears on a TIE route and must be set to YES.
<b>ISAR</b>	YES	Stepping to ISA allowed, in other words this is a service route which will be using ISA channels on a call by call basis. Setting this prompt to NO allows this service route to be used with standard dedicated "B" channels. if ISAR is set to YES the following four prompts will appear.
<b>RTN</b>	0-511	Specify the ISA route to be used by this service route.
— continued —		

## Setting up digital and ISDN trunks

STEP		ACTION
<i>6 continued ...</i>		
<b>SID</b>	0-511	<b>Service ID for this route. The service route ID must match the far end.</b>
<b>MIN</b>	0-254	Minimum number of channels reserved on the ISA route (service dependent). Coordinate with the far end.
<b>MAX</b>	1-254	Maximum number of channels on the ISA route to be used by this service route (service dependent). Coordinate with the far end.
<b>ICOG</b>	IAO	Incoming and outgoing trunk route.
<b>ACOD</b>	x . . x	Access code for the trunk route. The access code must not conflict with the numbering plan. Up to 4 digits with Directory Number Expansion (DNXP) package 150.
<b>TGAR</b>	0	Trunk access group restriction.
<b>REQ</b>	****	Enter **** to terminate Overlay.
— continued —		

## Setting up digital and ISDN trunks

STEP	ACTION		
7	Use Overlay 14 to configure the ISDN trunks		
	>LD 14		
REQ	NEW 24	Enter the multiple create command NEW 24 to create 24 new trunk members.	
TYPE	xxx	Trunk type.	
	TIE	Tie trunk	
	ISA	Integrated Services Access Trunk data block. Also called Call-By-Call service trunk type.	
TN	lll ch	Enter the PRI trunk loop (lll) and channel number (ch). ll=0-159, ch=1-24	
RTMB	RRR MMM	Enter the Route created in LD 16 (RRR) and the member number (MMM).	
CUST	0	Enter 0 as the customer number.	
TGAR	0	Trunk group access restriction. Notice for Release 22 the default is 1 which will automatically block direct access.	
CLS	UNR	Enter UNR to specify an unrestricted service.	
REQ	****	Enter **** to terminate Overlay.	
— continued —			

## Setting up digital and ISDN trunks

STEP		ACTION	
8		Use Overlay 73 to configure Clock's reference source	
		<b>&gt;LD 73</b>	
	<b>REQ</b>	CHG	Request.
	<b>TYPE</b>	DDB	Change the digital data block.
	<b>PREF</b>	0-159	Primary reference source for clock controller. Enter the PRI loop number of the QPC720 PRI pack which is physically connected to the clock controller card (QPC775 or QPC471 connector J2) via the QCAD130 cable. This is the PRI T1 which the clock controller will use as it's primary source to synchronize (to track) the system network clock. A carriage return here signifies the system will operate in free-run (non-tracking mode).
	<b>SREF</b>	0-159	Primary reference source for clock controller. Enter the PRI loop number of the QPC720 PRI pack which is physically connected to the clock controller card (QPC775 or QPC471 connector J1) via the QCAD130 cable. This is the PRI T1 which the clock controller will use as it's secondary source to synchronize (to track) the system network clock. Only used when unable to track on the primary source (i.e. too many slips). Carriage return if there is no secondary source.
	<b>REQ</b>	****	Enter **** to terminate Overlay.
— continued —			

## Setting up digital and ISDN trunks

STEP	ACTION		
	<i>8 continued ...</i>		
9	Check D-channel configuration in Overlay 22		
	>LD 22		
	REQ	PRT	Request.
	TYPE	ADAN DCH X	X= 0 - 15
			Print configuration for D-channel.
10	Check trunk configuration in Overlay 20		
	>LD 20		
	REQ	PRT	Request.
	TYPE	xxx	Enter Type of trunk programmed in Overlay 16.
	REQ	****	Enter **** to terminate Overlay.
— continued —			

## Setting up digital and ISDN trunks

STEP	ACTION	
11	Enable digital trunk interface in LD 60	
	<pre>&gt;LD 60</pre>	
	<pre>.ENLL 111</pre>	III = digital loop created in Step 3 (DLOP). Enable PRI loop.
	<pre>.STAT 111</pre>	Verify that the loop and all channels are enabled.
	<pre>REQ      ****</pre>	Enter **** to terminate Overlay.
12	Enable the D-channel in Overlay 96	
	<pre>&gt;LD 96</pre>	
	<pre>.ENL DCH X</pre>	X = 0 - 15 Enable D-channel.
	<pre>.STAT DCH X</pre>	X = 0 - 15 Verify that the D-channel created in step 4 is enabled.
	<pre>REQ      ****</pre>	Enter **** to terminate Overlay.
— continued —		



## Setting up digital and ISDN trunks

### STEP ACTION

- 13 Perform a data dump to permanently store the programming you have just completed.**

**CAUTION**

Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

- 14 Verify that the data dump was successful.**

On-screen response:

NO GO BAD DATA

or


DATA DUMP COMPLETE

- 15 Terminate this overlay program.**

\*\*\*\*

— continued —

## Setting up digital and ISDN trunks

STEP	ACTION
16	<b>Terminate this programming session.</b>  Log off.  >LOGO
17	<b>You have completed the programming required to configure digital trunks.</b>
	

## 510 Trunk Route Member Expansion

### Purpose

The 510 Trunk Route Member Expansion feature allows a customer to configure a maximum of 510 trunk route members per route (range 1-510). The previous maximum was 254 (range 1-254).

The need for this expansion was particularly evident for a Meridian 1 to DMS Central Office connectivity, where the full potential of a T-1 nB+D configuration (384 B-Channels) was not able to be realized. The DMS supports one D-Channel per route. With a limit of 254 route members per D-Channel, this meant that the maximum offered by nB+D could not be utilized.

With the 510 Trunk Route Member Expansion feature implemented, when connecting a Meridian 1 to another Meridian 1, or a Meridian 1 to a DMS Central Office PBX, users now have greater flexibility when configuring their systems.

For a Meridian 1 to Meridian 1 connectivity, a user is now able to configure, on one trunk route, one D-Channel with 382 B-Channels, a Backup D-Channel, and a second D-Channel with another 128 B-Channels. If desired, another Backup D-Channel may be configured allowing the user to configure the full complement of nB+D, which is one D-Channel with 382 B-Channels, and a Backup D-Channel.

---

## 510 Trunk Route Member Expansion

---

### Trunk Mode Configurations

This feature applies to the following trunk mode configurations:

- ◆ PRI mode
- ◆ DTI mode
- ◆ Shared mode
- ◆ Virtual Network Services (VNS)
- ◆ ISL mode
- ◆ Analog mode

The following trunk types are supported:

- ◆ ISA (Integrated Services Access)
- ◆ CBCT (NI-2 Call By Call Service Selection)
- ◆ COT (Central Office)
- ◆ TIE
- ◆ DID (Direct Inward Dial)
- ◆ FEX (Foreign Exchange)
- ◆ FGDT (Feature Group D)
- ◆ WATS (Wide Area Telecommunications Service)

### Affected Overlays

The overlay programs that are affected are:

- ◆ LD, 14, the Trunk Data Block
- ◆ LD, 16 the Route Data Block

---

## 510 Trunk Route Member Expansion

---

### Maintenance Routines

Maintenance routines are also affected.

For the Call Trace LD 80, the TRAC c r m (trace calls, customer c, member m) is modified to allow “member” input from 1 to 510.

For the Automatic Trunk Maintenance LD 92, the ATMR c r m (Test customer c, route r, member m) is modified to allow “member” input from 1 to 510.

For traffic measurements, in the Customer Traffic Measurement Output report TFC002, the total number of trunks for the “Trunks Equipped” and “Trunks Working” fields has been increased to a maximum of 510.

In the CDR output format, the Originating Identification (ORIGID) and Terminating Identification (TERID) fields now displays the trunk route member field in the range 1-510.

## 510 Trunk Route Member Expansion

---

## Configuring tones

### Purpose

Tones are used by the Meridian 1 and other telephone equipment for signalling. This equipment includes all 2500-type telephones and trunks that send Digitone Multifrequency (DTMF) tones to the system, and by Multifrequency (MF) trunks that send MF tones to the system. All 2500 sets and some trunks must have class of service (CLS) defined as Digitone (DTN).

Configuring tones is your final task, and should only be completed after 2500-type telephones and trunk requirements have been determined for the complete system. Refer to *System Engineering* for details on calculating tone configuring requirements

### Digitone receivers

Digitone receivers (DTR) are cards that are equipped on your Meridian 1 if you are using Digitone-type telephones or if your system connects to trunks that use Digitone signaling. The DTR interprets the Digitone tone signals, converting tones into a digital signal that the Meridian 1 CPU can use.

DTRs are shared among all the Digitone-type telephones and trunks. The number of DTRs needed on your system depends on the number of Digitone-type telephones to be used, the number of Digitone signaling trunks, and the expected level of traffic.

---

## Configuring tones

---

### Tone detectors

Tone detectors (TDET) are used by the Meridian 1 to identify tones being sent to the system across trunks. TDETs are shared among all the trunks equipped on the Meridian 1.

### Dial tone detectors

Dial tone detectors (DTD) are used by the Meridian 1 to detect dial tone on outgoing trunks. The number of DTDs needed on your system is determined by the number of trunks that have been equipped, and the level of outgoing traffic.

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1.



## Configuring tones

### What to have ready

The following checklist summarizes the steps you should take before configuring tones.

**Table 23**  
**Checklist**


Basic	Optional	Preparation
Đ		Prepare to equip Digitone receivers by determining the number of receivers needed, the TNs, and the card density.
Đ		Prepare to equip tone detectors by determining the number of detectors needed, the types of detector, the TNs, and the card density.
Đ		Prepare to equip multifrequency senders and receivers by determining the number of units needed, the TNs, and the card density.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure tones.

## Configuring tones



## Configuring tones

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of tone hardware.

STEP	ACTION		
<b>1</b>	<b>Log in</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
<b>2</b>	<b>Define a new dial tone detector.</b>		
	<b>&gt;LD 13</b>		
	<b>REQ</b>	NEW	Add data to the system.
	<b>TYPE</b>	DTD	Add a new dial tone detector (DTD).
	<b>TN</b>	L S C U	Enter the DTD's TN. (Loop number, Shelf number, Card number, Unit number).
	<b>POLR</b>	NORM, REV	Select either normal or reverse LED message polarity.
	<b>CDEN</b>	SD, DD, 4D	Choose a card density (single, double, or quadruple density).
— continued —			

## Configuring tones

STEP ACTION		
<b>3 Define a new Digitone receiver.</b>		
<b>REQ</b>	NEW	Add data to the system.
<b>TYPE</b>	DTR	Add a new Digitone receiver (DTR).
<b>TN</b>	L S C U	Enter the DTR's TN. ( <b>L</b> oop number, <b>S</b> helf number, <b>C</b> ard number, <b>U</b> nit number).
<b>CDEN</b>	SD, DD, 4D	Choose a card density (single, double, or quadruple density).
<b>4 Define a new multifrequency sender/receiver data block.</b>		
<b>REQ</b>	NEW	Add data to the system.
<b>TYPE</b>	MFC	Add a new multifrequency sender/receiver.
<b>TN</b>	L S C U	Enter the sender/receiver's TN. ( <b>L</b> oop number, <b>S</b> helf number, <b>C</b> ard number, <b>U</b> nit number).
<b>CDEN</b>	SD, DD, 4D	Choose a card density (single, double, or quadruple density).
— continued —		

## Configuring tones

STEP ACTION		
<b>5 Define a new tone detector.</b>		
<b>REQ</b>	NEW	Add data to the system.
<b>TYPE</b>	TDET	Add a new tone detector.
<b>TN</b>	L S C U	Enter the tone detector's TN. (Loop number, <b>S</b> helf number, <b>C</b> ard number, <b>U</b> nit number).
<b>CDEN</b>	SD, DD, 4D	Choose a card density (single, double, or quadruple density).
<b>6 Define a new extended dial tone detector and Digitone receiver.</b>		
<b>REQ</b>	NEW	Add data to the system.
<b>TYPE</b>	XTD	Add a new detector.
<b>TN</b>	L S C U	Enter the tone detector's TN. (Loop number, <b>S</b> helf number, <b>C</b> ard number, <b>U</b> nit number).
<b>XTDT</b>	0-7	Enter the extended tone detector table number.
<b>DTO</b>	YES, NO	Enter YES to disable dial tone detection, and NO to leave it enabled.
<b>CDEN</b>	SD, DD, 4D	Choose a card density (single, double, or quadruple density).
— continued —		

## Configuring tones

### STEP ACTION

#### 7 Check that your programming is correct.

Review your programming to ensure that it is correct, either by scrolling up in your terminal window or by reading the terminal's printer output. If you are using a terminal without scroll or printing capabilities, use overlay 22 to print out the data you have entered. For more information about overlay 22, see the beginning of this guide.

**If**

**Do**

everything is correct

step 8

something is not correct

step 1

#### 8 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Configuring tones

STEP	ACTION
9	<b>Verify that the data dump was successful.</b>  On-screen or printed response:  NO GO BAD DATA or DATA DUMP COMPLETE
10	<b>Terminate this overlay program.</b>  * * * *
11	<b>Terminate this programming session.</b>  Log off.  >LOGO
12	<b>You have completed the programming required to configure tones.</b>
	

## Configuring tones

---



# Defining flexible feature codes

## Purpose

Flexible Feature Codes (FFC) are user-defined numbers of up to seven digits that can be used in place of existing Special Prefix (SPRE) codes. The Flexible Feature Code (FFC) feature allows customers to define dialing codes that provide access to features normally provided on telephone function keys.

## Flexible feature codes

Basic FFC operation allows a telephone to access features normally available by dialing SPRE codes.

### Dialing FFCs

Users can dial the digits 0 through 9, and the asterisk (\*) and octothorpe (#) to activate features. Customers using the octothorpe as part of their dialing plan can use a predefined string of digits for end-of-dialing indicators.

#### **Attendant and Network-Wide Remote Call Forward**

If the Outpulsing of Asterisk and Octothorpe (OPAO) package is equipped, the octothorpe (#) is treated as a dialed digit and does not signal the end of dialing. From one to three end-of-entry characters are defined in overlay 15.

### Dialing plan

There is no limit to the number of FFCs used for each function, as long as each FFC is unique. FFCs cannot conflict with any Directory Number (DN) already in the dialing plan.

---

## Defining flexible feature codes

---

### Analog telephones

FFCs allow analog (500/2500 type) telephones to override established calls, based on the telephones' programmed Class of Service. Analog (500/2500 type) telephones can also activate and deactivate Call Forward by dialing a single FFC.

The FFC package lets analog telephones activate the following features:

- ◆ Automatic Wake Up (AWU)
- ◆ Electronic Lock (ELK)
- ◆ Override
- ◆ Remote Call Forward (RCFW).

Customers must define one or more codes for each feature function, at their discretion, in overlay 57.

### Meridian Digital Telephones

FFCs are not supported on a Meridian 1 telephone that is attempting a call pickup on a Dial Intercom ringing call.

### Controlled Class of Service (CCOS)

If Electronic Lock (ELK) is activated, the CCRS Class of Service is used whether CCOS is active or not. ELK takes precedence over CCOS. If ELK is deactivated, the set is treated as per existing operation.

When FFC ELKA and a password is entered, this set will use the CCRS Class of Service configured in overlay 15. The CCRS Class of Service will always be used whether or not CCOS is currently controlling the set's Class of Service. When FFC ELKD and a password is entered, the set will use the appropriate Class of Service associated with this set. If CCOS is enabled for the set, the associated customer Class of Service is used (for example, CCRS, ECC1, or ECC2). If CCOS is not enabled for this set, the set's own Class of Service is used.

---

## Defining flexible feature codes

---

When FFC ELK is deactivated, the set reverts back to the Class of Service as it should be without FFC ELK, instead of always reverting back to the set's Class of Service (for example, if CCOS is enabled, it will use the customer's Class of Service; if CCOS is not enabled, it will use the set's Class of Service).

### Station Control Password

Set the Station Control Password length for each telephone during the configuration of telephones in overlay programs 10 and 11. Procedures are provided later in this guide.

### Automatic Wake Up

Telephones can activate Automatic Wake Up (AWU) features for their own station with Common Controlled Switching Arrangement Class of Service.

### Call Forward All Calls

When FFC is configured for a customer, #1 automatically becomes the FFC DN for both Call Forward Activate (CFWA) and Call Forward Deactivate (CFWD). When the same DN is used for both CFWA and CFWD, FFC toggles the Call Forward activated/deactivated state of the telephone. When Call Forward is activated for a telephone, entering #1 automatically deactivates Call Forward, no matter what follows #1. When Call Forward is deactivated for a telephone, the result of entering #1 depends on what follows:

- ◆ If the telephone goes on hook immediately, Call Forward is activated for the telephone to its previous call forward number.
- ◆ If a valid DN is entered after #1, call forward is activated for the telephone to that valid DN.
- ◆ If an invalid DN is entered after #1, call forward remains deactivated for the telephone.

### FFC length

With DN Expansion (DNXP) package 150, FFCs can be up to seven digits long. Without package 150, FFCs are limited to four digits.

---

## Defining flexible feature codes

---

### Confirmation tone

Confirmation tone is the same as special dial tone.

Confirmation tone is a tone provided to analog (500/2500 type) telephones and Meridian 1 telephones when certain functions are complete. Confirmation tone is returned following these events:

- ◆ Automatic Wake Up (any function)
- ◆ Electronic Lock (any function)
- ◆ Ring Again (activate or deactivate)
- ◆ Call Forward (activate)
- ◆ Call Forward (deactivate)
- ◆ Permanent Hold (any function)
- ◆ Store Number (store)
- ◆ Flexible Feature Code (any verification).
- ◆ Room Status (any function)
- ◆ Speed Call (store)
- ◆ Speed Call Controller (add to Speed Call list), and
- ◆ Store Number (erase).

Confirmation Tone is provided for Speed Call store after the End-of-Dial string, such as the octothorpe (#), is entered.

To enable confirmation tone, respond to the FFCT prompt in overlay 57.

### Outgoing Call Barring

Flexible Feature Codes containing a "\*" or an "#" will always be allowed by Outgoing Call Barring (OCB). Therefore, FFCs which can be used to make a call should be entirely numeric if barring of them is required.

Some FFCs are equivalent to Special Prefix functions and these will be subject to barring based on the equivalent Special Prefix codes, even if the FFC is entirely numeric.

---

## Defining flexible feature codes

---

### Performing service change

Overlay 57 allows no more than 100 FFCs to be modified during a single pass through Service Change.

Changes to the Station Control Passwords (SCPW) do not take effect until after a data dump and system load (SYSLOAD).

Configuring the system or enabling the feature changes the Station Control Password Length (SCPL). This change takes effect immediately. When the SCPL is changed, all associated passwords change accordingly at the next data dump and SYSLOAD. For example, changing SCPL from three to five automatically inserts leading zeros before all existing three-character passwords. Changing SCPL from five to three automatically truncates the leading characters of all existing five-character passwords.

Any other change to SCPL in overlay 15 requires a data dump and SYSLOAD before taking effect.

### Special prefix codes

Special Prefix (SPRE) dialing operates normally with or without the FFC feature.

The SPRE must be assigned in overlay 15 in order for FFCs to operate for those features that also use SPRE codes. The SPRE feature must exist in order for FFC to operate.

A telephone can access a feature by way of FFCs only if that telephone already has access to the same feature by way of SPRE dialing. Any telephone that does not currently have SPRE access receives intercept treatment when dialing FFCs. Telephone operation is the same for both types of feature access: the FFC code is dialed instead of the SPRE code.

---

## Defining flexible feature codes

---

### Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

### Error messages

The following error messages sometimes appear during FFC programming.

**SCH3236**

þFFC block already exists.

**SCH3238**

þFFC package unequipped.

**SCH3242**

þInvalid FFC mnemonic.

**SCH3817**

þFFC state is being set to zero due to conflict with the new ASEQ.

**SCH3818**

þFFC conflicts with another FFC's numeric equivalent.

**SCH3820**

þFFC and/or equivalent conflicts with an already existing DN.

---

## Defining flexible feature codes

---

### What to have ready

The following checklist summarizes the steps you should take before configuring FFCs.

**Table 24**  
**Checklist**


Basic	Optional	Preparation
Đ		Get a list of functions that you want to make available using feature codes.
Đ		Get a list of the codes you are going to assign to each function.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure FFCs.

## Defining flexible feature codes



The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.



Defining flexible feature codes

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of FFCs.

STEP		ACTION	
1	Log in.		
For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .			
2	Configure Controlled Class of Service.		
>LD 15			
REQ	CHG		
TYPE	CCS_DATA	Enter CCS DATA to change controlled class of service.	
CUST	0-99	Enter the customer number.	
CCRS	aaa	Enter the Controlled Class of Service. For unrestricted COS, enter UNR. For toll denied COS, enter TLD. For conditionally toll denied COS, enter CTD. For conditionally unrestricted COS, enter CUN. For semi-restricted COS, enter SRE. For fully restricted COS, enter FRE. For fully restricted level 1 COS, enter FR1. For fully restricted level 2 COS, enter FR2.	
— continued —			

## Defining flexible feature codes

STEP		ACTION
3 Configure FFC parameters.		
TYPE	FFC_DATA	Enter FFC DATA to change FFC parameters.
CUST	0-99	Enter the customer number.
CCRS	aaa	Enter the Controlled Class of Service. For unrestricted COS, enter UNR. For toll denied COS, enter TLD. For conditionally toll denied COS, enter CTD. For conditionally unrestricted COS, enter CUN. For semi-restricted COS, enter SRE. For fully restricted COS, enter FRE. For fully restricted level 1 COS, enter FR1. For fully restricted level 2 COS, enter FR2.
SCPL	0-8	Specify the Station Control Password Length.
SBUP	YES, NO	Enter YES to enable use of Station Control Passwords for set-based administration user level access, or NO to disable set-based administration.
PWD2	xxxxx	If you responded to SBUP with YES, enter a password (PWD2) for confirmation.
SCPL	0-8	Specify the Station Control Password Length.
FFCS	YES, NO	Enter YES to change the FFC end-of-dialing indicator, or NO to leave it unchanged.
STRL	1-3	If you entered YES to the FFCS prompt, specify the string length for the end-of-dialing indicator.
STRG	aaa	If you entered YES to the FFCS prompt, specify the character string for the end-of-dialing indicator.
ADLD	0-20	Enter the autodial delay (in seconds).
REQ	END	Exit the overlay.
— continued —		

## Defining flexible feature codes

STEP		ACTION	
4	Define codes for FFCs.		
>LD 57			
REQ	NEW		
TYPE	FFC	Enter FFC to create FFCs.	
CUST	0-99	Enter the customer number.	
FFCT	YES, NO	Enter YES to enable FFC Confirmation Tone, or NO to disable it.	
CEPT	YES, NO	Enter YES to allow Conference European des Postes Tel defaults, or NO to deny the defaults.	
REP	n	Enter the single-character replacement for asterisk (*) and octothorpe (#) in CEPT defaults. To create only the default, press the carriage return.	
CODE	ALL, aaaa	Enter ALL to make FFCs for all features, or enter the FFC type to change only some FFCs.	
ASRC	xxxxx	Enter the Automatic Set Relocation code.	
ATDA	xxxxx	Enter the Autodial Activate code.	
ATDD	xxxxx	Enter the Autodial Deactivate code.	
AUTH	xxxxx	Enter the Authorization code.	
AWUA	xxxxx	Enter the Automatic Wake Up Activate code.	
— continued —			

## Defining flexible feature codes

STEP ACTION		
<b>4 continued ...</b>		
<b>AWUD</b>	xxxxx	Enter the Automatic Wake Up Deactivate code.
<b>AWUV</b>	xxxxx	Enter the Automatic Wake Up Verify code.
<b>BNRA</b>	xxxxx	Enter the Busy Number Redial code.
<b>BNRD</b>	xxxxx	Enter the Busy Number Redial Deactivate code.
<b>CCFA</b>	xxxxx	Enter the Customer Call Forward code.
<b>CCFD</b>	xxxxx	Enter the Customer Call Forward Deactivate code.
<b>CDRC</b>	xxxxx	Enter the Call Detail Recording Charge Account code.
<b>CFHO</b>	xxxxx	Enter the Call Forward/Hunt Override code.
<b>CFWA</b>	xxxxx	Enter the Call Forward All Calls Activate code.
<b>CFWD</b>	xxxxx	Enter the Call Forward All Calls Deactivate code.
<b>CFWV</b>	xxxxx	Enter the Call Forward All Calls Verify code.
<b>COND</b>	xxxxx	Enter the Conference Diagnostics code.
<b>CPAC</b>	xxxxx	Enter the Call Park Access code.
<b>CPP</b>	xxxxx	Enter the Calling Party Privacy code.
<b>CPRK</b>	xxxxx	Enter the Call Park code.
<b>— continued —</b>		

## Defining flexible feature codes

STEP		ACTION
<b>4 continued ...</b>		
	<b>CSHF</b>	xxxx Enter the Centrex Switch-hook Flash code.
	<b>CWGA</b>	xxxx Enter the Call Waiting Activated code.
	<b>CWGD</b>	xxxx Enter the Call Waiting Deactivated code.
	<b>C6DS</b>	xxxx Enter the Six-Party Conference code.
	<b>DEAF</b>	xxxx Enter the Deactivate Feature code.
	<b>DPVS</b>	xxxx Enter the Data Port Verification code.
	<b>ELKA</b>	xxxx Enter the Electronic Lock Activate code.
	<b>ELKD</b>	xxxx Enter the Electronic Lock Deactivate code.
	<b>EOVR</b>	xxxx Enter the Enhanced Override code.
	<b>GHTA</b>	xxxx Enter the Group Hunt Termination Allowed code.
	<b>GHTD</b>	xxxx Enter the Group Hunt Termination Disallowed code.
	<b>GRPF</b>	xxxx Enter the Group Call code.
	<b>GRCL</b>	xxxx Enter the Group Call List Number code.
	<b>HIDN</b>	xxxx Enter the Hospitality Identification (Hospitality Management) code.
— continued —		

## Defining flexible feature codes

STEP ACTION		
<b>4 continued ...</b>		
<b>HOLD</b>	xxxxx	Enter the Permanent Hold code.
<b>ICFA</b>	xxxxx	Enter the Internal Call Forward Activate code.
<b>ICFD</b>	xxxxx	Enter the Internal Call Forward Deactivate code.
<b>ICFY</b>	xxxxx	Enter the Internal Call Forward Verify code.
<b>INST</b>	xxxxx	Enter the Set Based Administration Installer code.
<b>HREL</b>	xxxxx	Enter the Hospitality Relocation (Hospitality Management) code.
<b>ICPA</b>	xxxxx	Enter the Intercept Computer Interface Activate code.
<b>ICPD</b>	xxxxx	Enter the Intercept Computer Interface Deactivate code.
<b>ICPO</b>	xxxxx	Enter the Intercept Computer Interface Override code.
<b>ICPP</b>	xxxxx	Enter the Intercept Computer Interface Print code.
<b>IMS</b>	xxxxx	Enter the Integrated Message System Access code.
<b>ITXX</b>	xxxxx	Enter the code for "1xx" Special Services (up to four digits).
— continued —		

## Defining flexible feature codes

STEP		ACTION
<b>4 continued ...</b>		
<b>RTXX</b>	xxxx	Enter the central office route number for the "1xx" service identified at the ITXX prompt.
<b>LILO</b>	xxxx	Enter the Log in -Log out code for analog ACD telephones.
<b>LIXX</b>	xxxx	Enter the Login (non-toggle mode) code for analog ACD telephones.
<b>MLIO</b>	xxxx	Enter the Multi-language I/O code.
<b>MNT</b>	xxxx	Enter the Set-based Administration Sequence code.
<b>MNTC</b>	xxxx	Enter the Maintenance Access code.
<b>MSBA</b>	xxxx	Enter the Make Set Busy Activated code.
<b>MSBD</b>	xxxx	Enter the Make Set Busy Deactivated code.
<b>MTRC</b>	xxxx	Enter the Malicious Call Trace code.
<b>MWRA</b>	xxxx	Enter the Repeat Multiple Wake Up Activated code.
<b>MWUA</b>	xxxx	Enter the Multiple Wake Up Activated code.
<b>MWUD</b>	xxxx	Enter the Multiple Wake Up Deactivated code.
<b>NRDV</b>	xxxx	Enter the Not Ready Activation/Deactivation code for analog ACD telephones.
— continued —		

## Defining flexible feature codes

STEP ACTION		
<i>4 continued ...</i>		
OCRD	xxxxx	Enter the Override and Priority Override code.
OCBA	xxxxx	Enter the Outgoing Call Barring code.
OCBD	xxxxx	Enter the Outgoing Call Barring Deactivate code.
OCBV	xxxxx	Enter the Outgoing Call Barring Verify code.
PGAP	xxxxx	Enter the Answer Parallel Paging code.
PGIP	xxxxx	Enter the Initiate Parallel Paging code.
PGSP	xxxxx	Enter the Initiate Serial Paging code.
PLDN	xxxxx	Enter the Pilot DN code.
PUDN	xxxxx	Enter the Pick Up DN code.
PUGR	xxxxx	Enter the Pick Up Group code.
PURN	xxxxx	Enter the Pick Up Ringing Number code.
RCFA	xxxxx	Enter the Remote Cal Forward Activate code.
RCFD	xxxxx	Enter the Remote Cal Forward Deactivate code.
RCFV	xxxxx	Enter the Remote Cal Forward Verify code.
RDLN	xxxxx	Enter the Redial Last Number code.
— continued —		



## Defining flexible feature codes

STEP		ACTION
<b>4 continued ...</b>		
	<b>RDNE</b>	xxxx Enter the Redial Number Erase code.
	<b>RDSN</b>	xxxx Enter the Redial Saved Number code.
	<b>RDST</b>	xxxx Enter the Redial Store code.
	<b>RGAA</b>	xxxx Enter the Ring Again Activate code.
	<b>RGAD</b>	xxxx Enter the Ring Again Deactivate code.
	<b>RGAV</b>	xxxx Enter the Ring Again Verify code.
	<b>RMST</b>	xxxx Enter the Room Status code.
	<b>RPAN</b>	xxxx Enter the Radio Paging Answer Call code.
	<b>RPAX</b>	xxxx Enter the Radio Paging Access code.
	<b>SADS</b>	xxxx Enter the SAR Disable code.
	<b>SAEN</b>	xxxx Enter the SAR Enable code.
	<b>SALK</b>	xxxx Enter the SAR Lock code.
	<b>SAUN</b>	xxxx Enter the SAR Unlock code.
	<b>SCPC</b>	xxxx Enter the Station Control Password Change code.
	<b>SFAC</b>	xxxx Enter the Secretarial Filtering Access code.
— continued —		

## Defining flexible feature codes

STEP		ACTION
<b>4 continued ...</b>		
	<b>SPCC</b>	xxxxx Enter the Speed Call Controller code.
	<b>SPCE</b>	xxxxx Enter the Speed Call Erase code.
	<b>SPCU</b>	xxxxx Enter the Speed Call User code.
	<b>SSPU</b>	xxxxx Enter the System Speed Call User code.
	<b>TFAS</b>	xxxxx Enter the Trunk Answer From Any Station code.
	<b>TNDN</b>	xxxxx Enter the DN-to-TN Conversion Utility code.
	<b>TRMD</b>	xxxxx Enter the Terminal Diagnostics code.
	<b>TRVS</b>	xxxxx Enter the Trunk Verification code.
	<b>USER</b>	xxxxx Enter the Set-based Administration User code.
	<b>USCR</b>	xxxxx Enter the User Selectable Call Redirection code.
	<b>USTA</b>	xxxxx Enter the User Status code.
— continued —		

## Defining flexible feature codes

### STEP ACTION

#### 5 Check that your programming is correct.

Review your programming to ensure that it is correct, either by scrolling up in your terminal window or by reading the terminal's printer output. If you are using a terminal without scroll or printing capabilities, use overlay 22 to print out the data you have entered. For more information about overlay 22, see the beginning of this guide.

If	Do
parameters are correct	step 6
parameters are not correct	step 1

#### 6 Perform a data dump to permanently store the programming you have just completed.



##### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Defining flexible feature codes


STEP	ACTION
7	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p><b>NO GO BAD DATA</b></p> <p>or</p> <p><b>DATA DUMP COMPLETE</b></p>
8	<p><b>Terminate this overlay program.</b></p> <p>* * * *</p>
9	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
10	<p><b>You have completed the programming required to configure flexible features codes.</b></p>
	

## Setting up speed call

### Purpose

Speed Call lets telephone users place calls to preprogrammed numbers by dialing a one-, two-, or three-digit code. Speed Call codes provide easy access to commonly called numbers.


The telephone numbers are stored in Speed Call lists.



## Setting up speed call

### Speed Call lists

There are two kinds of Speed Call list. One type of list, the system-wide Speed Call list, can be accessed from any telephone. The company can program commonly used numbers into the system-wide Speed Call list, giving all employees access to commonly used telephone numbers.




---

## Setting up speed call

---

The other type of Speed Call list is specific to each Directory Number. Telephone users can program these private Speed Call lists with the numbers they most frequently call.



### List limits

Each stored number is assigned a Speed Call code from the Speed Call list. Each list can contain up to 1000 telephone numbers (entries). The maximum number of digits of the telephone number that can be stored in each entry is specified by the customer. Speed Call entries can be 4, 8, 12, 16, 20, 24, 28, or 31 digits long.

You can define up to 8191 (0-8190) Speed Call lists per system, as long as enough memory is available. The limit includes all combined Speed Call, System Speed Call (SSC), and Hot Line lists.

You can have as many Speed Call lists as you have available key/lamp pairs on any Meridian 1 proprietary telephone, or attendant console. Any number of users can be assigned to a list. Analog (500/2500 type) telephones can access only one Speed Call list.

---

## Setting up speed call

---

A maximum of 31 digits for the telephone number is allowed per Speed Call list entry. An asterisk (\*), which indicates a pause, and an octothorpe (#), which indicates end-of-dialing, can be programmed as part of the entry.

Speed Call list entries can be defined in LD 18 or by Speed Call Controllers (SCC). SCCs must know the digit length (one, two, or three) required for the Speed Call codes in each list.

### Speed call operation

You can use Speed Call for both internal and external calls.

#### Programming and using lists

SCCs can program numbers into the Speed Call list. Speed Call Users (SCU) can use the Speed Call list. SCCs and SCUs can be analog (500/2500 type) telephones, Meridian 1 proprietary telephones, and attendant consoles.

Telephones designated as a SCUs cannot program numbers into lists.

You can assign more than one SCC to each list, but it is not recommended.

#### Speed Call dialing

When storing an external number on a Speed Call list, enter the appropriate trunk group access code in front of the digits in the call.

For example, an external number in North America, such as 555-1212 is stored as 95551212.

SL-1, Meridian SL-1 and Meridian 1 systems do not require a pause after a COT (Central Office Trunk) access code such as 9.

If a pause for dial tone is required between digits, use the asterisk (\*). The \* provides a 3 second pause between digits.



---

## Setting up speed call

---

If the call is to be routed over to another type of system first, and outpulsed from there, that system might require a pause after the trunk access code, before the other digits in the number are outpulsed. For example, if you want to send calls over a TIE trunk and then outpulse digits from the system at the other end, store the same number as described above as follows. If 82 is the TIE trunk access code for the TIE trunks to another system and it is not an SL-1, Meridian SL-1 or Meridian 1 system, store a number as 82\*9\*5551212. You might be able to remove the pauses if the other system does not require them. Experiment with the number of pauses you need until you find a sequence of digits and pauses that works every time.

Store an octothorpe (#) at the end of the digits to indicate end of dialing. This speeds up outpulsing of the call.

The Speed Call key cannot be used after a Centrex Switchhook Flash or during an established call to send digits out to the far site. The Speed Call key can be used only during the dialing stage.

### Privacy

A telephone user can store a Calling Party Privacy (CPP) code as part of a telephone number in the in the Speed Call list. An outgoing trunk call placed using the Speed Call code will carry the Privacy Indicator. The user cannot dial \*67 (or anything else) before accessing a Speed Call list entry.

### Authorization codes

If a Speed Call entry is programmed with a valid Authcode for Authcode Last followed by an octothorpe "#", the existing Authcode Last operation will reject the Authcode as an invalid Authcode. If Authcode Last Retry is defined, the caller will be reprompted for the Authcode.

### Last Number Redial

A number dialed using Speed Call will become the Last Number Redial number on all telephones except the M2317 and M3000.

---

## Setting up speed call

---

### Pretranslation

A Speed Call List number should be programmed to allow for Pretranslation. For example, if 9 pretranslates to 99 and you want to reach 99 nxx xxxx, you need to program the number in the Speed Call List as 9 nxx xxxx. When the Speed Call List is used, 9 nxx xxxx is pretranslated at call processing time to become 99 nxx xxxx.

### Three Wire Analog Trunk - Commonwealth of Independent States (CIS)

Speed Call on an E3W trunk will fail for toll calls. E3W trunks do not wait for the ANI request from the Public Exchange, that is expected to appear after the toll access code is dialed. The Public Exchange will not accept the call due to the failure to receive ANI information.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

---

## Setting up speed call

---

### What to have ready

The following checklist summarizes the steps you should take before configuring Speed Call.

**Table 25**  
**Checklist**


Basic	Optional	Preparation
☐		Decide what sizes of Speed Call list are required. (Consider both the length of DN, and the number of entries allowed in each list.)
☐		Define the contents of System Speed Call lists.
	☐	Define the contents of Speed Call lists.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure Speed Call.

## Setting up speed call



The flowchart summarizes the procedure. Use the instructions in the step-action table that follows this flowchart to perform the procedure.

## Setting up speed call

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of Speed Call.

STEP		ACTION
1		Log in.
		For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .
2		Calculate the available memory and disk space.
		>LD 18
REQ	COMP	Enter COMP to compute disk and memory requirements for new lists.
TYPE	SCL	Enter SCL to calculate space for Speed Call.
NOLS	1-8191	Enter the number of lists you are considering adding.
DNSZ	4-31	Enter the maximum length of DNs to be allowed in the new lists.
SIZE	1-1000	Enter the maximum number of DNs to be allowed in the new lists.
		Compare the values the system returns with the MEM AVAIL and DISK RECS AVAIL values to ensure that your system has sufficient memory and disk space.
		— continued —

## Setting up speed call

STEP ACTION		
<b>3 Configure Speed Call lists.</b>		
<b>REQ</b>	NEW	Add a new list.
<b>TYPE</b>	SCL, SSC	Enter SCL create a new Speed Call list, or SSC to create a new System Speed Call list.
<b>LSNO</b>	0-8190	Specify a list number.
<b>NCOS</b>	0-99	Specify the Network Class of Service for System Speed Call.
<b>DNSZ</b>	4-31	Enter the maximum allowable length of DNs in the list.
<b>SIZE</b>	1-1000	Enter the maximum number of DNs to be allowed in the list.
<b>WRT</b>	YES, NO	Enter YES to indicate that your data is correct, and to update the data store.
<b>STOR</b>	xxx y...y	Specify an entry number and the digits to be stored in the entry in the list.
<b>WRT</b>	YES, NO	Enter YES to indicate that your data is correct, and to update the data store.
<b>REQ</b>	END	Exit the overlay.
— continued —		

## Setting up speed call

### STEP ACTION

#### 4 Check your programming.

Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.

If	Do
the programming is correct	step 5
the programming is not correct	step 1

#### 5 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Setting up speed call

STEP	ACTION
6	<b>Verify that the data dump was successful.</b>  On-screen or printed response:  NO GO BAD DATA or DATA DUMP COMPLETE
7	<b>Terminate this overlay program.</b>  * * * *
8	<b>Terminate this programming session.</b>  Log off.  >LOGO
9	<b>You have completed the programming required to configure Speed Call.</b>
	



---

## Setting up speed call

---

### Using Speed Call

Users of Meridian 1 telephones and attendant consoles can press the Speed Call key to place a Speed Call call. Users of analog (500/2500 type) telephones can activate Speed Call by using Special Prefix (SPRE) codes or Flexible Feature Codes (FFC).

For more information about using Speed Call, refer to Task 25, “Setting up telephones”.

## Setting up speed call

---

## Configuring calling party name display

### Purpose

Call Party Name Display (CPND) identifies the calling or called number in addition to the DN. The identifier (that is, the name) is defined in LD 95.

Whenever the calling party's DN appears on the display of the terminating telephone, the calling party's name also appears.

### Display of incoming calls

#### Language

CPND can display the calling party's name on Meridian Digital Telephones in a Roman alphabet (used, for example, for English names), in or Katakana alphabet (the Japanese alphabet).

To select the default CPND language, respond to the CPND\_LANG prompt in overlay 95.

Store the names in the Meridian 1 database under each character set (or alphabet). Use the LANG prompts to select the character set, then use the NAME prompts to enter the ASCII string for the name.

Telephone users select the desired language using program keys on the telephone itself.

---

## Configuring calling party name display

---

### CPND string length

Set the maximum number of characters on a customer's Calling Party Name displays by responding to the MXLN prompt in overlay 95. Set the default display length for a customer by responding to the DFLN prompt.

Set the maximum length for names by responding to the XPLN prompt in overlay 95.

Make sure that you make the maximum display lengths and name lengths large enough. Once the maximum lengths are set, they cannot be changed without erasing associated CPND data.

### Hotel and motel environments

In hotel and motel environments, turn on static allocation of name storage by responding to the STAL prompt in overlay 95. Static allocation is recommended whenever CPND names are likely to change frequently (for example, when guests check in and out), to maintain the efficient use of memory.

### Multiple Appearance DNs

Multiple Appearance directory numbers (DN) are DNs that are connected to more than one telephone. To allow the display of names associated with Multiple Appearance DNs, respond to the DES prompt in overlay 95. This option appears only if the Office Data Administration System (ODAS) package is equipped on your Meridian 1.

---

## Configuring calling party name display

---

### Display of redirected calls

#### Dialed name display

CPND displays the DN and name of the originally dialed party for redirected calls. You must assign a Class of Service, DNDA/DNDD (Dialed Name Display Allowed or Denied) for each telephone using this option. The terminating telephone must have DNDA to display the name of the originally dialed party.

#### Display of reasons for redirection

CPND is capable of displaying a code on the telephone display indicating why an incoming call has been redirected to the telephone. To enable this option for a customer, respond to the RESN prompt in overlay 95. Enter codes to be displayed for various causes of redirection at the CFWD, CFNA, HUNT, NITC, PKUP, XFER, and AAA prompts in overlay 95.

### Display of outgoing calls

On an internal call, the called party's name appears with the displayed DN on the originator's telephone, as soon as the user has finished dialing a valid DN.

---

## Configuring calling party name display

---

### Names

You can assign names to individual DNs, to Dial Intercom Groups (DIG), and to incoming digit conversion (IDC) tables.

#### Names for DNs

To assign names to individual DNs, respond to the DN, LANG, NAME and XPLN prompts in overlay 95.

#### Names for DIGs

To assign names to DIGs, respond to the DIG, LANG, NAME and XPLN prompts in overlay 95.

#### Names for IDC tables

To assign names to digit conversion tables, respond to the DCNO, IDC, and NAME prompts in overlay 95.

### Configurations

There are several possible CPND configurations. CPND can operate in standalone mode, using a local (or inboard) directory system, or using a remote directory system. To identify your configuration, respond to the CNFG prompt in overlay 95.

## Configuring calling party name display

### What to have ready

The following checklist summarizes the steps you should take before configuring CPND.

**Table 26**  
**Checklist**


Basic	Optional	Preparation
☐		Get a list of names to be programmed for each DN, DIG, and IDC table.
☐		Identify the CPND configuration used on your Meridian 1.
	☐	Select maximum and default lengths for displays and names.
	☐	Select codes to use on displays to indicate causes of incoming call redirection.
	☐	Determine Katakana (or Roman) equivalents of the names to be programmed.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure CPND.

## Configuring calling party name display





## Configuring calling party name display

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of calling party name display.

STEP		ACTION	
1	Log in.	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .	
2	Set CPND parameters.	>LD 95	
		REQ	NEW
		TYPE	CPN Enter CPN to set CPND parameters.
		CUST	xx Enter the customer number.
		CNFG	ALON, REMO, LOCL Enter ALON for a standalone CPND configuration, REMO for interwork with a remote directory system, or LOCL to interwork with a local (inboard) system.
		MXLN	5-27 Specify the maximum allowable CPND length.
		STAL	YES, NO Enter YES to enable static allocation of name storage, or NO to disable it. (Enter YES for hotel or motel installations.)
		— continued —	

## Configuring calling party name display

STEP ACTION		
<b>2 continued ...</b>		
<b>DFLN</b>	5-27	Specify the default length of CPND character strings.
<b>DES</b>	YES, NO	Enter YES to allow designators for Multiple Appearance DNs, or NO to deny them.
<b>RESN</b>	YES, NO	Enter YES to allow the display of reasons for redirecting calls, or NO to deny it.
<b>CFWD</b>	aaaa	Enter a mnemonic for the display of Call Forward All Calls redirection.
<b>CFNA</b>	aaaa	Enter the mnemonic for the display of Call Forward No Answer redirection.
<b>HUNT</b>	aaaa	Enter the mnemonic for the display of Call Forward All Calls redirection.
<b>NITC</b>	aaaa	Enter the mnemonic for the display of Call Forward Non Intercom redirection.
<b>PKUP</b>	aaaa	Enter the mnemonic for the display of Call Pickup redirection.
<b>XFER</b>	aaaa	Enter the mnemonic for the display of Call Transfer redirection.
<b>AAA</b>	aaaa	Enter the mnemonic for the display of Attendant Alternative Answering redirection.
— continued —		

## Configuring calling party name display

STEP	ACTION		
3	Define names.		
	REQ	NEW	
	TYPE	NAME	Enter NAME to define calling party names.
	CUST	xx	Enter the customer number.
	CPND_LANG	ROM, KAT	Specify the CPND alphabet. Enter ROM to select a Roman alphabet, or KAT to select a Katakana alphabet.
	DIG	0-2045 0-99	Specify an existing Dial Intercom Group (DIG), followed by a member number.
	LANG	ROM, KAT, ALL	Specify the language for the DIG. Enter ROM for Roman alphabet displays or KAT for Katakana alphabet displays. Enter ALL to remove all names for the selected DIG.
	NAME	a . . . a	Specify the CPND name (in ASCII characters) for the DIG.
	XPLN	x	Set the expected length of display for the DIG.
	DISPLAY_FMT	FIRST, LAST	Set the display format. Enter FIRST for first name - last name format. Enter LAST for last name - first name format.
	DN	xxxxxxxx	Enter a directory number.
— continued —			

## Configuring calling party name display

STEP ACTION

3 continued ...

LANG	ROM, KAT, ALL	Specify the language for the DN. Enter ROM for Roman alphabet displays or KAT for Katakana alphabet displays. Enter ALL to remove the name for the selected DN.
NAME	a . . . a	Specify the CPND name for the DN (in ASCII characters).
XPLN	x	Set the expected length of display for the DN.
DCNO	0-254	Enter a digit conversion table number.
IDC	0-254	Enter an incoming DID digit conversion number.
NAME	a . . . a	Specify the CPND name (in ASCII characters).

4 Check your programming.

Review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.

If	Do
the programming is correct	step 5
the programming is not correct	step 1

— continued —

## Configuring calling party name display

STEP	ACTION
------	--------

- |   |   |
|---|---|
| 5 | Perform a data dump to permanently store the programming you have just completed. |
|---|---|

**CAUTION**

Check your maintenance agreement before working in LD 43.

Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

- |   |   |
|---|---|
| 6 | Verify that the data dump was successful. |
|---|---|

On-screen or printed response:


NO GO BAD DATA

or

DATA DUMP COMPLETE

— continued —

## Configuring calling party name display

STEP	ACTION
7	<b>Terminate this overlay program.</b>  * * * *
8	<b>Terminate this programming session.</b>  Log off.  >LOGO
9	<b>You have completed the programming required to configure CPND.</b>
	

# Setting up telephones

## Purpose


You must program a directory number, class of service, and a set of features for each telephone connected to the Meridian 1. Use overlay 10 to program 500/2500-type and analog telephones, and overlay 11 to program SL-1, and Meridian Digital Telephones.

To turn on each telephone extension connected to the Meridian 1, set the telephone extension up in the Meridian 1 software. The procedures for configuring each type of telephone vary. Information about the requirements for different telephones appear below. Detailed procedures appear later in this section.

## Basic configuration

Setup of a telephone involves the following steps:

1. Unpacking the telephone.
2. Installing the cabling for the telephone.
3. Configuring the telephone in the Meridian 1 software.
4. Testing the telephone.



This section tells you:

- ◆ what you need before setting up a telephone
- ◆ how to set up a telephone in software

For information about unpacking the telephone, refer to the documentation provided with the telephone.

## Setting up telephones


To use the procedures in this document, you should have prior experience with Meridian 1 administration.

### Telephone types

The Meridian 1 supports a number of different types of telephone. It is important for you to identify the different telephone types correctly before configuring them in software.

Nortel telephones have an identifying sticker attached to the base.

The model number of any Meridian telephone is identified here





## Setting up telephones

This guide provides information about configuring the following telephones:


- ◆ 500-type
- ◆ 2500-type
- ◆ M2317
- ◆ M2006
- ◆ M2008
- ◆ M2616
- ◆ M2216ACD

These telephones are the most popular for new Meridian 1 installations. If you need to configure other models of Nortel telephone, refer to the *Basic Telecom Management Guide*.

For more information about telephone features, functions and characteristics, refer to *Meridian 1 telephones*.

### Analog (500/2500 type) telephones

The analog (500/2500 type) telephones are basic telephones. The 500-type is a rotary dial unit, limited to pulse dialing. The 2500-type is a simple tone dial unit.




## Setting up telephones

### Meridian Digital Telephones

Meridian Digital Telephones are designed specifically for use with the Meridian 1, and offer features not found on other, more generic telephones. M2000- and M3000-series telephones are full featured digital telephones designed to work with the Meridian 1.


To identify a particular model of telephone, refer to the illustrations provided in this section.

#### M2317 telephone




## Setting up telephones

### M2006 telephones



## Setting up telephones

### M2008 telephones




---

## Setting up telephones


---

### M2616 telephones



## Setting up telephones

### M2216ACD telephones



The M2216ACD telephone is designed to accommodate Automatic Call Distribution (ACD) operation, but it can also be used as a normal telephone.

---

## Setting up telephones

---

### Planning for telephone configuration

When planning your telephone configuration, look at the following:

- ◆ Directory Numbers (DN)
- ◆ Terminal Numbers (TN)
- ◆ expected traffic levels
- ◆ line card density
- ◆ designators (six-character labels for TNs in the Meridian 1 database)
- ◆ telephone features, including:
  - Special Prefix (SPRE) codes
  - Flexible Feature Codes (FFC)

#### Directory Numbers

Directory Numbers (DNs) are the numbers assigned to the individual telephones. These are the telephone numbers users dial to call each other.

DNs can be one to seven digits in length.

#### Single Appearance or Multiple Appearance DNs

The term *appearance* means that a DN has been assigned to a telephone or a key on a telephone.

**Single Appearance DNs** appear on only one telephone. A Single Appearance DN can only be configured to handle one call at a time.

**Multiple Appearance DNs** appear on more than one telephone, or more than one key on a telephone such as a digital telephone.

There are two configurations to choose from when dealing with Multiple Appearance DNs, Single Call and Multiple Call.

#### Single Call DN

The DN can handle one call at a time.

---

## Setting up telephones

---

This means that when one person is using the DN, the indicator is lit steadily at other appearances of that DN on digital telephones or SL-1-type telephones.

Unless programmed otherwise, a Single Call configuration is the default configuration of a DN when it is programmed on a Digitone telephone.

If the same Single Call DN is shared between a Digitone telephone and an SL-1-type or digital telephone, there is no way to prevent a user from breaking in on an active call in progress on the shared DN.

If privacy is important, choose one of the following two options:

- ◆ do not assign the same Single Call DN to a Digitone telephone and an SL-1-type or digital telephone
- ◆ replace the Digitone telephone with an SL-1-type or digital telephone. There is privacy on shared Single Call DNs on these types of telephones

### Multiple Call DN

The DN can handle more than one call at a time.

This means that when one person is using the DN, the indicator is not lit at other appearances of that DN on digital telephones or SL-1-type telephones. These other appearances are available to receive additional calls, or can be used to make calls.

A Multiple Call DN is not treated as busy until there are calls on all the programmed appearances of the DN. There can be a maximum of 30 appearances of the same DN.

Your system might have memory constraints which prevent you from reaching the maximum numbers. Consult with your system supplier before you implement Multiple Appearance DNs.

### Multiple Call Class of Service

When you want to make a DN on a Digitone telephone a Multiple Call DN, you activate this in the Class of Service.



---

## Setting up telephones

---

This Class of Service is used in conjunction with the use of Meridian COMPANION™ wireless telephones on your system.

### Consistent configuration

Whether you choose Single Call or Multiple Call, all appearances of one DN must have the same configuration. You cannot have one appearance of a DN programmed as Single Call and another appearance of the same DN as Multiple Call. If you attempt to do that, you will see a Service Change Error message on your programming terminal.

The step-action table at the end of this module explains how to assign a DN on a new Digitone telephone.

### Numbering Plan

Many systems have a carefully planned scheme for the use of numbers such as Directory Numbers (DNs), trunk-group access codes, and feature-access codes. This is called the Numbering Plan. It is used to record the numbers which are currently in use on a site and might also include numbers that are reserved for some future use. If, for example, you have reserved Direct-Inward-Dial (DID) telephone numbers with your telephone company for future use, it is important to record that in the Numbering Plan.

Careful planning is required in order to:

- ◆ prevent conflicts between numbers used for different purposes
- ◆ organize the use of numbers to help simplify the administration of the system
- ◆ ensure there will be enough available numbers to accommodate the foreseeable growth of the system

You should keep a summary of the Numbering Plan on site. For more information on the Numbering Plan see the *Basic Telecom Management Guide*.

---

## Setting up telephones

---

### Terminal Number (TN)

You must use programming to identify the physical location of every telephone in the hardware of the system. The physical location or address is composed of a Loop number, Shelf number, Card number, and Unit number. These numbers make up the Terminal Number (TN) of the telephone.

Your system can use either loops or Superloops. Loops and Superloops belong in the Network Equipment part of the system.

If you are not sure what types of Network Equipment you are using, ask your system supplier. They can also tell you about your shelf and card equipment. Ask the person installing the jack and connecting it to the system what Terminal Number (TN) that person plans to assign to the new telephone.

Data terminals also require TNs, and if the user needs a data terminal, a separate Terminal Number must be assigned before you can program it. Talk to your system supplier about this.

### Traffic

Loops and Superloops perform best when they share equally in the total traffic load carried by the system.

Blockage within the system will be negligible or non-existent when the traffic load for each loop or Superloop is kept within the recommended guidelines. If all of your existing loops and Superloops are at their recommended capacity, consider adding more to your system, to allow for extra terminals in the future.

### Card density

Telephones are connected to interface cards in the system called line cards. There are three types of line cards for Digitone telephones: single-, double-, or quadruple-density.

Single-density line cards connect to a maximum of four telephones. Double-density line cards connect to a maximum of eight telephones. Quadruple (quad) density line cards connect to a maximum of sixteen telephones.

---

## Setting up telephones

---

Systems using Superloops can use intelligent line cards. They are called intelligent because they possess microprocessors.

Double-density intelligent line cards are available for off-premises extensions. They connect to a maximum of eight telephones.

On-site Digitone telephones can be connected to quadruple-density intelligent line cards which connect to a maximum of 16 telephones.

### Designator (DES)

When you want printouts of the data associated with telephones you can request DN-Block and TN-Block printouts. Using only those printouts it might be difficult to identify each telephone specifically, especially if several telephones share the same DN. For example, you might find it easier if a department name prints out along with the other data.

With Office Data Administration System (ODAS) software equipped on a system, you can program each telephone in the database with a designator (DES) code.

The DES code can be a maximum of six alphanumeric characters.

You can use the designator to identify telephones in many different ways for your own purposes. Here are some suggestions:

- ◆ location in the building, for instance the floor number or room number
- ◆ cable pair
- ◆ telephone user's department, to be used for billing or inventory purposes
- ◆ user's name, although the name does not display when the user makes calls

Once the designators have been assigned, you can request printouts of telephones according to the DES codes you have assigned.

---

## Setting up telephones

---

For example:

- ◆ you might want to know what telephones are in a specific department so you can bill the department manager. You would request a printout of the telephones that share the same department identifier you assigned as the DES code for that department.
- ◆ you might have a group of telephones that share the same DN. If you want to move, change or remove one of them, you can print the telephone with the DES code that is specific to that telephone and find what TN is assigned to it.
- ◆ you can print the data for all the telephones that share a DN and use the DES codes to help you identify quickly which telephone is to be moved, changed, or removed.

Check to see if you have a policy on assigning DES codes to telephones. If no policy is in place, decide if DES codes can be of use to you. If not, you can enter any code you like when the prompt appears. On most systems you must enter a code in order for the next prompt to appear.

You can use the step-action table at the end of this module for help in assigning a DES code to a new telephone.

### Class of Service (CLS)

When you are programming telephones using LD 10, you must enter a Class of Service for each telephone.

## Telephone features and services

Consider the following features when setting up telephones.

### Special Prefix codes (SPRE)

Regular telephone users can use the Special Prefix (SPRE) code to access most features. The SPRE code is a code, defined for the entire customer group, that lets the Meridian 1 know that you are about to use a feature. The control digit or digits that you dial after the SPRE code tell the system what feature you want.

---

## Setting up telephones

---

The control digits are not changeable. They are pre-programmed in the system database when the system is delivered to you.

For example, if the customer group to which a user belongs has a defined SPRE code 11, and all systems are shipped with a Night Service feature code 4, then to use the Night Service feature to answer calls ringing a night bell, the user lifts the handset and dials 114.

### Flexible Feature Codes

Flexible Feature Codes (FFC) are codes users can dial to access calling features that would normally require a programmed key on a Meridian Digital telephone. FFCs can be used at any telephone. If the telephone you are programming does not have enough keys to accommodate the required features, consider using FFCs to provide access to those features. You program an FFC of your choice for any of the features on your system.

FFCs are available on your Meridian 1 only if you have software package 139 installed. For more information about configuring FFCs, refer to the *Software Guide*.

### Telephone function keys

Many telephones have keys that you can program with features and DN's. You can add keys to some telephones by connecting extra modules. Each type of telephone has a limit to the number of keys it can provide.

To program function keys on telephones, respond to the KEY prompt in overlay 11.

Refer to the *Software Feature Guide* that was delivered with your system for more information on features that are not in this guide.

---

## Setting up telephones

---

### Administration tips



If users experience problems like delayed dial tone, it is important for you to consider the types of telephones being used. If the telephones are dial type, you do not need to investigate anything to do with DTRs. This can help to resolve the problem sooner.

### Copying telephones

When configuring a number of telephones with similar options and restrictions, you can use the Meridian 1's copy function. Respond to the CFTN prompt in overlay program 10 and 11 to copy the configuration of an existing telephone, then make changes to the copied configuration as required. For more information on copying configurations and using the CFTN prompt, refer to the *Software Guide*.

### SPRE code users

Regular telephone users sometimes complain that the SPRE code method is too difficult for them. You can do a number of things to assist them:


- ◆ limit the number of feature codes the users are required to remember
- ◆ train them frequently and allow them to practice
- ◆ supply them with training aids that they keep handy near the telephone for quick reference
- ◆ upgrade the telephones to Digitone-type, with buttons to store the codes
- ◆ upgrade the telephones to SL-1-type or digital to allow use of programmed keys for features
- ◆ implement Flexible Feature Codes (FFC) that are easier to remember than some of the SPRE codes.

---

## Setting up telephones

---

### Improving performance



The following options can make use of the telephones much more efficient.

#### Distinctive Ringing

There are four different Distinctive Ringing (DRG) options for the digital telephones. When you program the Class of Service of each telephone you choose one of the four options to set the ring tone and ring cadence. The choices are: DRG1, DRG2, DRG3, or DRG4.

You can make each telephone in one department ring a different way so that when a telephone rings and a user has stepped away from the area, the way the telephone rings helps the user identify which telephone is ringing.

Distinctive Ringing can be very useful with the Call Pickup feature. When telephones are ringing in the Pickup group, the users can tell which telephone is ringing and whether they are to answer. If a user does answer, the caller can be greeted appropriately.

#### Data option

When a Meridian Programmable Data Adapter (MPDA) or Meridian Communications Adapter (MCA) is installed inside the telephone and an RS-232C cable is used, you can set up a computer on the user's desk using the same pair of wires that the telephone uses. If you do this, then key 5 on the telephone must be used as a Program key to control various data parameter settings. There is a Quick Reference Card for the MPDA or MCA that explains these settings and how to use the Program key.

## Setting up telephones

### What to have ready

The following checklist summarizes the steps you should take before setting up telephones.

**Table 27**  
**Checklist**

Basic	Optional	Preparation
☐		Decide how many telephones you need, and where.
☐		Choose a DN for each telephone.
☐		Decide what options you want to provide each telephone extension user.
☐		Decide what keys you want to install on each M2000 or M3000 series telephone.
☐		Unpack and install the telephones, so that they can be tested once configured.
	☐	Choose a DN for the attendant overflow position.
	☐	Create any speed call lists to be used on the telephone.


### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to implement a telephone.



## Setting up telephones



## Setting up telephones

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of telephones.

STEP ACTION	
1	Log in.
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .
2	Choose the starting point in this procedure.
If	Do
you want to add a 500- or 2500-type telephone	step 3
you want to add an SL-1, M2000, or M3000-series telephone	step 4
— continued —	


## Setting up telephones

STEP		ACTION
<b>3 Add a 500/2500-type telephone.</b>		
	<b>&gt;LD 10</b>	
<b>REQ</b>	NEW	Define a new telephone.
<b>TYPE</b>	500	Dial or Digitone telephone.
<b>TN</b>	L S C U	Enter a Terminal Number for the telephone (Loop, Shelf, Card and Unit).
<b>CDEN</b>	SD, DD, 4D	Select the card density (either single, double or quad density).
<b>DES</b>	xxxxxxx	Enter a telephone designator (up to six characters long).
<b>CUST</b>	0-99	Enter the customer group number.
<b>DN</b>	xxxxxxx	Enter a telephone number (directory number) for the telephone. The DN can be up to 4 digits, up to 7 digits with Directory Number Expansion (DNXP) package 150.
<b>SCPW</b>	xxxxxxx	Enter a Station Control Password. (You set the length of the password earlier using the SCPL prompt in overlay 15.)
<b>CLS</b>	CCSA	Enter CCSA to enable CCOS for Electronic Lock (ELK) and Remote Call Forward (RCFW).
<b>CLS</b>	DIP, DTN	Specify the outpulsing type (dial or Digitone) for the telephone.
<b>CLS</b>	xxxx	Specify the Distinctive Ringing tone and cadence by entering DRG1, DRG2, DRG3, or DRG4.
— continued —		


## Setting up telephones

STEP	ACTION	
4	Add a Meridian Digital Telephone.	
	>LD 11	
	REQ	NEW Define a new telephone.
	TYPE	xxxx Enter the telephone type:
	To create an	Enter
	M2006 telephone	2006
	M2008 telephone	2008
	M2317 telephone	2317
	M2216ACD telephone	2216
	M2616 telephone	2616
	SL-1 telephone	SL1
	TN	L S C U Enter a Terminal Number for the telephone.
	CDEN	SD, DD, 4D Select the card density (either single, double or quad density). Press the carriage return to select the default.
	DES	xxxxxxx Enter a telephone designator (up to six characters long).
	CUST	0-99 Enter the customer group number.
	SCPW	xxxxxxx Enter a Station Control Password. (You set the length of the password earlier using the SCPL prompt in overlay 15.)
	CLS	CCSA Enter CCSA to enable CCOS for Electronic Lock (ELK) and Remote Call Forward (RCFW).
	CLS	xxxx Enter DRG1, DRG2, DRG3, or DRG4 to select Distinctive Ringing cadences.
	KEY	0 SCR x...x Program an SCR single call ringing DN, if required.
	KEY	0 SCN x...x Program an SCR single call non-ringing DN, if required.
	— continued —	

## Setting up telephones

STEP	ACTION						
5	<p><b>Check that the telephone which you have just programmed is working.</b></p> <p>Try the telephone and any installed keys to ensure that they are operating properly.</p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>everything works</td><td>step 6</td></tr> <tr> <td>something does not work</td><td>step 1</td></tr> </table>	<b>If</b>	<b>Do</b>	everything works	step 6	something does not work	step 1
<b>If</b>	<b>Do</b>						
everything works	step 6						
something does not work	step 1						
6	<p><b>Perform a data dump to permanently store the programming you have just completed.</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;">  <p><b>CAUTION</b> Check your maintenance agreement before working in LD 43</p> </div> <p>Refer to the <i>Software Input /Output Guide Book 1 of 2</i> for more information on LD 43.</p> <pre>&gt; LD 43  . EDD &lt;cr&gt;</pre>						
— continued —							

## Setting up telephones

STEP	ACTION
7	<b>Verify that the data dump was successful.</b>  On-screen or printed response:  NO GO BAD DATA or DATA DUMP COMPLETE
8	<b>Terminate this overlay program.</b>  * * * *
9	<b>Terminate this programming session.</b>  Log off.  >LOGO
10	<b>You have completed the programming required to add a telephone.</b>
	

---

## Setting up telephones

---

### Using telephones

From most telephones connected to a Meridian 1 you can place and receive calls, forward calls, place calls on hold, and control a number of special calling features. The functionality and features available at a specific telephone depends on the type of telephone and how it has been configured in the Meridian 1 software.

A number of tasks you can perform using telephones connected to the Meridian 1 are described below. Brief instructions are provided. For more information about these tasks, or about other tasks not described here, refer to the *Basic Telecom Management Guide*.

#### Placing a call

To place a call, lift the handset and dial a valid DN. Hang up the handset to end the call.

#### Using switch-hook flash

When you have a call in progress on a 500- or 2500-type telephone and you want to transfer the call or place the call on hold, press and release the button under the handset of the telephone. The button is called the switch-hook and pressing and releasing it is called sending a switch-hook flash.

You can also send a switch-hook flash to call forward your telephone or to place a call using Speed Call.

If you press the switch-hook for the correct amount of time, the system responds with a confirmation tone, three short bursts of tone followed by steady dial tone. Once you hear the confirmation tone, you can use the telephone keypad to send a command to the Meridian 1.

For information about how to use features, see the descriptions in this chapter.

## Setting up telephones





### Using the Link button

If your telephone has a Link button, you can press it instead of sending a switch-hook flash. The Link button performs a perfect switch-hook flash every time it is pressed.

### Transferring a call

To transfer a call in progress on your 500- or 2500-type telephone, send a switch-hook flash. Once you hear the confirmation dial tone, dial the digits of the DN to which you are transferring the call. When you hear ringback tone, hang up the telephone.

To transfer a call in progress on your Meridian Modular Telephone, press the Transfer key. Once you hear the confirmation dial tone, dial the digits of the DN to which you are transferring the call. When you hear ringback tone, press the Transfer key again and hang up the telephone.






553-0041T CTrans





## Setting up telephones

### Call forward

To call forward a 500- or 2500-type telephone to another DN, lift the handset and send a switch-hook flash. When you hear the confirmation dial tone, press or dial 1.





553-0051T CFAC





## Setting up telephones

To call forward a Meridian Digital telephone, lift the handset and press the C.FWRD key. Dial the DN to which you are forwarding, and then press the C.FRWD key again. Hang up the handset.



553-0052T CFAC




## Setting up telephones

### Conference

To create a conference on your 500- or 2500-type telephone, place a call to one of the parties you want to conference. Once you are connected, send a switch-hook flash. When you hear the confirmation dial tone, dial the second party. Once you are connected with the second party, send another switch-hook flash. You will now be connected with both parties.

To create a conference on a Meridian Digital telephone, place a call to one of the parties you want to conference. Once you are connected, press the CONF key on your telephone, or use a n FFC to activate conferencing. When you hear dial tone, dial the second party. Once you are connected with the second party, press the CONF key again. You will now be connected with both parties.



## Setting up telephones

---

### Hold

For example, when a user wants to put a call on hold at a Digitone™ telephone, they switch-hook flash and then dial #4 and hang-up.

To place an active call on permanent hold using your 500- or 2500-type telephone, send a switch-hook flash. When you hear the confirmation dial tone, press 4.

### Speed Call

#### Controlling Speed Call


To choose your Speed Call list using a 500- or 2500-type telephone, lift the handset and send a switch-hook flash. When you hear the confirmation dial tone, press 2.

#### Using Speed Call

To place a call using Speed Call from your 500- or 2500-type telephone, lift the handset and send a switch-hook flash. When you hear the confirmation dial tone, press 3, followed by the Speed Call number.

## Setting up telephones


To place a call using Speed Call from your Meridian Digital telephone, lift the handset and press the Speed Call key. Enter the Speed Call number.



## Setting up telephones

### SPRE codes

To use a feature on a telephone that lacks the feature key, lift the handset or press an idle DN key and type in the SPRE code defined in overlay 15. Press a number key to select a feature.



553-0101T USCR

### Common problems associated with telephones

1. Keys may be mislabelled.
2. The user may not be able to place or receive calls.
3. The user may have problems hearing or being heard.
4. The handset, headset or display may not operate properly.

---

## Setting up telephones

---

### Suggested solutions

Hardware problems are the most common cause of telephone problems. When you need to identify a hardware problem, refer to the *Fault Clearing Guide*. Some problems are described below, with a list of common causes.

#### Keys are incorrectly labelled

The best way to avoid the problem of mislabelled keys is to:

- ◆ use standardized installation forms, if you don't already do so
- ◆ always test each key on each telephone once installation and configuration is complete

#### User is not able to place or receive calls

A number of problems can prevent the user from placing or receiving calls on a newly configured telephone. When this happens, check for system messages.

An OVD message tells you that the cause of the problem is hardware. Possible hardware problems include:

- ◆ a defective peripheral equipment card
- ◆ a defective telephone
- ◆ defective wiring between the telephone and the Meridian 1
- ◆ a defective backplane

#### User is having trouble hearing or being heard

A number of hardware problems can cause audio problems on the telephone. If the user is having problems hearing or being heard, check the following possible causes:

- ◆ a defective handset or headset
- ◆ a defective telephone
- ◆ a defective peripheral or intelligent peripheral equipment (PE or IPE) card
- ◆ defective wiring between the telephone and the Meridian 1

## Setting up telephones

---

### **The handset or headset does not work properly**

Several problems can lead to the failure of a telephone headset or handset. These include:

- ◆ a failed signalling test between the Meridian 1 and the telephone
- ◆ a telephone fault
- ◆ a fault on the peripheral equipment card

### **The digit display does not work properly**

The digit display on a telephone can fail to operate because of hardware or administration problems, including:

- ◆ a disconnected or defective power supply
- ◆ a disabled terminal number (TN)
- ◆ failure to assign the feature in overlay 15
- ◆ a defective telephone



# Setting up attendant consoles

## Purpose

Attendant Consoles assist in placing and extending calls into and out of the Meridian 1 system. The operator of an Attendant Console is known as the attendant. The consoles provide the attendant with many unique features that increase the speed and ease of call processing.

This TASK section provides an overview of the Attendant Consoles and a description of the basic software capabilities and associated service changes. Additional information regarding attendant-related software features may be found in the *Software Feature Guides*.

## Basic configuration

Setup of an attendant console involves the following steps:

1. Unpacking the attendant console.
2. Installing the cabling for the attendant console.
3. Configuring the attendant console in the Meridian 1 software.

## Unpacking the attendant console

Use proper care while unpacking any attendant console. Check for damaged containers so that appropriate claims can be made to the transport company for items damaged in transit.

If an attendant console must be returned to the factory, pack it in the appropriate container to avoid damage during transit. Remember to include all loose parts (cords, handset, power unit, labels, and lenses) in the shipment.

---

## Setting up attendant consoles

---

### Installing the cabling for the attendant console

The steps below list the information required to cable the M1250 or M2250 attendant consoles. For added information about installing cabling for older model attendant consoles, refer to *Telephone and Attendant Console Installation*.

- 1 Ensure that a 16-pair or 25-pair cable equipped with a 25-pair Amphenol connector is installed at the attendant console's location.
- 2 Unpack and inspect the attendant console for damage. If the console is damaged, notify your supplier.
- 3 Connect the Amphenol plug on the attendant console to the Amphenol jack coming from the Main Distribution Frame (MDF).
  - Fasten the Amphenol connectors together and secure the captive screws on the cable.
  - Ensure that the connectors are secured in a connector mounting, if provided, or to the wall. Do not leave connectors unprotected on the floor.
- 4 Add a line circuit for the attendant console, if not already done. Refer to *Circuit card installation and testing* (553-3001-211).
- 5 See the cross-connecting attendant consoles section below.

### Cross-connecting attendant consoles

Terminations are located on the vertical side of the distributing frame when frame-mounted blocks are used and in the blue field when wall-mounted blocks are used.

---

## Setting up attendant consoles

---

Line circuit card (TN) terminations are located on the horizontal side of the distributing frame when frame-mounted blocks are used and in the white field when wall-mounted blocks are used.


### Procedure 1

#### Cross-connecting attendant consoles

- 1 Locate the attendant console terminations at the cross-connect terminal.
- 2 Connect Z-type cross-connecting wire to the leads of the attendant console.
- 3 Locate the line circuit card (TN) terminations.
- 4 Run and connect the other end of the cross-connecting wire to the assigned TN terminal block.

## Setting up attendant consoles

### QCW and M1250 attendant console cross-connections



---

## Setting up attendant consoles

---

The following notes refer to Figure , which illustrates QCW and M1250 attendant console cross-connections.

**Note 1:** Attendant consoles require 24 V of power. Attendant consoles equipped with the QMT3 module require 15 V of power in addition to the 24 V power supply.

**Note 2:** You can obtain 24 V of power from the following:


- 24 V transformers located within 25 ft (7.7 m) of the console. A separate transformer is required for each attendant console.
- QUT1 or QUAA1 centralized power supply. A separate fuse is required for each attendant console.
- Two circuits with a maximum loop resistance of  $300\frac{3}{4}$ . This cross-connection must not be used if the power is obtained from a source other than the Meridian 1 line circuit.

**Note 3:** (M1250) Connect to a solid ground (not the Meridian 1 system ground). The maximum distance between the ground source and the attendant console must be less than 200 ft (61 m). Run the ground directly to the console cable connector if the connection through the cross-connector exceeds 200 ft (61 m).

**Note 4:** When the BLF/CGM option is used on the M1250, an additional 16 V dc power supply must be cabled through the +VPS (pin 16) and the +VPS RTN (pins 42 and 17) wires. The maximum loop limit from the attendant console to the connector is 120 ft (36 m) at 24 AWG.

# Setting up attendant consoles

## M2250 attendant console cross-connections



See notes on next page.

---

## Setting up attendant consoles

---

The following notes refer to Figure , which illustrates the M2250 attendant console cross-connections.

**Note 1:** The M2250 is powered by means of the line circuits. In addition to the primary TN, secondary TN, and ASM TN, two TNs are cabled to the M2250 using the +AUX and –AUX leads. The maximum loop length is 3000 ft of 24 AWG wire.

**Note 2:** When additional options are used (BLF or display backlight option), an additional 16 V dc power supply is required. The 16 V dc source is cabled using +VPS and VPS RTN leads. The maximum distance from the console to the power source is 120 feet of 24 AWG wire. Please note if both options are installed, only one 16 V dc power supply is required.

**Note 3:** It is recommended that five consecutive TNs on the line circuit be allocated for each console.

**Note 4:** When used with the ISDLIC, the M2250 requires QPC578 vintage D or later.

### Attendant console features

The attendant console, in its standard configuration, allows you to perform basic operator tasks. Options are available to enhance or customize the attendant console, tailoring it to meet customer specific needs. Refer to the *Software Feature Guides* for programming attendant console features.

## Setting up attendant consoles

---

### Administration tips



Do not assign attendant consoles to high priority card slots. The high number of priority messages generated by attendant consoles can result in delays, both in messages output to the attendant consoles themselves, and to messages output to telephones and trunks.

Always assign attendant consoles to card slots 2 - 10. Avoid assigning a large number of attendant consoles to the same network loop.



## Setting up attendant consoles

### What to have ready

The following checklist summarizes the steps you should take before setting up an attendant console.

**Table 28**  
**Checklist**


Basic	Optional	Preparation
☐		Decide how many attendant consoles you need.
☐		Choose a DN for each attendant console.
☐		Unpack and install the attendant console, so that it can be tested once configured.

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to implement an attendant console.

## Setting up attendant consoles



## Setting up attendant consoles

The preceding material in this module contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of attendant consoles.

STEP ACTION	
1	Log in.
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .
2	Enable basic options you plan to install on the attendant console.
	>LD 15
REQ	CHG
TYPE	CDB Change the customer data block.
	ATT Release 21 and later gate opener.
CUST	0-99 Enter the customer number.
ATDN	(0)-xxxx Attendant Directory Number. Up to 4 digits, up to 7 digits with Directory Number Expansion (DNXP) package 150.
NCOS	(0)-99 Set the attendant network class of service for all consoles in this customer group. (0) -3 CDP (0) -3 BARS or NFCR (0) -15 NARS (0) -99 Release 13 and later Prompted with Network class of service (NCOS) package 32.
SPVC	0-63 Enter an attendant number for the supervisor console. (If there is no supervisor console required, enter 0.)
— continued —	

## Setting up attendant consoles

STEP ACTION		
<i>2 continued ...</i>		
REQ	****	Terminate the Overlay by entering ****.
<b>3 Program a new attendant console.</b>		
>LD 12		
REQ	NEW	Create a new attendant console.
TYPE	a . . a	Type of data block. TYPE = 1250, 2250 or ATT (QWC3 or QWC4).
TN	L S C U	Enter the attendant console's TN (Loop number, Shelf number, Card number, Unit number).
SETN	L S C U	Input the second TN to be assigned to the new attendant console (Loop number, Shelf number, Card number, Unit number).
CUST	0-99	Enter the customer number.
ANUM	1-63	Enter the attendant number.
REQ	****	Terminate the Overlay by entering ****.
<b>4 Assign power terminal numbers to analog consoles.</b>		
>LD 12		
REQ	NEW	
TYPE	PWR	Add a power TN.
TN	L S C U	Enter the TN to supply power to an attendant console (Loop number, Shelf number, Card number, Unit number).
— continued —		

## Setting up attendant consoles

### STEP ACTION

#### 5 Check that the attendant console which you have just programmed is working.

>LD 20

**REQ**            PRT            Enter PRT to verify attendant console.

**TYPE**           a . . a            Type of data block. TYPE = 1250, 2250 or ATT (QWC3 or QWC4) or PWR.

**REQ**            \* \* \* \*            Terminate the Overlay by entering \* \* \* \*.

Verify that the attendant console does exist in software.

Verify that the display is functioning on the attendant console.

#### 6 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43.


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cr>

— continued —

## Setting up attendant consoles

STEP	ACTION
7	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>or</p> <p>DATA DUMP COMPLETE</p>
8	<p><b>Terminate this overlay program.</b></p> <p>. ****</p>
9	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
10	<p><b>You have completed the programming required to add an attendant console.</b></p>
	

## Setting up message filters (Release 21

### Purpose

The Meridian 1 generates a large number of messages during normal operations. You may want to filter these messages, allowing only messages of interest to print out.

The information you enter during this stage of basic configuration is described in detail below. Procedures for entering this information are provided later in this chapter.

### System messages

The Meridian 1 reports system status and system events by printing out or displaying system messages. A number of different classes of message provide information about different types and severity of event.

A large number of messages are provided for information only, and in most situations at most installations do not require intervention or action.

For more information about system messages, refer to the *Input/Output Guide* and the *Fault Clearing Guide*.

## Setting up message filters (Release 21 and earlier)

### Message filters

The Meridian 1 can filter alarms and messages for you, alerting you to only those system events of interest to you. The Alarm Filter package 243 must be installed on your system to provide alarm and message filtering.

To turn alarm and message filtering on or off, respond to the AF\_STATUS prompt.

### Triggers

You can set up a trigger to raise an alarm if certain messages or types of messages are generated. This lets you highlight specific messages of concern and assign priorities to these messages.

You can also set filters that will ignore specific messages or ranges of messages. This lets you filter out nuisance messages or recurring messages that have no impact on your operation.

You can define up to 50 triggers and filters.

### Selecting messages

To identify messages of interest, add or change an alarm filter and enter a string that matches part or all of the messages at the TRIGGER prompt. You can use wildcards in a trigger string to capture a range of messages.

For example, if you want to get an alarm when a BUG1234 message is generated, enter BUG1234 as the trigger string at the TRIGGER prompt. If you want to get an alarm when any BUG message is generated, enter BUG++++ at the TRIGGER prompt. (The + sign indicates a wildcard character, meaning that the Meridian 1 will alarm any message beginning with BUG, regardless of the numbers that follow.)

The following mnemonics can be entered at the TRIGGER prompt: ACD, ADD, AMH, AMLM, ATM, AUD, AUTH, BERR, BIC, BSD, BUG, CCED, CCR, CDM, CED, CIOD, CMON, CNF, CNI, CSA,



---

## Setting up message filters (Release 21 and earlier)

---

CSC, DBMT, DCH, DLO, DSET, DTA, DTC, DTI, DTRK, EDD, ERR, ESDA, ESDI, HWI, IOD, ISR, LNK, MFR, MFS, MISP, MSDL, MWL, NPR, NWS, OSM, OVD, OVL, PCH, PMS, PRI, PWR, RPD, RPL, RPT, SCSI, SDL, TDS, TEMU, TFN, TRK, TSM, TTY, VAS, XCT, and XMI. For information about these message types, refer to the *Input/Output Guide*.

### Excluding messages

To identify messages you are not interested in, add or change an exception filter and enter a string that matches part or all of the messages at the TRIGGER prompt. You can use wildcards in a trigger string to ignore a range of messages.

For example, if you want to ignore BUG4321, enter BUG4321 as the trigger string at the TRIGGER prompt. If you want to ignore all ERR messages, enter ERR++++ at the TRIGGER prompt. (The + sign indicates a wildcard character, meaning that the Meridian 1 will ignore any message beginning with ERR, regardless of the numbers that follow.)

### Alarm severity

Alarm filters lets you assign different levels of severity to different messages. There are four levels of alarm severity:

- ◆ NONE, an alarm without a severity rating
- ◆ MINOR, an alarm normally indicating an error condition that does not affect system operation
- ◆ MAJOR, an alarm normally indicating a serious condition that is not preventing the system from operating
- ◆ CRITICAL, an alarm normally indicating a serious condition that is jeopardizing system operation

To specify the severity of an alarm associated with a particular trigger, respond to the SEVERITY prompt.

### Suppressing recurring alarms

The Meridian 1 can suppress the output of recurring alarms. To set the number of times an alarm can appear before the system stops reporting it, respond to the SUPPRESS prompt.

---

## Setting up message filters (Release 21 and earlier)

---

### Escalating recurring alarms

The Meridian 1 can report a major alarm as critical if it is a recurring alarm. To set the number of times a major alarm recurs before being reported as a critical alarm, respond to the ESCALATE prompt.

### Message formatting

You can turn the formatting of messages on or off. Formatting makes it easier to identify and read messages onscreen.

To turn formatting on or off, respond to the FMT\_OUTPUT prompt.

## Administration tips



A number of courses and administration aids are available from Nortel or your system supplier. Taking advantage of these courses and aids maximizes the effectiveness of your Meridian 1 administration efforts.

Nortel's support helpline is available to customers who want help setting up their Meridian 1. For more information, call your system supplier.

## Setting up message filters (Release 21 and earlier)

### What to have ready

The following checklist summarizes the steps you should take before configuring alarm filters.

**Table 29**  
**Checklist**


Basic	Optional	Preparation
☐		Identify the messages that are to generate critical alarms.
☐		Identify the messages that are to generate major alarms.
☐		Identify the messages that are to generate minor alarms.
☐		Identify the messages that are to generate unrated alarms.
☐		Identify the messages that are to be ignored.
	☐	Decide which alarms will be suppressed if they recur.
	☐	Decide which major alarms will require escalation if they recur.
	☐	Decide on the formatting of message output (on or off).

### What's next?

A flowchart follows which summarizes the implementation decisions and procedures.

A step-action table follows the flowchart. The table explains the programming steps necessary to configure alarm filters.

## Setting up message filters (Release 21 and earlier)



## Setting up message filters (Release 21 and earlier)

The preceding material in this chapter contains essential information. You should be aware of this information before you proceed.

This step-action table covers the prompts related to the implementation of alarm and message filters.

STEP	ACTION		
1	<b>Log in.</b>		
	For information on proper login procedures, see <i>Basic Programming Instructions</i> in <i>Basic Telecom Management</i> .		
2	<b>Turn message filtering on or off.</b>		
	<b>&gt;LD 17</b>		
	<b>REQ</b>	CHG	
	<b>TYPE</b>	CFN	Enter CFN to change configuration record.
	<b>ALARM</b>	YES	Enter YES to change alarm filter configuration data.
	The system will print out the present configuration of alarm and exception filters.		
	<b>FMT_OUTPUT</b>	(OFF) ON	Enter ON to turn on formatting of message output, or OFF to turn off formatting.
	<b>AF_STATUS</b>	(OFF) ON	Enter ON to turn on alarm and exception filtering, or OFF to turn off filtering.
	— continued —		

Setting up message filters (Release 21 and earlier)

STEP	ACTION	
3	Define the message alarm filters.	
	<b>A_FILTER</b> aaa	aaa = NEW, CHG, OUT
		Enter NEW to add an alarm filter, CHG to modify an existing alarm filter, or OUT to remove an existing alarm filter.
	If you are adding or changing a filter, respond to the following prompts:	
	<b>TRIGGER</b> xxx...xxx	Enter a trigger string for alarms. The trigger string can be up to 10 alphanumeric characters. At least one character must be alphabetic. To use a wildcard, enter a + sign.
		Possible entries include ACD, ADD, AMH, AMLM, ATM, AUD, AUTH, BERR, BIC, BSD, BUG, CCED, CCR, CDM, CED, CIOD, CMON, CNF,CNI, CSA, CSC, DBMT, DCH, DLO, DSET, DTA, DTC, DTI, DTRK, EDD, ERR, ESDA, ESDI, HWI, IOD, ISR, LNK, MFR, MFS, MISP, MSDL, MWL, NPR, NWS, OSM, OVD, OVL, PCH, PMS, PRI, PWR, RPD, RPL, PRT, SCSI, SDL, TDS, TEMU, TFN, TRK, TSM, TTY, VAS, XCT, XMI.
		For example, BUG++++ includes all BUG system messages. The mnemonics supported for this prompt are listed above. A value must be entered; <CR> is not accepted.
	<b>SEVERITY</b> xxxxx	Specify the severity of alarms and messages matching this trigger.
— continued —		

## Setting up message filters (Release 21 and earlier)

STEP ACTION

3 continued ...

If these messages mean	Enter
nothing	NONE
system operation is in jeopardy	CRITICAL
the system is operating, but the condition is serious	MAJOR
system operation is not affected, but an error was detected	MINOR

<b>SUPPRESS</b>	0-(5)-127	Specify the number of times an alarm occurs before the system stops outputting it. Enter 0 if all recurring alarms are to be output.
<b>ESCALATE</b>	0-(2)-127	Specify the number of times a major alarm occurs before the system shows it as critical. Enter 0 if no recurring major alarms are to be escalated.

4 Specify exception filters.

<b>E_FILTER</b>	aaa	aaa = NEW, CHG, OUT
-----------------	-----	---------------------

Enter NEW to add an exception filter, CHG to modify an existing exception filter, or OUT to remove an existing exception filter.

If you are adding or changing a filter, respond to the following prompt:

— continued —

Setting up message filters (Release 21 and earlier)

STEP ACTION

4 continued ...

**TRIGGER**    xxx . . . xxx    Enter a trigger string for exceptions. The trigger string can be up to 10 alphanumeric characters. At least one character must be alphabetic. To use a wildcard, enter a + sign.

Possible entries include ACD, ADD, AMH, AMLM, ATM, AUD, AUTH, BERR, BIC, BSD, BUG, CCED, CCR, CDM, CED, CIOD, CMON, CNF,CNI, CSA, CSC, DBMT, DCH, DLO, DSET, DTA, DTC, DTI, DTRK, EDD, ERR, ESDA, ESDI, HWI, IOD, ISR, LNK, MFR, MFS, MISP, MSDL, MWL, NPR, NWS, OSM, OVD, OVL, PCH, PMS, PRI, PWR, RPD, RPL, PRT, SCSI, SDL, TDS, TEMU, TFN, TRK, TSM, TTY, VAS, XCT, XMI.

For example, BUG++++ includes all BUG system messages. The mnemonics supported for this prompt are listed above. A value must be entered; <CR> is not accepted.

## 5 Route alarms to a terminal or printer.

From the TASK section on Configuring Terminals, choose a terminal that will display the alarms as they occur. Respond to the FIL prompt as shown below.

**ADAN**            TTY 0-15, PRT 0-15  
                     To send alarms to a terminal, enter TTY followed by the terminal number. To send alarms to a printer, enter PRT followed by the printer number.

**USER**            FIL  
                     Enter FIL to assign the user type for the port. Only alarm filtered messages will appear from the port. (When filtering is turned off, no messages appear.)

— continued —



## Setting up message filters (Release 21 and earlier)

### STEP ACTION

#### 6 Check your programming.

If possible, try to trigger various alarms to ensure that your programming is in effect. If you cannot check alarms at this time, review your programming to ensure that no errors were made. Use the scroll feature of your terminal, check your printout, or use overlay 22 to examine the contents of the database. For more information about reviewing your programming, refer to the About the Meridian 1 section of this book.

If	Do
the programming is correct	step 7
the programming is not correct	step 1

#### 7 Perform a data dump to permanently store the programming you have just completed.



#### CAUTION

Check your maintenance agreement before working in LD 43


Refer to the *Software Input /Output Guide Book 1 of 2* for more information on LD 43.

> LD 43

. EDD <cf>

— continued —

## Setting up message filters (Release 21 and earlier)

STEP	ACTION
8	<p><b>Verify that the data dump was successful.</b></p> <p>On-screen or printed response:</p> <p>NO GO BAD DATA</p> <p>or</p> <p>DATA DUMP COMPLETE</p>
9	<p><b>Terminate this overlay program.</b></p> <p>* * * *</p>
10	<p><b>Terminate this programming session.</b></p> <p>Log off.</p> <p>&gt;LOGO</p>
11	<p><b>You have completed the programming required to set up alarm filters.</b></p>
	

# Completing programming

## Purpose

Once you have performed basic programming, you must perform some testing and optimization to complete your installation. These tasks include:

- ◆ performing traffic studies to optimize buffer configurations
- ◆ ensuring that overnight and daily routines are running properly
- ◆ verifying that trunks, telephones and attendant consoles are operating properly

## Traffic studies and buffers

Once you have completed the basic programming required to allow the Meridian 1 to function, you should consider adjusting parameters to maximize efficiency.

The size of the various buffers are the most important parameters to examine. To find the best values for buffers, you must run traffic studies using a range of values and select sizes that provide the best traffic performance.

Traffic studies can take some time. You will have to start traffic studies and return later to examine results and take corrective action.

## Completing programming

---

### How to use traffic commands

The Traffic Control program is used to set traffic options, system ID, date and time. The conventions used to describe the traffic commands are:

- ◆ data entered by the user is shown in upper case, data output by the system is shown in lower case
- ◆ a period (.) prompt indicates that the system is ready to receive a new command
- ◆ a double dash (--) indicates that the system is ready to receive data
- ◆ a <cr> indicates that the return key should be pressed

**Note:** The message TFC000 output on your switch indicates that the traffic program is running.

### Setting traffic report schedules

To print current customer report schedule, use the following command:

```
TSHC C sd sm ed em sh eh so d d ...
```

To print current system report schedule, use the following command:

```
TSHS sd sm ed em sh eh so d d ...
```

To set customer report schedule, use the following command:

```
SSHC C sd sm ed em -- SD SM ED EM sh eh so -- SH EH SO d  
d ... -- D D ...<cr>
```

To set system report schedule, use the following command:

```
SSHS sd sm ed em -- SD SM ED EM sh eh so -- SH EH SO d d ...  
-- D D ...<cr>
```

---

## Completing programming

---

Where:

- ◆ C is the customer number and D is the day of the week:
  - 1 = Sunday
  - 2 = Monday
  - 3 = Tuesday
  - 4 = Wednesday
  - 5 = Thursday
  - 6 = Friday
  - 7 = Saturday
- ◆ ED is the end day (1-31)
- ◆ EH is the end hour (0-23)
- ◆ EM is the end month (1-12)
- ◆ SD is the start day (1-31)
- ◆ SH is the start hour (0-23)
- ◆ SM is the start month (1-12)
- ◆ SO is the schedule option:
  - 0 = no traffic scheduled
  - 1 = hourly on the hour
  - 2 = hourly on the half-hour
  - 3 = every half-hour

## Reports

To print the current report types, issue the following command:

```
TOPN C r r ...
```

To set one or more report types, issue the following command:

```
SOPN C r r ... -- R R ....<cr>
```

---

## Completing programming

---

To clear one or more report types, issue the following command:

```
COPN C r r ... -- R R ....<cr>
```

Where:

- ◆ C is the customer number
- ◆ R is traffic report type:
  - 1 = route list measurements
  - 2 = network class of service measurements
  - 3 = incoming trunk group measurements

**Note:** To use the print command enter a space (not a carriage return) after the customer number.

To print current customer being measured, issue the following command:

```
TCFT c
```

To set the customer to be measured, issue the following command:

```
SCFT c -- C
```

Where C is the customer number. Only one customer can have feature measurement set at a time.

---

## Completing programming

---

### Trunks

Use trunk diagnostic equipment to verify the operation of the different trunks connected to your Meridian 1.

Verify that all trunk routes are operating properly by placing calls over those trunk routes. (Remember that one successful call over a trunk route does not guarantee that all trunks in that trunk route are operating properly. Place a number of concurrent calls over the same trunk route to ensure that all trunks are operating.)

### Telephones and attendant consoles

You should test at least one telephone in each group of similarly programmed telephones before leaving the Meridian 1 site. You should also test every attendant console.

When testing, exercise every common telephone operation as well as any specially equipped keys or features. Remember to place calls to destinations both within the customer and outside the customer.

### Common problems associated with telephones and consoles

1. Keys may be mislabelled.
2. The user may not be able to place or receive calls.
3. The user may have problems hearing or being heard.
4. The handset, headset or display may not operate properly.

### Suggested solutions

Hardware problems are the most common cause of telephone and attendant console problems. When you need to identify a hardware problem, refer to the *Fault Clearing Guide*. Some problems are described below, with a list of common causes.

---

## Completing programming

---

### Keys are incorrectly labelled

The best way to avoid the problem of mislabelled keys is to:

- ◆ use standardized installation forms, if you don't already do so
- ◆ always test each key on each telephone and attendant console once installation and configuration is complete

### User is not able to place or receive calls

A number of problems can prevent the user from placing or receiving calls on a newly configured telephone or attendant console. When this happens, check for system messages.

An OVD message tells you that the cause of the problem is hardware. Possible hardware problems include:

- ◆ a defective peripheral equipment card
- ◆ a defective console
- ◆ defective wiring between the telephone or console and the Meridian 1
- ◆ a defective backplane

If no system message appears, the problem is likely to be one of the following:

- ◆ no power to the telephone or console
- ◆ a defective telephone or console
- ◆ a telephone or console connected to the wrong terminal numbers (TN)
- ◆ disabled TNs
- ◆ defective wiring



---

## Completing programming

---

### User is having trouble hearing or being heard

A number of hardware problems can cause audio problems on the telephone or attendant console. If the user is having problems hearing or being heard, check the following possible causes:

- ◆ a defective handset or headset
- ◆ a defective telephone or console
- ◆ a defective peripheral or intelligent peripheral equipment (PE or IPE) card
- ◆ defective wiring between the telephone or console and the Meridian 1

### The handset or headset does not work properly

Several problems can lead to the failure of a headset or handset. These include:

- ◆ a failed signaling test between the Meridian 1 and the telephone or console
- ◆ a telephone or console fault
- ◆ a fault on the peripheral equipment card

### The digit display does not work properly

The digit display on a telephone or attendant console can fail to operate because of hardware or administration problems, including:

- ◆ a disconnected or defective power supply
- ◆ a disabled terminal number (TN)
- ◆ failure to assign the feature in overlay 15
- ◆ a defective telephone or console

For more information about resolving telephone and attendant console problems, refer to *Telephone and Attendant Console Installation*.

---

## Completing programming

---

### SYSLOAD

You must perform a SYSLOAD before testing Meridian Digital Telephones. The sidetone (SOLR) and other parameters are downloaded to the telephones during SYSLOAD.

### Date and time adjustment

The time of day can be adjusted during the midnight routines to compensate for a fast or slow system clock.

To print the current adjustment: TDTA X y

To set the adjustment: SDTA X y -- X Y

Legend x = 0 for negative increment

= 1 for positive increment

y = 0-60 second adjustment in increments of 100 ms Set system ID

### Daily routines

The best way to verify that the daily routines you programming are running properly is to return to the site a day after the initial programming was completed. This gives you the chance to directly verify that the routines are running at the correct time and performing the intended tasks.

### Administration tips



Train your personnel to use the attendant console and telephones properly. Knowing how to use the tools provided by the attendant console and telephones will lead to fewer problems and greater efficiency.

---

## Completing programming

---

Your business will benefit greatly and you will spend less time managing problems if you stress good user habits in training sessions.

### Training tips



- ◆ Avoid the problems often associated with telephones and attendant consoles by doing proper training on an ongoing basis. Provide refresher training on an ongoing basis. Dial telephone users must remember a number of different feature access codes. They may need reminders after the initial training in order to effectively use all the features they need. This helps them get the most out of the system and in turn the system provides them with the expected benefits.
- ◆ When new features or options are added to telephones or attendant consoles, train the users in the use of those options. Some options radically change the way in which a telephone or attendant console handles calls.
- ◆ Provide attendant console training in context. Training is more effective if you provide it at the location where the user will actually perform attendant functions, using real telephone procedures.
- ◆ Short, customized lists of feature instructions and access codes for each user are worthwhile. Make them small enough to be placed underneath the telephone where they are readily accessible.
- ◆ If Flexible Feature Codes are in use on your system, keep the codes as simple as possible. Users will be confused and aggravated if you implement codes which are difficult to use. It is not a good idea to implement several codes for each feature unless you have users who are each accustomed to a different code and they are difficult to retrain.

## Completing programming

### What to have ready

The following checklist summarizes the steps you should take before performing verification and acceptance testing.

**Table 30**  
**Checklist**


Basic	Optional	Preparation
☐		Complete the programming required to allow proper testing. (If you are testing telephone features, ensure that the trunks and features you need are configured.)
☐		Determine whether the Meridian Digital Telephone sidetone (SOLR) value was changed from default (requiring a SYSLOAD).
	☐	Gather any worksheets or forms your company uses during testing.

### What's next?

A flowchart follows which summarizes the verification decisions and procedures.

A step-action table follows the flowchart. The table explains the steps necessary to perform verification and acceptance testing.

## Completing programming




---

## Completing programming

---

STEP	ACTION
1	<b>Verify your implementation of buffers.</b>  Perform traffic studies to determine the efficiency of the initial buffer sizes.
2	<b>Perform a SYSLOAD.</b>  Perform a SYSLOAD to download parameters to digital telephones. For more information about SYSLOADs, refer to the <i>Input/Output Guide</i> .
3	<b>Test attendant consoles.</b>  Test attendant consoles by placing calls and exercising all features and keys.
4	<b>Test telephones.</b>  Test at least one telephone from each group of similarly programmed telephones. Place calls, receive calls, and exercise all features and keys.
— continued —	

## Completing programming

STEP	ACTION						
5	<p><b>Test trunks and trunk routes.</b></p> <p>Test trunk routes by placing calls to destinations outside your Meridian 1. Ensure that you test all types of trunk route to all destinations.</p> <p>Test individual trunks using trunk diagnostic equipment.</p>						
6	<p><b>Perform traffic studies to optimize buffers.</b></p> <p>Optimize the system's buffers by performing traffic studies and adjusting buffer settings.</p> <p>For more information about traffic studies, refer to <i>Capacity Engineering</i>.</p>						
7	<p><b>Confirm that the system is operating properly.</b></p> <table> <tr> <td><b>If</b></td><td><b>Do</b></td></tr> <tr> <td>the system is operating</td><td>step 8</td></tr> <tr> <td>something is wrong</td><td>task 1</td></tr> </table>	<b>If</b>	<b>Do</b>	the system is operating	step 8	something is wrong	task 1
<b>If</b>	<b>Do</b>						
the system is operating	step 8						
something is wrong	task 1						
8	<p><b>You have completed the steps required to complete programming.</b></p>						
							

## Completing programming

---



# Circuit Cards

## In this chapter

Circuit card precautions . . . . .478

Circuit cards switch settings . . . . .479

## Circuit Cards

### Circuit Card Precautions

To avoid personal injury and equipment damage, review the following guidelines before handling Meridian 1 equipment.

#### **WARNING**

Module covers are not hinged; do not let go of the covers. Lift covers away from the module and set them out of your work area.

#### **WARNING**

Circuit cards may contain a lithium battery. There is a danger of explosion if the battery is incorrectly replaced. Do not replace components on any circuit card; you must replace the entire card.

Dispose of circuit cards according to the manufacturer's instructions.

To avoid damage to circuit cards from static discharge, wear a properly connected antistatic wrist strap when you work on Meridian 1 equipment. If a wrist strap is not available, regularly touch one of the bare metal strips in a module to discharge static.

Handle circuit cards as follows:

- Unpack or handle cards away from electric motors, transformers, or similar machinery.
- Handle cards by the edges only. Do not touch the contacts or components.
- Set cards on a protective antistatic bag. If an antistatic bag is not available, hand-hold the card, or set it in a card cage unseated from the connectors to set option settings.
- Keep cards installed in the system as much as possible to avoid dirty contacts and unnecessary wear.

## Circuit Cards

### Circuit card switch settings

#### NT6D11and NT5K35 D-Channel Interface Card

The next three tables list option settings for the NT6D11 (vintages AA, AB, and AC) and NT5K35 DCHI Card.

#### NT6D11AA, AB, AC, and NT5K35 jumper settings and group selection

Jumper settings				Address selection			
Option	Port	Socket number		Group number	Switch		
					1	2	3
DTE (terminal)	0 1	U11 U5	U9 U3	0 1	off off	off off	off on
DCE (modem)	0 1	U12 U6	U10 U4	2 3	off off	on on	off on
RS-232-C interface	0 1	U31 U25	U29 U23	4 5	on on	off off	off on
High-speed interface	0 1	U30 U24	U28 U22	6 7	on on	on on	off on
<b>Note:</b> Group and port numbers combine to define a complete port address. (The following two tables define port numbers.) There are 8 groups and 16 port numbers, for a total of 128 possible ports. Group 0 is the only group supported by Generic X11 Supplementary Features Group F (Phase 6). Therefore, when using Group F software set switches 1, 2, and 3 to OFF.							

## Circuit Cards

### NT6D11AA, AB, and AC port address settings for single port operation

Port number SDI/DCHI (J1/J2)	Switch						
	4	5	6	7	8	9	0
0	off	off	off	off	on	*	off
1	off	off	off	on	on	*	off
2	off	off	on	off	on	*	off
3	off	off	on	on	on	*	off
4	off	on	off	off	on	*	off
5	off	on	off	on	on	*	off
6	off	on	on	off	on	*	off
7	off	on	no	on	on	*	off
8	on	off	off	off	on	*	off
9	on	off	off	on	on	*	off
10	on	off	on	off	on	*	off
11	on	off	on	on	on	*	off
12	on	on	off	off	on	*	off
13	on	on	off	on	on	*	off
14	on	on	on	off	on	*	off
15	on	on	on	on	on	*	off

\* Set switch 9 to ON (1) to enable the SDI port and disable the DCHI port. Set switch 9 to OFF (0) to disable the SDI port and enable the DCHI port.

### NT6D11AA, AB, and AC port settings for dual port operation

Port number		Switch						
SDI (J1)	DCHI (J2)	4	5	6	7	8	9	0
0	1	off	off	off	*	off	*	off
2	3	off	off	on	*	off	*	off
4	5	off	on	off	*	off	*	off
6	7	off	on	on	*	off	*	off
8	9	on	off	off	*	off	*	off
10	11	on	off	on	*	off	*	off
12	13	on	on	off	*	off	*	off
14	15	on	on	on	*	off	*	off

\* Switches 7 and 9 do not affect dual port operation; they may be set to ON or OFF.

## Circuit Cards

### NT6D80 Multi-purpose Serial Data Link Card

RS-232-D DTE or DCE* RS-422-A DTE (terminal) RS-422-A DCE (modem)	<b>Port 0—SW4</b>  all off all off all on	<b>Port 0—SW8</b>  all off all on all off
RS-232-D DTE or DCE* RS-422-A DTE RS-422-A DCE	<b>Port 1—SW3</b>  all off all off all on	<b>Port 1—SW7</b>  all off all on all off
RS-232-D DTE or DCE* RS-422-A DTE RS-422-A DCE	<b>Port 2—SW2</b>  all off all off all on	<b>Port 2—SW6</b>  all off all on all off
RS-232-D DTE or DCE* RS-422-A DTE RS-422-A DCE	<b>Port 3—SW1</b>  all off all off all on	<b>Port 3—SW5</b>  all off all on all off
<p>* RS-232-D DTE and DCE modes are software configured. RS-422-A DTE and DEC modes are switch configured.</p> <p><b>Note:</b> The device number for the MSDL card is configured in LD17 at the prompt DNUM. You must also set the device number, using switches S9 and S10, on the MSDL card. S9 designates ones and S10 designates tens. To set the device number as 14, for example, set S10 to 1 and S9 to 4.</p>		

---

## Circuit Cards

---

### NT8D41 Dual Port Serial Data Interface Paddle Board

The next three tables list option settings for the NT8D41 SDI Paddle Board.

#### NT8D41 port addresses

Device number		SW4			
Port 1	Port 2	1	2	3	4
0	1	off	on	on	on
2	3	off	on	on	off
4	5	off	on	off	on
6	7	off	on	off	off
8	9	off	off	on	on
10	11	off	off	on	off
12	13	off	off	off	on
14	15	off	off	off	off

#### NT8D41 baud rate

Baud rate	Port 1–SW2				Port 2–SW3			
	1	2	3	4	1	2	3	4
150	off	off	on	on	off	off	on	on
300	off	on	off	on	off	on	off	on
600	off	off	off	on	off	off	off	on
1200	off	on	on	off	off	on	on	off
2400	off	off	on	off	off	off	on	off
4800	off	on	off	off	off	on	off	off
9600	off	off	off	off	off	off	off	off

## Circuit Cards

### NT8D41 DTE or DCE selection

Mode	Port 1—SW5						Port 1—SW6					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE (terminal)	on	on	on	on	on	on	off	off	off	off	off	off
DCE (modem)	off	off	off	off	off	off	on	off	on	on	on	on
NT1P61 (Fibre)	on	on	on	on	off	off	off	off	on	on	on	on
	Port 2—SW7						Port 2—SW8					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE	on	on	on	on	on	on	off	off	off	off	off	off
DCE	off	off	off	off	off	off	on	off	on	on	on	on

# Circuit Cards

## NTND02 Misc/SDI/Peripheral Signaling Card

The next four tables list option settings for the NTND02 MSPS Card.

### NTND02 port addresses

Device number		Even port SW8				Odd port SW9					
		1	2	3	4	1	2	3	4	5	6
0	1	*	off	off	off	off	off	off	on	on	on
2	3	*	off	off	off	off	off	off	on	on	off
4	5	*	off	off	off	off	off	off	on	off	on
6	7	*	off	off	off	off	off	off	on	off	off
8	9	*	off	off	off	off	off	off	off	on	on
10	11	*	off	off	off	off	off	off	off	on	off
12	13	*	off	off	off	off	off	off	off	off	on
14	15	*	off	off	off	off	off	off	off	off	off

\* Switch does not affect operation; it may be set to ON or OFF.

### NTND02 baud rates—switch settings

Baud rate	Even port—SW10				Odd port—SW11			
	1	2	3	4	1	2	3	4
150	*	off	on	on	*	off	on	on
300	*	on	off	on	*	on	off	on
600	*	off	off	on	*	off	off	on
1200	*	on	on	off	*	on	on	off
2400	*	off	on	off	*	off	on	off
4800	*	on	off	off	*	on	off	off
9600	*	off	off	off	*	off	off	off

\* Switch does not affect operation; it may be set to ON or OFF.



## Circuit Cards

### NTND02 DTE or DCE selection

Mode	Even port—SW4						Even port—SW5					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE (terminal)	off	off	off	off	off	off	on	on	on	on	on	on
DCE (modem)	on	on	on	on	on	on	off	off	off	off	off	off
NT1P61 (Fibre)	off	off	on	on	on	on	on	on	on	on	off	off
	Odd port—SW2						Odd port—SW3					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE	off	off	off	off	off	off	on	on	on	on	on	on
DCE	on	on	on	on	on	on	off	off	off	off	off	off

### NTND02 data format selection

Format	Even port—SW6				Odd port—SW7			
	1	2	3	4	1	2	3	4
7 bits/character		off	on			off	on	
8 bits/character		off	off			off	off	
Odd parity	on			on	on			on
Even parity	on			off	on			off
No parity	off			*	off			*
* Switch does not affect operation; it may be set to ON or OFF.								

## Circuit Cards

### QPC139 Serial Data Interface Card

The next two tables list option settings for the QPC139 SDI Card.

#### QPC139 address and output device selection

Address selection					Output device		
Device number	F7 switch					Port 1 plug location	Port 2 plug location
	1	2	3	4			
0–1	off	on	on	on	Modem	A13	A25
2–3	off	on	on	off	RS-232 data terminal	A16	A22
4–5	off	on	off	on			
6–7	off	on	off	off			
8–9	off	off	on	on			
10–11	off	off	on	off			
12–13	off	off	off	on			
14–15	off	off	off	off			
<b>Note 1:</b> Switches at D22 and D31 are not used and set to OFF. <b>Note 2:</b> When connecting to NT1P61 Fibre Superloop Network Card, install DIP switches as follows: location A13=off off on on off on on, A16= on on on on on off off, A22=on on on on on off off, A25=off off on on off on on							

#### QPC139 baud rate selection

Baud rate	Port 1 C34 switch				Port 2 C22 switch			
	1	2	3	4	1	2	3	4
110	off	on	on	on	off	on	on	on
150	off	off	on	on	off	off	on	on
300	off	on	off	on	off	on	off	on
600	off	off	off	on	off	off	off	on
1200	off	on	on	off	off	on	on	off
2400	off	off	on	off	off	off	on	off
4800	off	on	off	off	off	on	off	off
9600	off	off	off	off	off	off	off	off
<b>Note:</b> Switches at D22 and D31 are not used and set to OFF.								

## Circuit Cards

### QPC414 Network Card

Application	Pin connection J3/S2 and J4/S1
Option A: In-house remote peripheral equipment (RPE), microwave, fiber optics	connect pins 2 and 3 (pin 1 is next to the white dot)
Option B: T-1 facilities (including PRI/DTI),* channel service unit	connect pins 1 and 2 (pin 1 is next to the white dot)
<p>* To connect 1.5M RPE to T-1 through channel service unit, select option B. For 2M RPE, jumper plugs are not used.</p> <p><b>Note 1:</b> Possible jumper locations for vintage B (for different styles/series):  J3—E11 or H11  J4—H17 or E7  S1 and S2—E33</p> <p><b>Note 2:</b> Possible jumper locations for vintage A (for different styles/series). These cards do not have the option selection and can only be used in the option A setting:  J3—H5 or E11  J4—H17 or E7  S1 and S2—E33</p> <p><b>Note 3:</b> Connectors and loop relations:  Even loop: J1 faceplate connector, jumper at J4 or S1  Odd loop: J2 faceplate connector, jumper at J3 or S2</p>	

# Circuit Cards

## QPC513 Enhanced Serial Data Interface Card

Program socket selection				Switch S2—Address selection								
Option	Port	Socket number		Device number	Style A				Style B			
					1	2	3	4	1	2	3	4
DTE (terminal)	1	UA10	UA12	0—1	off	off	off	*	off	off	off	*
	2	UA17	UA19	2—3	on	off	off	*	off	off	on	*
DCE (modem)	1	UA9	UA11	4—5	off	on	off	*	off	on	off	*
	2	UA16	UA18	6—7	on	on	off	*	off	on	on	*
RS-232-C interface	1	UB9	UB11	8—9	off	off	on	*	on	off	off	*
	2	UB16	UB18	10—11	on	off	on	*	on	off	on	*
High-speed interface	1	UB10	UB12	12—13	off	on	on	*	on	on	off	*
	2	UB17	UB19	14—15	on	on	on	*	on	on	on	*

\* ON = synchronous mode; OFF = asynchronous mode. (Asynchronous mode is not supported. However, in releases prior to X11 release 18, asynchronous mode may work in some applications. With Release 18 and later, asynchronous mode will not work.)

## Circuit Cards

### QPC687 CPU Card

Address selection B1 switch					Speed selection B1 switch*							Output device	
Device number	1	2	3	4	Baud rate	5	6	7	8	9	10		
0	on	on	on	on	300	off	off	on	off	on	off	QPC687A Port	Plug location
1	off	on	on	on	600	off	on	off	on	on	off		
2	on	off	on	on	1200	on	off	on	on	on	off	Modem	A7
3	off	off	on	on	1800	off	on	on	on	on	off	EIA data terminal	A5
4	on	on	off	on	2400	off	off	on	off	off	on		
5	off	on	off	on	4800	off	on	off	on	off	on	QPC687B Port	Switch location
6	on	off	off	on	9600	on	off	on	on	off	on		
7	off	off	off	on									A23 B23
8	on	on	on	off									S1 S2
9	off	on	on	off								Modem	All on All off
10	on	off	on	off								EIA data terminal	All off All on
11	off	off	on	off									
12	on	on	off	off									
13	off	on	off	off									
14	on	off	off	off									
15	off	off	off	off									
* On vintage B, the option plug has been replaced with two switches (S1 and S2) in locations A23 and B23.													

# Circuit Cards

## QPC720 Primary Rate Interface Card

Switch S2 settings	To repeatered facility	To cross-connect point
5 on	0–45 m (0–150 ft)	0–30 m (0–100 ft)
2, 4, 6 on	46–135 m (151–450 ft)	31–100 m (101–355 ft)
1, 3, 7 on	136–225 m (451–750 ft)	101–200 m (356–655 ft)
<b>Switch 3 option for DTI with ESF</b>  SW3-1    on    = extended superframe format (ESF) off    = superframe format (SF)		
<p><b>Note 1:</b> All positions on S2 (location B22) are OFF except as shown under the column labeled “Switch S2 settings.”</p> <p><b>Note 2:</b> The switch 3 option for DTI with ESF applies to only X11 releases 16, 17, and 18. All other positions on the 8-pole SW3 (location E37) should be OFF.</p> <p><b>Note 3:</b> Before X11 release 19 (releases 16, 17, and 18), you must set the framing format as ESF with the DLOP prompt in LD17 before you set SW3-1 on the card for the DTI with ESF option.</p> <p><b>Note 4:</b> Beginning with X11 release 19, framing format, line encoding, and method of yellow alarm are selectable for both DTI and PRI in LD17 with the DLOP, LCMT, and YALM prompts. All SW3 switch positions should be OFF.</p> <p><b>Note 5:</b> QPC720E is a standard product since July, 1993 backwards compatible to X11 release 13 software.</p>		

## Circuit Cards

### QPC757 D-Channel Interface Card

Vintage A socket selection				Address selection				
Option	Port	Socket number		Device number	S2 switch			
					1	2	3	4
Data terminal equipment (DTE)	0	UA10	UA12	0–1	off	off	off	off
	1	UA17	UA19	2–3	off	off	on	off
Data communication equipment (DCE)	0	UA9	UA11	4–5	off	on	off	off
	1	UA16	UA18	6–7	off	on	on	off
RS-232-C interface	0	UB9	UB11	8–9	on	off	off	off
	1	UB16	UB18	10–11	on	off	on	off
High-speed interface	0	UB10	UB12	12–13	on	on	off	off
	1	UB17	UB19	14–15	on	on	on	off
Vintage C socket selection				Address selection				
DTE	0	U11	U9	0–1	off	off	off	off
	1	U5	U3	2–3	off	off	on	off
DCE	0	U12	U10	4–5	off	on	off	off
	1	U6	U4	6–7	off	on	on	off
RS-232-C interface	0	U31	U29	8–9	on	off	off	off
	1	U25	U23	10–11	on	off	on	off
High-speed interface	0	U30	U28	12–13	on	on	off	off
	1	U24	U22	14–15	on	on	on	on

QPC757 vintage G is a standard product starting 11/93 and it is backwards compatible with X11 release 14 and higher software. It has the same socket and address selection as vintage C.

# Circuit Cards

## QPC841 4-Port Serial Data Interface Card

The next four tables list option settings for the QPC841 4-Port SDI Card.

### QPC841 port 1 and 2 address selection

Device number		SW14							
Port 1	Port 2	1	2	3	4	5	6	7	8
0	1	off	off	off	off	off	on	on	on
2	3	off	off	off	off	off	on	on	off
4	5	off	off	off	off	off	on	off	on
6	7	off	off	off	off	off	on	off	off
8	9	off	off	off	off	off	off	on	on
10	11	off	off	off	off	off	off	on	off
12	13	off	off	off	off	off	off	off	on
14	15	off	off	off	off	off	off	off	off
<p><b>Note 1:</b> On SW16, positions 1, 2, 3, and 4 must be OFF.</p> <p><b>Note 2:</b> To avoid address conflicts, SW14 and SW15 can never have identical setting.</p> <p><b>Note 3:</b> To disable ports 1 and 2, set SW14 position 1 to ON.</p>									



## Circuit Cards

### QPC841 port 3 and 4 address selection

Device number		SW15							
Port 3	Port 4	1	2	3	4	5	6	7	8
0	1	off	off	off	off	off	on	on	on
2	3	off	off	off	off	off	on	on	off
4	5	off	off	off	off	off	on	off	on
6	7	off	off	off	off	off	on	off	off
8	9	off	off	off	off	off	off	on	on
10	11	off	off	off	off	off	off	on	off
12	13	off	off	off	off	off	off	off	on
14	15	off	off	off	off	off	off	off	off
<p><b>Note 1:</b> On SW16, positions 1, 2, 3, and 4 must be OFF.</p> <p><b>Note 2:</b> To avoid address conflicts, SW14 and SW15 can never have identical setting.</p> <p><b>Note 3:</b> To disable ports 3 and 4, set SW15 position 1 to ON</p>									

# Circuit Cards

## QPC841 baud rate

Baud rate	Port 1 SW10				Port 2 SW11				Port 3 SW12				Port 4 SW13			
	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
150	off	off	on	on	off	off	on	on	off	off	on	on	off	off	on	on
300	off	on	off	on	off	on	off	on	off	on	off	on	off	on	off	on
600	off	off	off	on	off	off	off	on	off	off	off	on	off	off	off	on
1200	off	on	on	off	off	on	on	off	off	on	on	off	off	on	on	off
2400	off	off	on	off	off	off	on	off	off	off	on	off	off	off	on	off
4800	off	on	off	off	off	on	off	off	off	on	off	off	off	on	off	off
9600	off	off	off	off	off	off	off	off	off	off	off	off	off	off	off	off

## QPC841 DTE or DCE selection

Mode	Port 1—SW8						Port 1—SW9					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE (terminal)	on	on	on	on	on	on	off	off	off	off	off	off
DCE (modem)	off	off	off	off	off	off	on	on	on	on	on	on
NT1P61 (Fibre)	on	off	off	on	off	off	on	off	off	off	on	on

## Circuit Cards

### QPC841 DTE or DCE selection

Mode	Port 1—SW8						Port 1—SW9					
	1	2	3	4	5	6	1	2	3	4	5	6
DTE DCE NT1P61 (Fibre)	Port 2—SW6						Port 2—SW7					
	on	on	on	on	on	on	off	off	off	off	off	off
	off	off	off	off	off	off	on	on	on	on	on	on
DTE DCE	Port 3—SW4						Port 3—SW5					
	on	on	on	on	on	on	off	off	off	off	off	off
	off	off	off	off	off	off	on	on	on	on	on	on
DTE DCE	Port 4—SW2						Port 4—SW3					
	on	on	on	on	on	on	off	off	off	off	off	off
	off	off	off	off	off	off	on	on	on	on	on	on

## Circuit Cards

---

# Terms and abbreviations

## 2500 set

A Digitone™ telephone. It is an analog telephone that has buttons, on a key-pad, on the front. When each button is pressed, the telephone transmits a unique tone which represents the digit corresponding to the button pressed. Calls are made by pressing these buttons for the digits in the phone number to be called.

## 500 set

Dial telephone, sometimes called a rotary telephone. It has a rotary device on the front, used for the purpose of dialing digits to make calls. Each time a person turns the dial with a finger in one of the holes, the dial returns to its rest position. In doing so, the circuit connecting the telephone to the system is broken and reconnected the number of times marked beside the hole in the dial.

## A-law companding

Except for North America, companding is accomplished using a logarithmic law called, A-law. See companding.

## Access Restriction

Sometimes called the Class of Service of a telephone. It is only one component of the Class of Service. The access-restriction type controls the types of calls which can be made from a telephone. For example, if the access-restriction type is programmed as Toll Denied, the telephone cannot be used to make any calls where the digit 1 or 0 is the first or second digit following the access code digits.

There are many different access restriction types that have different levels of control of the types of calls that can be made from the telephone.

---

## Terms and abbreviations

---

### **ACD (Automatic Call Distribution)**

Application software that puts incoming calls in a queue to one or more telephones referred to as agent telephones. The longest-waiting call is sent to the agent telephone that has been idle for the longest time. Incoming calls can be given a priority and answered at a prioritized telephone as an option. There are enhancements which can be added to basic ACD functionality to help with management and reporting tasks and also to customize and enhance the treatment incoming calls are given. ACD software packages A, B, C, D, and Custom Controlled Routing offer enhancements to management tools and reports, in order to add to the functionality of basic ACD.

### **analog (500/2500 type) telephone**

A name that replaces PBX set. The name describes a standard telephone set that works on many telephone systems. Examples of these systems are the Meridian 1, DMS or other vendors systems. Analog (500/2500 type) telephone describes the North American 500 set, United Kingdom analogue rotary dial, North American 2500 set, United Kingdom MF 4 and Unity telephones.

### **application processor**

A special purpose computer that attaches to the Meridian 1 system to decrease the load on the system processor. The application processor provides value-added and special services. Application processors are used with voice mail, interactive voice response and automatic call distribution.

### **Aries telephones**

Digital telephones called the M2006, M2008, M2216ACD, M2616 telephones. They are also known as Meridian Modular Digital telephones.

### **Attendant**

The main answering position on a system. From the attendant position, incoming calls are transferred to internal telephones. The terminal used at the attendant position is called a console. There can be one or more attendants on a system, although some systems do not have any attendants. Attendants can answer incoming calls for the

---

## Terms and abbreviations

---

main listed number, recalls which have not been answered, calls from users who are dialing incorrectly, and calls from users who are attempting to place restricted calls.

### **Automatic Call Distribution (ACD)**

Application software that puts incoming calls in a queue to one or more telephones referred to as agent telephones. The longest-waiting call is sent to the agent telephone that has been idle for the longest time. Incoming calls can be given a priority and answered at a prioritized telephone as an option. There are enhancements which can be added to basic ACD functionality to help with management and reporting tasks and also to customize and enhance the treatment incoming calls are given. ACD software packages A, B, C, D, and Custom Controlled Routing offer enhancements to management tools and reports, in order to add to the functionality of basic ACD.

### **Backup answering**

Otherwise known as Call Redirection, backup answering refers to the answering of calls done at a telephone or voice messaging port when the originally dialed caller is busy, not answering, or does not wish to be disturbed, and features like Call Forward are active.

### **Basic Rate Interface (BRI)**

An international standard for connecting terminals to a system. One BRI connection is composed of 2 B-channels at 64 kbit/s each, and 1 D-channel at 16 kbit/s.

### **BCS set (Business Communication Set)**

Northern Telecom term for analog telephones called SL-1 telephones and M1009, M1109, and M1309 telephones.

### **BRI (Basic Rate Interface)**

An international standard for connecting terminals to a system. One BRI connection is composed of two B-channels at 64 kbit/s each, and one D-channel at 16 kbit/s.

---

## Terms and abbreviations

---

### **Business Communication Set (BCS set)**

Northern Telecom term for analog telephones called SL-1 telephones and M1009, M1109, and M1309 telephones.

### **Call Center**

Another term for a queue of incoming calls being answered by one or more telephones.

### **Call Detail Recording (CDR)**

Printouts made when calls are dialed, giving information about the number dialed, the telephones involved, and the duration of the call. Additional information can be printed when CDR enhancements are installed on a system.

### **Call Pickup**

Also called pickup, ringing number pickup. The feature that allows one user to answer an incoming call ringing at another telephone.

### **call processing**

The action of the processor executing the workschedule routine to complete tasks controlled by telephone users. Call processing involves connecting telephone users to other telephones or facilities.

### **Call Redirection**

Also known as backup answering, call redirection refers to the answering of calls done at a telephone or voice messaging port when the originally dialed caller is busy, not answering, or does not wish to be disturbed, and features like Call Forward are active.

### **call register**

Call registers are located in a part of transient data memory. Call registers store temporary information about trunks and telephone sets in the process of establishing calls. Each telephone or trunk in use has a separate call register containing approximately 40 words of information. An example of the 40 words are Class of Service, features, and time slots in use. This information is known as transient data as it is held in a call register only for the duration of the call. Part



---

## Terms and abbreviations

---

of the call register information is transferred to the network or superloop cards. Once the information is transferred, the network or superloop cards set up and control the call. When the call is finished, the transient data is erased from the call register.

### **Camp-On**

This feature allows an attendant to extend a call to a busy telephone. The user of the telephone hears a tone indicating a call is Camped-On. When the user hangs up, the Camped-On call rings the telephone. If the user does not hang up within a programmed amount of time after hearing the tone, the Camped-On call recalls to the attendant.

### **carriage return**

An instruction directing you to press the key on the keyboard marked ENTER, or RETURN. You press key tells the system you have finished that line of input. In this book the symbol <cr> is used for carriage return.

### **CCSA (Common Control Switching Arrangement)**

A service offered by AT&T for private networks that allows any telephone in the network to call another using a seven-digit number.

### **CDR (Call Detail Recording)**

CDR records are printed when calls are dialed. CDR records show information about the number dialed, the telephones involved, and the duration of the call. Additional information can be printed when CDR enhancements are installed on a system.

### **CE (Common Equipment)**

A term for the part of the system that controls the operation of other system components. Common equipment is composed of CPU, memory, input/output ports, and disk storage.

### **Central Office (CO)**

A large telephone switching system that provides service to subscribers located over a large geographic area, usually as part of a public or military switched telephone network.

---

## Terms and abbreviations

---

### Central Office trunk (COT)

Physical carrier of voice and data traffic to and from a local Central Office. Can be copper wire, cable, or optical fibre.

### Central processing unit (CPU)

The card that controls the functions of the other system components, following instructions it gets from the system memory. Some systems have one CPU and others have two.

### Centrex

A type of telephone system that usually resides in the central office and can serve telephones distributed over a wide area. The Nortel system that provides this functionality is called the DMS. It provides services and features that are similar to those of a PBX and some that are different.

### channel

A transmission path capable of carrying voice or data.

### Class of Service

There are many different capabilities and features which can be activated or deactivated for each telephone or trunk. A programming term is used to refer to these capabilities and features collectively. It is Class of Service. For example, the Last Number Redial feature is activated in the Class of Service.

Some people use the term Class of Service when they are referring to one particular feature called Access Restriction. When you program Trunks, Meridian Mail channels, Authorization Codes, and Direct Inward System Access ports, you assign a class of service which is in fact the access-restriction type.

### CO (Central Office)

In North America a central office is the facility containing the switching equipment that provides telephone service to subscribers in the immediate geographical area.

---

## Terms and abbreviations

---

### **CODEC (coder-decoder)**

A device that codes analog signals into digital signals. It also decodes digital signals into analog signals.

### **Common Equipment (CE)**

A term for the part of the system that controls the operation of other system components. Common equipment is composed of CPU, memory, input/output ports, and disk storage.

### **companding**

Companding is derived from the words “compressing” and “expanding”. Companding is the process of compressing the amplitude range of a signal for transmission and then expanding the signal back to its original form at the receiving end.

The transmitted signal (speech) is normally a digital signal. An analog to digital conversion of speech is done in three steps. Sampling the analog signal, Quantizing the sample, and Encoding the quantized sample.

The process of sampling, quantizing, and encoding is known as Pulse Code Modulation (PCM). Eight bit PCM is an industry standard.

### **COMPANION™**

Meridian COMPANION™ systems offer digital wireless telephone capabilities to Meridian 1 systems that use software later than Release 15. Wireless telephone users can travel around their coverage area while answering, initiating, continuing, or transferring telephone calls using low-powered, pocket-size telephones.

### **CONF (Conference Card)**

The interface card in the system that is responsible for adding additional timeslots to an existing call so that more than two people can be bridged together for one call.

---

## Terms and abbreviations

---

### **configuration record**

A programmable data block that describes the location and function of the CE hardware in the system. The configuration record is programmed in overlay program (load) 17.

### **confirmation tone**

A form of special dial tone that indicates to a telephone user that a feature has been activated.

### **Core**

The processing and data storage portion of the Option 51C, 61C, 81 and 81C systems. The Core equates to the Common Equipment in Meridian 1 systems.

### **Core number**

The Option 61C, 81 and 81C systems has two redundant Core systems. The two Core systems are identified by the Core numbers 0 and 1.

### **COT (Central Office trunk)**

A central office trunk is a circuit between a public exchange network switch and a Meridian 1 system.

### **CPU (central processing unit)**

The card that controls the functions of the other system components, following instructions it gets from the system memory. Some systems have one CPU and others have two.

### **cross-connect panel**

Sometimes called the jumper panel or main distribution frame (MDF). The panel where wires from telephones and trunks are interconnected with corresponding wires from the system's line and trunks cards.

### **CSA trunk**

Common Control Switching Arrangement trunk. See CCSA.

---

## Terms and abbreviations

---

### Customer group

A group of users with their own trunk groups, attendants, features and Numbering Plan. A system can be used by one or more unique customer groups.

### Data dump

Storing information from memory onto disks.

### DCE (Data Circuit Terminating Equipment)

The formal name for a modem. Modem is an acronym for modulator-demodulator. The interfacing equipment that is sometimes required to convert digital signals from data terminal equipment (DTE) into quasi-analog signals. This conversion is needed for transmission over analog telephone communication circuits and vice versa.

### DDI (Direct Dialing In)

External callers dialing internal telephones directly, without the intervention of an attendant or interactive voice response system.

### Default

The response which is preprogrammed in the system software for a prompt which must have a response. If the programmer does not enter any value for this particular element or prompt, then the default value is retained in the database. These default responses, along with the changed data, are shown when a printout is made. They are also explained in the programming sections of this book and the other programming guides available from Nortel.

### delay dial

A trunk signal used to control the transfer of dialed digits. Upon seizure, the originating switch will not outpulse digits until the terminating switch does the following steps:

1. sends an off-hook to the originating switch
2. finds and attaches its digit collection equipment
3. sends an on-hook to the originating switch

---

## Terms and abbreviations

---

The on-hook indicates the terminating switch can now accept digits. The time between on-hook and off-hook varies with equipment types.

### Density

A term that refers to the number of terminals that can be connected to a card. Early vintages of cards such as line cards and trunk cards had capacities for fewer terminals than the cards that are made today. Early cards are referred to as single density. Later cards are called double density to indicate that the capacity had doubled. Still later, cards were introduced that are called quadruple (quad) density and octal density.

### Designator (DES)

An alphanumeric code that a programmer associates with a telephone, if the system is equipped with Office Data Administration Software package 20 (ODAS). The code can be up to six characters in length. It can be used to identify the telephone in some way that helps the programmer, usually for record keeping purposes. The programmer decides what the codes will be, and what they will mean. Printouts can be made of telephones with specified DES codes to sort the telephone database according to DES code parameters. For example, the DES system could be set up to identify what department the telephone is in and the floor and building where it is installed. A telephone that is in the accounting department, and on floor 2 of building 1 could have a DES code which is ACF2B1. The programmer could request a printout of all telephones with DES codes that begin with the letters AC to find out what telephones belong to the accounting department.

### Dial tone

The tone produced by the system after a user lifts the telephone handset to initiate a call. This tone is heard through the handset or on the handsfree speaker, if the user is doing on-hook dialing. The user can dial a call when this tone is heard.

### DID (Direct Inward Dialing)

External callers dialing internal telephones directly, without the intervention of an attendant or interactive voice response system.

---

## Terms and abbreviations

---

### **DID trunk**

A trunking feature that allows telephone callers connected to the public exchange network to dial directly to a telephone connected to the Meridian 1 system. DID happens without the intervention of an attendant or interactive voice system.

### **digital subscriber loop**

Any one of eight physical Basic Rate Interface (BRI) ports on a BRI line card. Each port has two B-channels and one D-channel.

### **digital telephones**

A telephone which uses digital signaling. An analog voice is converted into a digital signal within the telephone. A Macintosh, IBM-PC or other data terminal can be connected to the telephone. The data to and from that terminal is multiplexed on the same set of wires used by the telephone for voice calls.

### **Digitone**

Tones used for signaling the digits 0 through 9, # and \*. The tones are a combination of two voice frequencies, a high tone and a low tone.

### **Digitone-type telephone**

An analog telephone that has buttons, on a key-pad, on the front. When each button is pressed, the telephone transmits a unique tone which represents the digit corresponding to the button pressed. Calls are made by pressing these buttons for the digits in the phone number to be called.

### **DIP**

A signaling system that uses electrical pulses to transmit digits.

### **Direct Inward Dialing (DID)**

External callers dialing internal telephones directly, without the intervention of an attendant or interactive voice response system.

---

## Terms and abbreviations

---

### Direct Inward System Access (DISA)

A port configured to allow external callers to use the system as if they were internal users.

### Directory Number (DN)

A telephone number. This is the number internal callers dial to ring a telephone.

### Disks

Magnetic data storage media.

### Distinctive Ringing

There are three features that you can program that cause a telephone to ring differently from the way it rings normally.

You can use the feature called Distinctive Ringing to allow a user to recognize when a call from a particular trunk group is ringing a telephone. If this feature is activated on all trunk groups, then the telephone rings distinctively whenever an external call comes in.

You can program digital telephones to ring in one of four different ringing styles called Distinctive Ringing Groups. This allows a user to differentiate the various telephones when they ring.

You can program a telephone to ring distinctively when a call from a Dial Intercom Group member comes into the telephone. The user can then differentiate a call to a DN as opposed to an incoming call from the intercom group.

### DLC (Digital Line Card)

An intelligent digital line card used on systems with Superloops. It can accommodate up to 16 digital telephones and 16 associated data terminals.

### DN (Directory Number)

A telephone number. This is the number callers dial to ring a telephone.

### download

To receive data from another device.



---

## Terms and abbreviations

---

### **DTE (Data Terminal Equipment)**

Equipment consisting of digital end devices that convert user information into data signals for transmission, and reconvert the received data signals into user information.

### **DTMF**

Dual Tone Multi Frequency. See Digitone.

### **DTN (Digitone)**

A signaling system that uses audio tones to transmit information. Digitone signaling allows the transmission of digits 0-9, and on specially configured telephones, A-D.

### **DTR (Digitone receiver)**

A card with Digitone receiver units on it. The DTR units translate analog Digitone signals into a digital format.

### **Enhanced network**

A card accommodating two loops. Each loop has 32 timeslots.

### **exchange network**

The global network made up of telephone switches operated for the public by telephone utility companies and governments.

### **extender or extender pair**

A term used to describe a 3 Port Extender (3PE) card, Segmented Bus Extender (SBE) card, and the cable that connects them. These components extend the processor's control to the network shelves. The SBE is located on the common equipment shelf, with the processor. The 3PE is located on the network shelf.

### **far end**

The remote PBX at the distant end where your Tie trunk or Private circuit terminates.

---

## Terms and abbreviations

---

### Fast busy tone

A tone that sounds like busy tone, but turns on and off at a faster rate. Typically, fast busy tone is used to indicate that a call is not progressing or cannot be completed. It may also be called overflow or reorder tone.

### Features

Capabilities assigned to the terminals which allow the users to do more than make and receive basic calls. Features range from basic Call Transfer to something as complex as Network-wide Message Waiting. Features are provided by system software which is sometimes basic to every system or packaged as separate options which are either chargeable or non-chargeable. In programming a regular telephone there is an element of programming referred to as the “feature prompt”. This element of programming controls certain capabilities which can be activated for that telephone. Some capabilities are activated in the Class of Service.

### FEX (Foreign Exchange Trunk)

A trunk that provides telephone service to and from a public exchange switch that is outside the subscriber’s exchange area. A user in one city can dial the access code for his FEX trunk and receive dial tone from the foreign public exchange switch. The user can also receive calls dialed from the foreign exchange switch.

### firmware

Software, data, and programming instructions stored permanently in Read Only Memory hardware. (It is neither soft nor hard, therefore it must be firm.) Firmware provides the basic function needed by the Meridian 1 system during start-up, software loading, and other periods when software may not be available in memory. Firmware does not require regular update.

---

## Terms and abbreviations

---

### Flexible Features Codes

User-defined numbers of up to four digits that can be used in place of the preprogrammed Special Prefix (SPRE) feature access codes.

Flexible Feature Codes allow users to define different feature access codes for different features.

### Floppy disks

Magnetic data storage media.

### Foreign exchange trunk (FEX)

The physical carrier of voice and data communications to and from a remote or foreign central office (exchange office).

### Generic

A family of software releases that are designed to apply to a certain market or application. For example, the Generic called X11 was designed to be used in the North American business market. There are other generics that have existed through the years that were designed for the European market and for the hospitality market. In the future there will be one generic of software for all markets.

### group

A pair of interconnected network modules or shelves. A single network module or shelf is known as a half-group.

### Group Call

The name of a feature that allows one user to press a key on a proprietary telephone and automatically call several telephones.

When users answer these telephones they are automatically bridged into a conference connection with other users on the same Group Call.

### Handset

The receiver of a telephone.

---

## Terms and abbreviations

---

### **Handsfree**

Using a telephone without requiring a handset or headset. During handsfree operation, a properly equipped telephone picks up the user's voice through a microphone built into the telephone, and broadcasts the far end user's voice through a built-in speaker.

### **high-speed link**

A communications channel that uses EIA RS422 or RS423 to connect the Meridian 1 to an applications processor. For example a high speed link connects the Meridian 1 to the Meridian MAX.

### **immediate start**

A signal used on trunks to control the transfer of dialed digits. After a trunk seizure, the originating switch may start outpulsing digits to the terminating switch after a minimum delay of 70 ms.

### **Initialization**

During initialization, transient (unprotected) data is cleared from memory until the initialization is complete. During this time, established calls can remain connected. Calls cannot be originated or disconnected during this time. It generally lasts for a few seconds.

### **Input/output (I/O) ports**

The connection points through which the system outputs data and through which the system receives data input.

### **intercept treatments**

Invalid or denied actions coming from a telephone, TIE trunk, attendant, or CCSA/DID trunk are given a treatment called an intercept treatment. These treatments are defined customer wide. For example, if a user who is Toll Denied tries to dial a toll call, then the intercept treatment for that situation determines what will happen to that user. The user can hear overflow tone, or be routed to the attendant or can hear a recorded announcement.

---

## Terms and abbreviations

---

### **IPE (Intelligent Peripheral Equipment)**

The part of the system composed of interface cards that connect to terminals such as telephones and trunks, and the shelves on which these cards reside. The interface cards are equipped with microprocessors.

### **ISDL (Integrated Services Digital Line Card)**

Peripheral Equipment line cards that are used to support digital telephones. They can accommodate up to eight digital telephones and eight associated data terminals.

### **ISDN (Integrated Services Digital Network)**

A digital telephony network that allows the transmission of voice and data using internationally approved protocols.

### **Issue**

During development of a new release of software several versions, called issues, of the release are developed in sequence. Each issue fixes problems that have been identified from the previous issue.

### **Jumper panel**

Sometimes called the cross-connect panel or main distribution frame (MDF). The panel where wires from telephones and trunks are interconnected with corresponding wires from the system's line and trunks cards.

### **junct**

A passive device providing the interconnection for calls between network groups on multi-group Meridian 1 systems.

### **Key system**

A type of telephone system where the exchange lines can be directly accessed using keys or buttons on the telephones.

---

## Terms and abbreviations

---

### Key

The term used to describe a button on a proprietary telephone that you can assign as a feature or DN function. You assign these keys using overlay program 11. The programming for these keys is stored in the system memory.

### LD (Load)

An abbreviation for the term load; otherwise known as overlay program.

### link

1. Another name for a communications channel or circuit.
2. A button on certain types of telephones that users can press when they want to perform a switch-hook flash, instead of pressing the switch-hook under the handset.
3. A connection to another system, as in the Meridian Link application.

### Loop

A transmission path within the system. Line cards and trunk cards share the transmission path using 32 timeslots.

### low-speed link

A communications channel, using EIA RS232 to connect the Meridian 1 to a terminal.

### Main Distribution Frame (MDF)

Sometimes called the cross-connect panel or jumper panel. The panel where wires from telephones and trunks are interconnected with corresponding wires from the system's line and trunk cards.

### MARP (Multiple Appearance Directory Number Redirection Prime)

The telephone designated as the controlling one on a shared DN for features like Hunting, Call Forward No Answer, and Call Forward All Calls.

---

## Terms and abbreviations

---

### **MCA (Meridian Communications Adapter)**

A device that provides an interface between an IBM-PC, Macintosh, or data terminal, and an Aries telephone.

### **MCU (Meridian Communications Unit)**

A device that provides an interface between an IBM-PC, Macintosh, or data terminal, and the Meridian 1 system.

### **MDF (main distribution frame)**

Sometimes called the cross-connect panel or jumper panel. The panel where wires from telephones and trunks are interconnected with corresponding wires from the system's line and trunks cards.

### **MEM (memory)**

The hardware in the system that is used to store the information the system needs in order to operate.

### **memory (MEM)**

The hardware in the system that is used to store the information the system needs in order to operate.

### **Meridian 1 telephone**

A term replacing BCS set, describing a telephone set designed to operate exclusively with the Meridian 1 PBX. For example, the SL-1, M1009, M1109, M1309, M2009, M2018, M2112, M2006, M2008, M2317, M2616ACD, M2016S, M2216, and M3000 telephones.

### **Meridian Mail**

The voice mail system manufactured by Nortel to be compatible with the Meridian 1. Meridian Mail is provided using an external application processor.

---

## Terms and abbreviations

---

### Meridian Proprietary Telephone

A term replacing BCS set, which is used to describe the SL-1 telephone, the M1000, M1109, M1309, M2009, M2018, M2018S, M2112, M2317, M2006, M2008, M2616, M2216, and M3000. These telephones are designed to operate exclusively on SL-1, Meridian SL-1, and Meridian 1 switches.

### Message Center

A configuration where telephones are programmed to redirect calls to either a specific telephone, the attendant, or voice mail when calls are not answered or the telephone was busy.

### mnemonic

A code used as a memory aid. Mnemonic codes are also used in programming.

### module

1. Another name for a memory card.
2. A stylish aluminum box that holds a card cage. It is also called a Universal Equipment Module or UEM.

### MPU (Multi Processing Unit)

A processor that performs some of the tasks that would otherwise be performed by the CPU. For example, the IPE analog line card contains an MPU that interprets a series of on-hook, off-hook rotary dial pulses as a DN. The MPU then passes the DN on to the CPU, saves CPU resources. Without the MPU, the CPU would have to set and control timers to ensure the incoming pulses are not hook-switch flashes, hits on the line, or that the caller has abandoned the call. See time stamp 2.

### Mu-law companding

Companding is the process of compressing the amplitude range of a signal for transmission. At the receiving end the compressed signal is expanded back to its original form. Companding is a contraction of compressing and expanding. In North America, companding is accomplished using a logarithmic law called, “255 Law Companded Pulse Code Modulation Digital Coding Standard” or  $\mu$ -law. See companding.



---

## Terms and abbreviations

---

### Multiple Appearance Directory Number Redirection Prime (MARP)

The telephone designated as the controlling one on a shared DN for features like Hunting, Call Forward No Answer, and Call Forward All Calls.

### Multiple Appearance DN

A DN that is programmed to appear on more than one telephone or more than one key on one telephone.

### Multiple Call DN

A DN that appears on more than one telephone or more than one key on one telephone. It is capable of handling as many calls as there are appearances.

### NANP (North American Numbering Plan)

The North American Public Exchange Network has been divided into geographical areas with three digit codes which precede the seven digit local telephone number of the subscriber. Previous to 1995, the three digit area codes assigned to each geographical area were in the format where the first digit was any digit between 2-9 and the last digit was any digit between 0-9. The middle digit was either 0 or 1. As of January 1, 1995, the middle digit can be any digit between 0-9. This increases the capacity of three digit codes available.

### NE (Network Equipment)

The part of the Meridian 1 that serves to interconnect terminal equipment. Network Equipment also provides services such as conferencing and tones.

### near end

The local Meridian 1 system where your T1 trunk or Private circuit terminates.

### NET (Network Controller - Superloop)

The circuit pack on which the Superloop resides.

### Network Class of Service

A class of service that determines network access.

---

## Terms and abbreviations

---

### Network Equipment (NE)

The part of the Meridian 1 that serves to interconnect terminal equipment. Network Equipment also provides services such as conferencing and tones.

### NPA (Numbering Plan Area Code)

The North American Public Exchange Network has been divided into geographical areas with three digit codes which precede the seven digit local telephone number of the subscriber. It is used when dialing a long distance call. For example, when someone in a city in the 205 area code wants to direct dial someone located in the 613 area code, they dial 1613 followed by the person's seven digit telephone number.

### NTP (Northern Telecom Publication)

The manuals that are published by Northern Telecom that describe how to install, program and maintain all the features, services and components of a Meridian 1 system. Many of these manuals are shipped with every system. Some of the manuals are optional.

### Numbering Plan

The leading digits which are assigned to Directory Numbers, trunk route access codes, and the Special Prefix (SPRE) code for feature activation within one customer group database. The same digits cannot be assigned to two different numbers or codes. This is called the "leftwise unique rule".

For example, it is permissible to have access code 11 for SPRE and access code 130 for paging trunks but it is not permissible to assign access code 55 to a TIE trunk route and access code 552 to a dictation trunk route.

A typical Numbering Plan:

- 0 Attendant
- 11 Special Prefix Code (SPRE)
- 2XXX Directory numbers (DNs)
- 3XXX DID Directory numbers

---

## Terms and abbreviations

---

- 4 Unassigned (for future use)
- 5 Unassigned (for future use)
- 6 Unassigned (for future use)
- 7X Access codes for TIE trunks, paging trunks, dictation trunks
- 8 Access code to Automatic Route Selection calls
- 9 Access code to COT trunks or local calls

### NXX (Public Network Exchange code)

The first three digits of a seven digit telephone number assigned to each subscriber in North America. These digits identify the Central Office to which the subscriber is connected.

### Off-hook

The status of a telephone when the handset is lifted from the switch-hook. The telephone is described as being in an off-hook condition.

### office data

A term used to describe the data programmed on a Meridian 1 using the Administration overlay loads. The administration loads are as follows:

- ◆ LD 10 to LD 29
- ◆ LD 49 to LD 52
- ◆ LD 56 to LD 58
- ◆ LD 73 to LD 74
- ◆ LD 79
- ◆ LD 81 to LD 88
- ◆ LD 90
- ◆ LD 93 to LD 95
- ◆ LD 97

---

## Terms and abbreviations

---

### On-hook

The status of a telephone when the handset is resting on the switch-hook. The telephone is described as being in a non-hook condition.

### Outpulse

To transmit digits on external trunks to other systems. Also, telephones can outpulse digits to the system to which they are connected. The user causes either one of these types of outpulsing to occur by dialing digits on a telephone.

### output buffer

A storage area in transient data memory used to keep output information to be sent to a telephone or trunk from the processor. The information, called a messout, will control relays on trunk cards, LEDs or LCDs on telephones, and so on. There are two types of output buffers, SL-1 and 500.

### Overflow Tone

A tone that sounds like busy tone, but turns on and off at a faster rate. Typically, fast busy tone is used to indicate that a call is not progressing or cannot be completed. It may also be called fast busy or reorder tone.

### Overlay programs

The programs which must be used for entering the data required to customize a system for the particular site and users connected to it. It includes data for such things as features, telephones, trunk groups, hardware, data devices, Automatic Route Selection to name a few.

---

## Terms and abbreviations

---

### P data

The protected data store memory segment for Meridian SL-1NT, XT, Option 61, and 71 (or page 1, for previous systems), holds data blocks that have been entered on a DTE. Pdata describes the make up and provisioning or programmable data of the system. Some of the data blocks are as follows:

- ◆ configuration records (LD 17)
- ◆ customer data blocks (LD 15)
- ◆ route and trunk data blocks (LD 16, LD 14)
- ◆ telephone set data blocks (LD 10, LD 11)

### parameters

A range or limits set for entries in the software.

### PBX (Private Branch Exchange)

A telephone switch that serves trunks and telephones.

### PBX set

A term replaced by Analog (500/2500 type) telephone. A PBX set is a standard telephone set that works on many telephone systems. Examples of these systems are the Meridian 1, DMS or other vendor systems.

### PCM

Pulse Code Modulation. See companding.

### PE (Peripheral Equipment)

The part of the system composed of interface cards that connect to terminals such as telephones and trunks, and the shelves on which these cards reside.

---

## Terms and abbreviations

---

### PFTU

Power Fail Transfer Unit. A term used for QUA4, QUA5, QUA6 and NT8D39 (DEES) transfer units. The term implies that an emergency transfer will only result from a loss of power. All transfer units can be connected to perform the emergency transfer function when the CPU cannot process calls, due to a system reload or CPU failure.

### Phantom DN

ADN which appears on a secondary key of a telephone. It is not published.

### Phantom TN

A TN defined in software that does not exist in hardware.

### Pickup

Also called call pickup, ringing number pickup. The feature that allows one user to answer an incoming call ringing at another telephone.

### Pickup groups

A group of telephones provided to users who have to be able to answer incoming calls for each other.

### port

A port is:

1. the connection point for a terminal
2. another term for a Terminal Number
3. the connection point for an input/output (IO) device

### Primary Rate Interface (PRI)

An international standard for connecting telephone switches. A PRI connection is composed of 23 B-channels at 64 kbit/s each, and one D-channel at 16 kbit/s. A PRI2 connection is composed of 31 B-channels at 64 kbit/s each, and one D-channel at 16 kbit/s.

### Prime DN

The DN programmed on key 0 of a telephone.

---

## Terms and abbreviations

---

### Private line service

Also known as leased-line service or point-to-point service.

### Private network

Trunk connections between PBXs and Centrex systems that carry calls between users who reside on different systems that belong to one organization or company. The private network trunks can be used for calls that end up on the public network, if that is allowed in the area where the systems are installed.

### prompt

A mnemonic presented by the system when you are programming or issuing commands to the system.

### Proprietary telephone

A term replacing BCS set, which is used to describe the SL-1 telephone, the M1000, M1109, M1309, M2009, M2018, M2018S, M2112, M2317, M2006, M2008, M2616, M2216, and M3000. These telephones are designed to operate exclusively on SL-1, Meridian SL-1, and Meridian 1 switches.

### protected data (P data)

The protected data store memory segment for Meridian SL-1NT, XT, Option 61, and 71 (or page 1, for previous systems), holds data blocks that have been entered on a DTE. Pdata describes the make up and provisioning or programmable data of the system. Some of the data blocks are as follows:

- ◆ configuration records (LD 17)
- ◆ customer data blocks (LD 15)
- ◆ route and trunk data blocks (LD 16, LD 14)
- ◆ telephone set data blocks (LD 10, LD 11)

---

## Terms and abbreviations

---

### **PSTN (Public Switched Telephone Network)**

Otherwise known as the public network. The global network made up of telephone switches operated for the public by telephone utility companies and governments.

### **Public (Exchange) network**

Refer to Exchange network.

### **Queuing**

The organizing of calls so that the longest waiting or highest priority call is the first to be processed.

### **RAN**

Mnemonic for Recorded Announcement.

### **Redirection**

Otherwise known as backup answering, redirection refers to the answering of calls done at a telephone or voice messaging port when the originally dialed caller is busy, not answering, or does not wish to be disturbed, and features like Call Forward are active.

### **redundant**

A Meridian 1 with two processors is a redundant system. One processor controls the system while the other is in a standby mode. A redundant system is necessary to allow a software upgrade without interrupting service.

### **Regular telephone**

An analog telephone which can operate on any system. These telephones work when connected to a central office, key system or PrivateBranchExchange(PBX).Theyhaverotarydialordigitonekeypads.



---

## Terms and abbreviations

---

### Release

A version of software that contains certain features and capabilities (for example, Release 21). Not all releases can be used on all machine types. Each new release has greater functionality than its predecessor. Nortel introduces at least one new release of software each year.

### Reorder Tone

A tone that sounds like busy tone, but turns on and off at a faster rate. Typically, fast busy tone is used to indicate that a call is not progressing or cannot be completed. It may also be called overflow or fast busy tone.

### response

An mnemonic you type in answer to a prompt when you are programming.

### response time-out

A memory or I/O device does not respond to a read or write signal from the processor within 8 ms. A response time-out causes an initialize or a system reload.

### Restriction

Preventing telephone users from making certain types of calls or accessing certain features.

### Return key

The key on the keyboard marked ENTER, or RETURN. Pressing the key tells the system you have finished that line of input. In this book the symbol <cr> is used for carriage return.

### Ring Again

A feature that allows a telephone user to queue for a busy telephone or trunk group.

### Ringback tone

The tone the caller hears when the called telephone is ringing.

---

## Terms and abbreviations

---

### **Ringing number pickup**

Also called pickup, ringing number pickup. The feature that allows one user to answer an incoming call ringing at another telephone.

### **SDI (Serial Data Interface)**

Input/output port.

### **Secondary DN**

A DN programmed on a key other than key 0 of a telephone.

### **service change**

A term used when you program in administration overlay programs.

### **service loop**

Another name for Tone & Digit Switch and Conference loops. Service loops provide services such as dial tone and multi-party calls.

### **set**

Another term for telephone.

### **Single Appearance DN**

A DN that is programmed to appear on only one telephone and one key of one telephone.

### **Single Call DN**

A DN that appears on one telephone or more than one telephone. It is capable of handling one call at a time.

### **SL-1 telephone**

A telephone designed to work with an SL-1 PBX. It can be configured to have one or more than one Directory Number upon which to make and receive calls. It has buttons called keys which are programmable in the system database for such things as features and Directory Numbers.

### **SL-1-type telephone**

An M1009, M1109, or M1309 telephone.

---

## Terms and abbreviations

---

### slot number

A numbered designator indicating where cards are located within the card cage of the modules.

### software package

A component of software that, if equipped, provides certain features and capabilities. Software packages are listed by a mnemonic or a number or both.

### special dial tone

A dial tone that sounds different from normal dial tone and indicates to a telephone user the operation of a feature, that a message is waiting, or that a response is required.

### Special prefix code (SPRE)

A code defined customer-wide that users of 500- or 2500-type sets dial to access features. The code can also be used on Meridian Digital and SL-1 telephones to access certain features that have not been assigned to keys.

### Standard Network

A card that accommodates one loop. Each loop has 32 timeslots. Timeslots are used in matching pairs.

### starting arrangement

The protocol used between Meridian 1 PBX and a Central Office to control digit collection. See immediate start, delay dial and wink start.

### Station

Another term for telephone.

### Station Control Password

A password that is assigned to a telephone in overlay program 10 or 11 that the user of the telephone must dial in order to activate features such as Electronic Lock and Remote Call Forward.

---

## Terms and abbreviations

---

### **Superloop**

A transmission path within the system. Intelligent line and trunk cards share the transmission path using 128 timeslots.

### **Switch-hook flash**

The term used for pressing the button under the handset of a telephone for a specific amount of time. This is done to access certain features.

### **Switch-hook**

The term used to describe the button that sits under the handset of a telephone. The switch-hook is used to disconnect calls, initiate calls and perform features. The user does these things by depressing the switch-hook, lifting the receiver off the switch-hook, and flashing the switch-hook respectively. (Refer to switch-hook flash).

### **SYSLOAD**

The reset and startup of a telephone switch. During SYSLOAD, data is loaded into the system from storage media, and no call processing can take place.

### **system monitor**

A component found in the lower rear of Meridian 1 equipment columns. The system monitor reports the status of power related hardware for its column to the processor. The processor subsequently sends the system monitor's message to the SDI data terminals.

### **TDS (Tone and Digit Switch)**

A card that the system uses to provide many different tones to users.

### **Terminal Number (TN)**

A physical or hardware location address, consisting of a network loop number, PE shelf number, PE card number, and unit number.

### **TN (Terminal Number)**

A physical or hardware location address, consisting of a network loop number, PE shelf number, PE card number, and unit number.

---

## Terms and abbreviations

---

### TIE trunk

A dedicated circuit that connects two Meridian 1 systems or a Meridian 1 system and any other kind of PBX.

### time slot

An interval of time during which you occupy a shared transmission path during an active call.

### time stamp

There are two types of time stamp as follows:

1. 1. A time stamp is output within five minutes of the processor detecting an problem to warn service personnel. For example, TIM061 09:00 9/3/1994 CPU0. The time stamp is normally accompanied by a message.
2. 2. When a call register is established for a telephone or trunk, the processor marks the start time and each interval action time with a time stamp in milliseconds. The time stamps are used to start, stop and control timers. For example, a rotary dial telephone sends dialed digits as a series of precisely timed on/off-hooks. If the on-hook to off-hook time interval is short, the processor interprets this as a switch hook flash rather than a dialed digit. If an off-hook to on-hook transition lasts too long, the processor interprets this as a call which is finished or abandoned and tears down the connection.

### Traffic

A measurement of the level of activity of a specific resource.

### transient data

The same as U data. See unprotected data store.

### Trunk group

A defined set of trunks that can be used interchangeably by the system to reach a specific destination.

---

## Terms and abbreviations

---

### Trunk

One or more pairs of wires that connect one system to another. There are many types of trunks, distinguished by the types of calls they are designed to carry and the types of systems they inter-connect. Trunks are grouped together by type into trunk groups. Some examples of trunk types are TIE trunks, central office trunks, and Foreign Exchange trunks.

### TTY

A data terminal used to transmit and receive commands and responses when you are programming. Generically a TTY refer to any dumb terminal or DTE used to pass ASCII data. A DTE used for communicating alphanumeric information with the Meridian 1 system.

### U data (unprotected data)

The unprotected data store memory segment holds data blocks used by the processor to update information about the progression of calls. When the calls are finished the processor tears down the calls or erases the information in the unprotected data store segment. The data blocks can be varied in number to accommodate the variety of lines or trunks installed, amount of traffic, and so on. They contain:

- ◆ high and low priority input buffers for MESSIN
- ◆ SL-1 and 500 output buffers for MESSOUT
- ◆ call registers - one call register of some 40 plus words is needed for each call and holds information such as;
  - calling TN
  - called TN
  - time slots in use
  - dialed digits
  - timed status
  - call progress markers
  - network paths in use

---

## Terms and abbreviations

---

### UEM (Universal Equipment Module)

A stylish aluminum box holding a card cage.

### Unity telephone

A family of telephones manufactured by Nortel. They belong in the 500/2500-type telephone family.

### unprotected data (U data)

The unprotected data store memory segment holds data blocks used by the processor to update information about the progression of calls. When the calls are finished the processor tears down the calls or erases the information in the unprotected data store segment. The data blocks can be varied in number to accommodate the variety of lines or trunks installed, amount of traffic, and so on. They contain:

- ◆ high and low priority input buffers for MESSIN
- ◆ SL-1 and 500 output buffers for MESSOUT
- ◆ call registers - one call register of some 40 plus words is needed for each call and holds information such as;
  - calling TN
  - called TN
  - time slots in use
  - dialed digits
  - timed status
  - call progress markers
  - network paths in use

### WATS (Wide Area Telephone Service) trunk

In North America, a circuit between a public exchange network switch and a Meridian 1 system. WATS telephone calls are billed at a reduced rate.

---

## Terms and abbreviations

---

### **wink start**

A signal used on trunks to control the transfer of dialed digits. The terminating switch finds and attaches its digit collection equipment, then sends a 140 ms off-hook, on-hook pulse to the originating switch that requests the digits to be sent.

### **X08**

An early edition of the software package for International Business applications. X08 was replaced by X11 with Supplementary Features. With the release 20 software, X11 denotes global applications software.

### **X11**

A software package for North American Business applications. With the release 20 software, X11 denotes global applications software.

### **XNET**

A mnemonic for a superloop network card.

### **XPE0**

The first module (PE shelf) cabled to a superloop.

### **XPE1**

The second module (PE shelf) cabled to a superloop.

### **XPEC**

A mnemonic for System Monitor.

### **XSM**

A mnemonic for System Monitor. A component found in the lower rear of Meridian 1 equipment columns. The system monitor reports the status of power related hardware for its column to the processor. The processor subsequently sends the system monitor's message to the SDI data terminals.



---

## Terms and abbreviations

---

### **μ-law companding**

In North America, companding is accomplished using a logarithmic law called, “255 Law Companded Pulse Code Modulation Digital Coding Standard” or μ-law. See companding.

---

## Terms and abbreviations

---

# Index

## Symbols

μ-Law 103

μ-law companding 489

## Numerics

20PPS prompt 188

2500 set 453

3 Port Extender 466

3PE card 466

500 set 453

500/2500 buffers 141

500/2500 Line Cards guide 142

500/2500 type telephones 373

500/2500-type telephones 391

## A

AAA prompt 361, 366

ACB cables 149

ACCD prompt 213

Accept level 179

Access Restriction 453, 458

Access-denied numbers 213

ACD 76, 142, 378, 454, 455

ACD agents 112

ACD directory numbers 112

ACD printer 38, 44, 76

ACD reports 38

ACD/D AUX links 76

ACDN prompt 112

ADAN prompt 23, 29, 31, 40, 42, 48,  
51, 56, 57, 60, 70, 72, 75, 84,  
87, 88, 148

Address space 71

ADMIN1 91

Administration password 92

Administration passwords 97

Administration terminal 17, 28

AGC 168, 173

AGCD prompt 168, 173

AGNT prompt 112

air filters 4

airflow exits 4

A-law 103

A-law companding 453

ALL 368

ALON 365

Alphabet 368

ALUL prompt 105, 110

ALUS prompt 105, 110

AML 69

AML cards 180

AML port designation 77

Analog (500/2500 type) telephone  
454, 478

Analog (500/2500 type) telephones  
373

Analog line cards 105

Analog trunks 217

Analogue rotary dial telephones 454

---

## Index

---

- antistatic precautions 434
- ANUM prompt 416
- APL 76
- Application link module 187
- Application Module Link 69
- Application processor 454
- Application processors 468, 472
- Applications 38, 70
- Applications Module Link cards 180
- APRT prompt 76
- Area Code 474
- Aries parameters 168
- Aries telephones 454
- ASCII characters 367, 368
- ASCII string 359
- AST prompt 112
- Asynchronous port 71
- ATDN prompt 211, 415
- ATRN 172
- Attendant 454
- Attendant administration 76
- Attendant Alternative Answering 366
- Attendant console intercept treatments 202
- Attendant console options 406
- Attendant consoles 423, 430
- attendant consoles
  - cross-connecting 407, 408
- Attendant directory number 195
- Attendant DN 415
- Attendant incoming call indicators 209
- Attendant Network Class of Service 415
- Attendant number 416
- AUD messages 19, 38
- Audit 9
- Audit buffer 141
- Audit trail 101
- AUDT prompt 101, 141, 147
- Authorization codes 349
- Auto-answer 27
- Automatic Call Distribution 378, 454, 455
- Automatic call distribution 142
- Automatic gain control 168, 173
- Automatic maintenance 157
- Automatic set relocation 76
- Auto-terminate routes 194
- Auto-terminate trunks 193
- Auxiliary input queue 76
- Auxiliary output queue 76
- Auxiliary processor link 76
- AXQI prompt 76
- AXQO prompt 76
- B**
- B34 table type 104
- Background overlay programs 156
- Background terminal 17, 18, 33, 38, 44
- Backing up databases 47
- Backup answering 455, 456, 481
- Basic passwords 92
- Basic Rate Interface 455, 463
- Basic Rate Interface Line and Trunk cards 180
- Basic rate interface line cards 187
- Basic rate interface trunk cards 187
- Basic Rate Interface Trunk Universal ISDN Protocol Engine cards 180
- Basic rate interface Universal ISDN Protocol Engine 187
- BATT prompt 151
- Battery backup 151
- B-channels 455, 463

- BCS set 455, 472, 480
- Bell 103/212 compatible modems 27
- BGD 33, 44
- BKGD prompt 156, 162
- BLF/CGM (Busy Lamp Field/Console Graphics Module)
  - with attendant consoles 409, 411
- Blockage 178, 382
- blower units 4
- Break delay 179
- Break Duration 185
- BRI 455, 463
- BRK prompt 179, 185
- Buffer 477
- Buffer size 141
- Buffer sizes 139, 430
- Buffers 419
- BUG 44, 87
- BUG messages 19, 38, 92
- Bus Extender 149
- Business Communication Set 455
- Busy lamp field 212
- Busy tone 477
- C**
- C.FWRD key 398
- cable-rack mountings 4
- CACH prompt 156
  - Prompts
    - CACH 163
- Cache buffers 163
- Cache memory 156
- CAD prompt 179, 185
- Cadence 179, 185
- Call Center 456
- Call Detail Recording 37, 84, 456, 457
- Call Detail Recording Description and Format guide 16
- Call Forward 391
- Call forward 397
- Call Forward All Calls 366
- Call Forward forwarding party class of service 212
- Call Forward key 398
- Call Forward No Answer 366
- Call Forward Non Intercom 366
- Call Party Name Display 359
- Call Pickup 366, 387, 456
- Call pickup 479
- Call processing 456
- Call Processor cards 7, 11
- Call Redirection 455, 456
- Call register 456
- Call registers 76
- Call Transfer 366
- Call Waiting 194
- Call Waiting Tone 193
- Calling Party Privacy 349
- Camp-On 457
- Camp-on tone 196, 212
- Capacity Engineering guide 142, 431
- Card density 319, 320, 321, 382, 391, 392
- Card number 382
- Card type 180, 187
- cardcages 3
- cards
  - network 117
  - Superloop Network 117
- CARR 125
- Carriage return 457
- Carrier Link Superloop connections 125
- CBT card 13
- CCSA 457
- CDB 191

---

## Index

---

- CDEN prompt 319, 320, 321, 391, 392
- CDL 76
- CDR 37, 456, 457
- CDR data link 76
- CDR records 38, 44, 76
- CDR TTY port 38, 44, 76
- CE 457, 459
- CE parameters 124, 134
- CE/PE Modules 3
- Central Office 457, 458
- Central Office trunk 458, 460
- Central office trunks 104
- Central processing unit 458
- central processing unit 460
- Centrex 458, 479
- CEQU 134
- CFF 212
- CFNA prompt 361, 366
- CFWD prompt 361, 366
- Changing passwords 93
- Channel 458, 470
- Character set 359
- circuit cards
  - caution on replacing and handling 434
- Class of Service 361, 371, 380, 384, 453, 458, 466, 474
- CLDN prompt 213
- Clearing system faults 9
- CLS 384
- CLS prompt 391, 392
- CMC 76
- CMDU 56
- CMS 76
- CNFG prompt 362, 365
- CNI card 12
- CNI prompt 151
- CO 457, 458
- CODE prompt 111, 172
- CODEC 459
- CODEC coding 168, 172
- Coder-decoder 459
- columns 2
- Command and status link 76
- Commands
  - SSID 155
  - STAD 161
  - TSID 155, 161
  - TTAD 161
- Common Control Switching Arrangement 457
- Common Control Switching Arrangement trunk 460
- Common Equipment 457, 459, 460
- Common equipment parameters 124, 134
- Common/Peripheral Equipment (CE/PE) Modules 3
- Communications management center 76
- Companding 103, 453, 459, 473, 489
- COMPANION 381, 459
- Conditional download 180
- CONF 459
- CONF key 399
- Conference 399
- Conference card 459
- Conference key 399
- Conference loops 130, 483
- Configuration record 460
- Configuration records 477
- Configuring Speed Call lists 354
- Configuring the CPUs 149
- Configuring the memory 150
- Confirmation dial tone 397, 400
- Confirmation tone 395, 460

- connectors
  - attendant consoles 406
- CONT prompt 103, 111
- Controller number 125
- Controlling Speed Call 400
- Cooling status 18
- Copper cable connections 125
- Copying telephones 386
- Core 460
- Core Module 56
- Core Modules 3
- Core Multi Drive Unit 56
- Core-to-network interface card 151
- COT 458, 460
- COTL prompt 104, 109
- COTS prompt 104, 109
- covers for modules
  - caution on handling 434
- CPAD prompt 188
- CPND 359
- CPND alphabet 367
- CPND display length 365
- CPND name 368
- CPND\_LANG prompt 359, 367
- CPP 349
- CPU 458, 460
- CPU extenders 149
- CPU Modules 3
- CPU/Network Modules 3
- CRC continuity faults 103
- CRC maintenance threshold 111
- CRCF prompt 103, 111
- Creating a customer number 208
- Cross-connect panel 460, 470, 471
- cross-connections
  - attendant consoles 407
- CSA trunk 460
- CSC 76, 87
- CTA 212
- CTRC prompt
  - Prompts
  - CTRC 213
- CTVN prompt 213
- CTY 44, 76
- CTYP prompt 31, 42, 75
- CUST prompt 44, 76, 93, 100, 208, 209, 210, 211, 212, 213, 365, 367, 391, 392, 415, 416
- Customer data 477
- Customer Data Block 191
- Customer database 19
- Customer group 461
- Customer group number 391, 392
- Customer number 76, 208, 209, 210, 211, 212, 213, 365, 367, 415, 416
- Customer options 196
- CY45 prompt 158, 163
- Cyclic Redundancy Check 111
- Cyclic Redundancy Check continuity faults 103
- D**
- Daily maintenance routines 9
- Daily routines 157, 158, 162, 163, 426
- Data Circuit Terminating Equipment 461
- Data dump 9, 55, 102, 174, 189, 214, 369, 393, 461
- Data dumps 47
- Data option 387
- Data terminal 487
- Data Terminal Equipment 465
- Data terminals 17, 27
- Database backups 47
- Date and time 155

---

## Index

---

- Date and time adjustment 426
- DBA 212
- DCE 71, 461
- D-channel 455, 463
- D-Channel cards 180
- D-channel cards 187
- DCNO prompt 362, 368
- DDI 461
- Decoder 459
- DEES 478
- DEF 2006 prompt 112
- DEF 2008 prompt 112
- DEF 2216 prompt 112
- DEF 2500 prompt 112
- DEF 2616 prompt 112
- DEF 500 prompt 112
- Default 461
- Default display length 360
- Default length 366
- Default names 98
- Default passwords 91
- Defining names 367
- Defining passwords 97
- Defining the loops 124, 134
- DEFS prompt 112
- Delay 179
- Delay dial 462
- Density 462
- Departmental listed directory numbers 192, 208
- DES 383, 462
- DES prompt 77, 360, 366, 391, 392
- Designation 77
- Designator 383, 391, 392, 462
- Designators 366
- Detecting dial tone 179
- Device number 75
- DFLN prompt 360, 366
- DFQ prompt 179, 183
- DGRP prompt 209
- Diagnostic programs 9
- Diagnostic routines 8
- Diagnostics 9, 10, 156, 162
- Dial Intercom Groups 367
- Dial intercom groups 192, 209
- Dial pulse time 111
- Dial telephone 453
- Dial tone 463
- Dial tone detection 183, 321
- Dial tone detectors 179, 316, 319
- Dial tone discrimination 179
- Dial Tone Frequency band 183
- Dialed name display 361
- Dialed Name Display Allowed COS 361
- DID 463, 464
- DID digit conversion 368
- DID trunk intercepts 200
- DID trunks 104, 192, 463
- DIDS prompt 104, 109
- DIG 192, 362
- DIG prompt 362, 367
- Digit conversion 368
- Digital Line Card 465, 469
- Digital links 167
- Digital subscriber loop 463
- Digital subscriber loops 112
- Digital Telephone Line Engineering guide 16
- Digital telephone parameters 168
- Digital telephones 463
- Digital wireless telephones 459
- Digitone 463, 465
- Digitone receiver 321, 465
- Digitone Receiver parameters 186
- Digitone receivers 178, 186, 315



- Digitone telephone 453, 464
- DIP 464
- Direct Dialing In 461
- Direct inward dial trunks 104
- Direct Inward Dialing 463, 464
- Direct Inward System Access 194, 464
- Direct outward dial trunks 104
- Directory Number 464, 465
- Directory Numbers 379, 475
- Directory numbers 367, 371, 391
- DISA 194, 464
- Disk drives 47
- Disk space 353
- Disks 464
- Display format 367
- Display length 365
- Display of incoming calls 359
- Display of outgoing calls 361
- Display of redirected calls 361
- DISPLAY\_FMT prompt 367
- Distinctive Ringing 387, 391, 392, 464
- Distinctive ringing 209
- DLC 465
- DLDN 192
- DN 379, 464, 465
- DN prompt 362, 367, 391
- DNDA 361
- DNDD 361
- DNSZ prompt 353, 354
- DNUM prompt 70, 75
- DOD trunks 104
- Double-density intelligent line cards 383
- Download 465
- Downloading mode 180, 187
- DRG 387
- DROL prompt 157, 162
- DSET prompt 173
- DSL prompt 112
- DTD 179, 316, 319
- DTE 27, 71, 465
- DTMF 465
- DTMF prompt 188
- DTN 465
- DTO prompt 321
- DTR 178, 315, 465
- DTR tables 179
- Dual Tone Multi Frequency 465
- Dumb mode 27
- E**
- EDD command 25, 34
- Electrical interface 71
- Electronic Lock 391, 392
- Electronic mail 69
- Electronic Switched Network Description 16
- ELK 391, 392
- Emergency transfer 478
- EMI (electromagnetic interference) 4
- Enabling the MSDL card 33
- ENET 178
- Engineering and Assignment of Equipment guide 142
- Enhanced busy lamp field 196, 212
- Enhanced network 465
- Enhanced Night Service 193, 194
- Enhanced Peripheral Equipment cards 178
- Enhanced Serial Data Interface card 70, 75
- ENS option 193
- ENTER key 457, 482
- EPE cards 178
- EPE controller 126
- Equipment data dump 8, 9

---

## Index

---

- ERR messages 19, 38
- Error diagnostics 10
- ESDI 75
- ESDI card 70
- ESDI port 71
- Even-bit interleaved A law coding 168
- Event reporting 19
- Exchange network 466, 480
- Exchange office 467
- Exiting an overlay 40
- Exiting overlays 29, 57, 72, 84
- EXT0 prompt 149
- EXT1 149, 335, 354, 366
- EXT1 prompt 149
- Extended dial tone detector 321
- Extended Flexible Analog Line Card 111
- Extended flexible analog line card 103
- Extended Peripheral Equipment controller 125
- Extended Tone Detection Table 183
- Extended tone detector table number 321
- Extended/Network Digitone parameters 188
- Extender 466
- External processors 69
- F**
- Failed Login Threshold 94, 100
- Far end 466
- Fast busy 194, 466, 477, 481
- Fault detection 69, 158, 163
- FDLC prompt 180, 187
- Feature planning and provisioning 14
- Features 466
- FEX 467
- FFC 385, 467
- Fibre link connections 125
- Fibre optic links 280
- FIRE 125
- Firmware 10, 467
- Firmware faults 180
- Flexible Feature Codes 385, 427
- Flexible Features Codes 467
- Flexible incoming tones 212
- Flexible Night Service 192
- Flexible Tone and Digit Switch Card guide 16
- Floppy disk drives 47
- Floppy Disk Unit 47
- Floppy disks 467
- FLSH prompt 103, 111
- FLTH prompt 94, 100
- FNUM prompt 112
- Forced download 180, 187
- Foreign Exchange Trunk 467
- Foreign exchange trunk 467
- Four-port SDI 31, 32, 42, 43
- Frequency band 179
- FTYP prompt 51
- G**
- Generic 467
- Grey cards 178
- grounding 409
- Group 468
- Group Call 468
- Group Night Service 193
- Guides 475
- H**
- Hacking 93
- Half-group 468
- Handset 468
- Handsfree 468

- Hard disk drives 55
- Hard disk space 353
- Hardware location address 485
- Hardware planning 14
- Hayes compatible modems 27
- heat (thermal) sensor assemblies 4
- High-priority buffers 141
- High-speed link 468
- HIST prompt 82
- History buffer 142
- History File 83, 142
- History file buffer 87
- History log files 81
- Hold 400
- HOST 92, 100
- Host computers 69
- HOST mode login 100
- HOST prompt 93
- Hot Line lists 347
- Hotel environments 360
- Hotel installations 365
- Hotel/motel environment 17
- Hotel/motel environments 18
- HSL 76
- HUNT prompt 361, 366
- I**
- I/O (input/output) interfaces 4
- I/O ports 469
- IBL 212
- IBM-PC 463, 471
- IC2 212
- ICI prompt 209
- ICP5 76
- IDC prompt 362, 368
- IDC tables 362
- IHA 212
- ILF 212
- Immediate start 468
- Inboard CPND 362
- Inboard directory system 362
- Incoming call indicators 196, 209, 212
- Incoming DID digit conversion 368
- Incoming digit conversion 368
- Incoming digit conversion tables 362
- Incremental Software Management 112
- Individual hold 212
- INIT prompt 101
- Initialization 468
- Input/output (I/O) ports 469
- Input/Output Guide 28, 70, 83, 430
- Input/output Processor 56
- Input-output guides 15
- INRG prompt 209
- INSO prompt 112
- Integrated Services Digital Line Card 469
- Integrated Services Digital Network 469
- Intelligent line cards 177, 383
- Intelligent Peripheral Equipment 177, 469
- Intelligent Peripheral Equipment (IPE) Modules 3, 118–120, 121–??
- Interactive voice response 454
- Intercept computer link 76
- Intercept treatment 469
- Intercept treatments 197, 213
- Interface card 27
- Interface cards 20, 70
- InterGroup Modules 3
- International companding law 110
- INTN prompt 110
- Intrusion tones 188

---

## Index

---

- INTU prompt 188
- Inverted A law coding 168
- IOP 56
- IPE 177, 469
- IPE cards 178
- IPE Modules 3, 118–120, 121–??
- ISDL 469
- ISDN 469
- ISDN Basic Rate Interface 142
- ISDN Basic Rate Interface Description 16
- ISDN Protocol Engine cards 180
- ISDN Signaling Link cards 180
- ISDN signaling link cards 187
- ISM prompt 112
- Issue 469
- ITG 212
- IVMS 76
  
- J**
- Japanese alphabet 359
- Jumper panel 470, 471
- Junctor 470
  
- K**
- KAT 367, 368
- Katakana alphabet 359, 367, 368
- Key 470
- KEY prompt 392
- Key system 470
- KEY1 prompt 113
- KEY2 prompt 113
- KEY3 prompt 113
  
- L**
- LANG prompt 359, 362, 367, 368
- Language 359, 367, 368
- LAO 93
- LAO password 99, 100
- LAPW 93
- LAPW prompt 93, 99, 100
- LD 470
- LD 10 prompt 391
- LD 11 392
- LD 12 416
- LD 13 319
- LD 15 208, 415
- LD 17 23, 24, 25, 31, 42, 44, 51, 60, 75, 87, 88, 97, 124, 125, 134, 135, 148, 162, 167, 172, 460
- LD 18 193, 353
- LD 2 83, 155, 161
- LD 21 207
- LD 43 25, 34, 52, 102, 189, 214, 369, 393
- LD 45 158
- LD 48 33
- LD 73 173
- LD 95 359, 365
- LD 97 108, 183
- LD22 98
- LDA0 prompt 208
- LDA1 prompt 208
- LDA2 prompt 209
- LDA3 prompt 209
- LDN 192
- LDN1 prompt 208
- LDN2 prompt 209
- LDN3 prompt 209
- Leased-line service 479
- LED message polarity 319
- Level 1 password 99
- Limited Access to Overlays passwords 93, 100
- Line cards 177, 180, 382, 470
- line circuit card terminations

- attendant consoles 407, 411
- Link 470
- Link activation 69
- Link button 396
- List limits 347
- List number 354
- List of customers 100
- List of overlay programs 100
- List of tenants 100
- LLID prompt 101
- LNAME\_OPTION prompt 91, 98
- LOA 212
- Load 470
- Load manager 76
- LOC prompt 113
- Local CPND 362
- Local directory system 362
- Local loop back 163
- Location code 113
- LOCK prompt 94, 100
- Lockout 212
- Lock-out time 94, 100
- LOCL 365
- Log files 27
- Log size 27, 83, 88
- Logical port number 70
- Logical terminal IDs 113
- Login name 98
- Login name option 92
- LOGIN prompt 92
- LOGIN\_NAME prompt 99, 100
- Logs 81
- Loop 470
- Loop density 131
- Loopback testing 157
- Loops 129, 178, 382
- Loss and Level plan parameters 108
- Loss plan 104
- Low-priority buffers 141
- Low-speed link 471
- LSL 76
- LSNO prompt 354
- LTID prompt 113
- M**
  - M1250 attendant consoles
    - cross-connecting 408, 409
  - M2006 telephones 375
  - M2008 telephones 376
  - M2216ACD telephones 378
  - M2250 attendant consoles 196
    - cross-connecting 410, 411
  - M2317 telephone 374
  - M2616 telephones 377
  - Macintosh 463, 471
  - Magnetic data storage media 464, 467
  - Main Distribution Frame 471
  - Main distribution frame 470, 471
  - Maintenance 69, 156
  - Maintenance diagnostics 9
  - Maintenance printer 38
  - Maintenance routines 8
  - Maintenance schedules 157
  - Maintenance telephone 8
  - Maintenance telephones 28
  - Maintenance terminal 17, 18, 28, 33, 44
  - Maintenance terminals 19
  - Maintenance threshold 111
  - Maintenance thresholds 103
  - Maintenance-busy numbers 213
  - Manuals 475
  - MARP 471, 473
  - Mass storage 47, 55, 464
  - Mass storage space 353
  - MBNR prompt

---

## Index

---

- Prompts
  - MBNR 213
- MCA 387, 471
- MCU 471
- MDF 470, 471
- MDL prompt 179, 184, 186
- MDU 47, 55
- MED prompt 113
- MEM 471
- Member number 367
- Memory 55, 139, 471
- Memory allocation 360
- Memory card 472
- Memory configuration 139
- Memory tests 151
- Memory type 150
- Meridian 1 database 359
- Meridian 1 telephone 472
- Meridian 1 telephones 373
- Meridian Communications Adapter
  - 387, 471
- Meridian Communications Unit 471
- Meridian COMPANION 459
- Meridian Digital Telephones 167, 168,
  - 371, 374, 392, 426
- Meridian Mail 76, 113, 472
- Meridian Modular Digital telephones
  - 454
- Meridian Programmable Data Adapter
  - 387
- Meridian Proprietary Telephone 472
- Message Center 472
- Message types 87
- Message waiting lamp maintenance
  - tests 162
- Message waiting lamp tests 157
- Messages
  - AUD 19, 38
  - BUG 19, 38, 92
  - ERR 19, 38
  - OVD 403, 424
  - SCH 92
- MF 4 telephones 454
- MFRL prompt 111
- Midnight routines 9, 426
- Minimum Accept Level 186
- Minimum accept level 179
- Minimum Detect Level 184
- Minimum Validation 184
- Minimum Validation Time 186
- MINL prompt 179, 186
- MISP cards 187
- Mnemonic 472
- Modem cable 27
- Modems 18, 22, 461
- Modulator-demodulator 461
- Module 472
- module covers
  - caution on handling 434
- Modules 177
- MOPT prompt 113
- Motel environments 360
- Motel installations 365
- MPDA 387
- MPED prompt 134
- MPU 472
- MSDL 31, 32, 43, 75
- MSDL card 33, 42, 70
- MSDL cards 180, 187
- MTC 33, 44, 87
- MTYP prompt 150
- Mu law coding 168
- Mu-law companding 473
- Multi Disk Unit 47, 55
- Multi Processing Unit 472
- MULTI\_USER prompt 163

- Multifrequency sender/receiver 320
- Multiple Appearance Directory Number Redirection Prime 471, 473
- Multiple Appearance DN 473
- Multiple Appearance DNs 360, 366, 379
- Multiple Call Class of Service 380
- Multiple Call DN 380, 473
- Multiplexed cable 217, 280
- Multi-purpose ISDN Signaling Link cards 180
- Multipurpose ISDN signaling link cards 187
- Multipurpose Serial Data Line card 70
- Multipurpose Serial Data Link 31, 32, 42, 43
- Multipurpose Serial Data Link card 75
- Multipurpose Serial Data Link cards 180, 187
- Multipurpose Serial Data Link Description 16
- Multi-Tenant Service 194
- Multi-User Login 82
- Multi-user login 91
- MXLN prompt 360, 365
- MYT prompt 184
- N**
- NAME prompt 359, 362, 367, 368
- Name storage 365
- Names 362, 367
- NANP 473
- NASA prompt 228
- NATP prompt 104, 108
- NCOS prompt 354, 415
- Near end 474
- NET 474
- Network Attendant Service 228
- Network card 489
- Network card slots 125
- Network cards 117
  - superloop 120, ??–120
- Network Class of Service 354, 474
- Network Controller 474
- Network Equipment 474
- Network loop number 188
- network loops ??–120
- Network module 468
- Network Modules 3
- network switching ??–120
- Night Call Waiting Tone 193
- Night Call Waiting tone 193, 194, 195
- Night groups 193
- Night Number Table 193, 194
- Night Service 193
- Night service 192, 210
- Night Service DN 210
- Night Service Group Number 194
- Night Service Option 193
- NIT1 prompt 210
- NIT2 prompt 210
- NIT3 prompt 210
- NIT4 prompt 210
- NITC prompt 361, 366
- NITE prompt 192
- NLPW prompt 93
- NOLS prompt 353
- Non-resident programs 8
- Nortel telephones 372
- North American Numbering Plan 473
- North American Transmission Plan 108
- Northern Telecom Publication 475
- NPA 474
- NPW1 prompt 92, 99
- NPW2 prompt 92, 99

---

## Index

---

NPWD prompt 93  
NT5D10 Call Processor Card 12  
NT5D20 IOP/CMDU 56  
NT5K02 111  
NT6D39 CPU/Network Modules 3  
NT6D60 Core Modules 3  
NT6D64 Core Multi Drive Unit 56  
NT6D66 Call Processor Card 12  
NT8D04 Superloop Network Cards  
    117, 119–??, 120, ??–120  
NT8D11 Common/Peripheral Equip-  
    ment (CE/PE) Modules 3  
NT8D13 Peripheral Equipment (PE)  
    Modules 3  
NT8D17 188  
NT8D34 CPU Modules 3  
NT8D35 Network Modules 3  
NT8D36 InterGroup Modules 3  
NT8D37 Intelligent Peripheral Equip-  
    ment (IPE) Modules 3,  
    118–120  
NT8D39 478  
NT8D47 Remote Peripheral Equip-  
    ment (RPE) Modules 3  
NT9D19 Call Processor Card 7, 12  
NT9D33 Small System Multi Disk  
    Unit 48, 55  
NTND02 Misc/SDI/Peripheral Signal-  
    ing card  
    option settings 440  
NTND15 FDU 47  
NTND16 Multi Disk Unit 47, 55  
NTPs 475  
Numbering Plan 381, 473, 475  
Numbering Plan Area Code 474  
NUMD prompt 51, 56, 60  
NWT prompt 194, 195  
NXX 476

## O

ODAS 360, 383, 462  
Off-hook 476  
Off-hook validation timer 103, 111  
Office data 13, 55  
Office Data Administration Software  
    462  
Office Data Administration System  
    360, 383  
On-hook 476  
OPT prompt 212  
Optical fibre link connections 125  
Optimizing buffers 431  
Option 21 4  
    option 21  
        required/optional modules for 3  
Option 21 systems 125  
Option 21A 4  
    option 21A  
        required/optional modules for 3  
Option 21E 4  
    option 21E  
        required/optional modules for 3  
Option 51 4  
    option 51  
        required/optional modules for 3  
Option 51C 5  
    option 51C  
        required/optional modules for 3  
Option 61 5  
    option 61  
        required/optional modules for 3  
Option 61C 5  
    option 61C  
        required/optional modules for 3  
    option 61E  
        required/optional modules for 3  
Option 71 5



- option 71
    - required/optional modules for 3
  - Option 81 6
  - option 81
    - architecture 10–??
    - base hardware 7
    - required/optional modules for 3
  - Option 81 Core Module 56
  - option 81C
    - required/optional modules for 3
  - Originating side ringing cadence 196
  - Outgoing calls 361
  - Outpulse 477
  - Outpulsing 391
  - Output buffer 477
  - Output buffers 141
  - OVD message 424
  - OVD messages 403
  - Overflow conditions 83
  - Overflow Tone 477
  - Overflow tone 466, 481
  - Overlay 17 167
  - Overlay programs 155
  - Overlays 100, 167, 470, 477
    - Administration overlays 476
    - Overlay 11 392
    - Overlay 12 416
    - Overlay 13 319
    - Overlay 15 208, 415
    - Overlay 17 23, 24, 25, 31, 42, 44, 51, 60, 75, 87, 88, 97, 124, 125, 134, 135, 148, 162, 172, 460
    - Overlay 18 193, 353
    - Overlay 2 83, 155, 161
    - Overlay 21 207
    - Overlay 22 98
    - Overlay 43 25, 34, 52, 102, 189, 214, 369, 393
  - Overlay 45 158
  - Overlay 48 33
  - Overlay 73 173
  - Overlay 95 359, 365
  - Overlay 97 108, 183
  - OVLA prompt 93, 100
- P**
- P data 142, 477, 480
  - P10P prompt 188
  - P10R prompt 111
  - P20R prompt 112
  - PAD levels 173
  - PAD values 169, 188
  - Paging trunks 105
  - PAGT prompt 105, 110
  - Parameters 478
  - PASS prompt 92
  - Passive Bus Extender 149
  - Password audit buffer 141
  - Passwords 91, 92, 484
  - PBX 478
  - PBX set 454, 478
  - PBXH prompt 157, 162
  - PCM 459, 489
  - PDU (Power Distribution Units) 4
  - PE 177, 478
  - PE (Peripheral Equipment) Modules 3
  - pedestals 2, 4
  - Peripheral controller numbers 113
  - Peripheral Equipment 478
  - Peripheral equipment 177
  - Peripheral equipment controller number 188
  - Peripheral Equipment line cards 469
  - PFTU 478
  - Phantom DN 478

---

## Index

---

- Phantom loops 125
- Physical address 70, 485
- Pickup 456, 479, 482
- Pickup groups 479
- PKUP prompt 361, 366
- Placing a call 395
- Planning 14
- Planning examples 16
- Planning forms 16
- PMS 76
- Point-to-point service 479
- POLR prompt 319
- Port 479
- Port card type 75
- Port designation 77
- Port number 70
- PORT prompt 75
- Port speed restrictions 92
- ports
  - for I/O (input/output) interfaces 4
- Post flash timer 111
- Power Distribution Units (PDUs) 4
- Power Fail Transfer Unit 478
- Power failure 180
- Power status 18
- power supplies and power units
  - attendant console cross-connecting 409
- Power terminal numbers 416
- PRI 479
- Primary Rate Interface 479
- Primary rate interface Universal ISDN
  - Protocol Engine 187
- Primary Rate Interface Universal ISDN Protocol Engine cards 180
- Prime DN 479
- Print routines 8
- Printers 17, 37, 39, 81, 83
- printing
  - History File contents 81
- Priority overlays 163
- Privacy 349
- Private Branch Exchange 478
- Private line service 479
- Private network 479
- Processor 454
- Program key 387
- Program store 55
- Programmable read-only memory 10
- Programming examples 16
- PROM 10
- Prompt 480
- Prompts 179, 362
  - 20PPS 188
  - AAA 361, 366
  - ACCD 213
  - ACDN 112
  - ADAN 23, 29, 31, 40, 42, 48, 51, 56, 57, 60, 70, 72, 75, 84, 87, 88, 148
  - AGCD 168, 173
  - AGNT 112
  - ALUL 105, 110
  - ALUS 105, 110
  - ANUM 416
  - APRT 76
  - AST 112
  - ATDN 211, 415
  - AUD 141
  - AUDT 101, 147
  - AXQI 76
  - AXQO 76
  - BATT 151
  - BKGD 156, 162
  - BRK 179, 185

CACH 156	DNSZ 353, 354
CAD 179, 185	DNUM 70, 75
CDEN 319, 320, 321, 391, 392	DROL 157, 162
CFNA 361, 366	DSET 173
CFWD 361, 366	DSL 112
CLDN 213	DTMF 188
CLS 391, 392	DTO 321
CNFG 362, 365	EXT0 149
CNI 151	EXT1 149
CODE 111, 172	FDLC 180, 187
CONT 103, 111	FLSH 103, 111
COTL 104, 109	FLTH 94, 100
COTS 104, 109	FNUM 112
CPAD 188	FTYP 51
CPND_LANG 359, 367	HOST 93
CRCF 103, 111	HUNT 361, 366
CTVN 213	ICI 209
CTYP 31, 42, 75	IDC 362, 368
CUST 44, 76, 93, 100, 208, 209, 210, 211, 212, 213, 365, 367, 391, 392, 415, 416	INIT 101
CY45 158, 163	INRG 209
DCNO 362, 368	INSO 112
DEF 2006 112	INTN 110
DEF 2008 112	INTU 188
DEF 2216 112	ISM 112
DEF 2500 112	KEY 392
DEF 2616 112	KEY1 113
DEF 500 112	KEY2 113
DEFS 112	KEY3 113
DES 77, 360, 366, 391, 392	LANG 359, 362, 367, 368
DFLN 360, 366	LAPW 93, 99, 100
DFQ 179, 183	LDA0 208
DGRP 209	LDA1 208
DIDS 104, 109	LDA2 209
DIG 367	LDA3 209
DISPLAY_FMT 367	LDN1 208
DN 362, 367, 391	LDN2 209
	LDN3 209
	LLID 101

---

## Index

---

LNAME\_OPTION 91, 98  
LOC 113  
LOCK 94, 100  
LOGIN 92  
LOGIN\_NAME 99, 100  
LSNO 354  
LTID 113  
MDL 179, 184, 186  
MED 113  
MFRL 111  
MINL 179, 186  
MOPT 113  
MPED 134  
MTYP 150  
MULTI\_USER 163  
MXLN 360, 365  
MYT 184  
NAME 359, 362, 367, 368  
NASA 228  
NATP 104, 108  
NCOS 354, 415  
NIT1 210  
NIT2 210  
NIT3 210  
NIT4 210  
NITC 361, 366  
NITE 192  
NLPW 93  
NOLS 353  
NPW1 92, 99  
NPW2 92, 99  
NPWD 93  
NUMD 51, 56, 60  
NWT 194, 195  
OPT 212  
OVLA 93, 100  
P10P 188  
P10R 111  
P20R 112  
PAGT 105, 110  
PASS 92  
PBXH 157  
PKUP 361, 366  
POLR 319  
PORT 75  
PRTY 156, 163  
PWD2 97, 108  
PWnn 93, 100  
RANR 105, 110, 213  
REQ 23, 31, 42, 51, 60, 75, 87, 88,  
97, 108, 110, 124, 125,  
134, 147, 148, 149, 162,  
172, 173, 183, 186, 187,  
188, 207, 208, 209, 210,  
211, 212, 213, 319, 320,  
321, 353, 354, 365, 367,  
391, 392, 415, 416, 417  
RESN 361, 366  
RGTP 113  
RPEB 148  
S10P 188  
SBE 149  
SCPW 391, 392  
SETN 416  
SID 162  
SIZE 87, 88, 101, 141, 142, 147,  
148, 353, 354  
SLOT 114, 125  
SMEM 151  
SOLR 168, 173  
SPRE 210  
SPVC 415  
SSC 179, 185  
SSUP 76  
ST21 114, 125  
STAL 360, 365

- 
- STOR 354
  - SUPL 113, 125
  - SUPT 125
  - T2WN 105, 109
  - T2WT 104, 109
  - T2WV 105, 109
  - T4WN 105, 109
  - T4WT 105, 109
  - T4WV 105, 109
  - TBXH 162
  - TDP 103, 111
  - TDPO 111
  - TEN 93
  - TERD 130
  - TERM 124, 130
  - TERQ 130
  - TID 103, 111
  - TIM1 210
  - TIM2 210
  - TIM3 210
  - TIM4 210
  - TN 319, 320, 321, 391, 392, 416
  - TNS 112
  - TNUM 104, 108
  - TODR 157, 162
  - TOHY 103, 111
  - TPF 111
  - TRLL 157, 163
  - TTYLOG 27
  - TTYP 104, 108
  - TYPE 31, 42, 51, 60, 75, 87, 88, 97, 108, 124, 125, 134, 147, 148, 149, 162, 172, 173, 183, 186, 187, 188, 207, 208, 209, 210, 211, 213, 319, 320, 321, 353, 354, 365, 367, 391, 392, 415, 416, 417
  - USER 18, 38, 76, 87
  - VOLR 168, 173
  - WRT 354
  - XFER 361, 366
  - XMS 18, 33, 44
  - XNPD 188
  - XPE0 114, 125
  - XPE1 114, 126, 135
  - XPEC 113, 126, 188
  - XPLN 360, 362, 367, 368
  - XTDT 179, 183, 321
  - Property Management System 76
  - Proprietary telephone 480
  - Protected Data 142
  - Protected data 477, 480
  - Protected data store 47, 55
  - PRTY prompt 156, 163
  - PSTN 480
  - Public Network Exchange code 476
  - Public Switched Telephone Network 480
  - Pulse Code Modulation 459, 473, 489
  - Pulse dialing 103
  - PW1 92, 97
  - PWD1 91
  - PWD2 92, 97
  - PWD2 prompt 97, 108
  - PWnn prompt 93, 100
  - Q**
  - QCW attendant consoles
    - cross-connecting 408, 409
  - QMT3 Lamp Field Arrays
    - power supplies 409
  - QPC414 Network Cards 117
  - QPC513 Enhanced Serial Data Interface (SDI) Card 70
  - QPC578 cards 411

---

## Index

---

- QUA4 478
- QUA5 478
- QUA6 478
- QUAA power supplies 409
- Queue size 76
- Queuing 454, 455, 456, 480
- Quick Reference Card 387
- QUT1 power units
  - attendant console cross-connecting 409
- R**
- RAN 481
- RAN intercepted calls 213
- RAN trunks 105
- RANR prompt 105, 110, 213
- RCFW 391, 392
- Read Only Memory 467
- Reasons for redirection 361
- Receive levels 104
- Receiver 468
- Recorded Announcement 481
- Recorded announcement 197
- Recorded announcement trunks 105
- Recovery routines 10
- Redirected calls 361, 366
- Redirection 455, 481
- Redundancy 481
- Regular telephone 481
- Release 481
- REMO 365
- Remote access 18
- Remote Call Forward 391, 392
- Remote CPND 362
- Remote directory system 362, 365
- Remote Peripheral Equipment (RPE)
  - Modules 3
- Remote peripheral equipment loop-
  - back tests 157
- Remote peripheral equipment loops 130, 131
- Reorder Tone 481
- Reorder tone 466, 477
- Report schedules 420
- REQ prompt 23, 31, 42, 51, 60, 75, 87, 88, 97, 108, 110, 124, 125, 134, 147, 148, 149, 162, 172, 173, 183, 186, 187, 188, 207, 208, 209, 210, 211, 212, 213, 319, 320, 321, 353, 354, 365, 367, 391, 392, 415, 416, 417
- Resident programs 7
- RESN prompt 361, 366
- Response 481
- Response time-out 482
- Restriction 482
- RETURN key 457, 482
- Return key 482
- RFI (radio frequency interference) 4
- RGTP prompt 113
- Ring Again 482
- Ringback tone 482
- Ringing cadence 212
- Ringing number pickup 456, 479, 482
- ROM 367, 368, 467
- Roman alphabet 359, 367, 368
- ROR 212
- Rotary telephone 453
- Route data 477
- RPE local loopback 163
- RPE loopback tests 157
- RPE Modules 3
- RPEB prompt 148
- RS232 471
- RS-232 interface 71
- RS232C 387

RS422 468

RS423 468

## **S**

S10P prompt 188

Saving data 29, 40, 48, 57, 72, 84

SBA 212

SBE card 466

SBE prompt 149

SCC 348

SCH 33, 87

SCH messages 92

Schedules 9

SCPW prompt 391, 392

SCR single call non-ringing DN 392

SCR single call ringing DN 392

SCU 348

SDI 31, 482

SDI card 42, 180

SDI cards 180

SDI paddle board 31, 32, 42, 43

SDI port address 142

Second level administration password  
99

Secondary DN 482

Secondary key 478

Second-level administration password  
92

Secrecy on attendant consoles 212

Security

lock-outs 93

Security thresholds 93

Segmented Bus Extender 149, 466

Sender parameters 188

Senior supervisor 76

Sensitivity 179

Serial Data Interface 482

Serial Data Interface cards 180

Serial data interface cards 187

Serial Data Interface Cards Description 70

Serial data link card 180

Service administration programs 8

Service change 482

Service change routines 8

Service change terminal 18, 33

Service change terminals 19

Service loop 483

Set 483

Set database 19

SETN prompt 416

Setting CPND parameters 365

Setting PAD levels 173

Setting the history file 148

Setting the password audit trail buffer  
147

Setting the RPE buffer 148

Setting traffic log buffer sizes 148

Setting traffic report schedules 420

Setting up a history file 87

Setting up a traffic file 88

Setting up application module links 75

Setting up floppy disk drives 51

Setting up hard disk drives 60

Setting up printers 42

Setting up terminals 31

Shelf number 382

Shelf segment number 125

SID 155

SID prompt 162

Sidetone 426

Sidetone loudness 168

Sidetones 168

Signal companding 103

Signaling cards 180

Signaling Link cards 180

---

## Index

---

- Signaling link cards 187
- Single Appearance DN 483
- Single Appearance DNs 379
- Single Call DN 379, 483
- Single call non-ringing DN 392
- Single call ringing DN 392
- Single terminal access 28
- Size 88
- SIZE prompt 87, 88, 101, 141, 142, 147, 148, 353, 354
- SL-1 telephone 483
- SL-1 Telephone Line Cards guide 142
- Slot number 483
- SLOT prompt 114, 125
- Small System Multi Disk Unit 48, 55
- SMDU 48, 55
- SMEM prompt 151
- Software 7
  - audit 9
  - customization 13
  - data dump 9
  - Non-resident 8
  - printing 8
  - resident 7
  - service change 8
  - traffic data accumulation 9
- Software audit 8
- Software error printer 38, 44
- Software Input /Output Guide 25, 34, 45, 78, 102, 115, 127, 136, 152, 174, 189, 214, 369, 393
- Software Input /Output Guide Book 322
- Software issues 469
- Software packaging 483
- Software PAD values 188
- Software release 489
- Software releases 467, 469
- Software storage 55
- SOLR 426
- SOLR prompt 168, 173
- spacer kits 4
- Special dial tone 484
- Special prefix code 484
- Special Prefix codes 384
- Special prefix codes 195
- Special services 454
- Speed Call 400
- Speed Call Controllers 348
- Speed Call lists 346
- Speed Call Users 348
- SPRE 195, 384, 467, 484
- SPRE code users 386
- SPRE codes 402, 475
- SPRE prompt 210
- SPVC prompt 415
- SPWD 92
- SSC 347
- SSC prompt 179, 185
- SSID command 155
- SSUP prompt 76
- ST21 prompt 114, 125
- STA 28
- STAD command 161
- STAL prompt 360, 365
- Standalone CPND 362, 365
- Standard Network 484
- Starting arrangement 484
- Static allocation 360, 365
- static discharges
  - cautions to prevent 434
- Station 484
- Station Control Password 391, 392, 484
- Status reporting 18
- STD 125



- STOR prompt 354
  - String length 360
  - Superloop 474
  - Superloop network card 489
  - Superloop Network Cards 120, ??–120
  - Superloop number 113, 125
  - Superloop type 125
  - Superloops 178, 382, 465, 484
  - Supervisory stations 93
  - SUPL prompt 113, 125
  - SUPT prompt 125
  - SVA 212
  - Sweden coding 168
  - Switch settings 27, 70, 188
  - Switch-hook flash 395, 399, 470, 484
  - Switchhook flash time 103, 111
  - Synchronous port 71
  - SYSLOAD 426, 430, 485
  - sysloads
    - History File contents and 81
  - System clock 155
  - System Engineering guide 142
  - System error reporting 18
  - System events 81
  - System faults 9
  - System ID 155
  - System memory 55
  - system messages
    - History File storage of 81
  - System monitor 17, 18, 33, 44, 485, 489
  - System Monitors 4
  - System parameters 103
  - System planning examples 16
  - System power-up 55
  - System processor 454
  - System reload 55
  - System Speed Call lists 347
  - System terminal 8
- T**
- T2WN prompt 105, 109
  - T2WT prompt 104, 109
  - T2WV prompt 105, 109
  - T4WN prompt 105, 109
  - T4WT prompt 105, 109
  - T4WV prompt 105, 109
  - Tampering 91
  - TDET 316
  - TDP prompt 103, 111
  - TDPO prompt 111
  - TDS 483, 485
  - Telemarketing 69
  - Telephone and Attendant Console Installation guide 406, 425
  - Telephone data 477
  - Telephone function keys 385
  - Telephone number 391, 464
  - Telephone parameters 168
  - Telephone types 372
  - Telephones 423, 430
    - 500/2500 373
    - analog 373
    - Meridian Digital 374
  - TEN prompt 93
  - Tenant to route restrictions 194
  - TERD prompt 130
  - TERM prompt 124, 130
  - Terminal 487
  - Terminal emulation software 17
  - Terminal equipment loops 130
  - Terminal Number 479, 485
  - Terminal Numbers 382, 391, 392
  - Terminal port 27
  - Terminals 31
  - TERQ prompt 130

---

## Index

---

- thermal sensor assemblies 4
- Thresholds 93
- TID prompt 103, 111
- TIE trunk 485
- TIE trunk intercepts 198
- TIE trunks 104, 195
- TIM1 prompt 210
- TIM2 prompt 210
- TIM3 prompt 210
- TIM4 prompt 210
- Time of daily routines 162
- Time slot 485
- Time stamp 155, 486
- Timeslot continuity faults 103
- TN 382, 485
- TN prompt 319, 320, 321, 391, 392, 416
- TNS prompt 112
- TNUM prompt 104, 108
- TODR prompt 157, 162
- TOHY prompt 103, 111
- Tone & Digit Switch 483
- Tone and Digit Switch 485
- Tone and digit switch loops 129
- Tone cards 178
- Tone detectors 316
- Tone senders and receivers 178
- Tone table index 188
- top caps 2, 4
- TPF prompt 111
- Traffic 81, 178, 382, 486
- Traffic buffer 142
- Traffic commands 420
- Traffic Control program 420
- Traffic data 37
- Traffic levels 19
- Traffic log 88
- Traffic log files 83
- Traffic monitoring 83
- Traffic parameters 83
- Traffic print program 9
- Traffic printer 38
- Traffic report schedules 420
- Traffic reporting 69
- Traffic routines 8
- Traffic software 9
- Traffic studies 143, 157, 419, 430, 431
- Traffic terminal 18, 19, 28, 33, 44
- Transfer key 396
- Transfer Unit 478
- Transferring a call 395, 396
- transformers
  - attendant console cross-connecting 409
- Transient data 13, 456, 477, 486
- Transmission path 458
- Transmission paths 470, 484, 485
- Transmit levels 104
- TRF 33, 44, 87
- TRLL prompt 157, 163
- Trunk Barring 194
- Trunk cards 180, 470
- Trunk data 477
- Trunk group 486
- Trunk group busy lamp field 196, 212
- Trunk route access codes 475
- Trunk routes 431
- Trunk seizure 468
- Trunk signaling 316
- Trunk to Trunk Barring 195
- Trunk transmit and receive levels 104
- Trunks 217, 423, 431, 486
- TSID command 155, 161
- TTAD command 161
- TTY 487

TTY log files 82

TTYLOG prompt 27

TTYP prompt 104, 108

Twisted pair cable 217, 280

TYPE prompt 31, 42, 51, 60, 75, 87,  
88, 97, 108, 124, 125, 134, 147,  
148, 149, 162, 172, 173, 183,  
186, 187, 188, 207, 208, 209,  
210, 211, 213, 319, 320, 321,  
353, 354, 365, 367, 391, 392,  
415, 416, 417

## **U**

U data 486, 487

UEM 472, 487

UEMs (Universal Equipment Mod-  
ules) 2

Unit number 382

Unity telephone 487

Unity telephones 454

Universal Equipment Module 472, 487

Unprotected data 487

User names 91

USER prompt 18, 38, 76, 87

USER0 91

Using Speed Call 400

## **V**

Vacant numbers 213

Value-added services 454

Video data terminals 17

Voice loops 66, 117

Voice mail 454, 472

VOLR prompt 168, 173

Volume levels 168

Volume reset 168, 173

## **W**

Warning Tone 195

Warning Tone Class of Service 194,  
195

WATS 488

Wide Area Telephone Service 488

Wink start 488

Worksheets 16

wrist straps 434

WRT prompt 354

WTA 194, 195

WTD 194, 195

## **X**

X08 489

X11 467, 489

X11 System Management Applica-  
tions guide 16

XFALC 111

XFER prompt 361, 366

XMS prompt 18, 33, 44

XNET 489

XNPD prompt 188

XPE0 489

XPE0 prompt 125

XPE1 489

XPE1 prompt 114, 126, 135

XPEC 489

XPEC prompt 113, 126, 188

XPEO prompt 114

XPLN prompt 360, 362, 367, 368

XSDI 31, 42

XSM 489

XTDT prompt 179, 183, 321

---

# Index

---

Meridian 1 Options 21 through 81C  
**System Programming Guide**  
System Programming Guide

© 1995,1999 Nortel Networks

All rights reserved

Information is subject to change without notice. Nortel Networks Corporation reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense. SL-1, Meridian 1 and Digitone are trademarks of Nortel Networks Corporation.

PO Number: P0906780

Document release: Standard 5.00

Date: June 1999

Printed in Canada



*How the world shares ideas.*